

武汉市中江科技有限公司维修内容列表

武汉市中江科技有限公司维修内容列表

武汉市中江科技有限公司芯片级维修各种工业元件，工业控制系统，工业控制设备，具体维修内容列表如下：

芯片级维修各种变频器：

芯片级维修美国 **AB (ALLEN-BRADLEY)** 公司, 罗克韦尔 (**ROCKWELLAUTOMATION**) 变频器：

1336IMPACTAC 变频器:1336E-A010,1336E-A015,1336E-A020,1336E-A025,1336E-A030,1336E-A040,1336E-A050,1336E-A060,1336E-A075,1336E-A100,1336E-A125,1336E-BRF05,1336E-BRF07,1336E-BRF10,1336E-BRF15,1336E-BRF20,1336E-BRF30,1336E-BRF50,1336E-BRF75,1336E-BRF100,1336E-B015,1336E-B020,1336E-B025,1336E-B030,1336E-BX040,1336E-B040,1336E-B050,1336E-BX060,1336E-B060,1336E-B07,1336E-B100,1336E-B125,1336E-BX150,1336E-B15,1336E-B200,1336E-B250,1336E-BP300,1336E-BP350,1336E-BP400,1336E-BPR400,1336E-BPR400A,1336E-BP450,1336E-BPR450,1336E-BPR450A,1336E-B300,1336E-B300A,1336E-B300C,1336E-B350,1336E-B350A,1336E-B350C,1336E-B400,1336E-B400A,1336E-B400C,1336E-B450,1336E-B450A,1336E-B500,1336E-B500A,1336E-B600,1336E-B600A,1336E-B700C,1336E-B800C,1336E-12B700C,1336E-12B800C,1336E-CWF10,1336E-CWF20,1336E-CWF30,1336E-CWF50,1336E-CWF75,1336E-CWF100,1336E-C015,1336E-C020,1336E-C025,1336E-C030,1336E-C040,1336E-C050,1336E-C060,1336E-C075,1336E-C100,1336E-C125,1336E-C150,1336E-C200,1336E-C250,1336E-CP350,1336E-CP400,1336E-C300,1336E-C350,1336E-C400,1336E-C450,1336E-C500,1336E-C600,1336E-C650,1336E-C700C,1336E-C800C,1336E-12C700C,1336E-12C800C;

1336PLUS II 变频器:1336F-AOF05,1336F-AOF07,1336F-AOF10,1336F-AOF15,1336F-AOF20,1336F-AOF30,1336F-AOF50,1336F-AOF05,1336F-AOF07,1336F-AOF10,1336F-AOF15,1336F-AOF20,1336F-AOF25,1336F-AOF30,1336F-AOF40,1336F-AOF50,1336F-AOF60,1336F-AOF75,1336F-A100,1336F-A125,1336F-BRF05,1336F-BRF07,1336F-BRF10,1336F-BRF15,1336F-BRF20,1336F-BRF30,1336F-BRF50,1336F-BRF75,1336F-BRF100,1336F-BRF150,1336F-BRF200,1336F-BO15,1336F-BO20,1336F-BO25,1336F-BO30,1336F-BO40,1336F-BO50,1336F-BO60,1336F-BO75,1336F-BX040,1336F-BX070,1336F-BX150,1336F-BX250,1336F-B100,1336F-B125,1336F-B150,1336F-B200,1336F-B250,1336F-B300,1336F-B350,1336F-B400,1336F-B450,1336F-B5005,1336F-B6005,1336F-CWF10,1336F-CWF20,1336F-CWF30,1336F-CWF50,1336F-CWF75,1336F-CWF100,1336F-CWF150,1336F-CWF200,1336F-C025,1336F-C030,1336F-C040,1336F-C050,1336F-C060,1336F-C075,1336F-C100,1336F-C125,1336F-C150,1336F-C200,1336F-C250,1336F-CX300,1336F-C3005,1336F-C4005,1336F-C5005,1336F-C6005;

PowerFlex 400 系列应用于风机水泵的变频器:22C-B012N103,22C-B017N103,22C-B024N103,22C-B033N103,22C-B049N103,22C-B065N103,22C-B075N103,22C-B090N103,22C-B125N103,22C-B145N103,22C-D6P0N103,22C-D010N103,22C-D012N103,22C-D017N103,22C-D022N103,22C-D030N103,22C-D038A103,22C-D045A103,22C-D060A103,22C-D072A103,22C-D088A103,22C-D105A103,22C-D142A103,22C-D170A103,22C-D208A103,22C-B012F103C,22C-B017F103C,22C-B024F103C,22C-B033F103C,22C-D6P0F103C,22C-D010F103C,22C-D012F103C,22C-D017F103C,22C-D022F103(1)C,22C-D030F103(1);

PowerFlex TM4,PowerFlexTM40 系列变频器:22A-V1P5N104A,22A-V2P3N104A,22B-V2P3N104B,22A-V4P5N104B,22B-V5P0N104B,22A-V6P0N104B,22B-V6P0N104B,22A-A1P5N114A,22A-A2P3N114A,22B-A2P3N114B,22A-A4P5N114A,22B-A5P0N114B,22A-A8P0N114B,22B-A8P0N114B,22B-A012N114C,22A-A1P5N104A,22A-A2P3N104A,22B-A2P3N104B,22A-A4P5N104A,22B-A5P0N104B,22A-A8P0N104B,22B-A8P0N104B,22B-A012N104C,22A-B1P5N104A,22A-B2P3N104A,22B-B2P3N104B,22A-B4P5N104A,22B-B5P0N104B,22A-B8P0N104A,22B-B8P0N104B,22A-B012B014B,22B-B012N104B,22A-B017N104B,22B-B017N104B,22B-B024N104C,22A-D1P4N104A,22B-D1P4N104B,22A-D2P3N104A,22B-D2P3N104B,22A-D4P0N104A,22B-D4P0N104B,22A-D6P0N104B,22B-D6P0N104B,22A-D8P7N104B,22B-D010N104B,22B-D012N104C,22B-D017N104C;

PowerFlexX70 交流变频器:20AB2P2A0AYNNNNN,20AB2P2F0AYNNNNNA,20AB2P2A0AYNANNNA,20AB2P2F0AYNANNNA,20AB4P2A0AYNNNNN,20AB4P2F0AYNANNN,20AB4P2A0AYNANNNA,20AB4P2F0AYNANNNAB,20AB6P8A0AYNNNNN,20AB6P8F0AYNNNNN,20AB6P8A0AYNANNN,20AB6P8F0AYNANNNB,20AB9P6A0AYNNNNN,20AB9P6F0AYNANNNB,20AB9P6A0AYNANNN,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

20AB9P6F0AYNANNNB,20AB015A0AYNANNN,20AB015FA0AYNANNN,20AB022A0AYNANNN,20AB022FA0AYNANNND,20AB028A0AYNANNN,20AB028F0AYNANNND,20AD1P1A0AYNANNNN,20AD1P1F0AYNANNNNA,20AD1P1A0AYNANNN,20AD1P1F0AYNANNNB,20AD2P1A0AYNANNNN,20AD2P1F0AYNANNNNA,20AD2P1A0AYNANNN,20AD2P1F0AYNANNNB,20AD3P4A0AYNANNNN,20AD3P4F0AYNANNNNA,20AD3P4A0AYNANNN,20AD3P4F0AYNANNNB,20AD5P0A0AYNANNNN,20AD5P0FA0AYNANNNB,20AD5P0A0AYNANNN,20AD5P0F0AYNANNNB,20AD8P0A0AYNANNNN,20AD8P0FA0AYNANNNB,20AD8P0A0AYNANNN,20AD8P0F0AYNANNNB,20AD011A0AYNANNN,20AD011F0AYNANNNC,20AD014A0AYNANNN,20AD014F0AYNANNNC,20AD022A0AYNANN,20AD022F0AYNANNND,20AD027A0AYNANNN,20AD027F0AYNANNND,20AE0P9A0AYNANNNN,20AE0P9F0AYNANNNNA,20AE1P7A0AYNANNNN,

20AE1P7F0AYNANNNNA,20AE2P7A0AYNANNNN,20AE2P7F0AYNANNNNA,20AE3P9A0AYNANNNN,20AE3P9F0AYNANNNB,20AE6P1A0AYNANNNN,20AE6P1F0AYNANNNB,20AE9P0A0AYNANNNN,20AE9P0F0AYNANNNNC,20A011A0AYNANNNN,20AE011F0AYNANNNNC,20AE017A0AYNANNNN,20AE017FA0AYNANNND,20AE022A0AYNANNNN,20AE022F0AYNANNND;

PowerFlex700 系列变频器:220BC2P1,220BC3P5,220BC5P0,220BC8P7,20BC011,20BC015,20BC022,20BC030,20BC037,20BC043;

PowerFlexTM7000 系列中压变频器:PowerFlexTM7000A 型柜,PowerFlexTM7000B 型柜,PowerFlexTM7000C 型柜;

芯片级维修ABB变频器

ABB通用机械传动变频器ACS150系列:ACS150-01E-02A4-2,ACS150-01E-04A7-2,ACS150-01E-06A7-2,ACS150-01E-07A5-2,ACS150-01E-09A8-2,ACS150-03E-02A4-2,ACS150-03E-03A5-2,ACS150-03E-04A7-2,ASC150-03E-06A7-2,ACS150-03E-07A5-2,ACS150-03E-09A8-2,ACS150-03E-01A2-4,ACS150-03E-01A9-4,ACS150-03E-02A4-4,ACS150-03E-03A3-4,ACS150-03E-04A1-4,ACS150-03E-05A6-4,ACS150-03E-07A3-4,ACS150-03E-08A8-4,ACS150-01E-02A4-2,ACS150-01E-04A7-2,ACS150-01E-06A7-2,ACS150-01E-07A5-2,ACS150-01E-09A8-2,ACS150-03E-01A2-4,ACS150-03E-01A9-4,ACS150-03E-02A4-4,ACS150-03E-03A3-4,ACS150-03E-04A1-4,ACS150-03E-05A6-4,ACS150-03E-07A3-4,ACS150-03E-08A8-4,ACS150-03E-02A4-2,ACS150-03E-03A5-2,ACS150-03E-04A7-2,ASC150-03E-06A7-2,ACS150-03E-07A5-2,ACS150-03E-09A8-2;

ABBACS350通用机械传动变频器:ACS350-01E-02A4-2,ACS350-01E-04A7-2,ACS350-01E-06A7-2,ACS350-01E-07A5-2,ACS350-01E-09A8-2,ACS350-03E-02A4-2,ACS350-03E-03A5-2,ACS350-03E-04A7-2,ASC350-03E-06A7-2,ACS350-03E-07A5-2,ACS350-03E-09A8-2,ACS350-03E-13A3-2,ACS350-03E-17A6-2,ACS350-03E-01A2-4,ACS350-03E-01A9-4,ACS350-03E-02A4-4,ACS350-03E-03A3-4,ACS350-03E-04A1-4,ACS350-03E-05A6-4,ACS350-03X-07A3-4,ACS350-03E-08A8-4,ACS350-03E-12A5-4,ACS350-03E-15A6-4;

ABBACS510-01系列低压交流传动变频器:ACS510-01-03A3-4,ACS510-01-04A1-4,ACS510-01-05A6-4,ACS510-01-07A2-4,ACS510-01-09A4-4,ACS510-01-012A-4,ACS510-01-017A-4,ACS510-01-025A-4,ACS510-01-031A-4,ACS510-01-038A-4,ACS510-01-045A-4,ACS510-01-060A-4,ACS510-01-072A-4,ACS510-01-096A-4,ACS510-01-124A-4,ACS510-01-157A-4,ACS510-01-180A-4,ACS510-01-195A-4;

ABBACS550-01系列低压交流传动变频器:ACS550-01-03A3-4,ACS550-01-04A1-4,ACS550-01-05A4-4,ACS550-01-06A9-4,ACS550-01-08A8-4,ACS550-01-012A-4,ACS550-01-015A-4,ACS550-01-023A-4,ACS550-01-031A-4,ACS550-01-038A-4,ACS550-01-044A-4,ACS550-01-059A-4,ACS550-01-072A-4,ACS550-01-096A-4,ACS550-01-124A-4,ACS550-01-157A-4,ACS550-01-180A-4ACS550-01-195A-4;

ABBACS800系列单传动变频器:ACS800-01-0001-2,ACS800-01-0002-2,ACS800-01-0003-2,ACS800-01-0004-2,ACS800-01-0005-2,ACS800-01-0006-2,ACS800-01-0009-2,ACS800-01-0011-2,ACS800-01-0016-2,ACS800-01-0020-2,ACS800-01-0025-2,ACS800-01-0030-2,ACS800-01-0040-2,ACS800-01-0050-2,ACS800-01-0060-2,ACS800-01-0070-2,ACS800-01-0003-3,ACS800-01-0004-3,ACS800-01-0005-3,ACS800-01-0006-3,ACS800-01-0009-3,ACS800-01-0011-3,ACS800-01-0016-3,ACS800-01-0020-3,ACS800-01-0025-3,ACS800-01-0030-3,ACS800-01-0040-3,ACS800-01-0050-3,ACS800-01-0060-3,ACS800-01-0070-3,ACS800-01-0100-3,ACS8

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

00-01-0120-3,ACS800-01-0004-5,ACS800-01-0005-5,ACS800-01-0006-5,ACS800-01-0009-5,ACS800-01-0011-5,ACS800-01-0016-5,ACS800-01-0020-5,ACS800-01-0025-5,ACS800-01-0030-5,ACS800-01-0040-5,ACS800-01-0050-5,ACS800-01-0060-5,ACS800-01-0070-5,ACS800-01-0100-5,ACS800-01-0120-5,ACS800-01-0140-5,ACS800-01-0011-7,ACS800-01-0016-7,ACS800-01-0020-7,ACS800-01-0025-7,ACS800-01-0030-7,ACS800-01-0040-7,ACS800-01-0050-7,ACS800-01-0060-7,ACS800-01-0070-7,ACS800-01-0100-7,ACS800-01-0120-7,ACS800-11-0011-2,ACS800-11-0016-2,ACS800-11-0020-2,ACS800-11-0025-2,ACS800-11-0030-2,ACS800-11-0040-2,ACS800-11-0050-2,ACS800-11-0060-2,ACS800-11-0016-3,ACS800-11-0020-3,ACS800-11-0025-3,ACS800-11-0030-3,ACS800-11-0040-3,ACS800-11-0050-3,ACS800-11-0060-3,ACS800-11-0070-3,ACS800-11-0100-3,ACS800-11-0020-5,ACS800-11-0025-5,ACS800-11-0030-5,ACS800-11-0040-5,ACS800-11-0050-5,ACS800-11-0060-5,ACS800-11-0070-5,ACS800-11-0100-5,ACS800-11-0120-5,ACS800-04-0080-2,ACS800-04-0100-2,ACS800-04-0120-2,ACS800-04-0140-2,ACS800-04-0170-2,ACS800-04-0210-2,ACS800-04-0230-2,ACS800-04-0260-2,ACS800-04-0300-2,ACS800-04-0140-3,ACS800-04-0170-3,ACS800-04-0210-3,ACS800-04-0260-3,ACS800-04-0320-3,ACS800-04-0400-3,ACS800-04-0440-3,ACS800-04-0490-3,ACS800-04-0170-5,ACS800-04-0210-5,ACS800-04-0260-5,ACS800-04-0320-5,ACS800-04-0400-5,ACS800-04-0440-5,ACS800-04-0490-5,ACS800-04-0550-5,ACS800-04-0610-5,ACS800-04-0140-7,ACS800-04-0170-7,ACS800-04-0210-7,ACS800-04-0260-7,ACS800-04-0320-7,ACS800-04-0400-7,ACS800-04-0440-7,ACS800-04-0490-7,ACS800-04-0550-7,ACS800-04-0610-7,ACS800-02-0080-2,ACS800-02-0100-2,ACS800-02-0120-2,ACS800-02-0140-2,ACS800-02-0170-2,ACS800-02-0210-2,ACS800-02-0230-2,ACS800-02-0260-2,ACS800-02-0300-2,ACS800-02-0140-3,ACS800-02-0170-3,ACS800-02-0210-3,ACS800-02-0260-3,ACS800-02-0320-3,ACS800-02-0400-3,ACS800-02-0440-3,ACS800-02-0490-3,ACS800-02-0170-5,ACS800-02-0210-5,ACS800-02-0260-5,ACS800-02-0320-5,ACS800-02-0400-5,ACS800-02-0440-5,ACS800-02-0490-5,ACS800-02-0550-5,ACS800-02-0610-5,ACS800-02-0140-7,ACS800-02-0170-7,ACS800-02-0210-7,ACS800-02-0260-7,ACS800-02-0320-7,ACS800-02-0400-7,ACS800-02-0440-7,ACS800-02-0490-7,ACS800-02-0550-7,ACS800-02-0610-7,ACS800-07-0070-3,ACS800-07-0100-3,ACS800-07-0120-3,ACS800-07-0140-3,ACS800-07-0170-3,ACS800-07-0210-3,ACS800-07-0260-3,ACS800-07-0320-3,ACS800-07-0400-3,ACS800-07-0440-3,ACS800-07-0490-3,ACS800-07-0610-3,ACS800-07-0770-3,ACS800-07-0870-3,ACS800-07-1030-3,ACS800-07-1230-3,ACS800-07-1540-3,ACS800-07-1850-3,ACS800-07-0100-5,ACS800-07-0120-5,ACS800-07-0140-5,ACS800-07-0170-5,ACS800-07-0210-5,ACS800-07-0260-5,ACS800-07-0320-5,ACS800-07-0400-5,ACS800-07-0440-5,ACS800-07-0490-5,ACS800-07-0550-5,ACS800-07-0610-5,ACS800-07-0760-5,ACS800-07-0910-5,ACS800-07-1090-5,ACS800-07-1210-5,ACS800-07-1540-5,ACS800-07-1820-5,ACS800-07-2310-5,ACS800-07-0070-7,ACS800-07-0100-7,ACS800-07-0120-7,ACS800-07-0140-7,ACS800-07-0170-7,ACS800-07-0210-7,ACS800-07-0260-7,ACS800-07-0320-7,ACS800-07-0400-7,ACS800-07-0440-7,ACS800-07-0490-7,ACS800-07-0550-7,ACS800-07-0610-7,ACS800-07-0750-7,ACS800-07-0870-7,ACS800-07-1060-7,ACS800-07-1160-7,ACS800-07-1500-7,ACS800-07-1740-7,ACS800-07-2120-7,ACS800-07-2900-7,ACS800-07-3190-7,ACS800-07-3490-7,ACS800-17-0060-3,ACS800-17-0070-3,ACS800-17-0100-3,ACS800-17-0140-3,ACS800-17-0170-3,ACS800-17-0210-3,ACS800-17-0260-3,ACS800-17-0320-3,ACS800-17-0390-3,ACS800-17-0490-3,ACS800-17-0640-3,ACS800-17-0770-3,ACS800-17-0960-3,ACS800-17-1070-3,ACS800-17-1370-3,ACS800-17-1810-3,ACS800-17-0070-5,ACS800-17-0100-5,ACS800-17-0120-5,ACS800-17-0170-5,ACS800-17-0210-5,ACS800-17-0260-5,ACS800-17-0320-5,ACS800-17-0400-5,ACS800-17-0440-5,ACS800-17-0460-5,ACS800-17-0510-5,ACS800-17-0580-5,ACS800-17-0780-5,ACS800-17-0870-5,ACS800-17-1140-5,ACS800-17-1330-5,ACS800-17-1640-5,ACS800-17-2160-5,ACS800-17-0160-7,ACS800-17-0200-7,ACS800-17-0260-7,ACS800-17-0320-7,ACS800-17-0400-7,ACS800-17-0440-7,ACS800-17-0540-7,ACS800-17-0790-7,ACS800-17-0870-7,ACS800-17-1050-7,ACS800-17-1330-7,ACS800-17-1510-7,ACS800-17-1980-7,ACS800-17-2780-7,ACS800-17-2940-7,ACS800-37-0060-3,ACS800-37-0070-3,ACS800-37-0100-3,ACS800-37-0140-3,ACS800-37-0170-3,ACS800-37-0210-3,ACS800-37-0260-3,ACS800-37-0320-3,ACS800-37-0390-3,ACS800-37-0510-3,ACS800-37-0640-3,ACS800-37-0770-3,ACS800-37-0960-3,ACS800-37-1070-3,ACS800-37-1430-3,ACS800-37-1810-3,ACS800-37-0070-5,ACS800-37-0100-5,ACS800-37-0120-5,ACS800-37-0170-5,ACS800-37-0210-5,ACS800-37-0260-5,ACS800-37-0320-5,ACS

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

S800-37-0400-5,ACS800-37-0460-5,ACS800-37-0510-5,ACS800-37-0610-5,ACS800-37-0780-5,ACS800-37-0870-5,ACS800-37-1160-5,ACS800-37-1330-5,ACS800-37-1820-5,ACS800-37-2200-5,ACS800-37-0170-7,ACS800-37-0210-7,ACS800-37-0260-7,ACS800-37-0320-7,ACS800-37-0400-7,ACS800-37-0440-7,ACS800-37-0540-7,ACS800-37-0790-7,ACS800-37-0870-7,ACS800-37-1160-7,ACS800-37-1330-7,ACS800-37-1510-7,ACS800-37-2320-7,ACS800-37-2780-7,ACS800-37-3310-7;

ACS800传动单元:ACS800-107-0003-3,ACS800-107-0004-3,ACS800-107-0005-3,ACS800-107-0006-3,

ACS800-107-0009-3,ACS800-107-0011-3,ACS800-107-0016-3,ACS800-107-0020-3,ACS800-107-0025-3,ACS800-107-0030-3,ACS800-107-0040-3,ACS800-107-0050-3,ACS800-107-0060-3,ACS800-107-0105-3,ACS800-107-0125-3,ACS800-107-0145-3,ACS800-107-0175-3,ACS800-107-0260-3,ACS800-107-0320-3,ACS800-107-0390-3,ACS800-107-0510-3,ACS800-107-0770-3,ACS800-107-1030-3,ACS800-107-1540-3,ACS800-107-2050-3,ACS800-107-2570-3,ACS800-107-3080-3,ACS800-107-0004-5,ACS800-107-0005-5,ACS800-107-0006-5,ACS800-107-0009-5,ACS800-107-0011-5,ACS800-107-0016-5,ACS800-107-0020-5,ACS800-107-0025-5,ACS800-107-0030-5,ACS800-107-0040-5,ACS800-107-0050-5,ACS800-107-0060-5,ACS800-107-0070-5,ACS800-107-0105-5,ACS800-107-0125-5,ACS800-107-0145-5,ACS800-107-0175-5,ACS800-107-0215-5,ACS800-107-0260-5,ACS800-107-0320-5,ACS800-107-0400-5,ACS800-107-0460-5,ACS800-107-0610-5,ACS800-107-0910-5,ACS800-107-1210-5,ACS800-107-1820-5,ACS800-107-2430-5,ACS800-107-3030-5,ACS800-107-3640-5,ACS800-107-0011-7,ACS800-107-0016-7,ACS800-107-0020-7,ACS800-107-0025-7,ACS800-107-0030-7,ACS800-107-0040-7,ACS800-107-0050-7,ACS800-107-0060-7,ACS800-107-0075-7,ACS800-107-0105-7,ACS800-107-0125-7,ACS800-107-0145-7,ACS800-107-0175-7,ACS800-107-0215-7,ACS800-107-0260-7,ACS800-107-0320-7,ACS800-107-0400-7,ACS800-107-0440-7,ACS800-107-0580-7,ACS800-107-0870-7,ACS800-107-1160-7,ACS800-107-1740-7,ACS800-107-2320-7,ACS800-107-2900-7,ACS800-107-3490-7,ACS800-107-4070-7,ACS800-107-4650-7,ACS800-107-5230-7,ACS800-107-5810-7,ACS800-107-6390-7,ACS800-107-6970-7,ACS800-104-0003-3,ACS800-104-0004-3,ACS800-104-0005-3,ACS800-104-0006-3,ACS800-104-0009-3,ACS800-104-0011-3,ACS800-104-0016-3,ACS800-104-0020-3,ACS800-104-0025-3,ACS800-104-0030-3,ACS800-104-0040-3,ACS800-104-0050-3,ACS800-104-0060-3,ACS800-104-0105-3,ACS800-104-0125-3,ACS800-104-0145-3,ACS800-104-0175-3,ACS800-104-0260-3,ACS800-104-0320-3,ACS800-104-0390-3,ACS800-104-0510-3,ACS800-104-0770-3,ACS800-104-1030-3,ACS800-104-1540-3,ACS800-104-2050-3,ACS800-104-0004-5,ACS800-104-0005-5,ACS800-104-0006-5,ACS800-104-0009-5,ACS800-104-0011-5,ACS800-104-0016-5,ACS800-104-0020-5,ACS800-104-0025-5,ACS800-104-0030-5,ACS800-104-0040-5,ACS800-104-0050-5,ACS800-104-0060-5,ACS800-104-0070-5,ACS800-104-0105-5,ACS800-104-0125-5,ACS800-104-0145-5,ACS800-104-0175-5,ACS800-104-0215-5,ACS800-104-0260-5,ACS800-104-0320-5,ACS800-104-0400-5,ACS800-104-0460-5,ACS800-104-0610-5,ACS800-104-0910-5,ACS800-104-1210-5,ACS800-104-1820-5,ACS800-104-2430-5,ACS800-104-0011-7,ACS800-104-0016-7,ACS800-104-0020-7,ACS800-104-0025-7,ACS800-104-0030-7,ACS800-104-0040-7,ACS800-104-0050-7,ACS800-104-0060-7,ACS800-104-0075-7,ACS800-104-0105-7,ACS800-104-0125-7,ACS800-104-0145-7,ACS800-104-0175-7,ACS800-104-0215-7,ACS800-104-0260-7,ACS800-104-0320-7,ACS800-104-0400-7,ACS800-104-0440-7,ACS800-104-0580-7,ACS800-104-0870-7,ACS800-104-1160-7,ACS800-104-1740-7,ACS800-104-2320-7;

ACS800整流单元:ACS800-207-0135-3,ACS800-207-0155-3,ACS800-207-0200-3,ACS800-207-0260-3,

ACS800-207-0330-3,ACS800-207-0440-3,ACS800-207-0660-3,ACS800-207-0860-3,ACS800-207-1270-3,ACS800-207-1680-3,ACS800-207-2490-3,ACS800-307-0200-3,ACS800-307-0280-3,ACS800-307-0400-3,ACS800-307-0570-3,ACS800-307-0790-3,ACS800-307-1050-3,ACS800-307-1580-3,ACS800-307-2100-3,ACS800-307-2630-3,ACS800-407-0680-3,ACS800-407-1120-3,ACS800-407-1700-3,ACS800-407-2100-3,ACS800-507-0400-3,ACS800-507-0570-3,ACS800-507-0790-3,ACS800-507-1050-3,ACS800-507-1580-3,ACS800-507-2100-3,ACS800-507-2630-3,ACS800-807-1290-3,ACS800-807-2130-3,ACS800-807-3220-3,ACS800-207-0165-5,ACS800-207-0195-5,ACS800-207-0230-5,ACS800-207-0310-5,ACS800-207-0390-5,ACS800-207-0520-5,ACS800-207-0780-5,ACS800-207-1020-5,ACS800-207-1510-5,ACS800-207-2000-5,ACS800-207-2960-5,ACS800-307-0250-5,ACS800-307-0350-5,ACS800-307-0490-5,ACS800-307-0710-5,ACS800-307-0990-5,ACS800-307-1310-5,ACS800-307-1970-5,ACS800-307-2630-5,ACS800-307-

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

3290-5,ACS800-407-0850-5,ACS800-407-1400-5,ACS800-407-2120-5,ACS800-407-2600-5,ACS800-507-0490-5,ACS800-507-0710-5,ACS800-507-0990-5,ACS800-507-1310-5,ACS800-507-1970-5,ACS800-507-2630-5,ACS800-507-3290-5,ACS800-807-1615-5,ACS800-807-2660-5,ACS800-807-4030-5,ACS800-807-4700-5,ACS800-207-0155-7,ACS800-207-0175-7,ACS800-207-0220-7,ACS800-207-0300-7,ACS800-207-0360-7,ACS800-207-0480-7,ACS800-207-0720-7,ACS800-207-0940-7,ACS800-207-1390-7,ACS800-207-1840-7,ACS800-207-2730-7,ACS800-207-3630-7,ACS800-207-4550-7,ACS800-207-5450-7,ACS800-307-0340-7,ACS800-307-0490-7,ACS800-307-0680-7,ACS800-307-0980-7,ACS800-307-1370-7,ACS800-307-1810-7,ACS800-307-2720-7,ACS800-307-3630-7,ACS800-307-4540-7,ACS800-407-0850-7,ACS800-407-1400-7,ACS800-407-2600-7,ACS800-407-3600-7,ACS800-507-0680-7,ACS800-507-0980-7,ACS800-507-1370-7,ACS800-507-1810-7,ACS800-507-2720-7,ACS800-507-3630-7,ACS800-507-4540-7,ACS800-807-1615-7,ACS800-807-2660-7,ACS800-807-4950-7,ACS800-807-6500-7,ACS800-204-0135-3,ACS800-204-0155-3,ACS800-204-0200-3,ACS800-204-0260-3,ACS800-204-0330-3,ACS800-204-0440-3,ACS800-204-0660-3,ACS800-204-0860-3,ACS800-204-1270-3,ACS800-204-1680-3,ACS800-304-0320-7,ACS800-304-0450-7,ACS800-704-0640-7,ACS800-704-0910-7,ACS800-704-1370-7,ACS800-704-1810-7,ACS800-704-2720-7,ACS800-704-3630-7,ACS800-704-4540-7,ACS800-404-0680-3,ACS800-404-1120-3,ACS800-404-1700-3,ACS800-404-2100-3,ACS800-704-0640-7,ACS800-704-0910-7,ACS800-704-1370-7,ACS800-704-1810-7,ACS800-704-2720-7,ACS800-704-3630-7,ACS800-704-4540-7,ACS800-204-0165-5,ACS800-204-0195-5,ACS800-204-0230-5,ACS800-204-0310-5,ACS800-204-0390-5,ACS800-204-0520-5,ACS800-204-0780-5,ACS800-204-1020-5,ACS800-204-1510-5,ACS800-204-2000-5,ACS800-304-0320-7,ACS800-304-0450-7,ACS800-704-0640-7,ACS800-704-0910-7,ACS800-704-1370-7,ACS800-704-1810-7,ACS800-704-2720-7,ACS800-704-3630-7,ACS800-704-4540-7,ACS800-404-0850-5,ACS800-404-1400-5,ACS800-404-2120-5,ACS800-404-2600-5,ACS800-704-0640-7,ACS800-704-0910-7,ACS800-704-1370-7,ACS800-704-1810-7,ACS800-704-2720-7,ACS800-704-3630-7,ACS800-704-4540-7,ACS800-204-0155-7,ACS800-204-0175-7,ACS800-204-0220-7,ACS800-204-0300-7,ACS800-204-0360-7,ACS800-204-0480-7,ACS800-204-0720-7,ACS800-204-0940-7,ACS800-204-1390-7,ACS800-204-1840-7,ACS800-304-0320-7,ACS800-304-0450-7,ACS800-704-0640-7,ACS800-704-0910-7,ACS800-704-1370-7,ACS800-704-1810-7,ACS800-704-2720-7,ACS800-704-3630-7,ACS800-704-4540-7,ACS800-404-0850-7,ACS800-404-1400-7,ACS800-404-2600-7,ACS800-404-3600-7,ACS800-704-0640-7,ACS800-704-0910-7,ACS800-704-1370-7,ACS800-704-1810-7,ACS800-704-2720-7,ACS800-704-3630-7,ACS800-704-4540-7;

ACS800制动单元:ACS800-607-0320-3,ACS800-607-0640-3,ACS800-607-0960-3,ACS800-607-1280-3,

ACS800-607-1600-3,ACS800-607-1920-3,ACS800-607-0320-3+D151,ACS800-607-0640-3+D151,ACS800-607-0960-3+D151,ACS800-607-1280-3+D151,ACS800-607-1600-3+D151,ACS800-607-1920-3+D151,ACS800-607-0400-5,ACS800-607-0800-5,ACS800-607-1200-5,ACS800-607-1600-5,ACS800-607-2000-5,ACS800-607-2400-5,ACS800-607-0400-5+D151,ACS800-607-0800-5+D151,ACS800-607-1200-5+D151,ACS800-607-1600-5+D151,ACS800-607-2000-5+D151,ACS800-607-2400-5+D151,ACS800-607-0400-7,ACS800-607-0800-7,ACS800-607-1200-7,ACS800-607-1600-7,ACS800-607-2000-7,ACS800-607-2400-7,ACS800-607-0400-7+D151,ACS800-607-0800-7+D151,ACS800-607-1200-7+D151,ACS800-607-1600-7+D151,ACS800-607-2000-7+D151,ACS800-607-2400-7+D151;

ACS800传动模块:ACS800-04-0001-2,ACS800-04-0002-2,ACS800-04-0003-2,ACS800-04-0004-2,

ACS800-04-0005-2,ACS800-04-0006-2,ACS800-04-0009-2,ACS800-04-0011-2,ACS800-04-0016-2,ACS800-04-0020-2,ACS800-04-0025-2,ACS800-04-0030-2,ACS800-04-0040-2,ACS800-04-0050-2,ACS800-04-0060-2,ACS800-04-0070-2,ACS800-04-0080-2,ACS800-04-0100-2,ACS800-04-0120-2,ACS800-04-0140-2,ACS800-04-0170-2,ACS800-04-0210-2,ACS800-04-0230-2,ACS800-04-0260-2,ACS800-04-0300-2,ACS800-04-0003-3,ACS800-04-0004-3,ACS800-04-0005-3,ACS800-04-0006-3,ACS800-04-0009-3,ACS800-04-0011-3,ACS800-04-0016-3,ACS800-04-0020-3,ACS800-04-0023-3,ACS800-04-0025-3,ACS800-04-0030-3,ACS800-04-0035-3,ACS800-04-0040-3,ACS800-04-0050-3,ACS800-04-0060-3,ACS800-04-0070-3,ACS800-04-0100-3,ACS800-04-0120-3,ACS800-04-0130-3,ACS800-04-0140-3,ACS800-04-0170-3,ACS800-04-0210-3,ACS800-04-0260-3,ACS800-04-0320-3,ACS800-04-0400-3,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

ACS800-04-0440-3,ACS800-04-0490-3,ACS800-04-0610-3,ACS800-04-0770-3,ACS800-04-0870-3,ACS800-04-1030-3,ACS800-04-1230-3,ACS800-04-1540-3,ACS800-04-1850-3,ACS800-04-0004-5,ACS800-04-0005-5,ACS800-04-0006-5,ACS800-04-0009-5,ACS800-04-0011-5,ACS800-04-0016-5,ACS800-04-0020-5,ACS800-04-0025-5,ACS800-04-0028-5,ACS800-04-0030-5,ACS800-04-0040-5,ACS800-04-0045-5,ACS800-04-0050-5,ACS800-04-0060-5,ACS800-04-0070-5,ACS800-04-0100-5,ACS800-04-0120-5,ACS800-04-0140-5,ACS800-04-0150-5,ACS800-04-0170-5,ACS800-04-0210-5,ACS800-04-0260-5,ACS800-04-0320-5,ACS800-04-0400-5,ACS800-04-0440-5,ACS800-04-0490-5,ACS800-04-0550-5,ACS800-04-0610-5,ACS800-04-0760-5,ACS800-04-0910-5,ACS800-04-1090-5,ACS800-04-1210-5,ACS800-04-1540-5,ACS800-04-1820-5,ACS800-04-2310-5,ACS800-04-0011-7,ACS800-04-0016-7,ACS800-04-0020-7,ACS800-04-0025-7,ACS800-04-0030-7,ACS800-04-0040-7,ACS800-04-0050-7,ACS800-04-0060-7,ACS800-04-0070-7,ACS800-04-0100-7,ACS800-04-0120-7,ACS800-04-0140-7,ACS800-04-0170-7,ACS800-04-0210-7,ACS800-04-0260-7,ACS800-04-0320-7,ACS800-04-0400-7,ACS800-04-0440-7,ACS800-04-0490-7,ACS800-04-0550-7,ACS800-04-0610-7,ACS800-04-0750-7,ACS800-04-0870-7,ACS800-04-1060-7,ACS800-04-1160-7,ACS800-04-1500-7,ACS800-04-1740-7,ACS800-04-2120-7,ACS800-04-2320-7;

ACS1000中压变频器 (ACS1000MediumVoltageEACDriv) :ACS1012-A1-A0-00,ACS1012-A1-B0-00,ACS1012-A1-C0-00,ACS1012-A1-D0-00,ACS1012-A1-F0-00,ACS1012-A1-G0-00,ACS1012-A1-H0-00,ACS1012-A2-J0-00,ACS1012-A2-K0-00,ACS1012-A3-L0-00,ACS1012-A3-M0-00,ACS1012-W1-Q0-00,ACS1012-W2-S0-00,ACS1013-A1-A0-00,ACS1013-A1-B0-00,ACS1013-A1-C0-00,ACS1013-A1-D0-00,ACS1013-A1-E0-00,ACS1013-A1-F0-00,ACS1013-A1-G0-00,ACS1013-A1-H0-00,ACS1013-A2-J0-00,ACS1013-A2-K0-00,ACS1013-A2-L0-00,ACS1013-A2-M0-00,ACS1013-A2-N0-00,ACS1013-A2-P0-00,ACS1013-A3-Q0-00,ACS1013-A3-R0-00,ACS1013-W1-S0-00,ACS1013-W1-T0-00,ACS1013-W1-U0-00,ACS1013-W2-V0-00,ACS1013-W2-W0-00,ACS1013-W2-X0-00,ACS1013-W3-Y0-00,ACS1013-W3-Z0-00,ACS1013-W3-10-00,ACS1014-A1-A0-00,ACS1014-A1-B0-00,ACS1014-A1-C0-00,ACS1014-A1-D0-00,ACS1014-A1-E0-00,ACS1014-A1-F0-00,ACS1014-A1-G0-00,ACS1014-A1-H0-00,ACS1014-A2-J0-00,ACS1014-A2-K0-00,ACS1014-A3-L0-00,ACS1014-A3-M0-00,ACS1014-A3-N0-00,ACS1014-W1-P0-00,ACS1014-W1-Q0-00,ACS1014-W2-R0-00,ACS1014-W2-S0-00,ACS1014-W2-T0-00,ACS1014-W2-U0-00,ACS1014-W3-V0-00,ACS1014-W3-W0-00,ACS1014-W3-X0-00,ACS1012-A1-E0-00,ACS1012-A3-N0-00,

ACS5000中压变频器:ACS5060-36L121-1a122-W2,ACS5060-36L121-1a123-W2,ACS5060-36L123-1a122-W2,ACS5060-36L123-1a123-W2,ACS5060-36L243-2a122-W3,ACS5060-36L243-2a123-W3,ACS5060-36L245-2a123-W3,ACS5060-36L246-2a123-W3,ACS5066-36L121-1a122-W2,ACS5066-36L121-1a123-W2,ACS5066-36L123-1a122-W2,ACS5066-36L123-1a123-W2,ACS5066-36L243-2a122-W3,ACS5066-36L243-2a123-W3,ACS5066-36L245-2a123-W3,ACS5066-36L246-2a123-W3,ACS5069-36L121-1a122-W2,ACS5069-36L121-1a123-W2,ACS5069-36L123-1a122-W2,ACS5069-36L123-1a123-W2,ACS5069-36L243-2a122-W3,ACS5069-36L243-2a123-W3,ACS5069-36L245-2a123-W3,ACS5069-36L246-2a123-W3,ACS5060-36L121-1s122-W2,ACS5060-36L121-1s123-W2,ACS5060-36L123-1s122-W2,ACS5060-36L123-1s123-W2,ACS5060-36L243-2s122-W3,ACS5060-36L243-2s123-W3,ACS5060-36L245-2s123-W3,ACS5060-36L246-2s123-W3,ACS5066-36L121-1s122-W2,ACS5066-36L121-1s123-W2,ACS5066-36L123-1s122-W2,ACS5066-36L123-1s123-W2,ACS5066-36L243-2s122-W3,ACS5066-36L243-2s123-W3,ACS5066-36L245-2s123-W3,ACS5066-36L246-2s123-W3,ACS5069-36L121-1s122-W2,ACS5069-36L121-1s123-W2,ACS5069-36L123-1s122-W2,ACS5069-36L123-1s123-W2,ACS5069-36L243-2s122-W3,ACS5069-36L243-2s123-W3,ACS5069-36L245-2s123-W3,ACS5069-36L246-2s123-W3;

ACS50:ACS50-01E-01A4-2,ACS50-01E-02A2-2,ACS50-01E-04A3-2,ACS50-01E-07A6-2,ACS50-01E-09A8-2,ACS50-01N-01A4-2,ACS50-01N-02A2-2,ACS50-01N-04A3-2,ACS50-01N-07A6-2,ACS50-01N-09A8-2,ACS50-01E-01A4-1,ACS50-01E-02A2-1,ACS50-01N-01A4-1,ACS50-01N-02A2-1;

ACS550:ACS550-01-03A3-4,ACS550-01-04A1-4,ACS550-01-05A4-4,ACS550-01-06A9-4,ACS550-01-08A8-4,ACS550-01-012A-4,ACS550-01-015A-4,ACS550-01-023A-4,ACS550-01-031A-4,ACS550-01-038A-4,ACS550-01-044A-4,ACS550-01-059A-4,ACS550-0

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

1-072A-4,ACS550-01-096A-4,ACS550-01-124A-4,ACS550-01-157A-4,ACS550-01-180A-4,ACS550-01-195A-4,ACS550-02-245A-4,ACS550-02-289A-4,ACS550-02-368A-4,ACS550-02-486A-4,ACS550-02-526A-4,ACS550-02-602A-4,ACS550-02-645A-4;

ACS200ACS201-1P1-1,ACS201-1P6-1,ACS201-2P1-1,ACS201-2P7-1,ACS201-4P1-1,ACS201-1P6-3,ACS201-2P1-3,ACS201-2P7-3,ACS201-4P1-3,ACS201-4P9-3,ACS201-6P6-3;

芯片级维修保德变频器:

BALDOR MOTORS AND DRIVES (保德) 18H系列矢量控制变频器:ZD18H201-E,ZD18H202-E,ZD18H203-E,ZD18H205-E,ZD18H205-W,ZD18H207-E,ZD18H210-E,ZD18H210-ER,ZD18H210L-ER,ZD18H215-E,ZD18H215V-EO,ZD18H215-EO,ZD18H215-ER,ZD18H215L-ER,ZD18H220-EO,ZD18H220-ER,ZD18H220L-ER,ZD18H225V-EO,ZD18H225V-ER,ZD18H225-EO,ZD18H225-ER,ZD18H225L-ER,ZD18H230-EO,ZD18H230V-EO,ZD18H230V-ER,ZD18H230L-ER,ZD18H240-MO,ZD18H240-MR,ZD18H240L-MR,ZD18H250V-MO,ZD18H250V-MR,ZD18H250-MO,ZD18H250-MR,ZD18H401-E,ZD18H402-E,ZD18H402-EW,ZD18H403-E,ZD18H403-EW,ZD18H405-E,ZD18H405-W,ZD18H407-E,ZD18H407-EW,ZD18H410-E,ZD18H410-ER,ZD18H415V-EO,ZD18H415-EO,ZD18H415-ER,ZD18H415L-ER,ZD18H420-EO,ZD18H420-ER,ZD18H420L-ER,ZD18H425V-EO,ZD18H425V-ER,ZD18H425-EO,ZD18H425-ER,ZD18H425L-ER,ZD18H430V-EO,ZD18H430V-ER,ZD18H430-EO,ZD18H430L-ER,ZD18H440-EO,ZD18H440-ER,ZD18H440L-ER,ZD18H450-EO,ZD18H450-ER,ZD18H450L-ER,ZD18H460V-EO,ZD18H460V-ER,ZD18H460-EO,ZD18H460-ER,ZD18H460L-ER,ZD18H475-EO,ZD18H475L-EO,ZD18H4100-EO,ZD18H4150V-EO,ZD18H4150-EO,ZD18H4200-EO,ZD18H4250-EO,ZD18H4300-EO,ZD18H4350-EO,ZD18H4400-EO,ZD18H4400-EO,ZD18H4450-EO,ZD18H501-E,ZD18H502-E,ZD18H503-E,ZD18H505-EZD18H507-E,ZD18H510-E,ZD18H515-E,ZD18H515-EO,ZD18H515-ER,ZD18H520-EO,ZD18H520-EO,ZD18H525-EO,ZD18H525-ER,ZD18H530-EO,ZD18H530-ER,ZD18H540-EO,ZD18H540-ER,ZD18H550-EO,ZD18H550-ER,ZD18H560-EO,ZD18H560-ER,ZD18H575-EO,ZD18H5100-EO,ZD18H5150V-EO,ZD18H415-E,ZD18H401-W;

BALDOR (保德) 22H系列矢量控制变频器:ZD22H210-EL,ZD22H215-EL,ZD22H220-EL,ZD22H225-EL,ZD22H230-EL,ZD22H240-EL,ZD22H250-EL,ZD22H410-EL,ZD22H415-EL,ZD22H420-EL,ZD22H425-EL,ZD22H430-EL,ZD22H440-EL,ZD22H450-EL,ZD22H460-EK4,ZD22H475-EK,ZD22H4100-EK,ZD22H4150-EK,ZD22H4200-EK,ZD22H4250-EL,ZD22H4300-EL,ZD22H4350-EL,ZD22H4400-EL,ZD22H4450-EL;

BALDOR MOTORS AND DRIVES (保德) 25M系列多轴矢量控制变频器:ZD25M2A05-P0,ZD25M4A02-P0,ZD25M2A10-P0,ZD25M4A07-P0,ZD25M4A15-P0,ZD25M2A25-P0,ZD25M4A25-P0,ZD25M2A35-P0,ZD25M4A35-P0,ZD25M2A45-P0,ZD25M4A45-P0,ZD25M2A60-P0,ZD25M4A60-P0,ZD25M2A90-P0,ZD25M4A90-P0,ZD25M1A02-TR,ZD25M2A02-TR,ZD25M1A05-TR,ZD25M2A05-TR,ZD25M1A07-TR,ZD25M2A07-TR,ZD25M1A02-TR,ZD25M1A05-TR,ZD25M2A02-TR,ZD25M2A05-TR,PSM2A060-PR1,PSM2A060-PR2,PSM2A100-PR1,PSM2A100-PR2,PSM4A030-PR1,PSM4A030-PR2,PSM4A050-PR1,PSM4A050-PR2,PSM4A100-PR1,PSM4A100-PR2,ZD25M2A15-P0;

BALDOR MOTORS AND DRIVES (保德) 37D系列矢量控制变频器:ZD37D8A1F5-COD,ZD37D8A2F2-COD,ZD37D8A03-COD,ZD37D8A04-COD,ZD37D2A10-CRD,ZD37D2A16-CRD,ZD37D2A22-CRD,ZD37D2A28-CRD,ZD37D2A42-CRD,ZD37D2A54-CRD,ZD37D2A68-CRD,ZD37D2A80-CRD,ZD37D2A104-CRD1,ZD37D2A130-CRD1,ZD37D2A154-CRD1,ZD37D4A1F5-CRD,ZD37D4A02-CRD,ZD37D4A2F5-CRD,ZD37D4A4F5-CRD,ZD37D4A09-CRD,ZD37D4A12-CRD,ZD37D4A16-CRD,ZD37D4A23-ERD,ZD37D4A27-ERD,ZD37D4A31-ERD,ZD37D4A38-ERD,ZD37D4A45-ERD,ZD37D4A52-ERD,ZD37D4A59-ERD,ZD37D4A73-ERD,ZD37D4A87-ERD,ZD37D4A09-CRD,ZD37D4A105-CRD1,ZD37D4A125-CRD1,ZD37D4A156-CRD1,ZD37D4A180CRD1,ZD37D8A07-COD,ZD37D4A5F5-CRD;

BALDOR (保德) 38D系列矢量控制变频器:ZD38D8A04-ERD,ZD38D4A2F5-ERD,ZD38D8A07-ERD,ZD38D4A4F5-ERD,ZD38D8A10-ERD,ZD38D4A5F5-ERD,ZD38D2A04-ERD,ZD38D4A9F5-ERD,ZD38D2A07-ERD,ZD38D4A12-ERD,ZD38D2A10-ERD,ZD38D4A16-ERD,ZD38D2A16-ERD,ZD38D4A23-ERD,ZD38D2A22-ERD,ZD38D4A31-ERD,ZD38D2A28-ERD,ZD38D4A38-ERD,ZD38D2A42-ERD,ZD38D4A45-ERD,ZD38D2A54-ERD,ZD38D4A59-ERD,ZD38D2A68-ERD,ZD38D4A73-ERD,ZD38D2A80-ERD,ZD

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

38D4A87-ERD,ZD38D2A104-CRDX,ZD38D4A105-CRDX,ZD38D2A130-CRDX,ZD38D4A125-CRDX,ZD38D2A154-CRDX,ZD38D4A156-CRDX,ZD38D4A180-CRDX,ZD38D4A216-CRDX,ZD38D4A250-CRDX,ZD38D4A316-CRDX,ZD38D4A361-CRDX,ZD38D4A420-CRDX,ZD38D4A480-CRDX,ZD38D4A590-CRDX;

芯片级维修英国CT变频器:

英国CT Unidrive:UNI1401,UNI1402,UNI1403,UNI1404,UNI1405,UNI2401,UNI2402,UNI2403,UNI3401,UNI3402,UNI3403,UNI3404,UNI3405,UNI4401,UNI4402,UNI4403,UNI4404,UNI4405,UNI5401,UNI1201,UNI1202,UNI1203,UNI1204,UNI1205,UNI2201,UNI2202,UNI2203,UNI3201,UNI3202,UNI3203,UNI3204;

CommandeR SE:SE11200025,SE11200037,SE11200055,SE11200075,SE2D200075,SE2D200110,SE2D200150,SE2D200220,SE23200400,SE23400075,SE23400110,SE23400150,SE23400220,SE23400300,SE23400400,SE33200550,SE33400550,SE33200750,SE33400750,SE43401100,SE43401500,SE43401850,SE53402200,SE53403000,SE53403700;

CommandeR SK:SKA1200025,SKA1200037,SKA1200055,SKA1200075,SKBD200110,SKBD200150,SKCD200220,SKB3400037,SKB3400055,SKB3400075,SKB3400110,SKB3400150,SKC3400220,SKC3400300,SKC3400400;

CommandeR SX: SX13200037, SX13200055, SX13200075, SX23200110, SX23200150, SX23200220, SX33200300, SX33200400, SX13400075, SX13400110, SX13400150, SX23400220, SX23400300, SX23400400, SX33400550, SX33400750;

Unidrive ES:ES2401,ES2402,ES2403,ES2404,ES3401,ES3402,ES3403,ES4401,ES4402,ES4403;

Unidrive SP感应电机和伺服电机驱动器:SP1201,SP1202,SP1203,SP1204,SP2201,SP2202,SP2203,SP3201,SP3202,SP4201,SP4202,SP4203,SP1401,SP1402,SP1403,SP1404,SP1405,SP1406,SP2401,SP2402,SP2403,SP2404,SP3401,SP3402,SP3403,SP4401,SP4402,SP4403,SP5401,SP5402,SP6401,SP6402,SP3501,SP3502,SP3503,SP3504,SP3505,SP3506,SP3507,SP4601,SP4602,SP4603,SP4604,SP4605,SP4606,SP5601,SP5602,SP6601,SP6602,SP8411,SP8412,SP8413,SP8414,SP9411,SP9412,SP9413,SP9414,SP9415,SP6411,SP6412,SP7411,SP7412,SP6611,SP6612,SP7611,SP7612,SP8611,SP8612,SP6611,SP6612,SP9611,SP9612,SP9613,SP9614,SP9615,SP9616,SP8441,SP8442,SP8443,SP8444,SP9441,SP9442,SP9443,SP8641,SP8642,SP8643,SP8644,SP9641,SP9642,SP9643;SPMA1401,SPMA1402,SPMA1403,SPMA1404,SPMA1601,SPMA1602,SPMA1603,SPMA1604;

UNIDRIVE:UNI1201LV,UNI1202LV,UNI1203LV,UNI1204LV,UNI1205LV,UNI2201LV,UNI2202LV,UNI2203LV,UNI3201LV,UNI3202LV,UNI3203LV,UNI3204LV,UNI3205LV;

Digital Servodrive digifas 7100 series:7103, 7105, 7108, 7112, 7116, 7133, 7150;

SK 可编程变频器:SK-2S0002G,SK-2S0004G,SK-2S0005G,SK-2S0007G,SK-2D0011G,SK-2D0015G,SK-2D0022G,SK-4T0004G,SK-4T0005G,SK-4T0007G,SK-4T0011G,SK-4T0015G,SK-4T0022G,SK-4T0030G,SK-4T0037G,SK-2T0037G,SK-2T0055G,SK-4T0055G,SK-4T0075G,SK-4T0110G,SK-4T0150G,

芯片级维修艾默生网络能源有限公司变频器:

TD900系列通用变频器:TD900-4T0022G,TD900-4T0015G,TD900-4T0007G,TD900-2T0022G,TD900-2T0015G,TD900-2S0007G,TD900-2S0004G;

EV1000系列通用变频器:EV1000-2S0004G,EV1000-2S0007G,EV1000-2S0015G,EV1000-2S0022G,EV1000-4T0007G,EV1000-4T0015G,EV1000-4T0022G,EV1000-4T0037G,EV1000-4T0037P,EV1000-4T0055G,EV1000-4T0055P;

EV2000系列通用变频器:EV2000-4T0055G,EV2000-4T0075P,EV2000-4T0075G,EV2000-4T0110P,EV2000-4T0110G,EV2000-4T0150P,EV2000-4T0150G,EV2000-4T0185P,EV2000-4T0185G1,EV2000-4T0220P1,EV2000-4T0220G1,EV2000-4T0300P1,EV2000-4T0300G1,EV2000-4T0370P1,EV2000-4T0370G1,EV2000-4T0450P1,EV2000-4T0450G1,EV2000-4T0550P1,EV2000-4T0550G,EV2000-4T0750G,EV2000-4T0750P,EV2000-4T0900G,EV2000-4T0900P,EV2000-4T1100P;

EV3100系列电梯专用变频器:EV3100-4T0300E,EV3100-4T0220E,EV3100-4T0185E,EV3100-4T0150E,EV3100-4T0110E,EV3100-4T0075E,EV3100-4T0055E;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

TD1000系列通用变频器:TD1000-4T0055G,TD1000-4T0037G,TD1000-4T0022G,TD1000A-4T0022G,TD1000-4T0015G,TD1000-4T0007G,TD1000-2T0037G,TD1000-2T0022G,TD1000-2T0015G,TD1000-2S0022G,TD1000-2S0015G,TD1000-2S0007G,TD1000-4T0055P,TD1000-4T0037P;

TD2000通用变频器:TD2000-4T0450G,TD2000-4T0550P,TD2000-4T0370G,TD2000-4T0450P,TD2000-4T0300G,TD2000-4T0370P,TD2000-4T0220G,TD2000-4T0300P,TD2000-4T0185G,TD2000-4, T0220P,TD2000-4T0150G,TD2000-4T0185P,TD2000-4T0110G,TD2000-4T0150P,TD2000-4T0075G,TD2000-4T0110P,TD2000-4T0055G,TD2000-4T0075P,TD2000-4T2500P,TD2000-4T2200G,TD2000-4T2200P,TD2000-4T2000G,TD2000-4T2000P,TD2000-4T1600G,TD2000-4T1600P,TD2000-4T1320G,TD2000-4T1320P,TD2000-4T1100G,TD2000-4T1100P,TD2000-4T0900G,TD2000-4T0900P,TD2000-4T0750G,TD2000-4T0750P,TD2000-4T0550G;晶闸管整流单元:EV-TU-4T2200;**TD3300VariableSpeedDriveControl:**

TD2000-1系列供水专用变频器:TD2100-4T0055S,TD2100-4T0075S,TD2100-4T0110S,TD2100-4T0150S,TD2100-4T0185S,TD2100-4T0220S,TD2100-4T0300S,TD2100-4T0370S,TD2100-4T0450S,TD2100-4T0550S,TD2100-4T0750S;

TD2000-1系列高能矢量变频器:TD3000-4T0055G,TD3000-4T0075G,TD3000-4T0110G,TD3000-4T0150G,TD3000-4T0185G,TD3000-4T0220G,TD3000-4T0300G,TD3000-4T0370G,TD3000-4T0450G,TD3000-4T0550G,TD3000-4T0750G;**TD3200门机专用变频器:**TD3200-2S0004D,TD3200-2S0002D;

TD3200张力控制用变频器:EV800系列通用变频器:EV800-2S0002G,EV800-2S0004G,EV800-2S0005G,EV800-2S0007G,EV800-2S0011G,EV800-2S0015G,EV800-2S0022G,EV800-4T0004G,EV800-4T0005G,EV800-4T0007G,EV800-4T0011G,EV800-4T0015G,EV800-4T0022G,EV800-4T0030G,EV800-4T0037G;

TD3400注塑机专用变频器:TD3400-4T0075J,TD3400-4T0110J,TD3400-4T0150J,TD3400-4T0185J,TD3400-4T0220J,TD3400-4T0300J,TD3400-4T0370J,TD3400-4T0450J,TD3400-4T0550J,TD3400-4T0750J;**KBVF变频器:**KBVF-13,KBVF-23,KBVF-14,KBVF-23D,KBVF-24,KBVF-24D;

EV3500模块化大功率变频调速柜:EV3500-4T3150P,EV3500-4T3550P,EV3500-4T4000P,EV3500-4T4500P,EV3500-4T5600P,SPMA1401,SPMA1402,SPMD1401,SPMD1402,SPMD1403,SPMD1404,SPMU1401,SPMU1402,SPMU2402,SPMC1401,SPMC1402,SPMC2402;

芯片级维修**KEB变频器:**

KEBCOMBIVERT 56A/B:1056080-2008,1056080-2009,1056080-2018,1056080-2019,1056080-2028,1056080-2029,1156080-2008,1156080-2009,1156080-2019,1156080-2028,1156080-2029,1256080-2008,1256080-2009,1256080-2018,1256080-2019,1256080-2028,1256080-2029,1356080-2008,1356080-2009,1356080-2018,1356080-2019,1356080-2028,1356080-2029,0756080-4008,0756080-4009,0756080-4018,0756080-4019,0756080-4028,0756080-4029,0856080-4008,0856080-4009,0856080-4018,0856080-4019,0856080-4028,0856080-4029,0956080-4008,0956080-4009,0956080-4018,0956080-4019,0956080-4028,0956080-4029,1056080-4008,1056080-4009,1056080-4018,1056080-4019,1056080-4028,1056080-4029,1156080-4008,1156080-4009,1156080-4018,1156080-4019,1156080-4028,1156080-4029,1256080-4008,1256080-4009,1256080-4018,1256080-4019,1256080-4028,1256080-4029,1356080-4008,1356080-4009,1356080-4018,1356080-4019,1356080-4028,1356080-4029,1456080-4008,1456080-4009,1456080-4018,1456080-4019,1156080-4028,1456080-4029,1556080-4008,1556080-4009,1556080-4018,1556080-4019,1556080-4028,1556080-4029,1656080-4008,1656080-4009,1656080-4018,1656080-4019,1656080-4028,1656080-4029,1756080-4008,1756080-4009,1756080-4018,1756080-4019,1756080-4028,1756080-4029,1856080-4008,1856080-4009,1856080-4018,1856080-4019,1856080-4028,1856080-4029,1956080-4008,1956080-4009,1956080-4018,1956080-4019,1956080-4028,1956080-4029,2056080-4008,2056080-4009,2056080-4018,2056080-4019,2056080-4028,2056080-4029,2156080-4008,2156080-4009,2156080-4018,2156080-4019,2156080-4028,2156080-4029,2256080-4008,2256080-4009,2256080-4018,2256080-4019,2256080-4028,2256080-4029,2356080-4008,2356080-4009,2356080-4018,2356080-4019,2356080-4028,2356080-4029,2456080-4008,2456080-4009,2456080-4018,2456080-4019,2456080-4028,2456080-4029;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

019,2456080-4028,2456080-4029,2556080-4008,2556080-4009,2556080-4018,2556080-4019,2556080-4028,2556080-4029,1156080-2018;

COMBIVERT F4-S:05F4S1D-M420,06F4S1D-M420,07F4S1D-M420,08F4S1D-M420,09F4S1D-M420,10F4S1D-M420,11F4S1D-M420,12F4S1D-M420,13F4S1D-M420,14F4S1D-M420;

COMBIVERT R4-S:12R4S0G-3201,15R4S0G-3201,14R4S0G-3401,18R4S0G-3401,22R4S0R-3401;

COMBIVERT F4:07F4C1G-3240,09F4C1G-3240,10F4C1G-3240,13F4C1G-3240,14F4C1G-3240,15F4C1G-3240,16F4C1G-3240,17F4C1G-3240,18F4C1G-3240,19F4C1G-3240,20F4C1G-3240,21F4C1G-3240,07F4C1G-3440,09F4C1G-3440,10F4C1G-3440,13F4C1G-3440,14F4C1G-3440,15F4C1G-3440,16F4C1G-3440,17F4C1G-3440,18F4C1G-3440,19F4C1G-3440,20F4C1G-3440,21F4C1G-3440;

COMBIVERT F4-C:07F4C1D-1280,07F4C3D-1280,10F4C1D-1280,10F4C3D-1280,09F4C1D-1220,09F4C3D-1220,13F4C1E-3220,13U400E-BA01,14F4C1G-3280,14U400G-BA01,15F4C1H-3280,15U400H-BA01,16F4C1H-3280,16U400H-BA01,07F4C1D-3420,07F4C3D-3420,09F4C1D-3420,09F4C3D-3420,10F4C1D-3460,10F4C3D-3460,12F4C1D-3420,12F4C3D-3420,13F4C1D-3410,13F4C3D-3410,14F4C1E-3440,15F4C1E-3420,14U400E-BM01,15U400E-BM01,16F4C1G-3440,17F4C1G-3420,16U400G-BM01,17U400G-BM01;18F4C0H-3440,19F4C0H-3420,18U400H-BM01,19U400H-BM01,20F4C0R-3440,20F4C2R-3440,21F4C0R-3420,21F4C2R-3420,22F4C0R-3420,22F4C2R-3420,23F4C0R-3410,23U400U-BM01,24F4C0U-3420,25F4C0U-3420,25U400U-BM01,27F4C0U-3410,26F4C0U-3410,27U400U-BM01,28F4C0W-3410,28U4__W-3000,29F4C0W-3410,29U4C0W-3000,30F4C0W-3410,30U4C0W-3000;

COMBIVERT F4-F:07F4F1D-3240,07F4F3D-1240,10F4F1D-3440,10F4F3D-3440,14F4F1E-3440,12F4F1E-3440,13F4F1E-3440,14U400E-BM01,15F4F1G-3440,16F4F1G-3440,16U400G-BM01,17F4F1H-3440,18F4F1H-3440,18U400H-BM01,19F4F1R-3440,19F4F3R-3440,20F4F1R-3440,20F4F3R-3440,21F4F1R-3440,21F4F3R-3440,22F4F1R-3440,22F4F3R-3440;

COMBIVERT R4-F:14R4F0G-3241,16R4F0G-3440,20R4F0R-3440;

KEBCOMBIVERT F1-P:14F1P00-3449,15F1P00-3449,16F1P00-3449,17F1P00-3449,18F1P00-3449,19F1P00-3449,20F1P00-3449,21F1P00-3449,22F1P00-3449,23F1P00-3449,24F1P00-3449,25F1P00-3449,26F1P00-3449,27F1P00-3449,28F1P00-3449;

KEBCOMBIVERT F2:16F2210-3449,17F2210-3449,18F2210-3449,19F2210-3449,20F2210-3449,21F2210-3449,22F2210-3449,23F2210-3449,24F2210-3449,25F2210-3449,26F2210-3449,27F2210-3449;

KEBCOMBIVERT F1-K:13F1R10-3449,14F1R10-3449,15F1R10-3449,16F1R10-3449;

KEBCOMBIVERT F5-Lift:10F5A1D-3A0A,12F5A1D-3A0A,13F5A1D-390A,14F5A1E-3A0A,15F5A1E-350A,16F5A1G-360A,17F5A1G-350A,18F5A1G-340A,20F5A1H-380F,21F5A1R-960A,22F5A1R-960A,23F5A1R-940A,24F5A1R-940A;10F5-D,12F5-D,13F5-D,14F5-E,15F5-E,16F5-G,17F5-G,18F5-G,20F5-H,21F5-R,22F5-R,23F5-R,24F5-R;

KEBCOMBIVERT R6:15r6s3E-900A,19r6s3E-900A;

KEBCOMBIVERT F5 BASIC:05F5B3A-090A,07F5B3A-0A0A,09F5B1B-2B0A,10F5B1B-2A0A,12F5B1D-1A0A,13F5B1E-160A,14F5B1E-150A,05F5B3A-390A,07F5B3A-390A,09F5B3A-390A,10F5B1B-3A0A,12F5B1B-350A,13F5B1D-390A,14F5B1D-380A,15F5B1E-350A,16F5B1E-340A;

KEBCOMBIVERT F5 COMPACT:05F5C1B-2B0A,07F5C1B-2B0A,09F5C1B-2B0A,10F5C1B-2A0A,12F5C1D-1A0A,13F5C1E-160A,14F5C1E-150A,15F5C1G-150A,16F5C0H-170A,17F5C0H-160A,18F5C0R-760A,19F5C0R-760A,20F5C0R-760A,21F5C0R-760A,05F5C1B-3B0A,07F5C1B-3B0A,09F5C1B-3A0A,10F5C1B-3A0A,12F5C1B-350A,13F5C1D-390A,14F5C1D-380A,15F5C1E-350A,16F5C1E-340A,17F5C1G-350A,18F5C1G-340A,19F5C0H-350A,20F5C0H-940A,21F5C0R-950A,22F5C0R-950A,23F5C0R-940A,24F5C0R-940A;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

KEBCOMBIVERT F5 MULTI:09F5M1D-2B_A,10F5M1D-2B_A,12F5M1D-1A_A,13F5M1E-16_A,14F5M1E-15_A,15F5M1G-16_A,16F5M1H-17_A,17F5M1H-17_A,18F5M1R-76_A,19F5M1R-76_A,20F5M1R-76_A,21F5M1R-76_A,09F5M1D-3A_A,10F5M1D-39_A,12F5M1D-3A_A,13F5M1D-39_A,14F5M1D-38_A,15F5M1E-35_A,16F5M1E-34_A,17F5M1G-35_A,18F5M1G-34_A,19F5M1H-35_A,20F5M1H-34_A,21F5M1R-95_A,22F5M1R-95_A,23F5M1R-94_A,24F5M1R-94_A,25F5M1U-91_A,26F5M1U-91_A,27F5M1U-90_A,28F5M1W-90_A,29F5M1W-90_A,30F5M1W-A0_A;

KEBCOMBIVERTF5-B:05F5B3A-0A00,07F5B3A-0A00,09F5B1B-2B00,10F5B1B-2A00,12F5B1D-1A00,13F5B1E-1600,14F5B1E-1500,05F5B1B-3B00,07F5B1B-3B00,09F5B1B-3B00,10F5B1B-3A00,12F5B1B-3500,13F5B1D-3900,15F5B1E-3900,14F5B1E-3A00,16F5B1G-3600,17F5B1G-3500,18F5B0H-3600,19F5B0H-3500;

KEBCOMBIVERT M4:07M4C0D3220,09M4C0D3220,07M4C0D3420,09M4C0D3420,10M4C0D3420,11M4C0D3420;

KEBCOMBIVERT F5-G:05F5G1B-2B00,07F5G1B-2B00,09F5G1B-2B00,10F5G1B-2A00,12F5G1D-1A00,13F5G1E-1600,14F5G1E-1500,15F5G1G-1500,16F5G1H-1700,17F5G1H-1600,18F5G0R-7700,19F5G0R-7600,20F5G0R-7600,21F5G0U-7200,22F5G0U-7200,23F5G0U-7100,05F5G1B-3B00,07F5G1B-3B00,09F5G1B-3B00,10F5G1B-3A00,12F5G1B-3500,13F5G1D-3900,14F5G1E-3A00,15F5G1E-3900,16F5G1G-3600,17F5G1G-3500,18F5G0H-3600H,19F5G0H-3600H,20F5G0R-9600,21F5G0R-9500,22F5G0R-9500,23F5G0R-9400,24F5G0R-9400,25F5G0U-U9100,26F5G0UU-9100,27F5G0UU-9000,28F5G0W-9000,29F5G0WW-9000,30F5G0W0W-9000;

COMBIVERT R4:14R4S0G-3401,18R4S0G-3401,22R4S0R-3401,16R4F0G-3440,21R4F0R-3440;

KEBCOMBIVERT F5-M/S:09F5M1D-2B010F5M1D-2A_0,12F5M1D-1A_0,13F5M1E-16_0,14F5M1E-15_0,15F5M1G-15_0,16F5M1H-17_0,17F5M1H-16_0,18F5M1R-77_0,19F5M1R-76_0,20F5M1R-76_0,21F5M1U-72_0,22F5M1U-72_0,23F5M1U-71_0,09F5M1D-3A_0,10F5M1D-39_0,12F5M1D-3A_0,13F5M1D-39_0,14F5M1E-3A_0,15F5M1E-39_0,16F5M1G-36_0,17F5M1G-35_0,18F5M1H-36_0,19F5M1H-35_0,20F5M1R-96_0,21F5M1R-95_0,22F5M1R-95_0,23F5M1R-94_0,24F5M1R-94_0,25F5M1U-91_0,26F5M1U-91_0,27F5M1U-90_0,28F5M1W-90_0,29F5M1W-90_0,30F5M1W-90_0;

KEBCOMBIVERT F4-S:05F4S0C-1220,05F4S2C-1220,07F4S0C-1220,07F4S2C-1220,09F4S1D-1220,09F4S3D-1220,10F4S1D-1220,10F4S3D-1220,13F4S1E-3220,13U400E-BA00,07F4S1D-3420,07F4S1D-3410,07F4S3D-3420,07F4S3D-3410,09F4S1D-3420,09F4S1D-3410,09F4S3D-3420,09F4S3D-3410,10F4S1D-3420,10F4S1D-3410,10F4S3D-3420,10F4S3D-3410,12F4S1D-3420,12F4S1D-3410,12F4S3D-3420,12F4S3D-3410,13F4S1D-3420,13F4S1D-3410,13F4S3D-3420,13F4S3D-3410,14F4S1E3400,15F4S1E3200;

KEBCOMBIVERT F0V12:05F0/200V,07F0/200V,09F0/200V,10F0/200V,12F0/200V,09F0/400V,10F0/400V,11F0/400V,12F0/400V,13F0/400V,14F0/400V;

芯片级维修伦兹变频器:

SmD系列变频器:ESMD251X2SFA,ESMD371X2SFA,ESMD551X2SFA,ESMD751X2SFA,ESMD152X2SFA,ESMD222X2SFA,ESMD371X2TXA,ESMD751X2TXA,ESMD112X2TXA,ESMD152X2TXA,ESMD222X2TXA,ESMD302X2TXA,ESMD402X2TXA,ESMD552X2TXA,ESMD752X2TXA,ESMD113X2TXA,ESMD153X2TXA,ESMD371L4TXA,ESMD751L4TXA,ESMD112L4TXA,ESMD152L4TXA,ESMD222L4TXA,ESMD302L4TXA,ESMD402L4TXA,ESMD552L4TXA,ESMD752L4TXA,ESMD113L4TXA,ESMD153L4TXA,ESMD183L4TXA,,ESMD223L4TXA;

8200vector:E82CV251_2B,E82CV371_2B,E82CV551_2B,E82CV751_2B,E82CV152_2B,E82CV222_2B,E82CV551_4B,E82CV751_4B,E82CV152_4B,E82CV222_4B,E82EV251K2C200,E82EV371K2C200,E82EV551K2C200,E82EV751K2C200,E82EV152K2C200,E82EV222K2C200,E82EV551K2C200,E82EV751K2C200,E82EV152K2C200,E82EV222K2C200,E82EV302K2C200,E82EV402K2C200,E82EV552K2C200,E82EV752K2C200,E82EV551K4C200,E82EV751K4C200,E82EV152K4C200,E82EV222K4C200,E82EV302K4C200,E82EV402K4C200,E82EV552K4C200,E82EV752K4C200,E82EV113K4C200,E82EV551K4C,E82EV751K4C,E82EV15

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

2K4C,E82EV222K4C,E82EV302K4C,E82EV402K4C,E82EV552K4C,E82EV752K4C,E82EV113K4C,E82EV153K4B,E82EV223K4B,E82EV303K4B,E82EV453K4B,E82EV553K4B,E82EV753K4B,E82EV903K4B;E82EV251_2C,E82EV371_2C,E82EV551_2C,E82EV751_2C,E82EV152_2C,E82EV222_2C,E82EV302_2C,E82EV402_2C,E82EV552_2C,E82EV752_2C,E82EV551_4C,E82EV751_4C,E82EV152_4C,E82EV222_4C,E82EV302_4C,E82EV402_4C,E82EV552_4C,E82EV752_4C,E82EV113_4C,E82EV153_4B,E82EV223_4B,E82EV303_4B,E82EV453_4B,E82EV553_4B,E82EV753_4B,E82EV903_4B;EVF8201-E,EVF8202-E,EVF8203E,EVF8204-E,EVF8211-E,EVF8212-E,EVF8213-E,EVF8214-E,EVF8215-E,EVF8216-E,EVF8217-E,EVF8218-E,EVF8215-CV003,EVF8216-CV003,EVF8217-CV003,EVF8218-CV003,EVF8211-EV020,EVF8212-EV020,EVF8213-EV020,EVF8214-EV020,EVF8215-EV020,EVF8216-EV020,EVF8217-EV020,EVF8218-EV020;EVF8221-E,EVF8222-E,EVF8223-E,EVF8224-E,EVF8225-E,EVF8226-E,EVF8227-E,EVF8244-E,EVF8245-E,EVF8246-E,EVF8241-E,EVF8242-E,EVF8243-E,EVF8221-C-V003,EVF8222-C-V003,EVF8241-C-V003,EVF8242-C-V003,EVF8243-C-V003,EVF8244-C-V003,EVF8245-C-V003,EVF8246-C-V003;

9300 Vector工程型高性能矢量变频器:8200moteCfrequencYinverters:E82MV251_2B,E82MV371_2B,E82MV551_4B,E82MV751_4B,E82MV152_4B,E82MV222_4B,E82MV302_4B,E82MV402_4B,E82MV552_4B,E82MV752_4B;

LENZE9300-V100servOinverters:EVS9321-ESV100,EVS9322-ESV100,EVS9323-ESV100,EVS9324-ESV100,EVS9325-ESV100,EVS9321-CSV100,EVS9322-CSV100,EVS9323-CSV100,EVS9324-CSV100,EVS9325-CSV100,EVS9326-ESV100,EVS9327-ESV100,EVS9328-ESV100,EVS9329-ESV100,EVS9330-ESV100,EVS9331-ESV100,EVS9332-ESV100,EVS9326-CSV003,EVS9327-CSV100,EVS9328-CSV100;

LENZE FrequencY inverter 9300 vector:EVF9335-EV,EVF9335-EVV030,EVF9335-EVV060,EVF9335-EVV110,EVF9336-EV,EVF9336-EVV030,EVF9336-EVV060,EVF9336-EVV110,EVF9337-EV,EVF9337-EVV030,EVF9337-EVV060,EVF9337-EVV110,EVF9338-EV,EVF9338-EVV030,EVF9338-EVV060,EVF9338-EVV110,EVF9381-EV,EVF9381-EVV030,EVF9381-EVV060,EVF9381-EVV110,EVF9382-EV,EVF9382-EVV030,EVF9382-EVV060,EVF9382-EVV110,EVF9383-EV,EVF9383-EVV030,EVF9383-EVV060,EVF9383-EVV110,EVF9335-EVV210,EVF9335-EVV240,EVF9335-EVV270,EVF9335-EVV300,EVF9336-EVV210,EVF9336-EVV240,EVF9336-EVV270,EVF9336-EVV300,EVF9337-EVV210,EVF9337-EVV240,EVF9337-EVV270,EVF9337-EVV300,EVF9338-EVV210,EVF9338-EVV240,EVF9338-EVV270,EVF9338-EVV300,EVF9381-EVV210,EVF9381-EVV240,EVF9381-EVV270,EVF9381-EVV300,EVF9382-EVV210,EVF9382-EVV240,EVF9382-EVV270,EVF9382-EVV300,EVF9383-EVV210,EVF9383-EVV240,EVF9383-EVV270,EVF9383-EVV300,EVF9335-EVV210,EVF9335-EVV240,EVF9335-EVV270,EVF9335-EVV300,EVF9336-EVV210,EVF9336-EVV240,EVF9336-EVV270,EVF9336-EVV300,EVF9337-EVV210,EVF9337-EVV240,EVF9337-EVV270,EVF9337-EVV300,EVF9338-EVV210,EVF9338-EVV240,EVF9338-EVV270,EVF9338-EVV300,EVF9381-EVV210,EVF9381-EVV240,EVF9381-EVV270,EVF9381-EVV300,EVF9382-EVV210,EVF9382-EVV240,EVF9382-EVV270,EVF9382-EVV300,EVF9383-EVV210,EVF9383-EVV240,EVF9383-EVV270,EVF9383-EV;

LENZE9300矢量控制变频器:EVF9321-EV,EVF9322-EV,EVF9323-EV,EVF9324-EV,EVF9325-EV,EVF9326-EV,EVF9327-EV,EVF9328-EV,EVF9329-EV,EVF9330-EV,EVF9331-EV,EVF9332-EV,EVF9333-EV,EVF9321-CVV003,EVF9322-CVV003,EVF9323-CVV003,EVF9324-CVV003,EVF9325-CVV003,EVF9326-CVV003,EVF9327-CVV003,EVF9328-CVV003;

芯片级维修**LG变频器:**

IS3系列:SV022iS3-2,SV037iS3-2,SV055iS3-2,SV075iS3-2,SV110iS3-2(DB),SV150iS3-2(DB),SV185iS3-2(DB),SV220iS3-2(DB),SV022iS3-4,SV037iS3-4,SV055iS3-4,SV075iS3-4,SV110iS3-4(DB),SV150iS3-4(DB),SV185iS3-4(DB),SV220iS3-4(DB);

LG变频器IS5系列:SV008iS5-2,SV015iS5-2,SV022iS5-2,SV037iS5-2,SV055iS5-2,SV075iS5-2,SV110iS5-2,SV150iS5-2,SV185iS5-2,SV220iS5-2,SV008iS5-4,SV015iS5-4,SV022iS5-4,SV037iS5-4,SV055iS5-4,SV075iS5-4,SV110iS5-4,SV150iS5-4,SV185iS5-4,SV220iS5-4;

iG series:LGSV008iG-1,LGSV015iG-1,LGSV004iG-2,LGSV008iG-2,LGSV015iG-2,LGSV022iG-2,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

LGSV037iG-2,LGSV040iG-2,LGSV004iG-4,LGSV008iG-4,LGSV015iG-4,LGSV022iG-4,LGSV037iG-4,LGSV040iG-4,LGSV008iG-1,
LGSV015iG-1,LGSV022iG-2,LGSV037iG-2,LGSV040iG-2,LGSV004iG-2,LGSV008iG-2,LGSV015iG-2,LGSV022iG-2,LGSV037iG-2,
LGSV040iG-2,LGSV004iG-4,LGSV008iG-4,LGSV015iG-4,LGSV022iG-4,LGSV037iG-4,LGSV040iG-4;

iG5 series:,SV004iG5-1,SV008iG5-1,SV015iG5-1,SV004iG5-2,SV008iG5-2,SV015iG5-2,SV022iG5-2,
SV040iG5-2,SV004iG5-4,SV008iG5-4,SV015iG5-4,SV022iG5-4,SV040iG5-4,SV004iG5-1,SV008iG5-1,SV015iG5-1,SV004iG5-2,SV
008iG5-2,SV015iG5-2,SV022iG5-2,SV040iG5-2,SV004iG5-4,SV008iG5-4,SV015iG5-4,SV022iG5-4,SV040iG5-4;

iS5 series:SV008iS5-2,SV015iS5-2,SV022iS5-2,SV037iS5-2,SV055iS5-2,SV075iS5-2,SV110iS5-2,
SV150iS5-2,SV185iS5-2,SV220iS5-2,SV008iS5-4,SV015iS5-4,SV022iS5-4,SV037iS5-4,SV055iS5-4,SV075iS5-4,SV110iS5-4,SV15
0iS5-4,SV185iS5-4,SV220iS5-4,SV008iS5-2,SV015iS5-2,SV022iS5-2,SV037iS5-2,SV055iS5-2,SV075iS5-2,SV110iS5-2,SV150iS5-
2,SV185iS5-2,SV220iS5-2,SV008iS5-4,SV015iS5-4,SV022iS5-4,SV037iS5-4,SV055iS5-4,SV075iS5-4,SV110iS5-4,SV150iS5-4,SV
185iS5-4,SV220iS5-4;

iS3 series,LGSV022iS3-2,LGSV037iS3-2,LGSV055iS3-2,LGSV075iS3-2,LGSV110iS3-2,
LGSV150iS3-2,LGSV180iS3-2,LGSV220iS3-2,LGSV022iS3-4,LGSV037iS3-4,LGSV055iS3-4,LGSV075iS3-4,LGSV110iS3-4,LGSV
150iS3-4,LGSV180iS3-4,LGSV220iS3-4,LGSV022iS3-2,LGSV037iS3-2,LGSV055iS3-2,LGSV075iS3-2,LGSV110iS3-2,LGSV150iS3
-2,LGSV180iS3-2,LGSV220iS3-2,LGSV022iS3-4,LGSV037iS3-4,LGSV055iS3-4,LGSV075iS3-4,LGSV110iS3-4,LGSV150iS3-4,LGS
V180iS3-4,LGSV220iS3-4;

iH series:,LGSV030iH-2,LGSV037iH-2,LGSV045iH-2,LGSV055iH-2,LGSV030iH-4,LGSV037iH-4,
LGSV045iH-4,LGSV055iH-4,LGSV075iH-4,LGSV090iH-4,LGSV110iH-4,LGSV132iH-4,LGSV160iH-4,LGSV220iH-4;

芯片级维修普传变频器:

PI-168系列:PI-168G-8R40G1,PI-168G-8R75G1,PI-168G-81R5G1,PI-168G-82R2G1,PI-168G-8004G1,PI-168G-85R5G1,PI-168G-87
R5G1,PI-168G-8011G1,PI-168G-8015G1,PI-168G-8R40G2,PI-168G-8R75G2,PI-168G-81R5G2,PI-168G-82R2G2,PI-168G-8004G2,
PI-168G-85R5G2,PI-168G-87R5G2,PI-168G-8011G2,PI-168G-8015G2,PI-168G-8018G2,PI-168G-8022G2,PI-168G-8030G2,PI-168
G-8037G2,PI-168G-8045G2,PI-168G-8055G2,PI-168G-8075G2,PI-168G-8093G2,PI-168G-8110G2,PI-168G-8132G2,PI-168G-8160
G2,PI-168G-8187G2,PI-168G-8200G2,PI-168G-8220G2,PI-168G-8R75G3,PI-168G-81R5G3,PI-168G-82R2G3,PI-168G-8004G3,PI-
168G-85R5G3,PI-168G-87R5G3,PI-168G-8011G3,PI-168G-8015G3,PI-168G-8018G3,PI-168G-8022G3,PI-168G-8030G3,PI-168G-
8037G3,PI-168G-8045G3,PI-168G-8055G3,PI-168G-8075G3,PI-168G-8093G3,PI-168G-8110G3,PI-168G-8132G3,PI-168G-8160G
3,PI-168G-8187G3,PI-168G-8200G3,PI-168G-8220G3PI-168G-8250G3,PI-168G-8280G3,PI-168G-8315G3,PI-168G-8R75G4,PI-16
8G-81R5G4,PI-168G-82R2G4,PI-168G-8004G4,PI-168G-85R5G4,PI-168G-87R5G4,PI-168G-8011G4,PI-168G-8015G4,PI-168G-80
18G4,PI-168G-8022G4,PI-168G-8030G4,PI-168G-8037G4,PI-168G-8045G4,PI-168G-8055G4,PI-168G-8075G4,PI-168G-8093G4,P
I-168G-8110G4,PI-168G-8132G4,PI-168G-8160G4,PI-168G-8187G4,PI-168G-8200G4,PI-168G-8220G4,PI-168G-8250G4,PI-168G-
8280G4,PI-168G-8315G4,PI-168G-8375G4,PI-168G-8400G4,PI-168G-8500G4,PI-168G-8R75G5,PI-168G-81R5G5,PI-168G-82R2G
5,PI-168G-8004G5,PI-168G-85R5G5,PI-168G-87R5G5,PI-168G-8011G5,PI-168G-8015G5,PI-168G-8018G5,PI-168G-8022G5,PI-1
68G-8030G5,PI-168G-8037G5,PI-168G-8045G5,PI-168G-8055G5,PI-168G-8075G5,PI-168G-8093G5,PI-168G-8110G5,PI-168G-81
32G5,PI-168G-8160G5,PI-168G-8187G5,PI-168G-8200G5,PI-168G-8220G5,PI-168G-8250G5,PI-168G-8280G5,PI-168G-8315G5,P
I-168G-8375G5,PI-168G-8400G5,PI-168G-8500G5,PI-168G-8004G6,PI-168G-85R5G6,PI-168G-87R5G6,PI-168G-8011G6,PI-168G
-8015G6,PI-168G-8018G6,PI-168G-8022G6,PI-168G-8030G6,PI-168G-8037G6,PI-168G-8045G6,PI-168G-8055G6,PI-168G-8075G
6,PI-168G-8093G6,PI-168G-8110G6,PI-168G-8132G6,PI-168G-8160G6,PI-168G-8187G6,PI-168G-8200G6,PI-168G-8220G6,PI-16
8G-8250G6,PI-168G-8280G6,PI-168G-8315G6,PI-168G-8375G6,PI-168G-8400G6,PI-168G-8500G6,PI-168F-8R40F1,PI-168F-8R7
5F1,PI-168F-81R5F1,PI-168F-82R2F1,PI-168F-8004F1,PI-168F-85R5F1,PI-168F-87R5F1,PI-168F-8011F1,PI-168F-8015F1,PI-168
F-8R40F2,PI-168F-8R75F2,PI-168F-81R5F2,PI-168F-82R2F2,PI-168F-8004F2,PI-168F-85R5F2,PI-168F-87R5F2,PI-168F-8011F2,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

02R2G3,PI7000004G3,PI70005R5G3,PI70007R5G3PI7000011G3,PI7000015G3,PI7000018G3,PI7000022G3,PI7000030G3,PI7000037G3,PI7000045G3,PI7000055G3,PI7000075G3,PI7000093G3,PI7000110G3,PI7000132G3,PI7000160G3,PI7000187G3,PI7000200G3,PI7000220G3,PI7000250G3,PI7000280G3,PI7000315G3,PI7000R75G4,PI70001R5G4,PI70002R2G4,PI7000004G4PI70005R5G4,PI70007R5G4,PI7000011G4,PI7000015G4,PI7000018G4,PI7000022G4,PI7000030G4,PI7000037G4,PI7000045G4,PI7000055G4,PI7000075G4,PI7000093G4,PI7000110G4,PI7000132G4,PI7000160G4,PI7000187G4,PI7000200G4,PI7000220G4,PI7000250G4,PI7000280G4,PI7000315G4,PI7000375G4,PI7000400G4,PI7000500G4,PI7000R75G5,PI70001R5G5,PI70002R2G5,PI7000004G5,PI700005R5G5,PI70007R5G5,PI7000011G5,PI7000015G5,PI7000018G5,PI7000022G5,PI7000030G5,PI7000037G5,PI7000045G5,PI7000055G5,PI7000075G5,PI7000093G5,PI7000110G5,PI7000132G5,PI7000160G5,PI7000187G5,PI7000200G5,PI7000220G5,PI7000250G5,PI7000280G5,PI7000315G5,PI7000375G5,PI7000400G5,PI7000500G5,PI7000004G6,PI70005R5G6,PI70007R5G6,PI7000011G6,PI7000015G6,PI7000018G6,PI7000022G6,PI7000030G6,PI7000037G6,PI7000045G6,PI7000055G6,PI7000075G6,PI7000093G6,PI7000110G6,PI7000132G6,PI7000160G6,PI7000187G6,PI7000200G6,PI7000220G6,PI7000250G6,PI7000280G6,PI7000315G6,PI7000375G6,PI7000400G6,PI7000500G6,PI7000R40F1,PI7000R75F1,PI70001R5F1,PI70002R2F1,PI7000004F1,PI70005R5F1,PI70007R5F1,PI7000011F1,PI7000015F1,PI7000R40F2,PI7000R75F2,PI70001R5F2,PI70002R2F2,PI7000004F2PI70005R5F2,PI70007R5F2,PI7000011F2,PI7000015F2,PI7000018F2,PI7000022F2,PI7000030F2,PI7000037F2,PI7000045F2,PI7000055F2,PI7000075F2,PI7000093F2,PI7000110F2,PI7000132F2,PI7000160F2,PI7000187F2,PI7000200F2PI7000220F2,PI7000R75F3,PI70001R5F3,PI70002R2F3,PI7000004F3,PI70005R5F3,PI70007R5F3,PI7000011F3,PI7000015F3,PI7000018F3,PI7000022F3,PI7000030F3,PI7000037F3PI7000045F3,PI7000055F3,PI7000075F3,PI7000093F3,PI7000110F3,PI7000132F3,PI7000160F3,PI7000187F3,PI7000200F3,PI7000220F3,PI7000250F3,PI7000280F3,PI7000315F3,PI7000R75F4,PI70001R5F4,PI70002R2F4,PI7000004F4,PI70005R5F4,PI70007R5F4,PI7000011F4PI7000015F4,PI7000018F4,PI7000022F4,PI7000030F4,PI7000037F4,PI7000045F4,PI7000055F4,PI7000075F4,PI7000093F4,PI7000110F4,PI7000132F4,PI7000160F4,PI7000187F4,PI7000200F4,PI7000220F4,PI7000250F4,PI7000280F4,PI7000315F4,PI7000375F4,PI7000400F4,PI7000500F4,PI70001R5F5,PI70002R2F5,PI7000004F5,PI70005R5F5,PI70007R5F5,PI7000011F5,PI7000015F5,PI7000018F5,PI7000022F5,PI7000030F5,PI7000037F5,PI7000045F5,PI7000055F5,PI7000075F5,PI7000093F5,P7000110F5,PI7000132F5,PI7000160F5,PI7000187F5,PI7000200F5,PI7000220F5,PI7000250F5,PI7000280F5,PI7000315F5,PI7000375F5,PI7000400F5,PI7000500F5,PI7000011F6,PI7000015F6,PI7000018F6,PI7000022F6,PI7000030F6,PI7000037F6,PI7000045F6,PI7000055F6,PI7000075F6,PI7000093F6,PI7000110F6,PI7000132F6,PI7000160F6,PI7000187F6,PI7000200F6,PI7000220F6,P7000250F6,PI7000280F6,PI7000315F6,PI7000375F6,PI7000400F6,PI7000500F6;

芯片级维修三肯变频器:

SANKEN SAMCO-i系列:IHF-75K,IHF-90K,IHF-110K,IHF-132K,IHF-160K,IHF-220K,IHF-250K,IPF-75K,IPF-90K,IPF-110K,IPF-132K,IPF-160K,IPF-200K,IPF-220K,IPF-315K;

SANKEN VVVF InverteR SAMCO-E:ES-04K,ES-075K,ES-15K,ES-22K,EF-04K,EF-075K,EF-15K,EF-22K,EF-40k;

VVVF InverteR SAMCO-VM05:SHF-15K,SHF-22K,SPF-22K,SHF-40K,SPF-40K,SHF-55K,SPF-55K,SHF-75K,SPF-75K,SHF-11K,SPF-11K,SHF-15K,SPF-15K,vSHF-185K,SPF-185K,SHF-22K,SPF-22K,SHF-30K,SPF-30K,SHF-37K,SPF-37K,SHF-45K,SPF-45K,SHF-55K,SPF-55K,SPF-75K;

芯片级维修施耐德变频器:

施耐德**TELEMECANIQUE ATV**变频器:**ALTIVAR11**系列:ATV11HU05M2E,ATV11HU09M2E,ATV11HU12M2E,ATV11HU18M2E,ATV11HU29M2E,ATV11HU41M2E,ATV11HU05F1U,ATV11HU09F1U,ATV11HU18F1U,ATV11HU05M2U,ATV11HU09M2U,ATV11HU18M2U,ATV11HU29M2U,ATV11HU41M2U,ATV11HU05M3U,ATV11HU09M3U,ATV11HU18M3U,ATV11HU29M3U,ATV11HU41M3U,ATV11HU05F1A,ATV11HU09F1A,ATV11HU18F1A,ATV11HU05M2A,ATV11HU09M2A,ATV11HU18M2A,ATV11HU29M2A,ATV11HU41M2A,ATV11HU05M3A,ATV11HU09M3A,ATV11HU18M3A,ATV11HU29M3A,ATV11HU41M3A,ATV11PU09M2E,ATV11PU12

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

M2E,ATV11PU18M2E,ATV11PU09F1U,ATV11PU09M2U,ATV11PU18M2U,ATV11PU09M3U,ATV11PU18M3U,ATV11PU09F1A,ATV11PU09M2A,ATV11PU18M2A,ATV11PU09M3A,ATV11PU18M3A;

ATV16变频器:ATV16U09M2,ATV16U18M2,ATV16U29M2,ATV16U18N4,ATV16U29N4,ATV16U41M2,ATV16U41N4,ATV16U54N4,ATV16U72N4;

ATV18变频器:ATV18U09M2,ATV18U18M2,ATV18U29M2,ATV18U18N4,ATV18U29N4,ATV18U41M2,ATV18U54M2,ATV18U72M2,ATV18U41N4,ATV18U54N4,ATV18U72N4,ATV18U90M2,ATV18D12M2,ATV18U90N4,ATV18D12N4,ATV18D16N4,ATV18D23N4;

ATV21变频器:ATV21H075M3X,ATV21HU15M3X,ATV21HU22M3X,ATV21HU30M3X,ATV21HU40M3X,ATV21HU55M3X,ATV21HU75M3X,ATV21HD11M3X,ATV21HD15M3X,ATV21HD18M3X,ATV21HD22M3X,ATV21HD30M3X,ATV21H075N4,ATV21HU15N4,ATV21HU22N4,ATV21HU30N4,ATV21HU40N4,ATV21HU55N4,ATV21HU75N4,ATV21HD11N4,ATV21HD15N4,ATV21HD18N4,ATV21HD22N4,ATV21HD30N4,ATV21HD37N4,ATV21HD45N4,ATV21HD55N4,ATV21HD75N4,ATV21W075N4,ATV21WU15N4,ATV21WU22N4,ATV21WU30N4,ATV21WU40N4,ATV21WU55N4,ATV21WU75N4,ATV21WD11N4,ATV21WD15N4,ATV21WD18N4,ATV21WD22N4,ATV21WD30N4,ATV21WD37N4,ATV21WD45N4,ATV21WD55N4,ATV21WD75N4,ATV21W075N4C,ATV21WU15N4C,ATV21WU22N4C,ATV21WU30N4C,ATV21WU40N4C,ATV21WU55N4C,ATV21WU75N4C,ATV21WD11N4C,ATV21WD15N4C,ATV21WD18N4C,ATV21WD22N4C,ATV21WD30N4C,ATV21WD37N4C,ATV21WD45N4C,ATV21WD55N4C,ATV21WD75N4C;

ATV28变频器:ATV28HU09M2U,ATV28HU18M2U,ATV28HU29M2U,ATV28HU41M2U,ATV28HU54M2U,ATV28HU72M2U,ATV28HU90M2U,ATV28HD12M2U,ATV28HU18N4U,ATV28HU29N4U,ATV28HU41N4U,ATV28HU54N4U,ATV28HU72N4U,ATV28HU90N4U,ATV28HD12N4U,ATV28HD16N4U,ATV28HD23N4U;

ATV31变频器:ATV31H018M2A,ATV31H037M2A,ATV31H055M2A,ATV31H075M2A,ATV31HU11M2A,ATV31HU15M2A,ATV31HU22M2A,ATV31H018M3X,ATV31H037M3X,ATV31H055M3X,ATV31H075M3X,ATV31HU11M3X,ATV31HU15M3X,ATV31HU22M3X,ATV31HU30M3X,ATV31HU40M3X,ATV31HU55M3X,ATV31HU75M3X,ATV31HD11M3X,ATV31HD15M3X,ATV31H037N4A,ATV31H055N4A,ATV31H075N4A,ATV31HU11N4A,ATV31HU15N4A,ATV31HU22N4A,ATV31HU30N4A,ATV31HU40N4A,ATV31HU55N4A,ATV31HU75N4A,ATV31HD11N4A,ATV31HD15N4A,ATV31C018M2,ATV31C037M2,ATV31C055M2,ATV31C075M2,ATV31CU11M2,ATV31CU15M2,ATV31CU22M2,ATV31C037N4,ATV31C055N4,ATV31C075N4,ATV31CU11N4,ATV31CU15N4,ATV31CU22N4,ATV31CU30N4,ATV31CU40N4,ATV31CU55N4,ATV31CU75N4,ATV31CD11N4,ATV31CD15N4;ATV31H075S6X,ATV31HU15S6X,ATV31HU22S6X,ATV31HU40S6X,ATV31HU55S6X,ATV31HU75S6X,ATV31HD11S6X,ATV31HD15S6X;

ATV38变频器:ATV38HU18N4,ATV38HU29N4,ATV38HU41N4,ATV38HU54N4,ATV38HU72N4,ATV38HU90N4,ATV38HD12N4,ATV38HD16N4,ATV38HD23N4,ATV38HD25N4,ATV38HD28N4,ATV38HD33N4,ATV38HD46N4,ATV38HD54N4,ATV38HD64N4,ATV38HD79N4,ATV38HC10N4X,ATV38HC13N4X,ATV38HC15N4X,ATV38HC19N4X,ATV38HC23N4X,ATV38HC25N4X,ATV38HC28N4X,ATV38HC31N4X,ATV38HC33N4X,ATV38ED05N4,ATV38ED07N4,ATV38ED09N4,ATV38ED12N4,ATV38ED16N4,ATV38ED23N4,ATV38ED25N4,ATV38ED28N4,ATV38ED33N4,ATV38ED46N4,ATV38ED54N4,ATV38ED64N4,ATV38ED79N4;

Microdrive V690V系列交流电机变频器:MV100E20,MV167E20,MV200E20,MV300E20,MV400E20,MV500E20,MV600E20;

ATV58变频器:ATV-58HU09M2,ATV-58HU18M2,ATV-58HU29M2,ATV-58HU41M2,ATV-58HU72M2,ATV-58HU90M2,ATV-58HD12M2,ATV-58HU29M2,ATV-58HU41M2,ATV-58HU54M2,ATV-58HU72M2,ATV-58HU90M2,ATV-58HD12M2,ATV-58HU18N4,ATV-58HU29N4,ATV-58HU41N4,ATV-58HU54N4,ATV-58HU72N4,ATV-58HU90N4,ATV-58HD12N4,ATV-58HD16N4,ATV-58HD23N4,ATV-58HD28N4,ATV-58HD33N4,ATV-58HD46N4,ATV-58HD54N4,ATV-58HD64N4,ATV-58HD79N4,ATV-58HD28N4,ATV-58HD33N4,ATV-58HD46N4,ATV-58HD54N4,ATV-58HD64N4,ATV-58HD79N4,ATV-58HD16M2X,ATV-58HD23M2X,ATV-58HD28M2X,ATV-58HD33M2X,ATV-58HD46M2X,ATV-58HD28N4X,ATV-58HD33N4X,ATV-58HD46N4X,ATV-58HD54N4X,ATV-58HD64N4X,ATV-58HD79N4X,ATV-58HD16M2X,ATV-58HD23M2X,ATV-58HD28M2X,ATV-58HD33M2X,ATV-58HD46M2X,ATV-58HD28N4X,ATV-58HD33N4X,ATV-58HD46N4X,ATV-58HD54N4X,ATV-58HD64N4X,ATV-58PU09M2,ATV-58PU18M2,ATV-58PU29M2,ATV-58PU41M2,ATV-58PU72M2,ATV-58PU90M2,ATV-58PD12M2,ATV-58PU29M2,ATV-58PU41M2,ATV-58PU54M2,ATV-58PU72M2,ATV-58PU9

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

0M2,ATV-58PD12M2,ATV-58PU18N4,ATV-58PU29N4,ATV-58PU41N4,ATV-58PU54N4,ATV-58PU72N4,ATV-58PU90N4,ATV-58PD12N4,ATV-58PD16N4,ATV-58PD23N4;

ALTIVAR61变频器:ATV61H075M3,ATV61H022M3,ATV61H030M3,ATV61HU40M3,ATV61H075N4,ATV61HU40N4,ATV61HU55M3,ATV61HU55N4,ATV61HU75N4,ATV61HU73M3,ATV61HD11N4,DATV61H11M3X,ATV61HD15M3X,ATV61HD15N4,ATV61HD18N4,ATV61HD18M3X,ATV61HD22M3X,ATV61HD22N4,ATV61HD30N4,ATV61HD37N4,ATV61HD30M3X,ATV61HD37M3X,ATV61HD45M3X,ATV61HD45N4,ATV61HD55N4,ATV61HD75N4,ATV61HD55M3X,ATV61HD75M3X,ATV61HD90M3X,ATV61HD90N4,ATV61HC11N4,ATV61HC13N4,ATV61HC16N4,ATV61HC22N4,ATV61HC25N4,ATV61HC31N4,ATV61HC40N4,ATV61HC50N4,ATV61HC63N4;

ALTIVAR66变频器:ATV-66U41N4,ATV-66U41N4,ATV-66U41N4,ATV-66U54N4,ATV-66U72N4,ATV-66U90N4,ATV-66D12N4,ATV-66D16N4,ATV-66D23N4,ATV-66D33N4,ATV-66D46N4,ATV-66D54N4,ATV-66D64N4,ATV-66D79N4,ATV-66C10N4,ATV-66C13N4,ATV-66C15N4,ATV-66C19N4,ATV-66C23N4,ATV-66C28N4,ATV-66C31N4;

ATV68变频器:ATV-68C10N4,ATV-68C13N4,ATV-68C15N4,ATV-68C19N4,ATV-68C23N4,ATV-68C28N4,ATV-68C33N4,ATV-68C43N4,ATV-68C53N4,ATV-68C63N4,ATV-68C10N4,ATV-68C13N4,ATV-68C15N4,ATV-68C19N4,ATV-68C23N4,ATV-68C28N4,ATV-68C33N4,ATV-68C43N4,ATV-68C53N4,ATV-68C63N4;

ATV71变频器:ATV71H075M3,ATV71HU15M3,ATV71HU22M3,ATV71HU30M3,ATV71HU40M3,ATV71HU55M3,ATV71HU75M3,ATV71H037M3,ATV71H075M3,ATV71HU15M3,ATV71HU22M3,ATV71HU30M3,ATV71HU40M3,ATV71HU55M3,ATV71HU75M3,ATV71HD11M3X,ATV71HD15M3X,ATV71HD18M3X,ATV71HD22M3X,ATV71HD30M3X,ATV71HD37M3X,ATV71HD45M3X,ATV71HD55M3X,ATV71HD75M3X,ATV71H075N4,ATV71HU15N4,ATV71HU22N4,ATV71HU30N4,ATV71HU40N4,ATV71HU55N4,ATV71HU75N4,ATV71HD11N4,ATV71HD15N4,ATV71HD18N4,ATV71HD22N4,ATV71HD30N4,ATV71HD37N4,ATV71HD45N4,ATV71HD55N4,ATV71HD75N4,ATV71HD90N4,ATV71HC11N4,ATV71HC13N4,ATV71HC16N4,ATV71HC20N4,ATV71HC25N4,ATV71HC28N4,ATV71HC31N4,ATV71HC40N4,ATV71HC50N4,ATV71W075N4,ATV71WU15N4,ATV71WU22N4,ATV71WU30N4,ATV71WU40N4,ATV71WU55N4,ATV71WU75N4,ATV71WD11N4,ATV71WD15N4,ATV71WD18N4,ATV71WD22N4,ATV71WD30N4,ATV71WD37N4,ATV71WD45N4,ATV71WD55N4,ATV71WD75N4,ATV71P075N4Z,ATV71PU15N4Z,ATV71PU22N4Z,ATV71PU30N4Z,ATV71PU40N4Z,ATV71PU55N4Z,ATV71PU75N4Z;

ATV78变频器:ATV78pU22Y,ATV78pU30Y,ATV78pU40Y,ATV78pU55Y,ATV78pU75Y,ATV78pD11Y,ATV78pD15Y,ATV78pD18Y,ATV78pD22Y,ATV78pD30Y,ATV78pD37Y,ATV78pD45Y,ATV78pD55Y,ATV78pD75Y,ATV78pD90Y,ATV78pC11Y,ATV78pC13Y,ATV78pC16Y,ATV78C20Y,ATV78C25Y,ATV78C31Y,ATV78C35Y,ATV78C45Y,ATV78C50Y,ATV78C56Y,ATV78C63Y,ATV78C71Y,ATV78C80Y,ATV78C90Y,ATV78M10Y,ATV78M13Y,ATV78pU22Y,ATV78pU30Y,ATV78pU40Y,ATV78pU55Y,ATV78pU75Y,ATV78pD11Y,ATV78pD15Y,ATV78pD18Y,ATV78pD22Y,ATV78pD30Y,ATV78pD37Y,ATV78pD45Y,ATV78pD55Y,ATV78pD75Y,ATV78pD90Y,ATV78pC11Y,ATV78pC13Y,ATV78pC16Y,ATV78C20Y,ATV78C25Y,ATV78C31Y,ATV78C35Y,ATV78C45Y,ATV78C50Y,ATV78C56Y,ATV78C63Y,ATV78C71Y,ATV78C80Y,ATV78C90Y,ATV78M10Y,ATV78M13Y;

芯片级维修安川变频器:

VS-616F7,VS-606V7,VS-606J7系列:CIMR-F7A40P41A,CIMR-F7A40P71A,CIMR-F7A41P51A,CIMR-F7A42P21A,CIMR-F7A43P71A,CIMR-F7A45P51A,CIMR-F7A47P51A(KD),CIMR-F7A40111A(KD),CIMR-F7A40151A(KD),CIMR-F7A40180A(KD),CIMR-F7A40220A(KD),CIMR-F7A40300A(KD),CIMR-F7A40370A(KD),CIMR-F7A40450A(KD),CIMR-F7A40550A(KD),CIMR-F7A40750A(KD),CIMR-F7A40900A(KD),CIMR-F7A41100A(KD),CIMR-F7A41320A(KD),CIMR-F7A41600A(KD),CIMR-F7A41850A,CIMR-F7A42200A,CIMR-F7A43000A,CIMR-F7A20P41A,CIMR-F7A20P71A,CIMR-F7A21P51A,CIMR-F7A22P21A,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

CIMR-F7A23P71A,CIMR-F7A25P51A,CIMR-F7A27P51A,CIMR-F7A20111A,CIMR-F7A20151A,CIMR-F7A20181A,CIMR-F7A20220A,CIMR-F7A20300A,CIMR-F7A20370A,CIMR-F7A20450A,CIMR-F7A20550A,CIMR-F7A20750A,CIMR-F7A20900A,CIMR-F7A2110A,VS-616F7A20P41A3,VS-606V7ATB0P102,

VS-606J7AAB0P101,VS-616F7A20P71A3,VS-606V7ATB0P202,VS-606J7AAB0P201,VS-616F7A21P51A4,VS-606V7ATB0P402,VS-606J7AAB0P401,VS-616F7A22P21A4,VS-606V7ATB0P702,VS-606J7AAB0P701,VS-616F7A23P71A4,VS-606V7ATB1P502,VS-606J7AAB1P502,VS-616F7A25P51A6,VS-606V7ATB2P203,VS-606J7AA20P101,VS-616F7A27P51A7,VS-606V7ATB3P705,VS-606J7AA20P201,VS-616F7A20111A10,VS-606V7AT20P102,VS-606J7AA20P401,VS-616F7A20151A13,VS-606V7AT20P202,VS-606J7AA20P702,VS-616F7A20181A18,VS-606V7AT20P402,VS-606J7AA21P502,VS-616F7A20220A21,VS-606V7AT20P702,VS-606J7AA22P203,VS-616F7A20300A22,VS-606V7AT21P503,VS-606J7AA23P704,VS-616F7A20370A29,VS-606V7AT22P204,VS-606J7AA40P202,VS-616F7A20450A30,VS-606V7AT23P705,VS-606J7AA40P402,VS-616F7A20550A39,VS-606V7AT25P517,VS-606J7AA40P702,VS-616F7A20750A74,VS-606V7AT27P517,VS-606J7AA41P502,VS-616F7A20900A98,VS-606V7AT40P202,VS-606J7AA42P203,VS-616F7A21100A106,VS-606V7AT40P402,VS-606J7AA43P003,VS-616F7A40P41A4,VS-606V7AT40P702,VS-606J7AA43P704,VS-616F7A40P71A4,VS-606V7AT41P503,VS-616F7A41P51A5,VS-606V7AT42P204,VS-616F7A42P21A5,VS-606V7AT43P005,VS-616F7A43P71A6,VS-606V7AT43P705,VS-616F7A45P51A7,VS-606V7AT45P517,VS-616F7A47P51A[KD]7,VS-606V7AT47P517,VS-616F7A40111A[KD]9,VS-616F7A40151A[KD]12,VS-616F7A40180A[KD]15,VS-616F7A40220A[KD]18,3VS-616F7A40300A[KD]22,VS-616F7A40370A[KD]24,VS-616F7A40450A[KD]30,VS-616F7A40550A[KD]34,VS-616F7A40750A[KD]48,VS-616F7A40900A[KD]70,VS-616F7A41100A[KD]80,VS-616F7A41320A[KD]92,VS-616F7A41600A[KD]103,VS-616F7A41850A129,3VS-616F7A4220A149,VS-616F7A43000A203;

VS-616-G5,VS-616-G7:VS-616G5A20P41F4,VS-616G7A20P41C3,VS-616G5A20P71F5,VS-616G7A20P71C4,VS-616G5A21P51F5,VS-616G7A21P51C5,VS-616G5A22P21F6,VS-616G7A22P21C5,VS-616G5A23P71F7,VS-616G7A23P71C5,VS-616G5A25P51F9,VS-616G7A25P51C7,VS-616G5A27P51F10,

VS-616G7A27P51C8,VS-616G5A20111F14,VS-616G7A20111C12,VS-616G5A20151F17,VS-616G7A20151C15,VS-616G5A20180F24,VS-616G7A20180C22,VS-616G5A20220F26,VS-616G7A20220C24,VS-616G5A20300F35,VS-616G7A20300C26,VS-616G5A20370F45,VS-616G7A20370C34,VS-616G5A20450F52,VS-616G7A20450C36,VS-616G5A20550F61,VS-616G7A20550A46,VS-616G5A20750F99,VS-616G7A20750A88,VS-616G5A20900F139,VS-616G7A20900C124,VS-616G5A21100F148,VS-616G7A21100C134,VS-616G5A40P41F4,VS-616G7A40P41C5,VS-616G5A40P71F5,VS-616G7A40P71C5,VS-616G5A41P51F6,VS-616G7A41P51C6,VS-616G5A42P21F6,VS-616G7A42P21C6,VS-616G5A43P71F7,VS-616G7A43P71C8,VS-616G5A45P51F9,VS-616G7A45P51C9,VS-616G5A47P51F(KD)9,VS-616G7A47P51C10,VS-616G5A40111F(KD)13,VS-616G7A40111C13,VS-616G5A40151F(KD)16,VS-616G7A40151C16,VS-616G5A40180F(KD)19,VS-616G7A40180C23,VS-616G5A40220F(KD)21,VS-616G7A40220C25,VS-616G5A40300F(KD)26,VS-616G7A40300C33,VS-616G5A40370F(KD)33,VS-616G7A40370C40,VS-616G5A40450F(KD)40,VS-616G7A40450C47,VS-616G5A40550F(KD)51,VS-616G7A40550A55,VS-616G5A40750F(KD)67,VS-616G7A40750A72,VS-616G5A40900F80,VS-616G7A40900C92,VS-616G5A41100F(KD)91,VS-616G7A41100C95,VS-616G5A41320F102,VS-616G7A41320A124,VS-616G5A41600F115,VS-616G7A41600A146,VS-616G5A41850F141,VS-616G7A41850A181,VS-616G5A42200F165,VS-616G7A42200A212,VS-616G5A43000F226,VS-616G7A43000A289;

Varispeed E7:CIMR-E7B20P4,CIMR-E7B20P7,CIMR-E7B21P5,CIMR-E7B22P2,CIMR-E7B23P7,CIMR-E7B25P5,CIMR-E7B27P5,CIMR-E7B2011,CIMR-E7B2015,CIMR-E7B2018,CIMR-E7B2022,CIMR-E7B2030,CIMR-E7B2037,CIMR-E7B2045,CIMR-E7B2055,CIMR-E7B2075,CIMR-E7B2090,CIMR-E7B2110,CIMR-E7B40P4,CIMR-E7B40P7,CIMR-E7B41P5,CIMR-E7B42P2,CIMR-E7B43P7,CIMR-E7B44P0,CIMR-E7B45P5,CIMR-E7B47P5,CIMR-E7B4011,CIMR-E7B4015,CIMR-E7B4018,CIMR-E7B4022,CIMR-E7B4030,CIMR-E7B4037,CIMR-E7B4045,CIMR-E7B4055,CIMR-E7B4075,CIMR-E7B4090,CIMR-E7B4110,CIMR-E7B4132,CIMR-E7B4160,CIMR-E7B4185,CIMR-E7B4220,CIMR-E7B4300;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

电梯专用变频器**Varispeed**:L7CIMR-L7A23P7,CIMR-L7A25P5,CIMR-L7A27P5,CIMR-L7A2011,
CIMR-L7A2015,CIMR-L7A2018,CIMR-L7A2022,CIMR-L7A2030,CIMR-L7A20372CIMR-L7A20452CIMR-L7A20552CIMR-L7A43P7,
CIMR-L7A44P0,CIMR-L7A45P5,CIMR-L7A47P5,CIMR-L7A4011,CIMR-L7A4015,CIMR-L7A4018,CIMR-L7A4022,CIMR-L7A4030,CIMR-L7A4037,
CIMR-L7A4045,CIMR-L7A4055,CIMR-L7B23P7,CIMR-L7B25P5,CIMR-L7B27P5,CIMR-L7B2011,CIMR-L7B2015,CIMR-L7B2018,
CIMR-L7B2022,CIMR-L7B20302CIMR-L7B20372CIMR-L7A20452CIMR-L7B20552CIMR-L7B43P7,CIMR-L7B44P0,CIMR-L7B45P5,
CIMR-L7B47P5,CIMR-L7B4011,CIMR-L7B4015,CIMR-L7B4018,CIMR-L7B4022,CIMR-L7A4030,CIMR-L7B4037,CIMR-L7B4045,
CIMR-L7B4055,CIMR-L7C23P7,CIMR-L7C25P5,
CIMR-L7C27P5,CIMR-L7C2011,CIMR-L7C2015,CIMR-L7C2018,CIMR-L7C2022,CIMR-L7C20302CIMR-L7C20372CIMR-L7A2045,
CIMR-L7C20552CIMR-L7C43P7,CIMR-L7C44P0,CIMR-L7C45P5,CIMR-L7C47P5,CIMR-L7C4011,CIMR-L7C4015,CIMR-L7C4018,
CIMR-L7C4022,CIMR-L7A4030,CIMR-L7C4037,CIMR-L7C4045,CIMR-L7C4055,CIMR-L7E23P7,CIMR-L7E25P5,CIMR-L7E27P5,CIMR-L7E2011,
CIMR-L7E2015,CIMR-L7E2018,CIMR-L7E2022,CIMR-L7E20302CIMR-L7E20372CIMR-L7A2045,CIMR-L7E20552CIMR-L7E43P7,
CIMR-L7E44P0,CIMR-L7E45P5,CIMR-L7E47P5,CIMR-L7E4011,CIMR-L7E4015,CIMR-L7E4018,CIMR-L7E4022,CIMR-L7A4030,
CIMR-L7E4037,CIMR-L7E4045,CIMR-L7E4055;

VFD-F变频器: VFD007F23A,VFD007F43A,VFD015F23A,VFD015F43A,VFD022F23A,VFD022F43A,VFD037F23A,VFD037F43A,VFD055F23A,
VFD055F43A,VFD075F23A,VFD075F43A,VFD110F23A,VFD110F43A,VFD150F23A,VFD150F43A,VFD185F23A,VFD185F43A,
VFD220F23A,VFD220F43A,VFD300F23A,VFD300F43A,VFD370F23A,VFD370F43A,FD450F43A,FD550F43A,FD750F43A,
FD900F43A,FD1100F43A,FD1320F43A,FD1600F43A,FD1850F43A,FD2200F43A,FD900F43C,FD1100F43C;

VFD-G变频器: VFD-055F43A-G,VFD-075F43A-G,VFD-110F43A-G,VFD-150F43A-G,VFD-185F43A-G,
VFD-220F43A-G,VFD-300F43A-G,VFD-370F43A-G,VFD-450F43A-G,VFD-550F43A-G,VFD-750F43A-G;

VFD-G变频器: VFD007V23A-2,VFD007V43A-2,VFD015V23A-2,VFD015V43A-2,VFD022V23A-2,VFD022V43A-2,VFD037V23A-2,VFD037V43A-2,
VFD055V23A-2,VFD055V43A-2,VFD075V23A-2,VFD075V43A-2,VFD110V23A-2,VFD110V43A-2,VFD150V23A-2,VFD150V43A-2,
VFD185V23A-2,VFD185V43A-2,VFD220V23A-2,VFD220V43A-2,VFD300V23A-2,VFD300V43A-2,VFD370V23A-2,VFD370V43A-2,
VFD450V43A-2,VFD550V43C-2,VFD750V43C-2;

芯片级维修东元变频器:

GA7200系列:JNTGBGBA0001AZ,JNTGBGBA0002AZ,JNTGBGBA0003AZ,JNTGBGBA0005AZ,JNTGBGBA7R50AZ,JNTGBGBA0010AZ,
JNTGBGBA0015AZ,JNTGBGBA0020AZ,JNTGBGBA0025AZ,JNTGBGBA0030AZ,JNTGBGBA0040AZ,JNTGBGBA0050AZ,JNTGBGBA0060AZ,
JNTGBGBA0075AZ,JNTGBGBA0100AZ,JNTGBGBA0125AZ,JNTGBGBA0150AZ,JNTGBGBA0175AZ,JNTGBGBA0215AZ,JNTGBGBA0250AZ,
JNTGBGBA0300AZ,JNTGBGBA0400AZ,JNTGBGBB0001AZ,JNTGBGBB0002AZ,JNTGBGBB0003AZ,JNTGBGBB0005AZ,
JNTGBGBB7R50AZ,JNTGBGBB0010AZ,JNTGBGBB0015AZ,JNTGBGBB0020AZ,JNTGBGBB0025AZ,JNTGBGBB0030AZ,
JNTGBGBB0040AZ,JNTGBGBB0050AZ,JNTGBGBB0060AZ,JNTGBGBB0075AZ,JNTGBGBB0100AZ,JNTGBGBB0125AZ,
JNTGBGBB0150AZ,JNTGBGBB0175AZ,JNTGBGBB0215AZ,JNTGBGBB0250AZ,JNTGBGBB0300AZ,JNTGBGBB0400AZ,
JNTGBGBA0001JK,JNTGBGBA0002JK,JNTGBGBA0003JK,JNTGBGBA0005JK,JNTGBGBA7R50JK,JNTGBGBA0010JK,JNTGBGBA0015JK,
JNTGBGBA0020JK,JNTGBGBA0025JK,JNTGBGBA0030JK,JNTGBGBA0040JK,JNTGBGBA0050JK,JNTGBGBA0060JK,
JNTGBGBA0075JK,JNTGBGBA0100JK,JNTGBGBB0001JK,JNTGBGBB0002JK,JNTGBGBB0003JK,JNTGBGBB0005JK,JNTGBGBB7R50JK,
JNTGBGBB0010JK,JNTGBGBB0015JK,JNTGBGBB0020JK,JNTGBGBB0025JK,JNTGBGBB0030JK,JNTGBGBB0040JK,
JNTGBGBB0050JK,JNTGBGBB0060JK,JNTGBGBB0075JK,JNTGBGBB0100JK;

MA7200系列:MA7200-2001-N1,MA7200-2002-N1,MA7200-2003-N1,MA7200-2005-N1,MA7200-2007-N1,MA7200-2010-N1,MA7200-2015-N1,
MA7200-2020-N1,MA7200-2025-N1,MA7200-2030-N1,MA7200-2040-N1,MA7200-4001-N1,MA7200-4002-N1,MA7200-4003-N1,
MA7200-4005-N1,MA7200-4007-N1,MA7200-4010-N1,MA7200-4015-N1,MA7200-4020-N1,MA7200-4025-N1,MA7200-4030-N1,
MA7200-4040-N1,MA7200-4050-N1,MA7200-4060-N1,MA7200-4075-N1;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

PA7300系列:PA7300-2005-N1,PA7300-2010-N1,PA7300-2015-N1,PA7300-2020-N1,PA7300-2025-N1,PA7300-2030-N1,PA7300-2040-N1,PA7300-2050-N1,PA7300-2075-N1,PA7300-2100-N1,PA7300-2125-N1,PA7300-4005-N1,PA7300-4010-N1,PA7300-4015-N1,PA7300-4020-N1,PA7300-4025-N1,PA7300-4030-N1,PA7300-4040-N1,PA7300-4050-N1,PA7300-4075-N1,PA7300-4100-N1,PA7300-4125-N1,PA7300-4150-N1,PA7300-4175-N1,PA7300-4215-N1,PA7300-4250-N1,PA7300-4025-N1,PA7300-4300-N1,PA7300-4350-N1,PA7300-4400-N1,PA7300-4500-N1,PA7300-5005-N1,PA7300-5010-N1,PA7300-5015-N1,PA7300-5020-N1,PA7300-5025-N1,PA7300-5030-N1,PA7300-5040-N1,PA7300-5050-N1,PA7300-5075-N1,PA7300-5100-N1

7200GS系列:JNTEBGBA0025JK,JNTEBGBA0030JK,JNTEBGBA0040JK,JNTEBGBA0050JK,JNTEBGBA0060JK,JNTEBGBA0075JK,JNTEBGBA0100JK,JNTEBGBA0025AZ,JNTEBGBA0030AZ,JNTEBGBA0040AZ,JNTEBGBA0050AZ,JNTEBGBA0060AZ,JNTEBGBA0075AZ,JNTEBGBA0100AZ,JNTEBGBA0125AZ,JNTEBGBA0150AZ,JNTEBGBA0200AZ,JNTEBGBA0250AZ,JNTEBGBA0300AZ,JNTEBGBA0350AZ,JNTEBGBA0400AZ,JNTEBGBA0400AZ;JNTEBGBB0025JK,JNTEBGBB0030JK,JNTEBGBB0040JK,JNTEBGBB0050JK,JNTEBGBB0060JK,JNTEBGBB0075JK,JNTEBGBB0100JK,JNTEBGBB0025AZ,JNTEBGBB0030AZ,JNTEBGBB0040AZ,JNTEBGBB0050AZ,JNTEBGBB0060AZ,JNTEBGBB0075AZ,JNTEBGBB0100AZ,JNTEBGBB0125AZ,JNTEBGBB0150AZ,JNTEBGBB0200AZ,JNTEBGBB0250AZ,JNTEBGBB0300AZ,JNTEBGBB0350AZ,JNTEBGBB0400AZ,JNTEBGBB0400AZ;

FM100系列:FM100-2P5-N1,FM100-201-N1,FM100-202-N1,FM100-203-N1,FM100-205-N1,FM100-207-N1,FM100-210-N1,FM100-215-N1,FM100-220-N1,FM100-230-N1,FM100-401-N1,FM100-402-N1,FM100-403-N1,FM100-405-N1,FM100-407-N1,FM100-410-N1,FM100-415-N1,FM100-420-N1,FM100-430-N1;

FM50系列:FM50-2P2,FM50-2P5,FM50-201,FM50-202,FM50-203,FM50-401,FM50-402,FM50-403,FM50-202,FM50-203,FM50-401,FM50-402,FM50-403;

E2系列:E2-2P2-M1F,E2-2P2-H1F,E2-2P5-M1F,E2-2P5-H1F,E2-201-M1F,E2-201-H1F,E2-202H1F,E2-203H1F,E2-401-H3F,E2-401-H3F,E2-401-H3F;

EV_Micro_Drive:JNEV-1P2-H1,JNEV-1P5-H1,JNEV-101-H1,JNEV-2P2-H1,JNEV-2P5-H1,JNEV-201-H1,JNEV-202-H1,JNNEV-2P5-H3,JNEV-201-H,3JNEV-202-H,3JNEV-203-H,3EV-203-H1,JNEV-401-H3,JNEV-402-H3,JNEV-403-H3;

V2系列:V2-202-M,V2-203-M,V2-401-M3,V2-402-M3,V2-403-M3,V2-405-M3,V2-408-M3,V2-410-M3,V2-415-M3,V2-420-M3,V2-425-M3,V2-430-M3;

N2系列:N2-2P5,N2-201,N2-202,N2-203,N2-205,N2-208,N2-210,N2-215,N2-220,N2-230,N2-401,N2-402,N2-403,N2-405,N2-408,N2-410,N2-415,N2-420,N2-430;

N3系列:N3-2P5-CS,N3-201-CS,N3-202-CS,N3-203-CS,N3-2P5-C,N3-201-C,N3-202-C,N3-203-C,N3-205-C,N3-207-C,N3-210-C,N3-215-N1,N3-220-N1,N3-225-N1,N3-401-C,N3-402-C,N3-403-C,N3-405-C,N3-407-C,N3-410-C,N3-415-C,N3-420-N1,N3-425-N1,N3-430-N1;

ZY系列中压变频器:ZY1250-55,ZY1250-75,ZY1250-110,ZY1250-132,ZY1250-160,ZY1250-200,ZY1250-220,ZY1250-280,ZY1250-315,ZY1250-400,ZY1250-630,ZY1750-55,ZY1750-75,ZY1750-110,ZY1750-132,ZY1750-160,ZY1750-200,ZY1750-220,ZY1750-280,ZY1750-315,ZY1750-400,ZY1750-630,ZY2250-55,ZY2250-75,ZY2250-110,ZY2250-132,ZY2250-160,ZY2250-200,ZY2250-220,ZY2250-280,ZY2250-315,ZY2250-400,ZY2250-630;

芯片级维修东芝变频器:

E3系列:VT130E3U2035,VT130E3U2055,VT130E3U2080,VT130E3U2110,VT130E3U2160,VT130E3U2220,VT130E3U2270,VT130E3U2330,VT130E3U2400,VT130E3U2500,VT130E3U2600,VT130E3U4055,VT130E3U4080,VT130E3U4110,VT130E3U4160,VT130E3U4220,VT130E3U4270,VT130E3U4330,VT130E3U4400,VT130E3U4500,VT130E3U4600,VT130E3U4750,VT130E3U410K,VT130E3U412K,VT130E3U6060,VT130E3U6120,VT130E3U6160,VT130E3U6220,VT130E3U6270,VT130E3U6330,VT130E3U6400,VT130E3U6500,VT130E3U6600,VT130E3U6750,VT130E3U610K,VT130E3U612K;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

G3系列变频器:VT130G3U2010,VT130G3U2015,VT130G3U2025,VT130G3U2035,VT130G3U2055,VT130G3U2080,VT130G3U2110,VT130G3U2160,VT130G3U2220,VT130G3U2270,VT130G3U4015,VT130G3U4025,VT130G3U4035,VT130G3U4055,VT130G3U4080,VT130G3U4110,VT130G3U4160,VT130G3U4220,VT130G3U4270,VT130G3U4330,VT130G3U4400,VT130G3U4500,VT130G3U2330,VT130G3U4600,VT130G3U4750,VT130G3U410K,VT130G3U412K,VT130G3U415K,VT130G3U420K,VT130G3U425K,VT130G3U6060,VT130G3U6120,VT130G3U6160,VT130G3U6220,VT130G3U6270,VT130G3U6330,VT130G3U6400,VT130G3U6500,VT130G3U6600,VT130G3U6750,VT130G3U610K,VT130G3U612K,VT130G3U615K,VT130G3U620K,VT130G3U625K,VT130G3U430K,VT130G3U43K,VT130G3U4015N4,VT130G3U4025N4,VT130G3U4035N4,VT130G3U4055N4,VT130G3U4080N4,VT130G3U4110N4,VT130G3U2010N4,VT130G3U2015N4,VT130G3U2025N4,VT130G3U2035N4,VT130G3U2055N4,VT130G3U2080N4;

H3系列变频器:VT130H3U2035,VT130H3U2055,VT130H3U2080,VT130H3U2110,VT130H3U2160,VT130H3U2220,VT130H3U2270,VT130H3U2330,VT130H3U4055,VT130H3U4080,VT130H3U4110,VT130H3U4160,VT130H3U4220,VT130H3U4270,VT130H3U4330,VT130H3U4400,VT130H3U4500,VT130H3U4600,VT130H3U4750,VT130H3U410K,VT130H3U412K,VT130H3U415K,VT130H3U420K,VT130H3U425K,VT130H3U430K;

G7系列变频器:VT130G7U2010,VT130G7U2015,VT130G7U2025,VT130G7U2035,VT130G7U2055,VT130G7U2080,VT130G7U2110,VT130G7U2160,VT130G7U2220,VT130G7U2270,VT130G7U2330,VT130G7U4015,VT130G7U4025,VT130G7U4035,VT130G7U4055,VT130G7U4080,VT130G7U4110,VT130G7U4160,VT130G7U4220,VT130G7U4270,VT130G7U4330,VT130G7U4400,VT130G7U4500,VT130G7U4600,VT130G7U4750,VT130G7U410K,VT130G7U412K,VT130G7U415K,VT130G7U420K,VT130G7U425K,VT130G7U430K,VT130G7U6015,VT130G7U6025,VT130G7U6035,VT130G7U6060,VT130G7U6080,VT130G7U6110,VT130G7U6160,VT130G7U6220,VT130G7U6270,VT130G7U6330,VT130G7U6400,VT130G7U6500,VT130G7U6600,VT130G7U6750,VT130G7U610K,VT130G7U612K,VT130G7U615K,VT130G7U620K,VT130G7U625K,VT130G7U630K;

TOSVERTVF-S9:VFS9S-2002PL,VFS9S-2004PL,VFS9S-2007PL,VFS9S-2015PL,VFS9S-2022PL,VFS9-2002PM,VFS9-2004PM,VFS9-2007PM,VFS9-2015PM,VFS9-2022PM,VFS9-2037PM,VFS9-2055PL,VFS9-2075PL,VFS9-2110PM,VFS9-2150PM,VFS9-4007PL,VFS9-4015PL,VFS9-4022PL,VFS9-4037PL,VFS9-4055PL,VFS9-4075PL,VFS9-4110PL,VFS9-4150PL;

VF-S7S列变频器:VFS7S-2002P,VFS7S-2004P,VFS7S-2007P,VFS7S-2015P,VFS7S-2022P;

VF-A5/A5P系列变频器:VFA5-4300P,VFA5-4007P,VFA5-4015P,VFA5-4022P,VFA5-4037P,VFA5-4055P,VFA5-4075P,VFA5-4110P,VFA5-4150P,VFA5-4185P,VFA5-4220P,VFA5-4370P,VFA5-4450P,VFA5-4550P,VFA5-4750P,VFA5-4110KP,VFA5-4110KP,VFA5-4132KP,VFA5-4160KP,VFA5-4220KP,VFA5-4220KP,VFA5-4280KP,VFA5P-4185P,VFA5P-4220P,VFA5P-4300P,VFA5P-4370P,VFA5P-4450P,VFA5P-4550P,VFA5P-4750P,VFA5P-4900P,VFA5P-4110KP,VFA5P-4132KP,VFA5P-4160KP,VFA5P-4200KP,VFA5P-4220KP,VFA5P-4280KP,VFA5P-4315KP;

VF-S7系列变频器:4007P,4015P,4022P,4037P,4055P,4075P,4110P,4150P,2004P,2007P,2015P,2022P,2037P,2055P,2075P,110P,2150P;

芯片级维修富士变频器:

FRENIC5000 G11S/P11S:FRN02G11S-2JE,FRN04G11S-2JE,FRN075G11S-2JE,FRN15G11S-2JE,FRN22G11S-2JE,FRN37G11S-2JE,FRN55P11S-2JE,FRN55G11S-2JE,FRN75P11S-2JE,FRN75G11S-2JE,FRN11P11S-2JE,FRN11G11S-2JE,FRN15P11S-2JE,FRN15G11S-2JE,FRN185P11S-2JE,FRN185G11S-2JE,FRN22P11S-2JE,FRN22G11S-2JE,FRN30P11S-2JE,FRN30G11S-2JE,FRN37P11S-2JE,FRN37G11S-2JE,FRN45P11S-2JE,FRN45G11S-2JE,FRN55P11S-2JE,FRN55G11S-2JE,FRN75P11S-2JE,FRN75G11S-2JE,FRN90P11S-2JE,FRN90G11S-2JE,FRN110P11S-2JE,FRN04G11S-4JE,FRN075G11S-4JE,FRN15G11S-4JE,FRN22G11S-4JE,FRN37G11S-4JE,FRN55P11S-4JE,FRN55G11S-4JE,FRN75P11S-4JE,FRN75G11S-4JE,FRN11P11S-4JE,FRN11G11S-4JE,FRN15P11S-4JE,FRN15G11S-4JE,FRN185P11S-4JE,FRN185G11S-4JE,FRN22P11S-4JE,FRN22G11S-4JE,FRN30P11S-4JE,FRN30G11S-4JE,FRN37P11S-4JE,FRN37G11S-4JE,FRN45P11S-4JE,FRN45G11S-4JE,FRN55P11S-4JE,FRN55G11S-4JE,FRN75P11S-4JE,FRN75G11S-4JE,FRN90P11S-4JE,FRN90G11S-4JE,FRN110P11S-4JE,FRN110G11S-4JE,FRN132P11S-4JE,FRN132

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

G11S-4JE,FRN160P11S-4JE,FRN160G11S-4JE,FRN200P11S-4JE,FRN200G11S-4JE,FRN220P11S-4JE,FRN220G11S-4JE,FRN280P11S-4JE,FRN280G11S-4JE,FRN315P11S-4JE,FRN315G11S-4JE,FRN355P11S-4JE,FRN355G11S-4JE,FRN400P11S-4JE,FRN400G11S-4JE,FRN450P11S-4JE,FRN500P11S-4JE;FRN30G11UD-2C3,FRN37G11UD-2C3,FRN45G11UD-2C3,FRN55G11UD-2C3,

FRENIC5000G11UD II:FRN37G11UD-4C3,FRN55G11UD-4C3,FRN75G11UD-4C3,FRN11G11UD-4C3,FRN15G11UD-4C3,FRN30G185UD-4C3,FRN30G22UD-4C3,FRN30G11UD-4C3,FRN37G11UD-4C3,FRN45G11UD-4C3,FRN55G11UD-4C3;

FVR-E11S列变频器:FVR01E11S-7JE,FVR02E11S-7JE,FVR075E11S-7JE,FVR15E11S-7JE,FVR21E11S-7JE,FVR04E11S-4JE,FVR0751S-4JE,FVR15E11S-4JE,FVR22E11S-4JE,FVR37E11S-4JE,FVR55E11S-4JE,FVR75E11S-4JE,FVR01E11S-2JE,FVR02E11S-2JE,FVR04E11S-2JE,FVR15E11S-2JE,FVR22E11S-2JE,FVR37E11S-2JE,FVR55E11S-2JE,FVR75E11S-2JE,FVR075E11S-2JE;

FRN-MINI型变频器:FRN01C1S-7C,FRN02C1S-7C,FRN04C1S-7C,FRN15C1S-7C,FRN22C1S-7C,FRN075C1S-7C,FRN04C1S-4C,FRN15C1S-4C,FRN22C1S-4C,FRN37C1S-4C,FRN075C1S-4C;

FRN5000V G7S系列变频器:FRN075VG7S-2,FRN15VG7S-2,FRN22VG7S-2,FRN37VG7S-2,FRN55VG7S-2,FRN75VG7S-2,FRN11VG7S-2,FRN15VG7S-2,FRN185VG7S-2,FRN22VG7S-2,FRN30VG7S-2,FRN37VG7S-2,FRN45VG7S-2,FRN55VG7S-2,FRN75VG7S-2,FRN90VG7S-2;FRN37VG7S-2,FRN55VG7S-4,FRN75VG7S-4,FRN11VG7S-4,FRN15VG7S-4,FRN185VG7S-4,FRN22VG7S-4,FRN30VG7S-4,FRN37VG7S-4,FRN45VG7S-4,FRN55VG7S-4,FRN75VG7S-4,FRN90VG7S-4;FRN110VG7S-4,FRN132VG7S-4,FRN160VG7S-4,FRN200VG7S-4,FRN220VG7S-4,FRN280VG7S-4,FRN315VG7S-4,FRN355VG7S-4,FRN400VG7S-4;

FRENIC5000G11S or FRENIC5000P11S:FRN0.2G11S-2JE,FRN0.4G11S-2JE,FRN0.75G11S-2JE,FRN1.5G11S-2JE,FRN2.2G11S-2JE,FRN3.7G11S-2JE,FRN5.5P11S-2JE,FRN5.5G11S-2JE,FRN7.5P11S-2JE,FRN7.5G11S-2JE,FRN11P11S-2JE,FRN11G11S-2JE,FRN15P11S-2JE,FRN15G11S-2JE,

FRN18.5P11S-2JE,FRN18.5G11S-2JE,FRN22P11S-2JE,FRN22G11S-2JE,FRN30P11S-2JE,FRN30G11S-2JE,FRN37P11S-2JE,FRN37G11S-2JE,FRN45P11S-2JE,FRN45G11S-2JE,FRN55P11S-2JE,FRN55G11S-2JE,FRN75P11S-2JE,FRN75G11S-2JE,FRN90P11S-2JE,FRN90G11S-2JE,FRN110P11S-2JE,FRN0.4G11S-4JE,FRN0.75G11S-4JE,FRN1.5G11S-4JE,FRN2.2G11S-4JE,FRN3.7G11S-4JE,FRN5.5P11S-4JE,FRN5.5G11S-4JE,FRN7.5P11S-4JE,FRN7.5G11S-4JE,FRN11P11S-4JE,FRN11G11S-4JE,FRN15P11S-4JE,FRN15G11S-4JE,FRN18.5P11S-4JE,FRN18.5G11S-4JE,FRN22P11S-4JE,FRN22G11S-4JE,FRN30P11S-4JE,FRN30G11S-4JE,FRN37P11S-4JE,FRN37G11S-4JE,FRN45P11S-4JE,FRN45G11S-4JE,FRN55P11S-4JE,FRN55G11S-4JE,FRN75P11S-4JE,FRN75G11S-4JE,FRN90P11S-4JE,FRN90G11S-4JE,FRN110P11S-4JE,FRN110G11S-4JE,FRN132P11S-4JE,FRN132G11S-4JE,FRN160P11S-4JE,FRN160G11S-4JE,FRN200P11S-4JE,FRN200G11S-4JE,FRN220P11S-4JE,FRN220G11S-4JE,FRN280P11S-4JE,FRN280G11S-4JE,FRN315P11S-4JE,FRN315G11S-4JE,FRN355P11S-4JE,FRN355G11S-4JE,FRN400P11S-4JE,FRN400G11S-4JE,FRN450P11S-4JE,FRN500P11S-4JE,FRN0.2G11S-2JE,FRN0.4G11S-2JE,FRN0.75G11S-2JE,FRN1.5G11S-2JE,FRN2.2G11S-2JE,FRN3.7G11S-2JE,FRN5.5G11S-2JE,FRN5.5P11S-2JE,FRN7.5G11S-2JE,FRN7.5P11S-2JE,FRN11P11S-2JE,FRN11G11S-2JE,FRN15P11S-2JE,FRN15G11S-2JE,FRN18.5P11S-2JE,FRN18.5G11S-2JE,FRN22P11S-2JE,FRN22G11S-2JE,FRN30P11S-2JE,FRN30G11S-2JE,FRN37G11S-2JE,FRN37P11S-2JE,FRN45G11S-2JE,FRN45P11S-2JE,FRN55G11S-2JE,FRN55P11S-2JE,FRN75P11S-2JE,FRN75G11S-2JE,FRN90G11S-2JE,FRN90P11S-2JE,FRN110P11S-2JE,FRN0.4G11S-4JE,FRN0.75G11S-4JE,FRN1.5G11S-4JE,FRN2.2G11S-4JE,FRN3.7G11S-4JE,FRN5.5G11S-4JE,FRN5.5P11S-4JE,FRN7.5P11S-4JE,FRN7.5G11S-4JE,FRN11P11S-4JE,FRN11G11S-4JE,FRN15P11S-4JE,FRN15G11S-4JE,FRN18.5P11S-4JE,FRN18.5G11S-4JE,FRN22P11S-4JE,FRN22G11S-4JE,FRN30G11S-4JE,FRN30P11S-4JE,FRN37G11S-4JE,FRN37P11S-4JE,FRN45G11S-4JE,FRN45P11S-4JE,FRN55G11S-4JE,FRN55P11S-4JE,FRN75P11S-4JE,FRN75G11S-4JE,FRN90G11S-4JE,FRN90P11S-4JE,FRN110G11S-4JE,FRN110P11S-4JE,FRN132P11S-4JE,FRN132G11S-4JE,FRN160G11S-4JE,FRN160P11S-4JE,FRN200P11S-4JE,FRN200G11S-4JE,FRN220

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

G11S-4JE,FRN220P11S-4JE,FRN280G11S-4JE,FRN280P11S-4JE,FRN315G11S-4JE,FRN315/P11S-4JE,FRN355G11S-4JE,FRN355P11S-4JE,FRN400G11S-4JE,FRN400P11S-4JE,FRN450P11S-4JE,FRN500P11S-4JE;

FVR-E11S:S-7JEFVR0.2E11S-7JEFVR0.4E11S-7JEFVR0.75E11S-7JEFVR1.5E11S-7JE,FVR2.5E11S-7JE,FVR0.4E11S-4JE,FVR0.75E11S-4JE,FVR2.2E11S-4JE,FVR3.7E11S-4JE,FVR5.5E11S-4JE,FVR7.5E11S-4JE,FVR0.1E11S-2JE,FVR0.2E11S-2JE,FVR0.4E11S-2JE,FVR0.75E11S-2JE,FVR1.5E11S-2JE,FVR2.2E11S-2JE,FVR3.7E11S-2JE,FVR5.5E11S-2JE,FVR7.5E11S-2JE,FVR1.5E11S-4JE;

FRENIC5000MS5:FRN7.5PD5-2, FRN11PD5-2,FRN15PD5-2,FRN18.5PD5-2; FRN7.5PD5-4, FRN11PD5-4,FRN15PD5-4,FRN18.5PD5-4;FRN1.1M5-2,FRN2.2M5-2, FRN3.7M5-2, FRN5.5M5-2, FRN2.2V5-2, FRN3.7V5-2, FRN5.5V5-2,FRN7.5MC5-4, FRN11MC5-4, FRN15MC5-4, FRN18.5MC5-4;

FRENIC5000VG7S:FRN0.75VG7S-2,FRN1.5VG7S-2,FRN2.2VG7S-2,FRN3.7VG7S-2,FRN5.5VG7S-2,FRN7.5VG7S-2,FRN11VG7S-2,FRN15VG7S-2,FRN18.5VG7S-2,FRN22VG7S-2,FRN37VG7S-2,FRN30VG7S-2,FRN45VG7S-2,FRN55VG7S-2,FRN75VG7S-2,FRN90VG7S-2,FRN3.7VG7S-4,FRN5.5VG7S-4,FRN7.5VG7S-4,FRN11VG7S-4,FRN15VG7S-4,FRN18.5VG7S-4,FRN22VG7S-4,FRN37VG7S-4,FRN30VG7S-4,FRN45VG7S-4,FRN55VG7S-4,FRN75VG7S-4,FRN90VG7S-4,FRN110VG7S-4,FRN132VG7S-4,FRN160VG7S-4,FRN200VG7S-4;

芯片级维修安邦信变频器:

AMB-E11系列通用变频

器:AMB-E11-1R5T3,AMB-E11-2R2T3,AMB-E11-3R7T3,AMB-E11-5R5T3,AMB-E11-7R5T3,AMB-E11-011T3,AMB-E11-015T3,AMB-E11-018T3,AMB-E11-022T3,AMB-E11-030T3,AMB-E11-037T3,AMB-E11-045T3,AMB-E11-055T3;

AMB-HVI高压变频

器:AMB-HVI-036V060,AMB-HVI-048V060,AMB-HVI-061V060,AMB-HVI-077V060,AMB-HVI-096V060,AMB-HVI-120V060,AMB-HVI-144V060,AMB-HVI-173V060,AMB-HVI-180V060,AMB-HVI-220V060,AMB-HVI-260V060,AMB-HVI-036V100,AMB-HVI-046V100;

AMB-V11变频器型号:AMB-V11-0R4S2,AMB-V11-0R4S3,AMB-V11-0R75S2,AMB-V11-0R75S3,

AMB-V11-1R5S2,AMB-V11-1R5S3,AMB-V11-2R2S2,AMB-V11-2R2S3,AMB-V11-3R7S3,AMB-V11-5R5S3,AMB-V11-0R75T3,AMB-V11-1R5T3,

AMB-G7变频器:AMB-G7-0R7S2,AMB-G7-1R5S2,AMB-G7-2R2S2,AMB-G7-0R7T3,AMB-G7-1R5T3,

AMB-G7-2R2T3,AMB-G7-3R7T3,AMB-G7-5R5T3,AMB-G7-7R5T3,AMB-G7-011T3,AMB-G7-015T3,AMB-G7-018T3,AMB-G7-022T3,AMB-G7-030T3,AMB-G7-037T3,AMB-G7-045T3,AMB-G7-055T3,AMB-G7-075T3,AMB-G7-093T3,AMB-G7-110T3,AMB-G7-132T3,AMB-G7-160T3,AMB-G7-200T3,AMB-G7-220T3,AMB-G7-245T3,AMB-G7-280T3;

AMB-G9/P9系列变频器:AMB-G9-1R5T3,AMB-G9-2R2T3,AMB-G9-3R7T3,AMB-G9-5R5T3,

AMB-G9-7R5T3,AMB-G9-011T3,AMB-G9-015T3,AMB-G9-018T3,AMB-G9-022T3,AMB-G9-030T3,AMB-G9-037T3,AMB-G9-045T3,AMB-G9-055T3,AMB-G9-075T3,AMB-G9-093T3,AMB-G9-110T3,AMB-G9-132T3,AMB-G9-160T3,AMB-G9-185T3,AMB-G9-200T3,AMB-G9-220T3,AMB-G9-245T3,AMB-G9-280T3,AMB-G9-315T3,AMB-G9-355T3,AMB-G9-400T3;

芯片级维修佳灵公司变频器:

JP6C-T9:JP6C-T9-075,JP6C-T9-15,JP6C-T9-22,JP6C-T9-40,JP6C-T9-55,JP6C-T9-75,JP6C-T9-11,JP6C-T9-15,JP6C-T9-185,JP6C-T9-22,JP6C-T9-30,JP6C-T9-37,JP6C-T9-45,JP6C-T9-55,JP6C-T9-75,JP6C-T9-90,JP6C-T9-110,JP6C-T9-132,JP6C-T9-160,JP6C-T9-200,JP6C-T9-220,JP6C-T9-280,JP6C-T9-315,JP6C-T9-400,JP6C-T9-630;

J9Zn系列节能型变频器:J9Zn-075,J9Zn-15,J9Zn-22,J9Zn-40,J9Zn-55,J9Zn-75,J9Zn-11,J9Zn-15,J9Zn-185,J9Zn-22,J9Zn-30,J9Zn-37,J9Zn-45,J9Zn-55,J9Zn-75,J9Zn-90,J9Zn-110,J9Zn-132,J9Zn-160,J9Zn-200,J9Zn-220,J9Zn-280,J9Zn-315,J9Zn-400,J9Zn-630;

JP6C-Z9/Z9B2系列中频变频器:JP6C-Z9-6KVA,JP6C-Z9-10KVA,JP6C-Z9-15KVA,JP6C-Z9-25KVA,JP6C-Z9-30KVA,JP6C-Z9B2-10KVA,JP6C-Z9B2-15KVA,JP6C-Z9B2-25KVA,JP6C-Z9B2-30KVA;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

NKB系列中央空调专用变频器:NKB-075,NKB-15,NKB-22,NKB-40,NKB-55,NKB-75,NKB-11,NKB-15,NKB-185,NKB-22,NKB-30,NKB-37,NKB-45,NKB-55,NKB-75,NKB-90,NKB-110,NKB-132,NKB-160,NKB-200,NKB-220,NKB-280,NKB-315,NKB-400,NKB-630;

ZY系列中压变频器:ZY-1250-55,ZY-1250-75,ZY-1250-110,ZY-1250-132,ZY-1250-160,ZY-1250-200,ZY-2300-110,ZY-2300-132,ZY-2300-160,ZY-2300-200,ZY-2300-220,ZY-2300-280,ZY-2300-315,ZY-2300-630;

芯片级维修康沃变频调速器:

CVF-G1 系列:CVF-G1-4T0007,CVF-G1-4T0015,CVF-G1-4T0022,CVF-G1-4T0037,CVF-G1-4T0055,CVF-ZS-4T0055,CVF-G1-4T0075,CVF-ZS-4T0075,CVF-G1-4T0110,CVF-ZS-4T0110,CVF-G1-4T0150,CVF-ZS-4T0150,CVF-G1-4T0185,CVF-ZS-4T0185,CVF-G1-4T0220,CVF-ZS-4T0220,CVF-G1-4T0300,CVF-ZS-4T0300,CVF-G1-4T0370,CVF-ZS-4T0370,CVF-G1-4T0550,CVF-ZS-4T0450,CVF-G1-4T0550,CVF-ZS-4T0550,CVF-G1-4T0750,CVF-ZS-4T0750,CVF-G1-4T0900,CVF-G1-4T1100,CVF-G1-4T1320,CVF-G1-4T1600,CVF-G1-4T2000,CVF-G1-4T2200,CVF-G1-4T2500,CVF-G1-4T2800;

CVF-P1 系列风机、水泵专用变频调速:CVF-P1-4T0015,CVF-P1-4T0022,CVF-P1-4T0037,CVF-P1-4T0055,CVF-P1-4T0075,CVF-P1-4T0110,CVF-P1-4T0150,CVF-P1-4T0185,CVF-P1-4T0220,CVF-P1-4T0300,CVF-P1-4T0370,CVF-P1-4T0450,CVF-P1-4T0550,CVF-P1-4T0750,CVF-P1-4T0900,CVF-P1-4T1100,CVF-P1-4T1320,CVF-P1-4T1600,CVF-P1-4T2000,CVF-P1-4T2200,CVF-P1-4T2500,CVF-P1-4T2800,CVF-P1-4T3150;

CVF-G2 系列通用变频器:CVF-G2-4T0007,CVF-G2-4T0015,CVF-G2-4T0022,CVF-G2-4T0037,CVF-G2-4T0055,CVF-G2-4T0075,CVF-G2-4T0110,CVF-G2-4T0150,CVF-G2-4T0185,CVF-G2-4T0220,CVF-G2-4T0300,CVF-G2-4T0370,CVF-G2-4T0450,CVF-G2-4T0550;

CVF-P2 系列风机、水泵专用变频器:CVF-P2-4T0015,CVF-P2-4T0022,CVF-P2-4T0037,CVF-P2-4T0055,CVF-P2-4T0075,CVF-P2-4T0110,CVF-P2-4T0150,CVF-P2-4T0185,CVF-P2-4T0220,CVF-P2-4T0300,CVF-P2-4T0370,CVF-P2-4T0450,CVF-P2-4T0550,CVF-P2-4T0750;

CVF-ZS 系列注塑机专用变频调速器:CVF-ZS4T0110,CVF-ZS-4T0150,CVF-ZS-4T0185,CVF-ZS-4T0220,CVF-ZS-4T0300,CVF-ZS-4T0370,CVF-ZS-4T0450,CVF-ZS-4T0550;

芯片级维修三菱变频器:

V200E 系列:FR-V220E-15K,FR-V220E-22K,FR-V220E-37K,FR-V220E-55K,FR-V220E-75K,FR-V240E-15K,FR-V240E-22K,FR-V240E-37K,FR-V240E-55K,FR-V220E-11K,FR-V220E-15K,FR-V220E-185K,FR-V240E-75K,FR-V240E-11K,FR-V240E-15K,FR-V240E-185K,FR-V220E-22K,FR-V220E-30K,FR-V220E-37K,FR-V220E-45K,FR-V240E-22K,FR-V240E-30K,FR-V240E-37K,FR-V240E-45K;

变频器 FR-E500 系列:FR-E520-01K-NA,FR-E520-02K-NA,FR-E520-04K-NA,FR-E520-075K-NA,FR-E520-15K-NA,FR-E520-22K-NA,FR-E520-37K-NA,FR-E520-55K-NA,FR-E520-75K-NA,FR-E540-04K-NA,FR-E540-075K-NA,FR-E540-15K-NA,FR-E540-22K-NA,FR-E540-37K-NA,FR-E540-55K-NA,FR-E540-75K-NA,FR-E510W-01K-NA,FR-E510W-02K-NA,FR-E510W-04K-NA,FR-E510W-075K-NA,FR-A540L-75K-G1,FR-A540L-90K-G1,FR-A540L-110K-G1,FR-A540L-S132K,FR-A540L-S160K,FR-A540L-S220K,FR-A540L-S250K,FR-A540L-S280K,FR-A540L-S375K;

FR-A500 变频器:FR-A540-04K-CH,FR-A540-075K-CH,FR-A540-15K-CH,FR-A540-22K-CH,FR-A540-37K-CH,FR-A540-55K-CH,FR-A540-75K-CH,FR-A540-11K-CH,FR-A540-15K-CH,FR-A540-185K-CH,FR-A540-22K-CH,FR-A540-30K-CH,FR-A540-37K-CH,FR-A540-45K-CH,FR-A540-55K-C;

FR-S500 变频器:FR-S520E-04K,FR-S520E-075K,FR-S520SE-04K,FR-S520SE-075K,FR-S520E-15K,FR-S520E-22K,FR-S520E37K,FR-S540E-04K,FR-S540E-075K,FR-S540E-15K,FR-S540E-22K,FR-S540E-37K,FR-S520SE-15K;

FREQROL-F700 系列:FR-F740-075K-CH,FR-F740-15K-CH,FR-F740-22K-CH,FR-F740-37K-CH,FR-F740-55K-CH,FR-F740-75K-CH,FR-F740-11K-CH,FR-F740-15K-CH,FR-F740-185K-CH,FR-F740-22K-CH,FR-F740-30K-CH,FR-F740-37K-CH,FR-F740-45K-CH,FR-F740-55K-CH,FR-F740-S75K-CH,FR-F740-S90K-CH,FR-F740-S110K-CH,FR-F740-S132K-CH,FR-F740-S160K-CH,FR-F740-S

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

185K-CH,FR-F740-S220K-CH,FR-F740-S250K-CH,FR-F740-S280K-CH,FR-F740-S315K-CH,FR-F740-S355K-CH,FR-F740-S400K-CH,FR-F740-S450K-CH,FR-F740-S500K-CH,FR-F740-S560K-CH,

FR-F740-S630K-CH;

FR-F540J 变频器:FR-F540J-075K-CH,FR-F540J-04K-CH,FR-F540J-15K-CH,FR-F540J-22K-CH,FR-F540J-37K-CH,FR-F540J-55K-CH,FR-F540J-75K-CH,FR-F540J-11K-CH,FR-F540J-15K-CH;FR-V540-15K,FR-V540-22K,FR-V540-37K,FR-V540-55K,FR-V540-75K,FR-V540-11K,FR-V540-15K,FR-V540-185K

,FR-V540-22K,FR-V540-30K,FR-V540-37K,FR-V540-45K,FR-V540-55K,FR-V540-75K,FR-V540-90K,FR-V540-90K,FR-V540-110K,FR-V540-132K,FR-V540-160K,FR-V540-200K,FR-V540-250K;

Matsushit AVF-0 SerieS inverters:Matsushit **AVF-CE SerieS inverters:**BFVCE0022A,BFVCE0032A,BFVCE0072A,BFVCE0152A,BFVCE0222A,BFVCE0074A,BFVCE0154A,BFVCE0224A,BFVCE0404A;

Matsushit AVF-8X SerieS inverters:BFV80554XU,BFV80754XU,BFV81104XU,BFV81504XU,BFV81904XU,BFV82204XU,BFV83004XU,BFV83704XU;

NAISVF 系列变频器:BFV00022D,BFV00042D,BFV00042G,BFV00072D,BFV00072G,BFV00152D,BFV00152G,BFV00074,BFV00154,BFV00224,BFV00374;芯片级维修松下变频器: NAIsmotionControlLV2:PMT-H/PMT-F500HV 系列变频器:

VF-0:BFV00042GK,BFV00072GK,BFV00152GK,BFV00022DK,BFV00042DK,BFV00072DK,BFV00152DK,BFV00074,BFV00154,BFV00224,BFV00374;

芯片级维修台达变频器:

VFD-A系列:VFD007A21A,VFD007A23A,VFD015A21A,VFD015A23A,VFD007A43A,VFD015A43B,VFD022A21A,VFD022A23A,VFD037A23A,VFD022A43A,.,VFD037A43A,VFD055A23B,VFD075A23B,VFD055A43B,VFD075A43B,VFD110A23A,VFD150A23A,VFD185A23A,VFD220A23A,VFD110A43A,VFD150A43A,VFD185A43A,VFD220A43A;

VFD-M系列:VFD004M21A,VFD004M23A,VFD007M21A,VFD007M23A,VFD015M21A,VFD015M23A,VFD002M11A,VFD004M11A,VFD004M21B,VFD007M11A,VFD007M21B,VFD007M43B,VFD015M21B,VFD015M43B,VFD022M23B,VFD022M43B,VFD022M21A,VFD037M23A,VFD037M43A,VFD055M23A,VFD055M43A,VFD075M43A,

VFD-E系列:VFD002S11A/B,VFD002S21A/B/E,VFD002S23A,VFD004S11A/B,VFD004S21A/B/E,VFD004S23A,VFD004S43A/B/E,VFD007S11A/B,VFD007S21A/B/E,VFD007S23A,VFD007S43A/B/E,VFD015S21D/E,VFD015S23D,VFD015S43D/E/U,VFD022S21D/E/U,VFD022S23D,VFD022S43D/E/U,

VFD-B系列:VFD007B21A,VFD015B21A,VFD015B21B,VFD022B21A,VFD007B23A,VFD007B43A,VFD007B53A,VFD015B23A/B,VFD015B43A,VFD015B53A,VFD022B23A,VFD022B43B,VFD022B53A,VFD037B23A,VFD037B43A,VFD037B53A,VFD055B23A,VFD055B43A,VFD055B53A,VFD075B23A,VFD075B43A,VFD075B53A,VFD110B23A,VFD110B43A,VFD110B53A,VFD150B23A,VFD150B43A,VFD150B53A,VFD185B23A,VFD185B43A,VFD185B53A,VFD220B23A,VFD220B43A,VFD220B53A,VFD300B23A,VFD300B43A,VFD300B53A,VFD370B23A,VFD370B43A,VFD370B53A,VFD450B43A,VFD450B53A,VFD550B43A/C,VFD550B53A,VFD750B43A/C,VFD750B53A;

VFD-S系列:VFD002S11A/B,VFD002S21A/B/E,VFD004S11A/B,VFD004S21A/B/E,VFD007S11A/B,VFD007S21A/B/E,VFD015S21D/E,VFD022S21D/E/U,VFD002S23A,VFD004S23A,VFD004S43A/B/E,VFD007S23A,VFD007S43A/B/E,VFD015S23D,VFD015S43D/E/U,VFD022S23D,VFD022S43D/E/U;

VFD-V系列:VFD007V23A,VFD015V23A,VFD022V23A,VFD037V23A,VFD007V43A,VFD015V43A,VFD022V43A,VFD037V43A,VFD055V23A,VFD075V23A,VFD110V43A,VFD150V43A,VFD185V43A,VFD110V23A,VFD150V23A,VFD220V43A,VFD300V43A,VFD370V43A,VFD185V23A,VFD220V23A,VFD300V23A,VFD450V43A,VFD370V23A,VFD550V43A,VFD750V43A;

芯片级维修西门子变频器:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MM420/MM440 变频器:

6SE6420-2UD13-7AA0,6SE6420-2UD15-5AA0,6SE6420-2UD17-5AA0,6SE6420-2UD21-1AA0,6SE6420-2UD21-5AA0,6SE6420-2UD22-2BA0,6SE6420-2UD23-0BA0,6SE6420-2UD24-0BA0,6SE6420-2UD25-5CA0,6SE6420-2UD27-5CA0,6SE6420-2UD31-1CA0,6SE6440-2UD13-7AA0,6SE6440-2UD15-5AA0,6SE6440-2UD17-5AA0,6SE6440-2UD21-1AA0,6SE6440-2UD21-5AA0,6SE6440-2UD22-2BA0,6SE6440-2UD23-0BA0,6SE6440-2UD24-0BA0,6SE6440-2UD25-5CA0,6SE6440-2UD27-5CA0,6SE6440-2UD31-1CA0,6SE6440-2UD31-5DA0,6SE6440-2UD31-8DA0,6SE6440-2UD32-2DA0,6SE6440-2UD33-0EA0,6SE6440-2UD33-7EA0,6SE6440-2UD34-5FA0,6SE6440-2UD35-5FA0,6SE6440-2UD37-5FA0;

MICROMASTER 420,订货号如下:6SE6420-2UC11-2AA1,6SE6420-2UC12-5AA1,6SE6420-2UC13-7AA1,6SE6420-2UC15-5AA1,6SE6420-2UC17-5AA1,6SE6420-2UC21-1BA1,6SE6420-2UC21-5BA1,6SE6420-2UC22-2BA1,6SE6420-2UC23-0CA1,6SE6420-2AB11-2AA1,6SE6420-2AB12-5AA1,6SE6420-2AB13-7AA1,6SE6420-2AB15-5AA1,6SE6420-2AB17-5AA1,6SE6420-2AB21-1BA1,6SE6420-2AB21-5BA1,6SE6420-2AB22-2BA1,6SE6420-2AB23-0CA1,6SE6420-2UC11-2AA1,6SE6420-2UC12-5AA1,6SE6420-2UC13-7AA1,6SE6420-2UC15-5AA1,6SE6420-2UC17-5AA1,6SE6420-2UC21-1BA1,6SE6420-2UC21-5BA1,6SE6420-2UC22-2BA1,6SE6420-2UC23-0CA1,6SE6420-2UC24-0CA1,6SE6420-2UC25-5CA1,6SE6420-2AC23-0CA1,6SE6420-2AC24-0CA1,6SE6420-2AC25-5CA1,6SE6420-2UD13-7AA1,6SE6420-2UD15-5AA1,6SE6420-2UD17-5AA1,6SE6420-2UD21-1AA1,6SE6420-2UD21-5AA1,6SE6420-2UD22-2BA1,6SE6420-2UD23-0BA1,6SE6420-2UD24-0BA1,6SE6420-2UD25-5CA1,6SE6420-2UD27-5CA1,6SE6420-2UD31-1CA1,6SE6420-2AD22-2BA1,6SE6420-2AD23-0BA1,6SE6420-2AD24-0BA1,6SE6420-2AD25-5CA1,6SE6420-2AD27-5CA1,6SE6420-2AD31-1CA1;

MICROMASTER 430变频器订货号如下:6SE6430-2UD27-5CA0,6SE6430-2UD31-1CA0,6SE6430-2UD31-5CA0,6SE6430-2UD31-8DA0,6SE6430-2UD32-2DA0,6SE6430-2UD32-2DB0,6SE6430-2UD33-0DA0,6SE6430-2UD33-0DB0,6SE6430-2UD33-7EA0,6SE6430-2UD33-7EB0,6SE6430-2UD34-5EA0,6SE6430-2UD34-5EB0,6SE6430-2UD35-5FA0,6SE6430-2UD35-5FB0,6SE6430-2UD37-5FA0,6SE6430-2UD37-5FB0,6SE6430-2UD38-8FA0,6SE6430-2UD38-8FB0,6SE6430-2UD41-1FA0,6SE6430-2UD41-1FB0,6SE6430-2UD41-3FA0,6SE6430-2UD41-3FB0,6SE6430-2UD41-6GA0,6SE6430-2UD41-6GB0,6SE6430-2UD42-0GA0,6SE6430-2UD42-0GB0,6SE6430-2UD42-5GA0,6SE6430-2UD42-5GB0,6SE6430-2AD27-5CA0,6SE6430-2AD31-1CA0,6SE6430-2AD31-5CA0,6SE6430-2AD31-8DA0,6SE6430-2AD32-2DA0,6SE6430-2AD33-0DA0,6SE6430-2AD33-7EA0,6SE6430-2AD34-5EA0,6SE6430-2AD35-5FA0,6SE6430-2AD37-5FA0,6SE6430-2AD38-8FA0,6SE6430-2UD31-8DB0;

MICROMASTER 440变频器订货号如下:6SE6440-2UC11-2AA1,6SE6440-2UC12-5AA1,6SE6440-2UC13-7AA1,6SE6440-2UC15-5AA1,6SE6440-2UC21-1BA1,6SE6440-2UC21-5BA1,6SE6440-2UC22-2BA1,6SE6440-2UC23-0CA1,6SE6440-2UC11-2AA1,6SE6440-2UC12-5AA1,6SE6440-2UC13-7AA1,6SE6440-2UC15-5AA1,6SE6440-2UC17-5AA1,6SE6440-2UC21-1BA1,6SE6440-2UC21-5BA1,6SE6440-2UC22-2BA1,6SE6440-2UC23-0CA1,6SE6440-2UC24-0CA1,6SE6440-2UC25-5CA1,6SE6440-2UC27-5DA1,6SE6440-2UC31-1DA1,6SE6440-2UC31-5DA1,6SE6440-2UC31-8EA1,6SE6440-2UC32-2EA1,6SE6440-2UC33-0FA1,6SE6440-2UC33-7FA1,6SE6440-2UC34-5FA1,6SE6440-2UD13-7AA1,6SE6440-2UD15-5AA1,6SE6440-2UD17-5AA1,6SE6440-2UD21-1AA1,6SE6440-2UD21-5AA1,6SE6440-2UD22-2BA1,6SE6440-2UD23-0BA1,6SE6440-2UD24-0BA1,6SE6440-2UD25-5CA1,6SE6440-2UD27-5CA1,6SE6440-2UD31-1CA1,6SE6440-2UD31-5DA1,6SE6440-2UD31-5DB1,6SE6440-2UD31-8DA1,6SE6440-2UD31-8DB1,6SE6440-2UD32-2DA1,6SE6440-2UD32-2DB1,6SE6440-2UD33-0EA1,6SE6440-2UD33-0EB1,6SE6440-2UD33-7EA1,6SE6440-2UD33-7EB1,6SE6440-2UD34-5FA1,6SE6440-2UD34-5FB1,6SE6440-2UD35-5FA1,6SE6440-2UD35-5FB1,6SE6440-2UD37-5FA1,6SE6440-2UD37-5FB1,6SE6440-2UD38-8FA1,6SE6440-2UD38-8FB1,6SE6440-2UD41-1FA1,6SE6440-2UD41-1FB1,6SE6440-2UD41-3GA1,6SE6440-2UD41-3GB1,6SE6440-2UD41-6GA1,6SE6440-2UD41-6GB1,6SE6440-2UD42-0GA1,6SE6440-2UD42-0GB1,6SE6440-2UE17-5CA1,6SE6440-2UE21-5CA1,6SE6440-2UE22-2CA1,6SE6440-2UE24-0CA1,6SE6440-2UE25-5CA1,6SE6440-2UE27-5CA1,6SE6440-2UE31-1CA1,6SE6440-2UE31-5DA1,6SE6440-2UE31-8DA1,6SE6440-2UE32-2DA1,6SE6440-2UE33-0EA1,6SE6440-2UE33-7EA1,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6SE6440-2UE34-5FA1,6SE6440-2UE35-5FA1,6SE6440-2UE37-5FA1,6SE6440-2AB11-2AA1,6SE6440-2AB12-5AA1,6SE6440-2AB13-7AA1,6SE6440-2AB15-5AA1,6SE6440-2AB17-5AA1,6SE6440-2AB21-1BA1,6SE6440-2AB21-5BA1,6SE6440-2AB22-2BA1,6SE6440-2AB23-0CA1,6SE6440-2AC23-0CA1,6SE6440-2AC24-0CA1,6SE6440-2AC25-5CA1,6SE6440-2AD22-2BA1,6SE6440-2AD23-0BA1,6SE6440-2AD24-0BA1,6SE6440-2AD25-5CA1,6SE6440-2AD27-5CA1,6SE6440-2AD31-1CA1,6SE6440-2AD31-5DA1,6SE6440-2AD31-8DA1,6SE6440-2AD32-2DA1,6SE6440-2AD33-0EA1,6SE6440-2AD33-7EA1,6SE6440-2AD34-5FA1,6SE6440-2AD35-5FA1,6SE6440-2AD37-5FA1,6SE6440-2UC17-5AA1;

SINAMIC SG110变频器订货号如下:6SL3211-0AB11-2UA0,6SL3211-0AB11-2UB0,6SL3211-0KB11-2UA0,6SL3211-0KB11-2UB0,6SL3211-0AB12-5UA0,6SL3211-0AB12-5UB0,6SL3211-0KB12-5UA0,6SL3211-0KB12-5UB0,6SL3211-0AB13-7UA0,6SL3211-0AB13-7UB0,6SL3211-0KB13-7UA0,6SL3211-0KB13-7UB0,6SL3211-0AB15-5UA0,6SL3211-0AB15-5UB0,6SL3211-0KB15-5UA0,6SL3211-0KB15-5UB0,6SL3211-0AB17-5UA0,6SL3211-0AB17-5UB0,6SL3211-0KB17-5UA0,6SL3211-0KB17-5UB0,6SL3211-0AB21-1UA0,6SL3211-0AB21-1UB0,6SL3211-0AB21-5UA0,6SL3211-0AB21-5UB0,6SL3211-0AB22-2UA0,6SL3211-0AB22-2UB0,6SL3211-0AB23-0UA0,6SL3211-0AB23-0UB0,6SL3211-0AB11-2BA0,6SL3211-0AB11-2BB0,6SL3211-0KB11-2BA0,6SL3211-0KB11-2BB0,6SL3211-0AB12-5BA0,6SL3211-0AB12-5BB0,6SL3211-0KB12-5BA0,6SL3211-0KB12-5BB0,6SL3211-0AB13-7BA0,6SL3211-0AB13-7BB0,6SL3211-0KB13-7BA0,6SL3211-0KB13-7BB0,6SL3211-0AB15-5BA0,6SL3211-0AB15-5BB0,6SL3211-0KB15-5BA0,6SL3211-0KB15-5BB0,6SL3211-0AB17-5BA0,6SL3211-0AB17-5BB0,6SL3211-0KB17-5BA0,6SL3211-0KB17-5BB0,6SL3211-0AB21-1AA0,6SL3211-0AB21-1AB0,6SL3211-0AB21-5AA0,6SL3211-0AB21-5AB0,6SL3211-0AB22-2AA0,6SL3211-0AB22-2AB0,6SL3211-0AB23-0AA0,6SL3211-0AB23-0AB0;

MICROMASTER Eco&MIDIMASTER Eco变频器型号如下:ECO1-75/2,ECO1-110/2,ECO1-150/2,ECO1-220/2,ECO1-300/2,ECO1-400/2,ECO1-110/3,ECO1-150/3,ECO1-220/3,ECO1-300/3,ECO1-400/3,ECO1-550/3,ECO1-750/3,ECO1-220/3,ECO1-300/3,ECO1-400/3,ECO1-550/3,ECO1-750/3,ECO1-550/2,ECO1-750/2,ECO1-1100/2,ECO1-1500/2,ECO1-1850/2,ECO1-2200/2,ECO1-3000/2,ECO1-3700/2,ECO1-4500/2,ECO1-1100/3,ECO1-1500/3,ECO1-1850/3,ECO1-2200/3,ECO1-3000/3,ECO1-3700/3,ECO1-4500/3,ECO1-5500/3,ECO1-7500/3,ECO1-9000/3,ECO1-110K/3,ECO1-132K/3,ECO1-160K/3,ECO1-200K/3,ECO1-250K/3,ECO1-315K/3,ECO1-400/4,ECO1-550/4,ECO1-750/4,ECO1-1100/4,ECO1-1500/4,ECO1-1850/4,ECO1-2200/4,ECO1-3000/4,ECO1-3700/4,ECO1-4500/4,ECO1-550/2,ECO1-750/2,ECO1-1100/2,ECO1-1500/2,ECO1-1850/2,ECO1-2200/2,ECO1-3000/2,ECO1-3700/2,ECO1-4500/2,ECO1-1100/3,ECO1-1500/3,ECO1-1850/3,ECO1-2200/3,ECO1-3000/3,ECO1-3700/3,ECO1-4500/3,ECO1-5500/3,ECO1-7500/3,ECO1-9000/3,ECO1-110/2,ECO1-150/2,ECO1-220/2,

ECO1-300/2,ECO1-400/2,ECO1-550/2,ECO1-750/2,ECO1-1100/2,ECO1-1500/2,ECO1-1850/2,ECO1-2200/2,ECO1-3000/2,ECO1-3700/2,ECO1-4500/2,ECO1-110/2,ECO1-150/2,ECO1-220/2,ECO1-300/2,ECO1-400/2,ECO1-550/2,ECO1-750/2,ECO1-1100/2,ECO1-1500/2,ECO1-1850/2,ECO1-2200/2,ECO1-3000/2,ECO1-3700/2,ECO1-4500/2,ECO1-300/3,ECO1-400/3,ECO1-550/3,ECO1-750/3,ECO1-1100/3,ECO1-1500/3,ECO1-1850/3,ECO1-2200/3,ECO1-3000/3,ECO1-3700/3,ECO1-4500/3,ECO1-5500/3,ECO1-7500/3,ECO1-9000/3,ECO1-300/3,ECO1-400/3,ECO1-550/3,ECO1-750/3,ECO1-1100/3,ECO1-1500/3,ECO1-1850/3,ECO1-2200/3,ECO1-3000/3,ECO1-3700/3,ECO1-4500/3,ECO1-5500/3,ECO1-7500/3,ECO1-9000/3,ECO1-400/4,ECO1-550/4,ECO1-750/4,ECO1-1100/4,ECO1-1500/4,ECO1-1850/4,ECO1-2200/4,ECO1-3000/4,ECO1-3700/4,ECO1-4500/4;

MICROMASTER Eco&MIDIMASTER Eco变频器订货号如下:6SE9513-8CA40,6SE9515-5CB40,6SE9517-5CB40,6SE9521-0CC40,6SE9521-4CC40,6SE9521-8CC40,6SE9513-0DA40,6SE9514-5DA40,6SE9516-0DB40,6SE9517-7DB40,6SE9521-0DB40,6SE9521-3DC40,6SE9521-7DC40,6SE9516-0DB50,6SE9517-7DB50,6SE9521-0DC50,6SE9521-3DC50,6SE9521-7DC50,6SE9522-3CG40,6SE9522-8CG40,6SE9524-2CH40,6SE9525-4CH40,6SE9526-8CJ40,6SE9528-0CJ40,6SE9531-0CK40,6SE9531-3CK40,6SE9531-5CK40,6SE9522-4DG40,6SE9523-0DG40,6SE9523-7DH40,6SE9524-3DH40,6SE9525-8DJ40,6SE9527-1DJ40,6SE9528-4DJ40,6SE9531-0DK40,6SE9531-4DK40,6SE9531-7DK40,6SE9532-1EL40,6SE9532-6EL40,6SE9533-2EL40,6SE9533-7EL40,6SE9535-1EM40,6SE9536-0EM40,6SE9516-1FG40,6SE9521-0FG40,6SE9521-1FG40,6SE9521-7FG40,6SE9522-2FG40,6SE9522-7FH40,6S

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

E9523-2FH40,6SE9524-1FJ40,6SE9525-2FJ40,6SE9526-2FJ40,6SE9522-3CG50,6SE9522-8CG50,6SE9524-2CH50,6SE9525-4CJ50,6SE9526-8CJ50,6SE9528-0CJ50,6SE9531-0CK50,6SE9531-3CK50,6SE9531-5CK50,6SE9522-4DG50,6SE9523-0DG50,6SE9523-7DH50,6SE9524-3DH50,6SE9525-8DJ50,6SE9527-1DJ50,6SE9528-4DJ50,6SE9531-0DK50,6SE9531-4DK50,6SE9531-7DK50,6SE9515-5CS45,6SE9517-4CS45,6SE9521-0CS45,6SE9521-4CS45,6SE9521-8CS45,6SE9522-3CS45,6SE9522-8CS45,6SE9524-2CS45,6SE9525-4CS45,6SE9526-8CS45,6SE9528-0CS45,6SE9531-0CS45,6SE9531-3CS45,6SE9531-5CS45,6SE9515-5CS55,6SE9517-4CS55,6SE9521-0CS55,6SE9521-4CS55,6SE9521-8CS55,6SE9522-3CS55,6SE9522-8CS55,6SE9524-2CS55,6SE9525-4CS55,6SE9526-8CS55,6SE9528-0CS55,6SE9531-0CS55,6SE9531-3CS55,6SE9531-5CS55,6SE9517-7DS45,6SE9521-0DS45,6SE9521-3DS45,6SE9521-7DS45,6SE9522-4DS45,6SE9523-0DS45,6SE9523-7DS45,6SE9524-3DS45,6SE9525-8DS45,6SE9527-1DS45,6SE9528-4DS45,6SE9531-0DS45,6SE9531-4DS45,6SE9531-7DS45,6SE9517-7DS55,6SE9521-0DS55,6SE9521-3DS55,6SE9521-7DS55,6SE9522-4DS55,6SE9523-0DS55,6SE9523-7DS55,6SE9524-3DS55,6SE9525-8DS55,6SE9527-1DS55,6SE9528-4DS55,6SE9531-0DS55,6SE9531-4DS55,6SE9531-7DS55,6SE9516-1FS45,6SE9521-0FS45,6SE9521-1FS45,6SE9521-7FS45,6SE9522-2FS45,6SE9522-7FS45,6SE9523-2FS45,6SE9524-1FS45,6SE9525-2FS45,6SE9526-2FS45;

6SE70书本型变频器:6SE7016-1EA61,6SE7018-0EA61,6SE7021-0EA61,6SE7021-3EB61,6SE7021-8EB61,6SE7022-6EC61,6SE7023-4EC61,6SE7023-8ED61,6SE7024-7ED61,6SE7026-0ED61,6SE7027-2ED61,6SE7031-0EE60,6SE7031-2EF60,6SE7031-5EF60,6SE7031-8EF60,6SE7032-1EG60,6SE7032-6EG60,6SE7033-2EG60,6SE7033-7EG60,6SE7035-1EK60,6SE7036-0EK60,6SE7037-0EK60;

6SE70书本型逆变器:6SE7016-1TA61,6SE7018-0TA61,6SE7021-0TA61,6SE7021-3TB61,6SE7021-8TB61,6SE7022-6TC61,6SE7023-4TC61,6SE7023-8TD61,6SE7024-7TD61,6SE7026-0TD61,6SE7027-2TD61,6SE7031-0TE60,6SE7031-2TF60,6SE7031-5TF60,6SE7031-8TF60,6SE7032-1TG60,6SE7032-6TG60,6SE7033-2TG60,6SE7033-7TG60,6SE7035-1TJ60,6SE7036-0TJ60,6SE7037-0TJ60,6SE7038-6TK60,6SE7041-1TK60,6SE7041-3TL60;

6SE71变频调速柜:6SE7131-0EB61-3BA0,6SE7131-2EC61-3BA0,6SE7131-5EC61-3BA0,6SE7131-8EC61-3BA0,6SE7132-1ED61-3BA0,6SE7132-6ED61-3BA0,6SE7133-2ED61-3BA0,6SE7133-7ED61-3BA0,6SE7135-1EE62-3BA0,6SE7136-0EE62-3BA0,6SE7137-0EE62-3BA0,6SE7138-6EG62-3BA0,6SE7141-1EH62-3BA0,6SE7141-3EJ62-3BA0,6SE7126-0HC61-3BA0,6SE7128-2HC61-3BA0,6SE7131-0HD61-3BA0,6SE7131-2HD61-3BA0,6SE7131-5HD61-3BA0,6SE7131-7HD61-3BA0,6SE7132-1HD61-3BA0,6SE7133-0HE62-3BA0,6SE7133-5HE62-3BA0,6SE7134-5HE62-3BA0,6SE7135-7HG62-3BA0,6SE7136-5HG62-3BA0,6SE7138-6HG62-3BA0,6SE7141-1HJ62-3BA0,6SE7141-2HJ62-3BA0,6SE7141-4HL62-3BA0,6SE7141-6HL62-3BA0,6SE7141-4HN62-3BA0,6SE7141-6HN62-3BA0;6SE7131-0EC61-4BA0,6SE7131-2ED61-4BA0,6SE7131-5ED61-4BA0,6SE7131-8ED61-4BA0,6SE7132-1EE61-4BA0,6SE7132-6EE61-4BA0,6SE7133-2EE61-4BA0,6SE7133-7EE61-4BA0,6SE7135-1EF62-4BA0,6SE7136-0EG62-4BA0,6SE7137-0EG62-4BA1,6SE7138-6EG62-4BA0,6SE7141-1EH62-4BA0,6SE7141-3EJ62-4BA0,6SE7126-0HD61-4BA0,6SE7128-2HC61-4BA0,6SE7131-0HE61-4BA0,6SE7131-2HE61-4BA0,6SE7131-5HE61-4BA0,6SE7131-7HE61-4BA0,6SE7132-1HE61-4BA0,6SE7133-0HF62-4BA0,6SE7133-5HF62-4BA0,6SE7134-5HF62-4BA0,6SE7135-7HG62-4BA0,6SE7136-5HG62-4BA0,6SE7138-5HG62-4BA0,6SE7141-1HJ62-4BA0,6SE7141-2HJ62-4BA0,6SE7141-4HL62-4BA0,6SE7141-6HL62-4BA0,6SE7141-4HN62-4BA0,6SE7141-6HN62-4BA0;

MM,MMV,MDV系列通用变频器:MM12,MMV12,MM25,MMV25,MM37,MMV37,MM55,MMV55,MM75,MMV75,MM110,MMV110,MM150,MMV150,MM220,MMV220,MM300,MMV300,MM12/2,MM25/2,MM37/2,MM55/2,MM75/2,MM110/2,MM150/2,MM220/2,MM300/2,MM400/2,MMV12/2,MMV25/2,MMV37/2,MMV55/2,MMV75/2,MMV110/2,MMV150/2,MMV220/2,MMV300/2,MMV400/2,MDV550/2,MDV750/2,MDV1100/2,MDV1500/2,MDV1850/2,MDV2200/2,MDV3000/2,MDV3700/2,MDV4500/2,MDV750/3,MDV1100/3,MDV1500/3,MDV1850/3,MDV2200/3,MDV3000/3,MDV3700/3,MDV4500/3,MDV5500/3,MDV7500/3,MDV220/4,MDV400/4,MDV550/4,MDV750/4,MDV1100/4,MDV1500/4,MDV1850/4,MDV2200/4,MDV3000/4,MDV3700/4,MDV550/2,MDV750/2,MDV1100/2,MDV1500/2,MDV1850/2,MDV2200/2,MDV3000/2,MDV3700/2,MDV4500/2,MDV750/3,MDV1100/3,MDV1500/3,MDV1850/3,MDV2200/3,MDV3000/3,MDV

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

DV3700/3,MDV4500/3,MDV5500/3,MDV7500/3,MDV220/4,MDV400/4,MDV550/4,MDV750/4,MDV1100/4,MDV1500/4,MDV1850/4,MDV2200/4,MDV3000/4,MDV3700/4;

通用变频器**MM,MMV,MDV**系列, 订货号如下:6SE9210-7BA40,6SE9211-5BA40,6SE9212-1BA40,6SE9212-8BA40,6SE9213-6BA40,6SE9215-2BB40,6SE9216-8BB40,6SE9221-0BC40,6SE9221-3BC40,6SE9210-7CA40,6SE9211-5CA40,6SE9212-1CA40,6SE9212-8CA40,6SE9213-6CA40,6SE9215-2CB40,6SE9216-8CB40,6SE9221-0CC40,6SE9221-3CC40,6SE9221-8CC13,6SE9211-1DA40,6SE9211-4DA40,6SE9212-0DA40,6SE9212-7DA40,6SE9214-0DA40,6SE9215-8DB40,6SE9217-3DB40,6SE9221-0DC40,6SE9221-3DC40,6SE9221-5DC40,6SE3210-7BA40,6SE3211-5BA40,6SE3212-1BA40,6SE3212-8BA40,6SE3213-6BA40,6SE3215-2BB40,6SE3216-8BB40,6SE3221-0BC40,6SE3221-3BC40,6SE3210-7CA40,6SE3211-5CA40,6SE3212-1CA40,6SE3212-8CA40,6SE3213-6CA40,6SE3215-2CB40,6SE3216-8CB40,6SE3221-0CC40,6SE3221-3CC40,6SE3221-8CC40,6SE3211-1DA40,6SE3211-4DA40,6SE3211-0DA40,6SE3212-7DA40,6SE3214-0DA40,6SE3215-8DB40,6SE3217-3DB40,6SE3221-0DC40,6SE3221-3DC40,6SE3221-5DC40,6SE3222-3CG40,6SE3223-1CG40,6SE3224-2CH40,6SE3225-4CH40,6SE3226-8CJ40,6SE3227-5CJ40,6SE3231-0CK40,6SE3231-3CK40,6SE3231-5CK40,6SE3221-7DG40,6SE3222-4DG40,6SE3223-0DH40,6SE3223-5DH40,6SE3224-2DJ40,6SE3225-5DJ40,6SE3226-8DJ40,6SE3228-4DK40,6SE3231-0DK40,6SE3231-4DK40,6SE3213-9FG40,6SE3216-1FG40,6SE3219-0FG40,6SE3221-1FG40,6SE3221-7FG40,6SE3222-2FH40,6SE3222-7FH40,6SE3223-2FJ40,6SE3224-1FJ40,6SE3225-2FJ40,6SE3222-3CG50,6SE3223-1CG50,6SE3224-2CH50,6SE3225-4CH50,6SE3226-8CJ50,6SE3227-5CJ50,6SE3231-0CK50,6SE3231-3CK50,6SE3231-5CK50,6SE3221-7DG50,6SE3222-4DG50,6SE3223-0DH50,6SE3223-5DH50,6SE3224-2DJ50,6SE3225-5DJ50,6SE3226-8DJ50,6SE3228-4DK50,6SE3231-0DK50,6SE3231-4DK50,6SE3222-3CS45,6SE3223-1CS45,6SE3224-2CS45,6SE3225-4CS45,6SE3226-8CS45,6SE3227-5CS45,6SE3231-0CS45,6SE3231-3CS45,6SE3231-5CS45,6SE3221-7DS45,6SE3222-4DS45,6SE3223-0DS45,6SE3223-5DS45,6SE3224-2DS45,6SE3225-5DS45,6SE3226-8DS45,6SE3228-4DS45,6SE3231-0DS45,6SE3231-4DS45,6SE3213-9FS45,6SE3216-1FS45,6SE3219-0FS45,6SE3221-1FS45,6SE3221-7FS45,6SE3222-2FS45,6SE3222-7FS45,6SE3223-2FS45,6SE3224-1FS45,6SE3225-2FS45,6SE3290-0DG87-0FA5,6SE3290-0DH87-0FA5,6SE3290-0DJ87-0FA6,6SE3290-0DJ87-0FA6,6SE3290-0DJ87-0FA6,6SE3290-0DK87-0FA7,6SE3290-0DK87-0FA7,6SE3290-0DK87-0FA7,6SE3290-0DK87-0FA7,6SE3290-0DK87-0FA7,6SE3290-0DK87-0FA7,6SE3290-0DK87-0FA7,6SE3290-0DK87-0FA7,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20,6SE2100-1FC20;

SINAMIC SG150高性能单机传动变频调速柜**A**型柜, 订货号如下:6SL3710-1GE32-1AA0,6SL3710-1GE32-6AA0,6SL3710-1GE33-1AA0,6SL3710-1GE33-8AA0,6SL3710-1GE35-0AA0,6SL3710-1GE36-1AA0,6SL3710-1GE37-5AA0,6SL3710-1GE38-4AA0,6SL3710-1GE41-0AA0,6SL3710-1GE31-8AA0,6SL3710-1GE32-2AA0,6SL3710-1GE33-3AA0,6SL3710-1GE32-6AA0,6SL3710-1GE34-1AA0,6SL3710-1GE34-7AA0,6SL3710-1GE35-8AA0,6SL3710-1GE37-4AA0,6SL3710-1GE38-1AA0,6SL3710-1GH28-5AA0,6SL3710-1GH31-0AA0,6SL3710-1GH31-2AA0,6SL3710-1GH31-5AA0,6SL3710-1GH31-8AA0,6SL3710-1GH32-2AA0,6SL3710-1GH32-6AA0,6SL3710-1GH33-3AA0,6SL3710-1GH34-1AA0,6SL3710-1GH34-7AA0,6SL3710-1GH38-8AA0,6SL3710-1GH37-4AA0,6SL3710-1GH38-1AA0,6SL3710-1GE32-1CA0,6SL3710-1GE32-6CA0,6SL3710-1GE33-1CA0,6SL3710-1GE33-8CA0,6SL3710-1GE35-0CA0,6SL3710-1GE36-1CA0,6SL3710-1GE37-5CA0,6SL3710-1GE38-4AA0,6SL3710-1GE41-0CA0,6SL3710-1GE31-8CA0,6SL3710-1GE32-2CA0,6SL3710-1GE33-3CA0,6SL3710-1GE32-6CA0,6SL3710-1GE34-1CA0,6SL3710-1GE34-7CA0,6SL3710-1GE35-8CA0,6SL3710-1G

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

E37-4CA0,

6SL3710-1GE38-1CA0,6SL3710-1GH28-5AA0,6SL3710-1GH31-0CA0,6SL3710-1GH31-2CA0,6SL3710-1GH31-5CA0,6SL3710-1GH31-8CA0,

6SL3710-1GH32-2CA0,6SL3710-1GH32-6CA0,6SL3710-1GH33-3CA0,6SL3710-1GH34-1CA0,6SL3710-1GH34-7CA0,6SL3710-1GH38-8CA0,

6SL3710-1GH37-4CAA0,6SL3710-1GH38-1CA0;

AFE整流单元, 订货号如下:6SE7131-0EC61-5BA0,6SE7131-2ED61-5BA0,6SE7131-5ED61-5BA0,6SE7131-8ED61-5BA0,6SE7132-1EF61-5BA0,

6SE7132-6EF61-5BA0,6SE7133-2EF61-5BA0,6SE7133-7EF61-5BA0,6SE7135-1EH62-5BA0,6SE7136-0EH62-5BA0,6SE7137-0EK62-5BA0,6SE7138-6EK62-5BA0,

6SE7141-1EK62-5BA0,6SE7141-3EN62-5BA0,6SE7126-1FC61-5BA0,6SE7126-6FC61-5BA0,6SE7128-0FD61-5BA0,6SE7131-1FD61-5BA0,6SE7131-3FF61-5BA0,

6SE7131-6FF61-5BA0,6SE7132-0FF61-5BA0,6SE7132-3FF61-5BA0,6SE7133-0FH62-5BA0,6SE7133-5FH62-5BA0,6SE7134-5FH62-5BA0,6SE7135-7FK62-5BA0,

6SE7136-5FK62-5BA0,6SE7138-6FK62-5BA0,6SE7141-1FN62-5BA0,6SE7141-2FN62-5BA0,6SE7126-0HD61-5BA0,6SE7128-2HD61-5BA0,

6SE7131-0HF61-5BA0,6SE7131-2HF61-5BA0,6SE7131-5HF61-5BA0,6SE7131-7HF61-5BA0,6SE7132-1HF61-5BA0,6SE7133-0HH62-5BA0,

6SE7133-5HH62-5BA0,6SE7134-5HH62-5BA0,6SE7135-7HK62-5BA0,6SE7136-5HK62-5BA0,6SE7138-6HK62-5BA0,6SE7141-1HN62-5BA0,

6SE7141-2HN62-5BA0;

芯片级维修路斯特变频器

Lust SMARTDRIVE Frequency Inverters VF1000 SeriesS/M/L:VF1000S变频器

器:VF1104S, VF1202S, VF1204S, VF1402S, VF1000S, VF1000M,

VF1200S, VF1400S, VF1000L;

VF1000M变频器

器:VF1205M, VF1207M, VF1404M, VF1406M, VF1408M, VF1410M; **VF1000L**: VF1207L, VF1404L, VF1406L, VF1408L, VF1209L, VF1410L, VF1414L,

VF1418L, VF1424L, VF1432L, VF1445L, VF1408L, HF, VF1410L, HF, VF1414L, HF, VF1418L, HF, VF1424L, HF; VF1408LHF08,

VF1410LHF08, VF1414LHF08,

VF1418LHF08, VF1424LHF08; VF1205 M, VF1207 M, VF1404 M, VF1406 M, VF1408 M, VF1410 M;

芯片级维修MOELLER变频器:

DF4变频器: DF4-120-037, DF4-120-075, DF4-120-1K5, DF4-120-2K2, DF4-340-075, DF4-340-1K5, DF4-340-2K2, DF4-340-3K0, DF4-340-4K0, DF4-340-5K5,

DF4-340-7K5, DF4-340-11K, DF4-340-15K, DF4-340-22K, DF4-340-30K, DF4-340-45K, DF4-340-55K, DF4-340-75K, DF4-340-90K;

DV4变频器: : DV4-120-025, DV4-120-037, DV4-120-055, DV4-120-075, DV4-120-1K5, DV4-120-2K2, DV4-322-055, DV4-322-075, DV4-322-1K5, DV4-322-2K2,

DV4-320-3K0, DV4-320-4K0, DV4-320-5K5, DV4-320-7K5, DV4-340-055, DV4-340-075, DV4-340-1K5, DV4-340-2K2, DV4-340-3K0, DV4-340-4K0, DV4-340-5K5,

DV4-340-7K5, DV4-340-11K; DE4-IOM-STD-F, DE4-IOM-APP-F, DE4-NET-K-F, DE4-NET-DP-F, DE4-ICOM-2X;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

DF5变频器:DF5-322-018,DF5-322-037,DV5-322-018,DV5-322-037,DV5-322-055,DF5-322-055,DF5-322-075,DF5-322-1K1,DF5-322-1K5,DF5-322-2K2,

DF5-340-037,DF5-340-075,DF5-340-1K5,DF5-340-2K2,DF5-340-3K0,DF5-340-4K0,DF5-340-5K5,DF5-340-7K5,DV5-322-075,DV5-322-1K1,DV5-322-1K5,

DV5-322-2K2,DV5-340-037,DV5-340-075,DV5-340-1K5,DV5-340-2K2,DV5-340-3K0,DV5-340-4K0,DV5-340-5K5,DV5-340-7K5;

DF6变频器:DF6-340-11K,DF6-340-15K,DF6-340-18K5,DF6-340-22K,DF6-340-30K,DF6-340-37K,DF6-340-45K,DF6-340-55K,DF6-340-75K,DF6-340-90K,

DF6-340-110K,DF6-340-132K,DV6-340-075,DV6-340-1K5,DV6-340-2K2,DV6-340-4K0,DV6-340-5K5,DV6-340-7K5,DV6-340-11K,DV6-340-15K,DV6-340-18K5,

DV6-340-22K,DV6-340-30K,DV6-340-37K,DV6-340-45K,DV6-340-55K,DV6-340-75K,DV6-340-90K,DV6-340-110K,DV6-340-132K;

芯片级维修各种软启动器

芯片级维修**ABB**软启动器

PSD系列:PSD75,PSD110,PSD145,PSD175,PSD210,PSD250,PSD300,PSD370,PSD470,PSD570,PSD720,PSD840;

PSDH系列:PSDH30,PSDH45,PSDH60,PSDH75,PSDH110,PSDH145,PSDH175,PSDH210,PSDH250,PSDH300,PSDH370,PSDH470,PSDH570,PSDH720;

芯片级维修**BALDOR**（保德）软启动器:

单相软启动器:S20CA,S21CA,S22CA,S23CA,S25CA;

BALDOR数字软启动器:MD7-009-CB,MD7-016-CB,MD7-023-CB,MD7-030-CB,MD7-044-CB,MD7-059-CB,MD7-072-CB,MD7-085-CB,MD7-105-CB,

MD7-146-CB,MD7-174-CB,MD7-202-CB,MD7-242-CB,MD7-300-CB,MD7-370-CB,MD7-500-CB,MD7-600-CB,MD7-750-CB,MD7-900-CB,MD8-009-CB,

MD8-016-CB,MD8-023-CB,MD8-030-CB,MD8-044-CB,MD8-059-CB,MD8-072-CB,MD8-085-CB,MD8-105-CB,MD8-146-CB,MD8-174-CB,MD8-202-CB,

MD8-242-CB,MD8-300-CB,MD8-370-CB,MD8-500-CB,MD8-600-CB,MD8-750-CB,MD8-900-CB,MD8-1100-CB,MD8-1200-CB;

保德多用途软启动器**8-840**安培:MA9-008-CB-00,MA9-016-CB-00,MA9-030-CB-00,MA9-055-CB-00,MA9-080-CB-00,MA9-160-CB-00,MA9-250-CB-00,

MA9-420-CB-00,MA9-600-CB-00,MA9-840-CB-00,MB9-008-CB-00,MB9-016-CB-00,MB9-030-CB-00,MB9-055-CB-00,MB9-080-CB-00,MB9-160-CB-00,

MB9-250-CB-00,MB9-420-CB-00,MB9-600-CB-00,MB9-840-CB-00,MA9-008-JB-00,MA9-016-JB-00,MA9-030-JB-00,MA9-055-JB-00,MA9-080-JB-00,

MA9-160-JB-00,MA9-250-JB-00,MA9-420-JB-00,MA9-600-JB-00,MA9-840-JB-00,MB9-008-JB-00,MB9-016-JB-00,MB9-030-JB-00,MB9-055-JB-00,MB9-080-JB-00,

MB9-160-JB-00,MB9-250-JB-00,MB9-420-JB-00,MB9-600-JB-00,MB9-840-JCB-00;

芯片级维修施奈德**TELEMECANIQUE**软启动器

ATS01系列:ATS01N103FT,ATS01N106FT,ATS01N109FT,ATS01N112FT,ATS01N112FT,ATS01N103FT,ATS01N106FT,ATS01N206LU,ATS01N206QN,

ATS01N206RT,ATS01N109FT,ATS01N209LU,ATS01N209QN,ATS01N209RT,ATS01N112FT,ATS01N212LU,ATS01N212QN,ATS01N212RT,ATS01N222LU,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

ATS01N222QN,ATS01N222RT,ATS01N112FT,ATS01N232LU,ATS01N232QN,ATS01N232RT,ATS01N230LY,ATS01N244LY,ATS01N244Q,ATS01N272LY,
ATS01N272Q,ATS01N285LY,ATS01N285Q,ATSU01N206LT,ATSU01N206LT,ATSU01N209LT,ATSU01N209LT,ATSU01N212LT,ATSU01N212LT,ATSU01N222LT,
ATSU01N222LT,ATSU01N232LT;
ATS46软启动器:ATS-46D17N,ATS-46D22N,ATS-46D32N,ATS-46D38N,ATS-46D47N,ATS-46D62N,,ATS-46D75N,ATS-46D88N,ATS-46C11N,ATS-46C14N,
ATS-46C17N,ATS-46C21N,ATS-46C25N,ATS-46C32N,ATS-46C41N,ATS-46C48N,ATS-46C59N,ATS-46C66N,ATS-46C79N,ATS-46M10N,ATS-46M12N;
ATS48软启动器:ATS48D17Q,ATS48D22Q,ATS48D32Q,ATS48D38Q,ATS48D47Q,ATS48D62Q,ATS48D75Q,ATS48D88Q,ATS48C11Q,ATS48C14Q,ATS48C17Q,
ATS48C21Q,ATS48C25Q,ATS48C32Q,ATS48C41Q,ATS48C48Q,ATS48C59Q,ATS48C66Q,ATS48C79Q,ATS48M10Q,ATS48M12Q,ATS48D17Q,ATS48D22Q,
ATS48D32Q,ATS48D38Q,ATS48D47Q,ATS48D62Q,ATS48D75Q,ATS48D88Q,ATS48C11Q,ATS48C14Q,ATS48C17Q,ATS48C21Q,ATS48C25Q,ATS48C32Q,
ATS48C41Q,ATS48C48Q,ATS48C59Q,ATS48C66Q,ATS48C79Q,ATS48M10Q,ATS48M12Q,ATS48D17Y,ATS48D22Y,ATS48D32Y,ATS48D38Y,ATS48D47Y,
ATS48D62Y,ATS48D75Y,ATS48D88Y,ATS48C11Y,ATS48C14Y,ATS48C17Y,ATS48C21Y,ATS48C25Y,ATS48C32Y,ATS48C41Y,ATS48C48Y,ATS48C59Y,
ATS48C66Y,ATS48C79Y,ATS48M10Y,ATS48M12Y,ATS48D17Y,ATS48D22Y,ATS48D32Y,ATS48D38Y,ATS48D47Y,ATS48D62Y,ATS48D75Y,ATS48D88Y,
ATS48C11Y,ATS48C14Y,ATS48C17Y,ATS48C21Y,ATS48C25Y,ATS48C32Y,ATS48C41Y,ATS48C48Y,ATS48C59Y,ATS48C66Y,ATS48C79Y,ATS48M10Y,
ATS48M12Y;
芯片级维修东元软启动器S7系列:SA7-017SA7-030,SA7-045,SA7-060,SA7-075,SA7-085,SA7-110,SA7-145,SA7-170,SA7-210,SA7-250;
芯片级维修MOELLERD M4软启动器:DM4-340-7K5,DM4-340-11K,DM4-340-15K,DM4-340-22K,DM4-340-30K,DM4-340-37K,DM4-340-45K,DM4-340-55K,DM4-340-75K,DM4-340-110K,DM4-340-90K,DM4-340-132K,DM4-340-160K,DM4-340-200K,DM4-340-250K,DM4-340-315K,DM4-340-400K,DM4-340-500K;
芯片级维修西门子软启动器:3RW3014-1CB14,3RW3016-1CB14,3RW3024-1AB14,3RW3025-1AB14,3RW3026-1AB14,3RW3034-1AB14,3RW3035-1AB14,3RW3036-1AB14,3RW3044-1AB14,3RW3045-1AB14,3RW3457-0DC44,3RW3457-0DC44,3RW3458-0DC44,3RW3465-0DC44,
3RW3466-0DC44,3RW3467-0DC44,3RW3472-0DC44,3RW3472-0DC44,3RW3483-0DC44,3RW3484-0DC44;
电子式软起动机3RW34:3RW3454-0DC4,3RW3455-0DC4,3RW3457-0DC4,3RW3458-0DC4,3RW3465-0DC4,3RW3466-0DC4,3RW3467-0DC4,3RW3472-0DC4,
3RW3483-0DC4,3RW3484-0DC4,3RW3486-0DC4;
电子式软起动机3RW22:3RW2221-1A5,3RW2221-1A5,3RW2223-1A5,3RW2223-1A5,3RW2225-1A5,3RW2225-1A5,3RW2226-1A5,3RW2227-1A5,3RW2228-1A5,
3RW2230-1A5,3RW2231-1A5,3RW2231-1A5,3RW2234-0DB15,3RW2235-0DB15,3RW2236-0DB15,3RW2238-0DB15,3RW2238-0DB15,3RW2240-0DB15,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

3RW2241-0DB15,3RW2242-0DB1,3RW2243-0DB1,3RW2243-0DB1,3RW2245-0DB1,3RW2247-0DB1,3RW2250-0DB1;

3RW22SIKO START电子式电动机软起动

器:3RW2221-1AB15,3RW2223-1AB15,3RW2225-1AB15,3RW2226-1AB15,3RW2227-1AB15,3RW2228-1AB15,
3RW2230-1AB15,3RW2231-1AB15,3RW2234-0DB15,3RW2235-0DB15,3RW2236-0DB15,3RW2238-0DB15,3RW2240-0DB15,3R
W2241-0DB15,3RW2242-0DB14,3RW2243-0DB14,3RW2245-0DB14,3RW2247-0DB14,3RW2250-0DB14,3RW2242-0DB15,3RW2
243-0DB15,3RW2245-0DB15,3RW2247-0DB15,3RW2250-0DB15,3RW2236-0DB18,3RW2240-0DB18,3RW2242-0DB18;

3RW34SIKO START电子式电动机软起动

器:3RW3454-0DC24,3RW3455-0DC24,3RW3457-0DC24,3RW3457-0DC24,3RW3458-0DC24,3RW3465-0DC24,
3RW3466-0DC24,3RW3467-0DC24,3RW3472-0DC24,3RW3483-0DC24,3RW3484-0DC24,3RW3486-0DC24,3RW3454-0DC25,3R
W3455-0DC25,3RW3457-0DC25,3RW3458-0DC25,3RW3465-0DC25,3RW3466-0DC25,3RW3467-0DC25,3RW3472-0DC25,3RW3
483-0DC25,3RW3484-0DC25,3RW3486-0DC25,3RW3454-0DC24,3RW3455-0DC24,3RW3457-0DC24,3RW3458-0DC24,3RW346
5-0DC24,3RW3466-0DC24,3RW3467-0DC24,3RW3472-0DC24,3RW3483-0DC24,3RW3484-0DC24,3RW3486-0DC24,3RW3454-0
DC25,3RW3455-0DC25,3RW3457-0DC25,3RW3458-0DC25,3RW3465-0DC25,3RW3467-0DC25,3RW3472-0DC25,3RW3483-0DC
25,3RW3484-0DC25,3RW3486-0DC25,3RW3454-0DC44,3RW3455-0DC44,3RW3457-0DC44,3RW3458-0DC44,3RW3465-0DC44,
3RW3466-0DC44,3RW3467-0DC44,3RW3472-0DC44,3RW3483-0DC44,3RW3484-0DC44,3RW3486-0DC44,3R
W3486-0DC44,3RW3454-0DC45,3RW3455-0DC45,3RW3457-0DC45,3RW3458-0DC45,3RW3465-0DC45,3RW3466-0DC45,3RW3
467-0DC45,3RW3472-0DC45,3RW3483-0DC45,3RW3484-0DC45,3RW3484-0DC45,3RW3486-0DC45,3RW3486-0DC45,3RW345
4-0DC44,3RW3455-0DC44,3RW3457-0DC44,3RW3458-0DC44,3RW3465-0DC44,3RW3466-0DC44,3RW3467-0DC44,3RW3472-0
DC44,3RW3483-0DC44,3RW3484-0DC44,3RW3486-0DC44,3RW3454-0DC45,3RW3455-0DC45,3RW3457-0DC45,3RW3458-0DC
45,3RW3465-0DC45,3RW3467-0DC45,3RW3472-0DC45,3RW3483-0DC45,3RW3484-0DC45,3RW3486-0DC45,3RW3486-0DC45;

SIRIUS3R电子式电动机软起动器:3RW3014-1CB04,

3RW3016-1CB04,3RW3024-1AB04,3RW3025-1AB04,3RW3026-1AB04,3RW3034-1AB04,3RW3035-1AB04,
3RW3036-1AB04,3RW3044-1AB04,3RW3045-1AB04, 3RW3046-1AB04,
3RW3026-1AB05,3RW3034-1AB05,3RW3035-1AB05,3RW3036-1AB05,3RW3044-1AB05,
3RW3045-1AB05,3RW3045-1AB05,3RW3046-1AB05,3RW3016-1CB14,3RW3024-1AB14,3RW3025-1AB14,3RW3026-1AB1,43RW
3034-1AB14,3RW3035-1AB14,
3RW3036-1AB14,3RW3044-1AB14,3RW3045-1AB14,
3RW3046-1AB04,3RW3024-1AB05,3RW3025-1AB05,3RW3034-1AB05,3RW3035-1AB05,3RW3036-1AB05,
3RW3044-1AB05,3RW3045-1AB05,3RW3046-1AB05;

芯片级维修智能马达控制器

芯片级维修美国 **AB (ALLEN-BRADLEY)** 公司,罗克韦尔 (**ROCKWELLAUTOMATION**) 智能马达控制器:

TM 系列:150-C3NBD,150-C9NBD,150-C16NBD,150-C19NBD,150-C25NBD,150-C30NBD,150-C37NBD,150-A54NB,150-A54NB-NA,
150-A68NB,150-A68NB-NA,
150-A97NB,150-A97NB-NA,150-A97NBDB,150-A135NBD,150-A135NBDA,150-A135NBDB,150-A180NBD,150-A180NBDA,150-A1
80NBDB,150-A240NBD,
150-A240NBDA,150-A240NBDB,150-A360NBD,150-A360NBDA,150-A360NBDB,150-A500NBD,150-A500NBDA,150-A500NBDB,1
50-A650NBD,150-A650NBDA,
150-A650NBDB,150-A720NBD,150-A720NBDA,150-A720NBDB,150-A850NBD,150-A850NBDA,150-A850NBDB,150-A1000NBD,1
50-A1000NBDA,
150-A1000NBDB;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

STCTM 系列智能马达控制器:154-A11NL,154-A16NL,154-A22NL,154-A11NA,154-A16NA,154-A22NA,154-A11NA,154-A16NA,154-A22NA,154-A11NA,154-A16NA,

154-A22NA,154-A11NB,154-A16NB,154-A22NB;

SMC-2:150-A05NB,150-A05NB-NA,150-A09NB,150-A09NB-NA,150-A16NB,150-A16NB-NA,150-A24NB,150-A24NB-NA,150-A35NB,150-A35NB-NA,150-A54NB,

150-A54NB-NA,150-A68NB,150-A68NB-NA,150-A97NB,150-A97NB-NA,150-A05NC,150-A05NC-NA,150-A09NC,150-A09NC-NA,150-A16NC,150-A16NC-NA,

150-A24NC,150-A24NC-NA,150-A35NC,150-A35NC-NA,150-A54NC,150-A54NC-NA,150-A68NC,150-A68NC-NA,150-A97NC,150-A97NC-NA;

SMC-Delta 系列智能马达控制器:150-D3NBD,150-D3NBR,150-D9NBD,150-D9NBR,150-D16NBD,150-D16NBR,150-D20NBD,150-D20NBR,150-D25NBD,

150-D25NBR,150-D32NBD,150-D32NBR,150-D51NBD,150-D51NBR,150-D64NBD,150-D64NBR,150-D3NCD,150-D3NCR,150-D9NCD,150-D9NCR,150-D16NCD,

150-D16NCR,150-D20NCD,150-D20NCR,150-D25NCD,150-D25NCR,150-D32NCD,150-D32NCR,150-D51NCD,150-D51NCR,150-D64NCD,150-D64NCR,

150-D64NCD,150-D74NCD,150-D104NCD,150-D147NCD,150-D74NCR,150-D104NCR,150-D147NCR;

SMC-3 系列智能马达控制器:150-C3NBD,150-C3NBR,150-C9NBD,150-C9NBR,150-C16NBD,150-C16NBR,150-C19NBD,150-C19NBR,150-C25NBD,150-C25NBR,

150-C30NBD,150-C30NBR,150-C37NBD,150-C37NBR,150-C3NCD,150-C3NCR,150-C9NCD,150-C9NCR,150-C16NCD,150-C16NCR,150-C19NCD,150-C19NCR,

150-C25NCD,150-C25NCR,150-C30NCD,150-C30NCR,150-C37NCD,150-C37NCR;

SMC-YD/SMC-DP 系列智能马达控制器:150YD-A52NA1-7FA2,150YD-A64NA1-7FA2,150YD-A78NA1-7FA2,150YD-A104NA1-7FA2,150YD-A146NA1-7FA2,

150YD-A168NA1-7FA2,150YD-A52NB1-7FA2,150YD-A64NB1-7FA2,150YD-A78NB1-7FA2,150YD-A104NB1-7FA2,150YD-A146NB1-7FA2,150YD-A168NB1-7FA2,

150YD-A52NC1-7FA2,150YD-A64NC1-7FA2,150YD-A78NC1-7FA2,150YD-A104NC1-7FA2,150YD-A146NC1-7FA2,150YD-A168NC1-7FA2;

SMC Plus 系列智能马达控制器:150-A24NBD,150-A24NBDA,150-A35NBD,150-A35NBDA,150-A54NBD,150-A54NBDA,150-A97NBD,150-A97NBDA,150-A135NBD,

150-A135NBDA,150-A180NBD,150-A180NBDA,150-A240NBD,150-A240NBDA,150-A360NBD,150-A360NBDA,150-A500NBD,150-A500NBDA,150-A650NBD,

150-A650NBDA,150-A720NBD,150-A720NBDA,150-A850NBD,150-A850NBDA,150-A1000NBD,150-A1000NBDA,150-A24NBDB,150-A35NBDB,150-A54NBDB,

150-A97NBDB,150-A135NBDB,150-A180NBDB,150-A240NBDB,150-A360NBDB,150-A500NBDB,150-A650NBDB,150-A720NBDB,150-A850NBDB,

150-A1000NBDB;

SMC DialoG Plus 系列智能马达控制器:150-B24NBD,150-B24NBDA,150-B35NBD,150-B35NBDA,150-B54NBD,150-B54NBDA,150-B97NBD,150-B97NBDA,

150-B135NBD,150-B135NBDA,150-B180NBD,150-B180NBDA,150-B240NBD,150-B240NBDA,150-B360NBD,150-B360NBDA,150-B500NBD,150-B500NBDA,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

150-B650NBD,150-B650NBDA,150-B720NBD,150-B720NBDA,150-B850NBD,150-B850NBDA,150-B1000NBD,150-B1000NBDA;
MV DialoG PlusTM系列智能马达控制
器:**BulletiN1560D,BulletiN1562D**; ,150-F5NBD,150-F25NBD,150-F43NBD,150-F60NBD,150-F85NBD,150-F108NBD,
150-F135NBD,150-F201NBD,150-F251NBD,150-F317NBD,150-F361NBD,150-F480NBD,150-F5NBD,150-F25NBD,150-F43NBD,1
50-F60NBD,150-F85NBD,
150-F108NBD,150-F135NBD,150-F201NBD,150-F251NBD,150-F317NBD,150-F361NBD,150-F480NBD,150-F5NBD,150-F25NBD,
150-F43NBD,150-F60NBD,
150-F85NBD,150-F108NBD,150-F135NBD,150-F201NBD,150-F251NBD,150-F317NBD,150-F361NBD,150-F480NBD,150-F5NBDB
,150-F25NBDB,150-F43NBDB,
150-F60NBDB,150-F85NBDB,150-F108NBDB,150-F135NBDB,150-F201NBDB,150-F251NBDB,150-F317NBDB,150-F361NBDB,15
0-F480NBDB,150-B24NBDB,
150-B35NBDB,150-B54NBDB,150-B97NBDB,150-B135NBDB,150-B180NBDB,150-B240NBDB,150-B360NBDB,150-B500NBDB,15
0-B650NBDB,150-B720NBDB,
150-B850NBDB,150-B1000NBDB,150-B24NCD,150-B24NCDA,150-B24NCDB,150-B35NCD,150-B35NCDA,150-B35NCDB,150-B5
4NCD,150-B54NCDA,
150-B54NCDB,150-B97NCD,150-B97NCDA,150-B97NCDB,150-B135NCD,150-B135NCDA,150-B135NCDB,150-B180NCD,150-B1
80NCDA,150-B180NCDB,
150-B240NCD,150-B240NCDA,150-B240NCDB,150-B360NCD,150-B360NCDA,150-B360NCDB,150-B500NCD,150-B500NCDA,15
0-B500NCDB,150-B650NCD,
150-B650NCDA,150-B650NCDB,150-B720NCD,150-B720NCDA,150-B720NCDB,150-B850NCD,150-B850NCDA,150-B850NCDB,
150-B1000NCD,
150-B1000NCDA,150-B1000NCDB;
芯片级维修各种直流调速器
芯片级维修**ABB**直流调速器:
DCS400晶闸管变频器直流传动系统:DCS401.0020,DCS401.0045,DCS401.0065,DCS401.0090,DCS401.0125,DCS401.0180,DCS40
1.0230,DCS401.0315,
DCS401.0405,DCS401.0500,DCS401.0610,DCS401.0740,DCS401.0900,DCS402.0025,DCS402.0050,DCS402.0075,DCS402.0100,
DCS402.0140,DCS402.0200,
DCS402.0260,DCS402.0350,DCS402.0450,DCS402.0550,DCS402.0680,DCS402.0820,DCS402.1000;
DCS500系列**12**脉冲直流调速器:DCS50xB0025-41/51,DCS50xB0050-41/51,DCS50xB0075-41/51,DCS50xB0100-41/51,DCS501B01
40-41/51,DCS502B0140-41/51,
DCS501B0200-41/51,DCS502B0200-41/51,DCS501B0250-41/51,DCS502B0250-41/51,DCS501B0350-41/51,DCS502B0350-41/51,
DCS501B0450-41/51,
DCS502B0450-41/51,DCS501B0520-41/51,DCS502B0520-41/51,DCS501B0680-41/51,DCS502B0680-41/51,DCS501B0820-41/51,
DCS502B0820-41/51,
DCS501B1000-41/51,DCS502B1000-41/51,DCS50xB1203-41/51,DCS50xB1503-41/51,DCS50xB2003-41/51,DCS50xB2053-51,DC
S501B2503-41/51,
DCS502B2503-41/51,DCS501B3003-41/51,DCS502B3003-41/51,,DCS50xB3303-41/51,DCS50xB4003-41/51,DCS50xB5203-41/51,
DCS50xB0050-61,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

DCS501B0110-61,DCS502B0110-61,DCS501B0270-61,DCS502B0270-61,DCS501B0450-61,DCS502B0450-61,DCS50xB0903-61/71,DCS50xB1503-61/71,
DCS501B2003-61/71,DCS50xB2053-61/71,DCS501B2503-61/71,DCS502B2503-61/71,DCS501B3003-61/71,DCS502B3003-61/71,DCS50xB3303-61/71,
DCS50xB4003-61/71,DCV50xB4803-61/71,DCS50xB1903-81,DCS501B2503-81,DCS502B2503-81,DCS501B3003-81,DCS502B3003-81,DCS50xB3303-81,
DCS50xB4003-81,DCS50xB4803-81,DCS50xB2053-91,DCS50xB2603-91,DCS50xB3303-91,DCS50xB4003-91;
DCS600系列直流调速器 (DCS600MultiDrive) :DCS60x-0025-41/51,DCS60x-0050-41/51,DCS60x-0075-41/51,DCS60x-0100-41/51,DCS601-0140-41/51,
DCS602-0140-41/51,DCS601-0200-41/51,DCS602-0200-41/51,DCS601-0250-41/51,DCS602-0250-41/51,DCS601-0350-41/51,DCS602-0350-41/51,
DCS601-0450-41/51,DCS602-0450-41/51,DCS601-0520-41/51,DCS602-0520-41/51,DCS601-0680-41/51,DCS602-0680-41/51,DCS601-0820-41/51,
DCS602-0820-41/51,DCS601-1000-41/51,DCS602-1000-41/51,DCS60x-1203-41/51,DCS60x-1503-41/51,DCS60x-2003-41/51,DCS60x-2500-41/51,
DCS60x-3300-41/51,DCS60x-4000-41/51,DCS60x-5150-41/51,DCS60x-0050-61,DCS601-0110-61,DCS602-0110-61,DCS601-0270-61,DCS602-0270-61,
DCS601-0450-61,DCS602-0450-61,DCS60x-0903-61/71,DCS60x-1503-61/71,DCS601-2003-61/71,DCS60x-2050-61/71,DCS60x-2500-61/71,DCS60x-3300-61/71,
DCS60x-4000-61/71,DCV60x-4750-61/71,DCS60x-2050-81,DCS60x-3200-81,DCS60x-4000-81,DCS60x-4750-81,DCS60x-2050-91,DCS60x-2650-91,
DCS60x-3200-91,DCS60x-4000-91;
DCS800直流传动:DCS800-S01-0020-04/05,DCS800-S01-0045-04/05,DCS800-S02-0050-04/05,DCS800-S01-0065-04/05,DCS800-S02-0075-04/05,
DCS800-S01-0090-04/05,DCS800-S02-0100-04/05,DCS800-S01-0125-04/05,DCS800-S02-0140-04/05,DCS800-S01-0180-04/05,DCS800-S02-0200-04/05,
DCS800-S01-0230-04/05,DCS800-S02-0260-04/05,DCS800-S01-0315-04/05,DCS800-S02-0350-04/05,DCS800-S01-0405-04/05,DCS800-S02-0450-04/05,
DCS800-S01-0470-04/05,DCS800-S02-0520-04/05,DCS800-S01-0610-04/05,DCS800-S02-0680-04/05,DCS800-S01-0740-04/05,DCS800-S02-0820-04/05,
DCS800-S01-0900-04/05,DCS800-S02-1000-04/05,DCS800-S01-1200-04/05,DCS800-S02-1200-04/05,DCS800-S01-1500-04/05,DCS800-S02-1500-04/05,
DCS800-S01-2000-04/05,DCS800-S02-2000-04/05,DCS800-S01-2050-05,DCS800-S02-2050-05,DCS800-S01-2500-04/05,DCS800-S02-2500-04/05,
DCS800-S01-3000-04/05,DCS800-S02-3000-04/05,DCS800-S01-3300-04/05,DCS800-S02-3300-04/05,DCS800-S01-4000-04/05,DCS800-S02-4000-04/05,
DCS800-S01-5200-04/05,DCS800-S02-5200-04/05,DCS800-S01-0290-06,DCS800-S02-0320-06,DCS800-S01-0590-06,DCS800-S02-0650-06,
DCS800-S01-0900-06/07,DCS800-S02-0900-06/07,DCS800-S01-1500-06/07,DCS800-S02-1500-06/07,DCS800-S01-2000-06/07,DCS800-S02-2050-06/07,

公司地址:武汉市洪山区雄楚大街 699 号
业务联系电话:027-63005490 027-51778300 13487094272
网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理
传真:027-51778300
邮编:430074

武汉市中江科技有限公司维修内容列表

DCS800-S02-2050-06/07,DCS800-S01-2500-06/07,DCS800-S02-2500-06/07,DCS800-S01-3000-06/07,DCS800-S02-3000-06/07,DCS800-S01-3300-06/07,

DCS800-S02-3300-06/07,DCS800-S01-4000-06/07,DCS800-S02-4000-06/07,DCS800-S01-4800-06/07,DCS800-S02-4800-06/07,DCS800-S01-1900-08,

DCS800-S02-1900-08,DCS800-S01-2500-08,DCS800-S02-2500-08,DCS800-S01-3000-08,DCS800-S02-3000-08,DCS800-S01-3300-08,DCS800-S02-3300-08,

DCS800-S01-4000-08,DCS800-S02-4000-08,DCS800-S01-4800-08,DCS800-S02-4800-08,DCS800-S01-2050-10,DCS800-S02-2050-10,DCS800-S01-2600-10,

DCS800-S02-2600-09,DCS800-S01-3300-10,DCS800-S02-3300-09,DCS800-S01-4000-10,DCS800-S02-4000-09;

DCR500B/DCR600直流传动:DCR501B0000-00-2100000,DCR501-0000-00-1100000,DCR501-0000-00-2100000,DCR502B,DCR601-0000-00-15000A0,DCR602;

芯片级维修保德 (BALDOR) 直流调速器:

BC155 SOLID STATE DC MOTOR SPEED CONTROL;BC140 SOLIDSTATE DC MOTOR SPEED CONTROL;BC141、BC142、BC142-6SUPPLEMENTA;

BC154ANDBCW140ADJUSTABLESPEEDDCCONTROL;BC138-BC139DCCONTROL;BC160NEMA4XDCCONTROL;BC202、BC212DCCONTROL;

BC20 (5HP) DCCONTROL;BC200&BC201DCCONTROL;

BC153 ELECTRONIC FORWARD BRAKE REVERSE;BC212 BIPOLAR SIGNAL ISOLATOR FOR BC200,

BC201,BC202,BC203;BC204DCCONTROL;BC440-6&BC450-6DIGITALDCSpeedControl;SERIES19HDigitalDCSCRControl:BC19H205-CO,BC19H210-CO,

BC19H420-CO,BC19H215-CO,BC19H430-CO,BC19H220-CO,BC19H440-CO,BC19H225-CO,BC19H450-CO,BC19H240-CO,BC19H475-CO,BC19H250-CO,

BC19H4100-CO,BC19H260-CO,BC19H4125-CO,BC19H275-CO,BC19H4150-CO,BC19H4200-CO,BC19H4250-CO,BC19H4300-CO;

Subfractional Motor Speed Control for Permanent Magnet Motor Series BC110、115、130;

芯片级维修CT直流调速器:

MentoR II DC Drives:M25,M25R,M45,M45R,M75,M75R,M105,M105R,M155,M155R,M210,M210R,M350,M350R,M420,M420R,M550,M550R,M700,M700R,M825,

M825R,M900,M900R,M1200,M1200R,M1850,M1850R;

芯片级维修KB直流调速器:KBAP-240D,KBIC-120,KBIC-125,KBIC-240,KBIC-225,KBIC-240D,KBIC-240DS,KBMM-125,KBMM-225,KBMM-225D;

芯片级维修LENZE直流调速器

4800/4900:EVD4902-E,EVD4903-E,EVD4904-E,EVD4905-E,EVD4906-E,EVD4907-E,EVD4908-E,EVD4909-E,EVD4911-E,EVD4912-E,EVD4913,EVD4808-E,

EVD4809-E,EVD4811-E,EVD4812-E,EVD4813,EVD4903-E-V014,EVD4904-E-V014,EVD4905-E-V014,EVD4906-E-V014,EVD4907-E-V014,EVD4808-E-V014,

EVD4809-E-V014,EVD4811-E-V014,EVD4812-E-V014,EVD4813-E-V014;

芯片级维修施奈德TELEMECANIQUE直流调速器:

DCV94/104全数字直流调速器:DCV104D40S,DCV104D70S,DCV104C11S,DCV104C18S,DCV104C28S,DCV104C42S,DCV104C65S,DCV104C77S,DCV104M11S,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

DCV104M15S,DCV104M14Y,DCV104M20S,DCV104M20Y,DCV104M27S,DCV104M27Y,DCV94D70S,DCV94C11S,DCV94C18S,DCV94C28S,DCV94C42S,
DCV94C65S,DCV94C77S,DCV94M10SDCV94M15S,DCV94M14Y,DCV94M20S,DCV94M20Y,DCV94M27S,DCV94M27Y,
RTV直流调速器:RTV641D16Q,RTV84D16Q,RTV641D32Q,RTV641D32S,RTV84D32Q,RTV84D32S,RTV641D48Q,RTV641D48S,R
TV84D48Q,RTV84D48S,
RTV641D72Q,RTV641D72S,RTV84D72Q,RTV84D72S,RTV641C18Q,RTV641C18S,RTV84C18Q,RTV84C18S,RTV641C27Q,RTV
641C27S,RTV84C27Q,
RTV84C27S,RTV641C40Q,RTV641C40S,RTV84C40Q,RTV84C40S,RTV641C65QRTV641C65S,RTV84C65Q,RTV84C65S,RTV64
1C80Q,RTV641C80S,
RTV84C80Q,RTV84C80S,RTV641M12Q,RTV641M12S,RTV84M12Q,RTV84M12S,RTV641M12Y,RTV84M12Y,RTV641M17Q,RTV
641M17S,RTV84M17Q,
RTV84M17S,RTV641M17Y,RTV84M17Y,RTV641M30Q,RTV641M30S,RTV641M30Y,RTV84M30Q,RTV84M30S,RTV84M30Y,RTV
541D32Q,RTV541D32S,
RTV74D32Q,RTV74D32S,RTV541D48Q,RTV541D48S,RTV74D48Q,RTV74D48S,RTV541D72Q,RTV541D72S,RTV74D72Q,RTV7
4D72S,RTV541C18Q,
RTV541C18S,RTV74C18Q,RTV74C18S,RTV541C27Q,RTV541C27S,RTV74C27Q,RTV74C27S,RTV541C40Q,RTV541C40S,RTV
74C40Q,RTV74C40S,
RTV541C65Q,RTV541C65S,RTV74C65Q,RTV74C65S,RTV541C80Q,RTV541C80S,RTV74C80Q,RTV74C80S,RTV541M12Q,RTV
541M12S,RTV74M12Q,
RTV74M12S,RTV541M12Y,RTV74M12Y,RTV541M17QRTV541M17S,RTV74M17Q,RTV74M17S,RTV541M17Y,RTV74M17Y,RTV6
41M30Q,RTV641M30S,
RTV641M30Y,RTV84M30Q,RTV84M30S,RTV84M30Y;

芯片级维修欧陆直流调速器:

EUROTHERM DRIVES 590+SerieS DC Digital Drive:591P/0015/220/,590P/0015/220/,591P/0035/220/,590P/0035/220/,591P/0
015/500/,590P/0015/500/,
591P/0035/500/,590P/0035/500/,591P/0040/220/,590P/0040/220/,591P/0070/220/,590P/0070/220/,591P/0110/220/,590P/0110/220/,
591P/0165/220/,590P/0165/220/,
591P/0040/500/,590P/0040/500/,591P/0070/500/,590P/0070/500/,591P/0110/500/,590P/0110/500/,591P/0165/500/,590P/0165/500/,
591P/0180/220/,590P/0180/220/,
591P/0270/220/,590P/0270/220/,591P/0180/500/,590P/0180/500/,591P/0270/500/,590P/0270/500/,591P/0380/220/,590P/0380/220/,
591P/0500/220/,590P/0500/220/,
591P/0725/220/,590P/0725/220/,591P/0830/220/,590P/0830/220/,591P/0380/500/,590P/0380/500/,591P/0500/500/,590P/0500/500/,
591P/0725/500/,590P/0725/500/,
591P/0830/500/,590P/0830/500/,591P/0380/600/,590P/0380/600/,591P/0500/600/,590P/0500/600/,591P/0725/600/,590P/0725/600/,
591P/0830/600/,590P/0830/600/,
591P/0380/220/,590P/0380/220/,591P/0500/220/,590P/0500/220/,591P/0725/220/,590P/0725/220/,591P/0830/220/,590P/0830/220/,
591P/0380/500/,590P/0380/500/,
591P/0500/500/,590P/0500/500/,591P/0725/500/,590P/0725/500/,591P/0830/500/,590P/0830/500/,591P/0380/600/,590P/0380/600/,
591P/0500/600/,590P/0500/600/,
591P/0725/600/,590P/0725/600/,591P/0830/600/,590P/0830/600/,591P/1580/220/,590P/1580/220/,591P/1580/500/,590P/1580/500/,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

591P/1580/600/,590P/1580/600/,
591P/1580/220/,590P/1580/220/,591P/1580/500/,590P/1580/500/,591P/1580/600/,590P/1580/600/,591P/1200/500/,590P/1200/500/,
591P/1700/500/,590P/1700/500/,
591P/2200/500/,590P/2200/500/,591P/2700/500/,590P/2700/500/,591P/1200/690/,590P/1200/690/,591P/1700/690/,590P/1700/690/,
591P/2200/690/,590P/2200/690/,
591P/2700/690/,590P/2700/690/,591P/1200/500/,590P/1200/500/,591P/1700/500/,590P/1700/500/,591P/2200/500/,590P/2200/500/,
591P/2700/500/,590P/2700/500/,
591P/1200/690/,590P/1200/690/,591P/1700/690/,590P/1700/690/,591P/2200/690/,590P/2200/690/,591P/2700/690/,590P/2700/690/;
英国欧陆**512C/514C**直流调速器:512C/04,512C/08,512C/16,512C/32;
芯片级维修西门子直流调速器:
SIMOREGDC-MASTER6RA70:6RA7018-6DS22,6RA7025-6DS22,6RA7028-6DS22,6RA7031-6DS22,6RA7075-6DS22,6RA7078-6DS22,6RA7081-6DS22,
6RA7085-6DS22,6RA7087-6DS22,6RA7091-6DS22,6RA7093-4DS22,6RA7095-4DS22,6RA7098-4DS22,6RA7018-6FS22,6RA7025-6FS22,6RA7028-6FS22,
6RA7031-6FS22,6RA7075-6FS22,6RA7078-6FS22,,6RA7082-6FS22,6RA7085-6FS22,6RA7087-6FS22,6RA7091-6FS22,6RA7025-6GS22,6RA7031-6GS22,
6RA7075-6GS22,6RA7081-6GS22,6RA7085-6GS22,6RA7087-6GS22,6RA7090-6GS22,6RA7093-4GS22,6RA7095-4GS22,6RA7096-4GS22,6RA7097-4GS22,
6RA7086-6KS22,6RA7088-6KS22,6RA7093-4KS22,6RA7095-4KS22,6RA7097-4KS22,6RA7088-6LS22,6RA7093-4LS22,6RA7095-4LS22,6RA7096-4MS22,
6RA7013-6DV62,6RA7018-6DV62,6RA7025-6DV62,6RA7028-6DV62,6RA7031-6DV62,6RA7075-6DV62,6RA7078-6DV62,6RA7081-6DV62,6RA7085-6DV62,
6RA7087-6DV62,6RA7091-6DV62,6RA7093-4DV62,6RA7095-4DV62,6RA7098-4DV62,6RA7018-6FV62,6RA7025-6FV62,6RA7028-6FV62,6RA7031-6FV62,
6RA7075-6FV62,6RA7078-6FV62,6RA7082-6FV62,6RA7085-6FV62,6RA7087-6FV62,6RA7091-6FV62,6RA7025-6GV62,6RA7031-6GV62,6RA7075-6GV62,
6RA7081-6GV62,6RA7085-6GV62,6RA7087-6GV62,6RA7090-6GV62,6RA7093-4GV62,6RA7095-4GV62,6RA7096-4GV62,6RA7097-4GV62,6RA7086-6KV62,
6RA7090-6KV62,6RA7093-4KV62,6RA7095-4KV62,6RA7097-4KV62,6RA7088-6LV62,6RA7093-4LV62,6RA7095-4LV62,6RA7096-4MV62;
6RA22SIMOREGK:6RA2203-8DD21-0,6RA2211-8DD21-0,6RA2216-8DD21-0,6RA2221-8DD21-0,6RA2203-8DD21-1,6RA2211-8DD21-1,6RA2216-8DD21-1,
6RA2221-8DD21-1,6RA2220-8DS31,6RA2223-8DS31,6RA2226-8DS31,6RA2230-8DS31,6RA2232-8DS31,6RA2233-8DS31,6RA2276-8DS31,6RA2280-8DS31,
6RA2283-8DS31,6RA2203-8DK27-0,6RA2211-8DK27-0,6RA2216-8DK27-0,6RA2221-8DK27-0,6RA2203-8DK27-1,6RA2211-8DK27-1,6RA2216-8DK27-1,
6RA2221-8DK27-1,6RA2220-8DV71,6RA2223-8DV71,6RA2226-8DV71,6RA2230-8DV71,6RA2232-8DV71,6RA2233-8DV71,6RA2276-8DV71,6RA2280-8DV71,
6RA2283-8DV71;6DM1001-0WB00-25SD420,6DM1001-0WB00-25SD420,6DM1001-0WB00-25SD440,6DM1001-0WB00-25SD420,6DM1001-0WB00-25SD440,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6RA2200-8DD00,6RA8222-8PA0,6RA8222-1WB0;

SIMOREGK6RA28整流装置：6RA2818-6DS21-0,6RA2825-6DS21-0,6RA2828-6DS21-0,6RA2831-6DS21-0,6RA2875-6DS21-0,6RA2877-6DS21-0,

6RA2881-6DS21-0,6RA2885-6DS21-0,6RA2818-6DV61-0,6RA2825-6DV61-0,6RA2830-6DV61-0,6RA2832-6DV61-0,6RA2875-6DV61-0,6RA2877-6DV61-0,

6RA2881-6DV61-0,6RA2885-6DV61-0;

西门子**SIMOREGK**整流装

置:6RA2818-6DS21-0,6RA2825-6DS21-0,6RA2828-6DS21-0,6RA2831-6DS21-0,6RA2875-6DS21-0,6RA2877-6DS21-0,

6RA2881-6DS21-0,6RA2885-6DS21-0,6RA2818-6DV61-0,6RA2825-6DV61-0,6RA2830-6DV61-0,6RA2832-6DV61-0,6RA2875-6DV61-0,6RA2877-6DV61-0,6RA2881-6DV61-0,6RA2885-6DV61-0;

SIMOREGDC-MASTER:6RA7018-6DS22-0,6RA7025-6DS22-0,6RA7028-6DS22-0,6RA7031-6DS22-0,6RA7075-6DS22-0,6RA7078-6DS22-0,6RA7081-6DS22-0,

6RA7085-6DS22-0,6RA7087-6DS22-0,6RA7091-6DS22-0,6RA7093-4DS22-0,6RA7095-4DS22-0,6RA7025-6GS22-0,6RA7031-6GS22-0,6RA7075-6GS22-0,6RA7081-6GS22-0,6RA7085-6GS22-0,6RA7087-6GS22-0,6RA7090-6GS22-0,6RA7093-4GS22-0,6RA7095-4GS22-0,6RA7086-6KS22-0,6RA7088-6KS22-0,6RA7093-4K22-0,6RA7095-4KS22-0,6RA7088-6LS22-0,6RA7093-4LS22-0,6RA7095-4LS22-0,6RA7013-6DV62-0,6RA7018-6DV62-0,6RA7025-6DV62-0,6RA7028-6DV62-0,6RA7031-6DV62-0,6RA7075-6DV62-0,6RA7078-6DV62-0,6RA7081-6DV62-0,6RA7085-6DV62-0,6RA7087-6DV62-0,6RA7091-6DV62-0,6RA7093-4DV62-0,6RA7095-4DV62-0,6RA7025-6GV62-0,6RA7031-6GV62-0,6RA7075-6GV62-0,6RA7081-6GV62-0,6RA7085-6GV62-0,6RA7087-6GV62-0,6RA7090-6GV62-0,6RA7095-4GV62-0,6RA7086-6KV62-0,6RA7090-6KV62-0,6RA7093-4KV62-0,6RA7095-4KV62-0,6RA7088-6LV62-0,6RA7093-4LV62-0,6RA7095-4LV62-0,6RX1700-0AS00,6RX1700-0AK00,6RA7028-6DV62-0,6RA7031-6DV62-0,6RA7078-6DV62-0,6RB2000-0GA00,6RB2000-0GB01,6RB2000-0NE00,6RB2100-0NA11,

6RB2100-0NA21,6RB2130-0FD01,6RB2140-0FD01;

芯片级维修各种伺服驱动器

芯片级维修**ABB**交流伺服:

BivectorR 300/500:Bivector300-05/10,Bivector300-10/20,Bivector300-14/28,Bivector300-18/36,Bivector500-3,Bivector500-5,Bivector500-9,Bivector500-13,

Bivector500-18,Bivector500-25,DGV300,DGV700,DGV300R03,DGV300R05,DGV300R07,MVC300R03,MVC300R05,MVC300R07;

芯片级维修**B&R (Bernecker+Rainier Industrie-Elektronik GesmbH) ACOPOS**伺服驱动器:

ACOPOS1022,1045,1090系列伺服驱动器:8V102200-2,8V104500-2,8V109000-2,8AC11060-2,8AC11260-1,8AC12060-1,8AC12260-2,8AC12360-1,8AC13060-1,

8AC13160-1,0PS3201;**ACOPOS 1180,1320**系列伺服驱动器:7CP47660-1,8V118000-2,8V132000-2;**ACOPOS1640,128M**系列伺服驱动器:8V164000-2,8V128M00-2;

ACOPOS servo drives:

0AC912.9,0AC913.92,0PS320.1,7AC911.9,7TB712.9,7TB712.91,7TB712:90-02,7TB712:91-02,8AC110.60-2,8AC112.60-1,8AC120.60-1,

8AC122.60-2,8AC123.60-1,8AC130.60-1,8AC131.60-1,8CE005.12-1,8CE007.12-1,8CE010.12-1,8CE015.12-1,8CE020.12-1,8CE025.12-1,8CM005.12-1,8CM005.12-3,8CM005.12-5,8CM005.12-8,8CM007.12-1,8CM007.12-3,8CM007.12-5,8CM007.12-8,8CM010.12-1,8CM010.12-3,8CM010.12-5,8CM010.12-8,8CM015.12-1,8CM015.12-3,8CM015.12-5,8CM015.12-8,8CM020.12-1,8CM020.12-3,8CM020.12-5,8CM020.12-8,8CM025.12-1,8CM025.12-3,8CM025.12-5,8CM025.12-8,8CR005.12-1,8CR007.12-1,8CR010.12-1,8CR

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

015.12-1,8CR020.12-1,8CR025.12-1,8PE001.00-1,8PM001.00-1,8PM002.00-1,8PM003.00-1,8PR001.00-1,8V1022.00-2,8V1045.00-2,8V1090.00-2,8V1180.00-2,8V128M.00-2,8V1320.00-2,8V1640.00-2;

芯片级维修BALDOR伺服驱动器:

BRUSHLESS DC SERVOAMPLIFIERS UNIDRIVER(无刷直流伺服放大器):UM2-150W,BS2W-150,SH1-150,SPD1,BD2010-150;

MCC SERIES MOTIONCONTROL CARD:PROGRAMMABLEMOTIONCONTROLFORDCSERVOSSUM-4SERIES:SUM-4-100-1-02S-1,SUM-4-100-1-02S-1,SUM-4-100-1-02S-1,SUM-4-100-1-02S-1,SUM-4-100-1-02S-1,SUM-4-100-1-02S-1;

S-BTS10R-SerieS SmarT Brushless ServoAmplifier:S-BTS10R200-25,S-BTS10R200-5,S-BTS10R200-10,S-BTS10R200-15,S-BTS10R200-225,

BPS200-020R,BPS200-040R,BPS200-060R; **BRUSH TYPE SERVOAMPLIFIERS(有刷电机伺服放大器):**UM2015,UM4030,UM6045;

BTS10R/RL-SERIES BRUSHLESS SERVOAMPLIFIER:BTS200-1RL,BTS200-25RL,BTS200-5RL,BTS200-75RL,BTS200-10R,BTS200-15R,BTS200-225R,

BPS200-020R,BPS200-040R,BPS200-060R;

BTS15-SERIES SERVODRIVER FOR BRUSHLESS DC MOTOR:BTS15-C2-1R,BTS15-C2-2R,BTS15-C4-3RBTS15-C4-4R,BTS15-15-CR,BTS15-15-CH;

BTS10P/PAL-SERIES BRUSHLESS SERVOAMPLIFIER:BTS10P200-25,BTS10P200-5,BTS10P200-15,BTS10P200-225,BTS10P200-020P,BTS10P200-040P,

BTS10P200-060P,BTS20PA300-10,BTS20PA300-20,BTS20PA300-30,BTS20PA300-40,BTS20PA300-50,BPS20P30-060,BPS20P30-120,BPS20P30-240;

DBTS10R/RL-SERIES SERVOCONTROL FOR BRUSHLESS AC MOTORS:DBTS10-25RL,DBTS10-5RL,DBTS10-75RL,DBTS10-10R,DBTS10-15R,

DBTS10-225R

AC BRUSHLESS SERVOCONTROL BTS15-SERIES;SERIES23H AC ServoControl:SD23H2A03-E,SD23H2A04-E,SD23H2A04-W,SD23H2A07-E,

SD23H2A10-E,SD23H2A10-W,SD23H2A15-E,SD23H2A16-E,SD23H2A16-E,SD23H2A22-E,SD23H2A22-E,SD23H2A28-E,SD23H2A28-E,SD23H2A30-ER,

SD23H2A42-E,SD23H2A42-EO,SD23H2A45-ER,SD23H2A54-ER,SD23H2A55-ER,SD23H4A04-E,SD23H4A05-E,SD23H4A08-E,SD23H4A11-E,SD23H4A11-E,

SD23H4A14-E,SD23H4A14-E,SD23H4A15-E,SD23H4A15-E,SD23H4A15-ER,SD23H4A21-E,SD23H4A21-EO,SD23H4A-ER,SD23H4A27-ER,SD23H4A30-ER;

SerieS H2 CloseD Loop AC ServoControl:SHH2A03-E,SHH2A04-E,SHH2A07-E,SHH2A10-E,SHH2A15-E,SHH2A22-E,SHH2A28-E,SHH2A42-E,

SHH2A54-E,SHH4A03-E,SHH4A05-E,SHH4A08-E,SHH4A11-E,SHH4A14-E,SHH4A21-E,SHH4A27-E;

BALDOR MOTORS AND DRIVES (保德) THREE PHASE TORQUECONTROL:T70EA,T71EA,T72EA,T73EA,T80EA,T81EA,T82EA,T83EA;

TSD SERIES DC Servo Control:TSD-050-05-1-U,TSD-050-05-1-I,TSD-050-05-2-U,TSD-050-05-2-I,TSD-100-05-1-U,TSD-100-05-1-I,TSD-100-05-2-U,

TSD-100-05-2-I;

BSC SerieS1000/1100ServoControl foR Brushless AC Motors:BSC1002,BSC1102,BSC1105-1,BSC1005,BSC1105,BSC1100-1,BSC1010,BSC1110,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

BSC1115-1,BSC1015,BSC1115; **AC BRUSHLESS SERVOCONTROL BTS10/20SERIES:**BTS10P,BTS20P,BTS20PA,BPS10P,BPS20P;

AC BRUSHLESS SERVOCONTROL SBSC1000/1100SERIES:SBSC1002-24-1,SBSC1005-24-1,SBSC1010-24-1,SBSC1015-24-1,SBSC1102-24-1,

SBSC1105-24-1,SBSC1110-24-1,SBSC1115-24-1,SBSC1002-TH-1,SBSC1005-TH-1,SBSC1010-TH-1,SBSC1015-TH-1,SBSC1102-TH-1,SBSC1105-TH-1,

SBSC1110-TH-1,SBSC1115-TH-1,SBSC1002-24,SBSC1005-24,SBSC1010-24,SBSC1015-24,SBSC1102-24,SBSC1105-24,SBSC1110-24,SBSC1115-24,

SBSC1002-TH,SBSC1005-TH,SBSC1010-TH,SBSC1015-TH,SBSC1102-TH,SBSC1105-TH,SBSC1110-TH,SBSC1115-TH;

PULSEWIDTH MODULATED TRANSISTOR SERVODRIVES:TSNM60-6-01,TSNM90-6-01,TSNM150-6-01,TSNM180-6-01,TSNM200-6-01,TSNM60-12-01,

TSNM90-12-01,TSNM150-12-01,TSNM180-12-01,TSNM200-12-01,PSNM60-30-X,PSNM90-30-X,PSNM150-30-X,PSNM180-30-X,PSNM200-30-X,PSNM60-70-X,

PSNM90-70-X,PSNM150-70-X,PSNM180-70-X,PSNM200-70-X,RTSN1-C,RTSN2-C,RTSN3-C,RTSN4-C,RTSN5-C,RTSN6-C,RTSN1-D,RTSN2-D,RTSN3-D,

RTSN4-D,RTSN5-D,RTSN6-D,RTSN1-S,RTSN2-S,RTSN3-S,RTSN4-S,RTSN5-S,RTSN6-S;

DC ServOControl THM SERIES:THM180-20-01,THM180-30-01,THM180-40-01,THM180-60-01,THM180-90-01,THM200-20-01,THM200-30-01,THM200-40-01,

THM200-60-01,THM200-90-01,PHMCARD-1000,PHMCARD-1001,PHMCARD-1002,RTSH4K4,RTSH4K3,RTSH4K2,RTSH4K1,RTSH2K1,RTSH2K2,RRV2,RRV3;

DC ServOControl TFM SERIES:TFM60,TFM90,TFM120,TFM150,PSNM; **SERIES LD DC ServOControl:**LD2-O,LD4-O;

BALDOR MOTORS AND DRIVES (保德) SERVODRIVES UM SerieS DC ServO Control:UM2-100-1-10S,UM2-100-1-01S,UM2-150-1-01S,

UM2-100-1-20S,UM2-100-1-02S,UM2-150-1-02S,UM4-100-2-30S,UM4-100-2-03S,UM4-150-2-03S,UM4-100-2-40S,UM4-100-2-04S,UM4-150-2-04S,

UM6-100-2-50S,UM6-100-2-05S,UM6-150-2-05S,UM6-100-2-60S,UM6-100-2-06S,UM6-150-2-06S;

DBSC100SerieS AC ServOControl:DBSC102,DBSC105;**BPS SerieS 2000/3000 PoweRSupply foR DBSC2000/3000:**BPS2060,BPS2100,BPS3030,BPS3050;

D-BSCSerieS1000tO3000 ServOControl foR BrushlesS AC MotorS WITH DIGITAL COMTROL PLATFORM(DCP);DBSC

SerieS1000/1100 ServOControlfoR BrushlesS AC Motors:DBSC1002AAA-1,DBSC1005BAA-1,DBSC1010EAA-1,DBSC1015EBA-1,DBSC1102AAA-1,DBSC1105BAA-1,DBSC1110EAA-1,

DBSC1115EBA-1; **SerieS 29M ServOControl:**SD29M1A02-PR,SD29M1A05-PR,SD29M2A02-PR,SD29M2A05-PR;

DBSC SerieS2000/3000ServOControl foR BrushlesS AC Motors:DBSC2015,DBSC2025,DBSC2035,DBSC2045,DBSC3007DBSC3015DBSC3025DBSC3035;

SerieS 26M Multi-Axis ServOControl:SD26M1A02-TR,SD26M1A05-TR,SD26M1A07-TR,SD26M2A02-TR,SD26M2A05-TR,SD26M2A07-TR,SD26M2A05-PO,

SD26M2A10-PO,SD26M2A15-PO,SD26M2A25-PO,SD26M2A35-PO,SD26M2A45-PO,SD26M2A60-PO,SD26M2A90-PO,SD26M4A02-PO,SD26M4A07-PO,

SD26M4A15-PO,SD26M4A25-PO,SD26M4A35-PO,SD26M4A60-PO,SD26M4A90-PO,PSM2A060-PR2,PSM2A100-PR2,PSM2A060-PR1,PSM2A100-PR1,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

PSM4A030-PR2,PSM4A050-PR2,PSM4A100-PR2,PSM4A030-PR1,PSM4A050-PR1,PSM4A100-PR1;

FlexDrive ServOControl:FD1A02SR-XXXX,FD2A02SR-XXXX,FD1A02TR-XXXX,FD2A02TR-XXXX,FD4A02TB-XXXX,FD1A05SR-XXXX,FD1A05SR-XXXX,

FD1A05TR-XXXX,FD2A05TR-XXXX,FD4A05TB-XXXX,FD1A07TR-XXXX,FD2A07TR-XXXX,FD4A07TR-XXXX,FD1A10SR-XXXX,FD2A10SR-XXXX,

FD1A15SR-XXXX,FD2A15SR-XXXX,FD4A15TR-XXXX,FD4A20TR-XXXX,FD4A27TR-XXXX,FD1A02PO-XXXX,FD2A02PO-XXXX,FD1A05PO-XXXX,

FD2A05PO-XXXX,FD1A10PO-XXXX,FD2A10PO-XXXX,FD1A15PO-XXXX,FD2A15PO-XXXX;

Flex+Drive ServOControl:FP1A02SR-XXXX,FP2A02SR-XXXX,FP1A02TR-XXXX,FP2A02TR-XXXX,FP4A02TB-XXXX,FP1A05SR-XXXX,FP1A05SR-XXXX,

FP1A05TR-XXXX,FP2A05TR-XXXX,FP4A05TB-XXXX,FP1A07TR-XXXX,FP2A07TR-XXXX,FP4A07TR-XXXX,FP1A10SR-XXXX,FP2A10SR-XXXX,

FP1A15SR-XXXX,FP2A15SR-XXXX,FP4A15TR-XXXX,FP4A20TR-XXXX,FP4A27TR-XXXX,FP1A02PO-xxxx,FP2A02PO-xxxx,FP1A05PO-xxxx,FP2A05PO-xxxx,

FP1A10PO-xxxx,FP2A10PO-xxxx,FP1A15PO-xxxx,FP2A15PO-xxxx;

Flex+Drive and Mint Drive Brushless AC ServOControls:MDH1A02TB-RN20,MDH2A02TB-RN20,MDH1A05TB-RN20,MDH2A05TB-RN20,

MDH1A07TR-RN20,MDH2A07TR-RN20,MDH1A02TB-RN23,MDH2A02TB-RN23,MDH4A02TB-RN23,MDH1A05TB-RN23,MDH2A05TB-RN23,MDH4A05TB-RN23,

MDH1A07TR-RN23,MDH2A07TR-RN23,MDH4A07TR-RN23,MDH4A15TR-RN23,MDH4A20TR-RN23,MDH4A27TR-RN23,FPH1A02TB-RN20,FPH2A02TB-RN20,

FPH4A02TB-RN23,FPH1A05TB-RN20,FPH2A05TB-RN20,FPH4A05TB-RN23,FPH1A07TR-RN20,FPH2A07TR-RN20,FPH4A07TR-RN23,FPH4A15TR-RN23,

FPH4A20TR-RN23,FPH4A27TR-RN23,FDH1A02TB-RN20,FDH2A02TB-RN20,FDH4A02TB-RN23,FDH1A05TB-RN20,FDH2A05TB-RN20,FDH4A05TB-RN23,

FDH1A07TR-RN20,FDH2A07TR-RN20,FDH4A07TR-RN23,FDH4A15TR-RN23,FDH4A20TR-RN23,FDH4A27TR-RN23;

Micro Flex ServO Control:FMH1A03TR-EN23,FMH2A03TR-EN23,FMH2A06TR-EN23,FMH2A09TR-EN23,FMH1A03TR-RN23,FMH2A03TR-RN23,

FMH2A06TR-RN23,FMH2A09TR-RN23,FMH1A03TR-EN43,FMH2A03TR-EN43,FMH2A06TR-EN43,FMH2A09TR-EN43,FMH1A03TR-RN43,FMH2A03TR-RN43,

FMH2A06TR-RN43,FMH2A09TR-RN43,

Macro Drive ServOControl:MA1A02SR-XXXX,MA2A02SR-XXXX,MA1A02TR-XXXX,MA2A02TR-XXXX,MA4A02TB-XXXX,MA1A05SR-XXXX,MA1A05SR-XXXX,

MA1A05TR-XXXX,MA2A05TR-XXXX,MA4A05TB-XXXX,MA1A07TR-XXXX,MA2A07TR-XXXX,MA4A07TR-XXXX,MA1A10SR-XXXX,MA2A10SR-XXXX,

MA1A15SR-XXXX,MA2A15SR-XXXX,MA4A15TR-XXXX,MA1A02PO-XXXX,MA2A02PO-XXXX,MA1A05PO-XXXX,MA2A05PO-XXXX,MA1A10PO-XXXX,

MA2A10PO-XXXX,MA1A15PO-XXXX,MA2A15PO-XXXX; **LiNSteP Micros teppinG Driver:**LX1D1A07F9,LX2D1A06F9,LX1D2A03F9;

LiNDrive ServOControl:LD1A02SR-EN43,LD2A02SR-EN40,LD1A02TR-EN23,LD2A02TR-EN20,LD4A02TB-RN43,LD1A05SR-EN

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

40,LD1A05SR-EN23,
LD1A05TR-EN20,LD2A05TR-EN43,LD4A05TB-RN40,LD1A07TR-EN23,LD2A07TR-EN20,LD4A07TR-RN43,LD1A10SR-EN40,LD2
A10SR-EN23,LD1A15SR-EN20,
LD2A15SR-EN43,LD4A15TR-RN40,LD4A20TR-RN23,LD1A02PO-EN20,LD2A02PO-EN43,LD1A05PO-EN40,LD2A05PO-EN23,LD
1A10PO-EN20,LD2A10PO-EN43,
LD1A15PO-EN40,LD2A15PO-EN23;**Lin+DriveServOControl**:LP1A02SR-EC43,LP2A02SR-EC40,LP1A02TR-EC23,LP2A02TR-EC
20,LP4A02TB-EN43,
LP1A05SR-EN40,LP1A05SR-EN23,LP1A05TR-EN20,LP2A05TR-EXXX,LP4A05TB-EXXX,LP1A07TR-EXXX,LP2A07TR-EXXX,LP4
A07TR-EXXX,LP1A10SR-EXXX,
LP2A10SR-EXXX,LP1A15SR-EXXX,LP4A15TR-EXXX,LP4A20TR-EXXX,LP1A02PO-EXXX,LP2A02PO-EXXX,LP1A05PO-EXXX,L
P2A05PO-EXXX,
LP1A10PO-EXXX,LP2A10PO-EXXX,LP1A15PO-EXXX,LP2A15PO-EXXX;**LinStep+Dual-Axis Micro steppinG Indexer/Driver**:L
X2P1A06-2,LX2P2A06-2;
FlexDrive/Flex+Drive ServO Controls:FDH1A02TB-RC23,FPH1A02TR-EC20,FDH2A02TB-DC20,FPH2A02TR-RB20,FDH1A05T
R-EB20,FPH1A05TB-DB20,
FDH2A05TB-RC20,FPH2A05TB-EC23,FDH1A07TR-RC23,FPH1A07TR-RC20,FDH2A07TR-EC23,FPH2A07TB-DC23,FDH4A02TR
-DC23,FPH4A02TR-DC20,
FDH4A05TR-RB23,FPH4A05TR-EB23,FDH4A07TB-RB23,FPH4A07TB-EB20,FDH2A15TB-RB20,FPH2A15TB-EB23,FDH4A15TB-
DB23,FPH4A15TR-DB20,
FDH4A20TR-DB23,FDH1A05TB-RC23,FPH4A20xx-xxxx,FDH4A27xx-xxxx,FPH4A27xx-xxxx;
BSC SerieS2000/3000ServO Control:BSC2015-24,BSC2025-24,BSC2035-24,BSC2045-24,BSC3015-24,BSC3025-24,BSC3035-
24,BSC3045-24,BSC2015-MR,
BSC2025-MR,BSC2035-MR,BSC2045-MR,BSC3015-MR,BSC3025-MR,BSC3035-MR,BSC3045-MR; **Euro Flex ServOControl**:E
FL001-501;
BSC SerieS2000/3000ServO Control FOR BRUSHLESS AC MOTOR:SBSC2015-TH,SBSC2025-TH,SBSC2035-TH,SBSC204
5-TH,SBSC3015-TH,
SBSC3025-TH,SBSC3035-TH,SBSC3045-TH,SBSC2015-YUF,SBSC2025-YUF,SBSC2035-YUF,SBSC2045-YUF,SBSC3015-YUF,
SBSC3025-YUF,SBSC3035-YUF,
SBSC3045-YUF; **LinStep+Single-Axis Micro steppinG Indexer/Driver**:LX1P1A07F9,LX1P2A06,LX1P1A03;
芯片级维修DANAHERMOTION数字伺服放大器:
DANAHERMOTION数字伺服放大器servostaR600:servostaR601,servostaR603,servostaR606,servostaR610,servostaR614,servost
aR620,servostaR640,
servostaR670; **Servo staR300**:servostaR303,servostaR306,servostaR310,servostaR341,servostaR343,servostaR346;
芯片级维修LENZE伦次伺服驱动器:
9300标准型伺服控制器:EVS9321-ES,EVS9322-ES,EVS9323-ESE,VS9324-ES,EVS9325-ES,EVS9321-CS,EVS9322-CS,EVS9323-
CS,EVS9324-CS,EVS9325-CS,
EVS9326-ES,EVS9327-ES,EVS9328-ES,EVS9329-ES,EVS9330-ES,EVS9331-ES,EVS9332-ES,EVS9326-CS,EVS9327-CS,EVS93
28-CS;
9300 servO positioningcontroller:EVS9321-EP,EVS9322-EP,EVS9323-EP,EVS9324-EP,EVS9325-EP,EVS9321-CP,EVS9322-C
P,EVS9323-CP,EVS9324-CP,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

EVS9325-CP,EVS9326-EP,EVS9327-EP,EVS9328-EP,EVS9329-EP,EVS9330-EP,EVS9331-EP,EVS9332-EP,EVS9326-CP,EVS9327-CP,EVS9328-CP;

RegenerativE powersupplies9340:EMB9341-E,EMB9342-E,EMB9343-E;**9360 DC supply units:**EME9364-E,EME9365-E;

9300 ServO PLC:EVS9321-EI,EVS9322-EI,KEVS9323-EI,EVS9324-EI,EVS9325-EI,EVS9321-CI,EVS9322-CI,EVS9323-CI,EVS9324-CI,EVS9325-CI,EVS9326-EI,EVS9327-EI,EVS9328-EI,EVS9329-EI,EVS9330-EI,EVS9331-EI,EVS9332-EI,EVS9326-C,IEVS9327-CI,EVS9328-CI;

9300c aMprofiler:EVS9321-EK,EVS9322-EK,EVS9323-EK,EVS9324-EK,EVS9325-EK,EVS9321-CK,EVS9322-CK,EVS9323-CK,EVS9324-CK,EVS9325-CK,

EVS9326-EK,EVS9327-EK,EVS9328-EK,EVS9329-EK,EVS9330-EK,EVS9331-EK,EVS9332-EK,EVS9326-CK,EVS9327-CK,EVS9328-CK;

Global DrivE 9300 Planning:EVS9321-EX,EVS9322-EX,EVS9323-EX,EVS9324-EX,EVS9325-EX,EVS9326-EX,EVS9327-EX,EVS9328-EX,EVS9329-EX,

EVS9330-EX,EVS9331-EX,EVS9332-EX,EVS9321-CPV003,EVS9322-CPV003,EVS9323-CPV003,EVS9324-CPV003,EVS9325-CPV003,EVS9326-CPV003,

EVS9327-CPV003,EVS9328-CPV003;

Global DrivE9300 ServO register controller:EVS9321-ER,EVS9322-ER,EVS9323-ER,EVS9324-ER,EVS9325-ER,EVS9321-CR,EVS9322-CR,EVS9323-CR,

EVS9324-CR,EVS9325-CR,EVS9326-ER,EVS9327-ER,EVS9328-ER,EVS9329-ER,EVS9330-ER,EVS9331-ER,EVS9332-ER,EVS9326-CR,EVS9327-CR,

EVS9328-CR;

ECS servosystem:轴控制模

块:ECSxS004,ECSxS008,ECSxS016,ECSxS032,ECSxS048,ECSxS064,ECSxP004,ECSxP008,ECSxP016,ECSxP032,ECSxP048,ECSxP064,ECSxM004,ECSxM008,ECSxM016,ECSxM032,ECSxM048,ECSxM064,ECSxA004,ECSxA008,ECSxA016,ECSxA032,ECSxA048,ECSxA064;

INVERTER 8200

MOTEC:E82MV251-2B,E82MV371-2B,E82MV551-4B,E82MV751-4B,E82MV152-4B,E82MV222-4B,E82MV302-4B,E82MV402-4B,E82MV552-4B,

E82MV752-4B; 电源模块:ECSxE012,ECSxE020,ECSxE040;

芯片级维修路斯特 (LUST) 伺服驱动器:

CDD3000:CDD32003,Cxx,CDD32004-HF,CDD32006-HF,CDD32008-HF,CDD34003-HF,CDD34005-HF,CDD34006-HF,CDD34008-HF,CDD34010-HF,

CDD34014-HF,CDD34017-HF,CDD34024-HF,CDD34032-HF;(CDD34003,Cxx,CDD34005,Cxx1),CDD34006,Wxx,CDD34008,Wxx,CDD34010,Wxx,CDD34014,Wxx,

CDD34017,Wxx,CDD34024,Wxx,CDD34032,Wxx,CDD34045,Wxx,CDD34060,Wxx,CDD34072,Wxx,CDD34090,Wxx,CDD34110,Wxx,CDD34143,Wxx,

CDD34170Wxx; **Lust Servoconverter A-DS0061-0751:**A-DS0061,A-DS0121,A-DS0201,A-DS0351,A-DS0451,A-DS0551,A-DS0751;

Drive StarB-DS:B-DS0601,B-DS1251,B-DS1601;HS321BR,HS32200,HS322BR,HS342BR;ISA00,ISA01,OSA00,ISD00,ISD01,ISD02,ISD03,ENPO,OSD00,OSD01,

OSD02,PTC1/2,IED00,IED07,OED00,ED03; **Inverter modules for 230V systems:**CDA32004,Cxx,CDA32006,Cxx,CDA32008,Cx

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

x;

Inverter modules for400/460Vsystems:CDA34003,Cxx,CDA34005,Cxx,CDA34006,Wxx,CDA34008,Wxx,CDA34010,Wxx,CDA34014,Wxx,CDA34017,Wxx,

CDA34024,Wxx,CDA34032,Wxx,CDA34045,Wxx,CDA34060,Wxx,CDA34072,Wxx,CDA34090,Wxx,CDA34110,Wxx,CDA34143,Wxx,CDA34170,Wxx,

CDA34250,Wxx;CDS44017,CDS44032,CDA34003HF,CDD34003HF,CDA34005HF,CDD34005HF,CDA34006HF,CDD34006HF,CD A34008HF,CDD34008HF,

CDA34010HF,CDD34010HF,CDA34014HF,CDD34014HF,CDA34017HF,CDD34017HF,CDA34024HF,CDD34024HF,CDA34032HF,CDD34032HF,CDA34044HF,

CDD34044HF,CDA34058HF,CDD34058HF,CDA34070HF,CDD34070HF,CDA34088HF,CDD34088HF,CDA34108HF,CDD34108HF,CDA34140HF,CDD34140HF,

CDA34168HF,CDD34168HF;ED12005,ED12005,Cxx,KP100,BC1300; **Mains Module AEB3:**AEB0303,AEB1253,AKM1253;AER0403,AER1253,AER1603;

MC6000 Servo controller:MC6404,MC6408,MC6412,MC6416,MC6432,MC6464;**Drive Star powerpack type:**R-DS1251,R-DS1601;

Servosystem SO8000:SO84004,SO84006,SO84008,SO84012,SO84016,SO84020,SO84024,SO84032,SO84045,SO84060,SO84072,SO84090,SO84110,

SO84143,SO84170; **MC7000 Servo controller:**MC7402,MC7404,MC7408,MC7412,MC7416,MC7432,MC7464;

LUST Servo converter U-DS0061-0451:U-DS0061,U-DS0121,U-DS0201,U-DS0351,U-DS0451;

芯片级维修玛威诺伺服系统:

MAVILORSMT-BD1数字伺服系统:SMT-BD1-220/04,SMT-BD1-220/08,SMT-BD1-220/12,SMT-BD1-220/17,SMT-BD1-220/30,SMT-BD1-220/30r,SMT-BD1-220/60,

SMT-BD1-220/60r,SMT-BD1-220/70,SMT-BD1-220/100,SMT-BD1-400/15,SMT-BD1-400/30,SMT-BD1-400/45,SMT-BD1-400/60;

CD1-a系列数字伺服系统:CD1-a-230/225,CD1-a-230/45,CD1-a-230/75,CD1-a-230/105,CD1-a-230/18,CD1-a-230/25,CD1-a-230/51,CD1-a-230/72;

MSD1系列数字伺服驱动器:MSD13004,MSD13005,MSD13006,MSD13010,MSD13012,MSD13015,MSD15004,MSD15006,MSD15008;

MQA系列无刷直流同步电机伺服驱动器:MQA1204,MQA1206,MQA1208,MQA1210,MQA2404,MQA2406,MQA2410;

SMVE/N系列直流电机伺服驱动器:SMVE/N0510,SMVE/N0520,SMVE/N0530,SMVE/N2410,SMVE/N2420,SMVE/N2430;

MQC系列直流电机驱动器:MQC0606,MQC0608,MQC0610,MQC1206,MQC1208,MQC1210,MQC1510,MQC1515;

MESA伺服驱动器MSD1/A:MSD13004,MSD13006,MSD13008,MSD13010,MSD13012,MSD13015,MSD15004,MSD15006,MSD15008,MSD15010;

LXM05A交流伺服驱动装置:LXM05D10F1,LXM05D17F1,LXM05D28F1,LXM05D10M2,LXM05D17M2D28M2,LXM05D10M3X,LXM05D17M3X,

LXM05D42M3X,LXM05D14N4,LXM05D22N4,LXM05D34N4D57N4; **OEMAX伺服控制器:**CSDP-15BX2,CSDP-20BX2,CSDP-30BX2,CSDP-40BX2,CSDP-50BX2;

芯片级维修富士**FALDIC-β**伺服驱动器:RYB500S3-VBC,RYB101S3-VBC,RYB201S3-VBC,RYB401S3-VBC,RYB751S3-VBC,RYB500S3-VBC6,RYB101S3-VBC6,

RYB201S3-VBC6,RYS500S3-VVS,RYS101S3-VVS,RYS201S3-VVSRYS401S3-VVS,RYS751S3-VVS,RYS102S3-VVS,RYS152S3-VVS,RYS202S3-VVS,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

RYS302S3-VVS,RYS402S3-VVS,RYS502S3-VVS,RYS500S3-VVS6,RYS101S3-VVS6,RYS201S3-VVS6,RYS500S3-VSS,RYS101S3-VSS,RYS201S3-VSS,
RYS401S3-VSS,RYS751S3-VSS,RYS102S3-VSS,RYS152S3-VSS,RYS202S3-VSS,RYS302S3-VSS,RYS402S3-VSS,RYS502S3-VSS,RYS500S3-LPS,
RYS101S3-LPS,RYS201S3-LPS,RYS401S3-LPS,RYS751S3-LPS,RYS102S3-LPS,RYS152S3-LPS,RYS202S3-LPS,RYS302S3-LPS,RYS402S3-LPS,
RYS502S3-LPS,RYS500S3-LSS,RYS101S3-LSS,RYS201S3-LSS,RYS401S3-LSS,RYS751S3-LSS,RYS102S3-LSS,RYS152S3-LSS,RYS202S3-LSS,
RYS302S3-LSS,RYS402S3-LSS,RYS502S3-LSS,RYS500S3-LTS,RYS101S3-LTS,RYS201S3-LTS,RYS401S3-LTS,RYS751S3-LTS,RYS102S3-LTS,
RYS152S3-LTS,RYS500S3-LRS,RYS101S3-LRS,RYS201S3-LRS,RYS401S3-LRS,RYS751S3-LRS,RYS102S3-LRS,RYS152S3-LRS,RYS500S3-RPS,
RYS101S3-RPS,RYS201S3-RPS,RYS401S3-RPS,RYS751S3-RPS,RYS102S3-RPS,RYS152S3-RPS,RYS202S3-RPS,RYS302S3-RPS,RYS402S3-RPS,
RYS502S3-RPS,RYS500S3-RSS,RYS101S3-RSS,RYS201S3-RSS,RYS401S3-RSS,RYS751S3-RSS,RYS102S3-RSS,RYS152S3-RSS,RYS202S3-RSS,
RYS302S3-RSS,RYS402S3-RSS,RYS502S3-RSS,RYS500S3-RTS,RYS101S3-RTS,RYS201S3-RTS,RYS401S3-RTS,RYS751S3-RTS,RYS102S3-RTS,
RYS152S3-RTS;
富士工具机床用主轴驱动系统**FRENIC5000MS5**:FRN75PD5-2,FRN11PD5-2,FRN15PD5-2,FRN185PD5-2,FRN75PD5-4,FRN11PD5-4,FRN15PD5-4,FRN185PD5-4,
FRN11M5-2,FRN22M5-2,FRN37M5-2,FRN55M5-2,FRN55M5-4,FRN22V5-2,FRN37V5-2,FRN55V5-2,FRN75MC5-4,FRN11MC5-4,FRN15MC5-4,FRN185MC5-4;
芯片级维修科勒-摩根伺服放大器:SO-4004,SO-4008,RO-2004,RO-20012,ROL-2004ROL-20012,BJR-4004,BJR-4008,BJRL-4004,BJRL-4008;
芯片级维修三菱伺服驱动器:
MDS-C1-V1/V2系列:MDS-C1-V1-01,MDS-C1-V1-02,MDS-C1-V1-03,MDS-C1-V1-05,MDS-C1-V1-10,MDS-C1-V1-20,MDS-C1-V1-35,MDS-C1-V1-45,MDS-C1-V1-70,
MDS-C1-V1-90,MDS-C1-V1-45S,MDS-C1-V1-70S,MDS-C1-V1-110,MDS-C1-V1-150,MDS-C1-V2-0101,MDS-C1-V2-0301,MDS-C1-V2-0303,MDS-C1-V2-0501,
MDS-C1-V2-0503,MDS-C1-V2-0505,MDS-C1-V2-1003,MDS-C1-V2-1005,MDS-C1-V2-1010,MDS-C1-V2-2010,MDS-C1-V2-2020,MDS-C1-V2-3510,
MDS-C1-V2-3520,MDS-C1-V2-3535,MDS-C1-V2-4520,MDS-C1-V2-4535,MDS-C1-V2-4545,MDS-C1-V2-7035,MDS-C1-V2-7045,MDS-C1-V2-7070,
MDS-C1-V2-3510S,MDS-C1-V2-3520S,MDS-C1-V2-7070S;
MSD-B-SPA/SPAH系列:MDS-B-SPA/SPAH-04,MDS-B-SPA/SPAH-15,MDS-B-SPA/SPAH-22,MDS-B-SPA/SPAH-37,MDS-B-SPA/SPAH-55,MDS-B-SPA/SPAH-75,
MDS-B-SPA/SPAH-075,MDS-B-SPA/SPAH-110,MDS-B-SPA/SPAH-150,MDS-B-SPA/SPAH-185,MDS-B-SPA/SPAH-220,MDS-B-SPA/SPAH-260,
MDS-B-SPA/SPAH-300,MDS-B-SPA/SPAH-370,MDS-B-SPA/SPAH-450,MDS-B-SPA/SPAH-550;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MDS-B-V14L系列:MDS-B-V14L-01,MDS-B-V14L-03,MDS-B-V14L-05,MDS-B-V14L-10,MDS-B-V14L-20,MDS-B-V14L-35,MDS-B-V14L-45,MDS-B-V14L-70,
MDS-B-V14L-90,MDS-B-V14L-110,MDS-B-V14L-150;

MDS-B/C1-SP/SPH系列:MDS-B/C1-SP/SPH-04,MDS-B/C1-SP/SPH-15,MDS-B/C1-SP/SPH-075,MDS-B/C1-SP/SPH-22,MDS-B/C1-SP/SPH-37,
MDS-B/C1-SP/SPH-55,MDS-B/C1-SP/SPH-75,MDS-B/C1-SP/SPH-110,MDS-B/C1-SP/SPH-150S,MDS-B/C1-SP/SPH-150,MDS-B/C1-SP/SPH-185,
MDS-B/C1-SP/SPH-220,MDS-B/C1-SP/SPH-260U,MDS-B/C1-SP/SPH-260,MDS-B/C1-SP/SPH-300U,MDS-B/C1-SP/SPH-300,MDS-B/C1-SP/SPH-370,
MDS-B/C1-SP/SPH-450,MDS-B/C1-SP/SPH-550; **MDS-R-V2**系列:MDS-R-V2-2020,MDS-R-V2-4040,MDS-R-V2-8080;

MDS-B-SVJ2系列:MDS-B-SVJ2-01,MDS-B-SVJ2-03,MDS-B-SVJ2-04,MDS-B-SVJ2-06,MDS-B-SVJ2-07,MDS-B-SVJ2-10,MDS-B-SVJ2-20;

MR-J2-CT系列:MR-J2-10CT,MR-J2-20CT,MR-J2-40CT,MR-J2-60CT,MR-J2-70CT,MR-J2-100CT,MR-J2-200CT,MR-J2-350CT;

MDS-B-CVE/A-CR/C1-CV系列:MDS-C1-CV-37,MDS-C1-CV-55,MDS-C1-CV-75,MDS-C1-CV-110,MDS-C1-CV-150,MDS-C1-CV-185,MDS-C1-CV-220,
MDS-C1-CV-260,MDS-C1-CV-300,MDS-C1-CV-370,MDS-C1-CVE-450,MDS-C1-CVE-550,MDS-C1-CR-10,MDS-C1-CR-15,MDS-C1-CR-22,MDS-C1-CR-37,
MDS-C1-CR-55,MDS-C1-CR-75,MDS-C1-CR-90; **MDS-R-V1**系列:MDS-R-V1-20,MDS-R-V1-40,MDS-R-V1-80;

MDS-B-SPJ2系列:MDS-B-SPJ2-02,MDS-B-SPJ2-04,MDS-B-SPJ2-15,MDS-B-SPJ2-22,MDS-B-SPJ2-37,MDS-B-SPJ2-55,MDS-B-SPJ2-75,MDS-B-SPJ2-075,
MDS-B-SPJ2-110,MDS-B-SPJ2-110C;

三菱伺服驱动器HC系列:HC-MFS053,HC-MFS13,HC-MFS23,HC-MFS43,HC-MFS73,HC-KFS053,HC-KFS13,HC-KFS23,HC-KFS43,HC-KFS73,HC-KFS46,
HC-KFS410,HC-SFS81,HC-SFS121,HC-SFS201,HC-SFS301,HC-SFS52,HC-SFS102,HC-SFS152,HC-SFS202,HC-SFS352,HC-SFS502,HC-SFS703,HC-SFS53,
HC-SFS103,HC-SFS153,HC-SFS203,HC-SFS353,HC-RFS103,HC-RFS153,HC-RFS203,HC-RFS353,HC-RFS503,HC-UFS13,HC-UFS23,HC-UFS43,HC-UFS73,
HC-UFS72,HC-UFS152,HC-UFS202,HC-UFS352,HC-UFS502,HC-LFS52,HC-LFS102,HC-LFS152,HC-LFS202,HC-LFS302;HC52,HC102,HC152,HC202,HC352,
HC452,HC702,HC902,HC53,HC103,HC153,HC203,HC353,HC453,HC703,HC52,HC102,HC152,HC202,HC352,HC452,HC702,HC902,HC53,HC103,HC153,HC203,
HC353,HC453,HC703,HC-H152,HC-H202,HC-H352,HC-H452,HC-H702,HC-H902,HC-H1102,HC53,HC-H103,HC-H153,HC-H203,HC-H353,HC-H453,HC-H703,
HC-H903,HC-H1103,HC103R,HC153R,HC203R,HC353R,HC503R,HC-SF53,HC-SF52,HC-SF102,HC-SF103,HC-SF53152,HC-SF153,HC-SF202,HC-SF203,
HC-SF352,HC-SF353,HC-MF053,HC-MF13,HC-MF23,HC-MF43,HC-MF73,HC-SF52,HC-SF102,HC-SF103,HC-SF152,HC-SF153,HC-SF202,HC-SF203,HC-SF352,
HC-SF353,HC-RF103,HC-RF153,HC-RF203;

三菱伺服驱动器HA系列:HA-LFS601,HA-LFS801,HA-LFS12K1,HA-LFS15K1,HA-LFS20K1,HA-LFS25K1,HA-LFS30K1,HA-LFS37K1,HA-LFS30K14,HA-LFS37K14,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

HA-LFS701M,HA-LFS11K1M,HA-LFS15K1M,HA-LFS22K1M,HA-LFS30K1M,HA-LFS37K1M,HA-LFS30K1M,HA-LFS37K1M,HA-LFS45K1M,HA-LFS50K1M,

HA-LFS502,HA-LFS702,HA-LFS11K2,HA-LFS15K2,HA-LFS22K2,HA-LFS30K2,HA-LFS37K2,HA-LFS30K24,HA-LFS37K24,HA-LFS45K24,HA-LFS50K24,

HC-AQ0135D,HC-AQ0235D,HC-AQ0335D;HA40N,HA80N,HA40N,HA100N,HA200N,HA300N,HA700N,HA900N,HA053,HA13,HA053N,HA13N,HA13N,HA23N,

HA33N,HA43N,HA83N,HA103N,HA203N,HA303N,HA703N,HA50NL,HA100NL,HA150NL,HA200NL,HA300NL,HA500NL,HA-LH11K2,HA-LH15K2,HA53NL,HA103NL,HA153NL,HA203NL,HA303NL,HA503NL,HA-FF053,HA-FF13,HA-FF23,HA-FF33,HA-FF43,HA-FF63;

三菱伺服驱动器**LM-N**列:LM-NP2S-05M,LM-NP2M-10M,LM-NP2L-15M,LM-NP4S-10M,LM-NP4M-20M,LM-NP4L-30M,LM-NP4G-40M;

芯片级维修时光科技有限公司伺服控制器:

IMS-GL,IMS-HL系列伺服控制器:IMS-GCS20P4SGL,IMS-GCS20P7SGL,IMS-GCT20P4SGL,IMS-GCT20P7SGL,IMS-GCT21P5SGL,IMS-GCT40P4SGL,

IMS-GCT40P7SGL,IMS-GCT41P5SGL,IMS-GCT42P2SGL,IMS-GCT43P7SGL,IMS-GCT45P5SGL,IMS-GCT47P5SGL,IMS-GCT4011SGL,IMS-GCT4015SGL,

IMS-GCT4018SGL,IMS-GCT4022SGL,IMS-GCT4030SGL,IMS-GCT4037SGL,IMS-GCT4045SL,IMS-GCT4055SL,IMS-GCT4075SL,IMS-GCT4090SL,

IMS-GCT4110SL,IMS-GCS20P4WGL,IMS-GCS20P7WGL,IMS-GCT20P4WGL,IMS-GCT20P7WGL,IMS-GCT21P5WGL,IMS-GCT40P4WGL,IMS-GCT40P7WGL,

IMS-GCT41P5WGL,IMS-GCT42P2WGL,IMS-GCT43P7WGL,IMS-GCT45P5WGL,IMS-GCT47P5WGL,IMS-GCT4011WGL,IMS-GCT4015WGL,IMS-GCT4018WGL,

IMS-GCT4022WGL,IMS-GCT4030WGL,IMS-GCT4037WGL,IMS-GCT4045WGL,IMS-GCT4055WGL,IMS-GCT4075WGL,IMS-GCT4090WGL,IMS-GCT4110WGL;

芯片级维修松下交流伺服驱动器:

MSDA系列:MSDA3A1A1A,MSDA5A1A1A,MSDA011A1A,MSDA021A1A,MSDA041A1A,MSDA3A3A1A,MSDA5A3A1A,MSDA013A1A,MSDA023A1A,MSDA043A1A,

MSDA083A1A,MSDA103A1A,MSDA153A1A,MSDA203A1A,MSDA253A1A,MSDA303A1A,MSDA353A1A,MSDA403A1A,MSDA453A1A,MSDA503A1A,

MSDA3A1D1A,MSDA5A1D1A,MSDA011D1A,MSDA021D1A,MSDA041D1A,MSDA3A3D1A,MSDA5A3D1A,MSDA013D1A,MSDA023D1A,MSDA043D1A,

MSDA083D1A,MSDA103D1A,MSDA153D1A,MSDA203D1A,MSDA253D1A,MSDA303D1A,MSDA353D1A,MSDA403D1A,MSDA453D1A,MSDA503D1A;

MDDA系列:MDDA083AIA,MDDA103AIA,MDDA153AIA,MDDA203AIA,MDDA253AIA,MDDA303AIA,MDDA353AIA,MDDA403AIA,MDDA453AIA,MDDA503AIA,

MDDA083DIA,MDDA103DIA,MDDA153DIA,MDDA203DIA,MDDA253DIA,MDDA303DIA,MDDA353DIA,MDDA403DIA,MDDA453DIA,MDDM503DIA;

MHDA系列:MHDA053AIA,MHDA103AIA,MHDA153AIA,MHDA203AIA,MHDA303AIA,MHDA403AIA,MHDA503AIA,MHDA053DIA,MHDA103DIA,MHDA153DIA,

MHDA203DIA,MHDA303DIA,MHDA403DIA,MHDA503DIA;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MFDA系列:MFDA043AIA,MFDA083AIA,MFDA153AIA,MFDA253AIA,MFDA353AIA,MFDA453AIA,MFDA043DIA,MFDA083DIA,MFDA153DIA,MFDA253DIA,

MFDA353DIA,MFDA453DIA;

MGDA系列:MGDA033AIA,MGDA063AIA,MGDA093AIA,MGDA123AIA,MGDA203AIA,MGDA303AIA,MGDA453AIA,MGDA033DIA,MGDA063DIA,MGDA093DIA,

MGDA123DIA,MGDA203DIA,MGDA303DIA,MGDA453DIA;

MQDA系列:MQDA011AIA,MQDA021AIA,MQDA041AIA,MQDA013AIA,MQDA023AIA,MQDA043AIA,MQDA011DIA,MQDA021DIA,MQDA041DIA,MQDA013DIA,

MQDA023DIA,MQDA043DIA;

MINASA4系列AC系列伺服驱动器:MADDT1105,MADDT1107,MADDT1205,MADDT1207,MBDDT2110,MBDDT2210,MCDDT3120,MCDDT3520;

芯片级维修台达伺服驱动器:

ASDA-A:ASD-A0121L,ASD-A0221L,ASD-A0421L,ASD-A0721L,ASD-A1021L,ASD-A1021M,ASD-A1521M,ASD-A2023L,ASD-A2023M,ASD-A3023L,ASD-A3023M;

PLC模块DVP-ES/EX:DVP08SP11R,DVP16SP11R,DVP08SP11T,DVP16SP11T,DVP08SM10N,DVP08SM11N,DVP08SN11R,DVP06SN11R,DVP08SN11T,

DVP14ES00R2,DVP24ES00R2,DVP32ES00R2,DVP40ES00R2,DVP60ES00R2,DVP14ES00T2,DVP24ES00T2,DVP32ES00T2,DVP40ES00T2,DVP60ES00T2,

DVP14ES01R2,DVP24ES01R2,DVP24ES11R2,DVP32ES01R2,DVP14ES01T2,DVP24ES01T2,DVP32ES01T2,DVP20EX00R2,DVP20EX00T2,DVP20EX11R2,

DVP24XN00R,DVP24XP00R,DVP32XP00R,DVP24XN00T,DVP24XP00T,DVP32XP00T,DVP16XM01N,DVP16XN01R,DVP24XN01R,DVP24XP01R,DVP32XP01R,

DVP16XN01T,DVP24XN01T,DVP24XP01T,DVP32XP01T,DVP08XM11N,DVP16XM11N,DVP08XN11R,DVP16XN11R,DVP24XN11R,DVP08XP11R,DVP24XP11R,DVP32XP11R,DVP08XN11T,DVP16XN11T,DVP24XN11T,DVP08XP11T,DVP24XP11T,DVP32XP11T;DVP08SM11N,DVP08SN11R,DVP08SN11T,DVP08SP11R,

DVP16SP11R,DVP08SP11T,DVP16SP11T,DVPPS01,DVPPS02,DVP04AD-S,DVP02DA-S,DVP04DA-S,DVP06XA-S,DVP04PT-S,DVP04TC-S,DVP08RT-S,

170AAI03000; **ASDA-B型伺服驱动器:**ASD-B0221-A,ASD-B0421-A,ASD-B0721-A,ASD-B1021-A,ASD-B1521-A,ASD-B2023-A;

芯片级维修安川伺服系统:

芯片级维修安川自动控制产品**YASKAWA MachinE Controller:**

MP2000系列:MP2100,MP2100M,MP2200,MP2300,JAPMC-MC2100,JAPMC-MC2140,JEPMC-BU2200,JEPMC-BU2210,JEPMC-MP2300JAPMC-CP2200,

JAPMC-EX2200,JAPMC-MC2310,JAPMC-MC2300,JAPMC-CM2310,JAPMC-CM2300,JAPMC-CM2320,JAPMC-CM2330JAPMC-IO2300,J-APMC-IO2301,

JAPMC-IO2303,JEPMC-IO2310,JEPMC-PL2900,JEPMC-PL2910,JEPMC-AN2900,JEPMC-AN2910,CPMC-MPA700,JEVSA-YV250,JEPMC-REP2000,CPU-01,

CPU-02,EXIOIF,218IF-01,260IF-01,261IF-01,217IF-01,215IF-01,SVB-01,SVA-01,LIO-01,LIO-02,LIO-04,LIO-05DO-01,,AI-01,AO-0,1CNTR-01,PO-01,AFMP-01,I

O2310,PL2900,PL2910,AN2900,AN2910,REP2000,MYVIS,SGDH□□□□E,SGDH□□□□E□NS100,SGDH□□□□E□NS115,SGDS□□□□01,SGDS□□□□02,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

SGDS□□□□05,SGDS□□□□15,SGDJ□□□□P,SGDM□□□□D,SGDP□□□□P,SGDJ□□□□S,SGDJ□□□□P,SGDS□□□□12,SGDS□□□□15;MP930;MP2300;

YASKAWA-II系列的SGDM型伺服单元:SGDM-A3AD,SGDM-A5AD,SGDM-A5ADA,SGDM-01AD,SGDM-01ADA,SGDM-02AD,SGDM-02ADA,SGDM-04AD,SGDM-04ADA,SGDM-05AD,SGDM-05ADA,SGDM-08AD,SGDM-08ADA,SGDM-10AD,SGDM-10ADA,SGDM-15AD,SGDM-15ADA,SGDM-20AD,SGDM-20ADASGDM-30AD,SGDM-30ADA,SGDM-50ADA,SGDM-60ADA,SGDM-75ADA,SGDM-1EADA,SGDM-A3BD,SGDM-A3BDA,SGDM-A5BD,SGDM-A5BDA,SGDM-01BD,SGDM-01BDA,SGDM-02BD,SGDM-02BDA;

伺服驱动器:SGDH-A3AE,SGDH-A5AE,SGDH-01AE,SGDH-02AE,SGDH-04AE,SGDH-08AE-S,SGDH-15AE-S,SGDH-05AE,SGDH-08AE,SGDH-10AE,SGDH-15AE,SGDH--230AE,SGDH-50AE,SGDH-60AE,SGDH-75AE,SGDH-1AAE,SGDH-1EAE,SGDH-A3BE,S GDH-A5BE,SGDH-01BE,SGDH-02BE,SGDH-A3BE,SGDH-A5BE,SGDH-01BE,SGDH-02BE,SGDH-1250AE,SGDH-30AE;**Junma series**骏马系列伺服系统**SJDE**伺服单元: SJDE-01APA,SJDE-02APA,SJDE-04APA,SJDE-08APA;

Robotic Arms:OE-1375,T-900HM-G,StarSTEC-411,TM-800F,STEC-311Mc,TM-800FII,TM-800F,STEC-311Mc,TW-800B,STEC-211B,TW-800FM,TW-800B,90017MH,MTC-09,SHD-100,THD-100ET,MD350S3,THD-400ET,SHD-200,THD-50;SHD200,HM1004,723-4m/QT,ML500,BH2-UMA,CUR12103S,LPN3055,CB03-2,V1000SN1540,OT-516A,2056C-D,2056A,2056C-P,USP-500A,XL35/3,EFK-250,ASC-250-01,T3422710-CDRX,HKA10130,ISCHL-EQ,SN3165HG,ST305,PJ-3000,B100FF,SCO-4,THS-B4H,KGS-84MSI,SXZ6-116DM,SSR-XF100,SSR-EP200/50,SSR-XF200/50,MDH45W000X101,TM201PII-1,RKS-3119A,HS6103-I4,GCT-076S,PO-06452,BAK-600,BPU-420-E,ST-700,WKP250A/UNO-030A,CTI8200,CTI8500,WMC-3300;

Σ-III系列SGDS型伺服放大
器:SGDS-A3B,SGDS-A5F,SGDS-01F,SGDS-02F,SGDS-04F,SGDS-A5A,SGDS-01A,SGDS-02A,SGDS-04A,SGDS-08A,SGDS-05A,SGDS-10A,SGDS-15A,SGDS-20A,SGDS-30A,SGDS-50A,SGDS-60A,SGDS-75A;SGDV-R70A,SGDV-R90A,SGDV-1R6A,SGDV-2R8A,SGDV-5R5A;

芯片级维修西门子伺服控制驱动系统:
芯片级维修西门子SINAMICSS120伺服控制驱动系统:
电源滤波器和电源电器:6SL3130-6AE15-0AA0,6SL3000-0GE15-0AA0,6SL3130-6AE21-0AA0,6SL3000-0GE21-0AA0,6SL3130-7TE21-6AA1,6SL3000-0FE21-6AA0,6SL3130-7TE23-6AA1,6SL3000-0FE23-6AA0,6SL3130-7TE25-5AA1,6SL3000-0FE25-5AA0,6SL3130-7TE28-0AA0,6SL3000-0FE28-8-0AA0,6SL3130-7TE31-2AA0,6SL3000-0FE31-2AA1,6SL3000-0FE21-6AA0,6SL3000-0FE23-6AA0,6SL3060-1FE21-6AA0,6SN1162-0GA00-0CA0,6SL3130-6AE15-0AA0,6SL3000-0CE15-0AA0,6SL3130-6AE21-0AA0,6SL3000-0CE21-0AA0,6SL3130-7TE21-6AA1,6SN1111-0AA00-0BA1,6SL3130-7TE23-6AA1,6SN1111-0AA00-0CA1,6SL3130-7TE25-5AA1,6SN1111-0AA00-0DA1,6SL3130-7TE28-0AA0,6SN1111-0AA00-1EA0,6SL3130-7TE31-2AA0,6SL3000-0DE31-2BA0,6SL3130-6AE15-0AA0,6SL3130-6AE21-0AA0,6SL3166-3AB00-0AA0;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

单轴电机模块:6SL3120-1TE13-0AA0,6SL3120-1TE15-0AA0,6SL3120-1TE21-0AA1,6SL3120-1TE21-8AA1,6SL3120-1TE23-0AA1,6SL3120-1TE24-5AA1,6SL3120-1TE26-0AA1,6SL3120-1TE28-5AA1,6SL3120-1TE31-3AA0,6SL3120-1TE32-0AA0; **SMC20**机柜安装式传感器模块:6SL3055-0AA00-5BA1;

双轴电机模块:6SL3120-2TE13-0AA0,6SL3120-2TE15-0AA0,6SL3120-2TE21-0AA0,6SL3120-2TE21-8AA0;**SMC30**机柜安装式传感器模块:6SL3055-0AA00-5CA0;

控制供电模块:6SL3100-1DE22-0AA0;直流链路电源适配器:6SL3162-2BD00-0AA0;直流链路电源适配器:6SL3162-2BM00-0AA0;**CU320**控制装置(不包括**CF**卡):6SL3040-0MA00-0AA1;**CF**卡:6SL3054-0AA00-1AA0;6SL3054-0AA01-1AA0;**CBC10**通讯板卡:6SL3055-0AA00-2CA0;T

B30端子模板:6SL3055-0AA00-2TA0;**TM31**端子模块:6SL3055-0AA00-3AA0;**SMC10**机柜安装式传感器模块:6SL3055-0AA00-5AA0;**NUMDRIVE**:UAC5030/10,UAC5030/10,UAC5030/10,MNDA2010,MNDA2010,MNDA2015,MDLA014,MDLA014,MDLA021;制动模块:6SL3100-1AE31-0AA0;

芯片级维修各种运动控制系统
芯片级维修保德运动控产品:

BALDOR MOTION PRODUCTGROUP:SMART MOTION CONTROL CARD:SMCC SERIES;PROGRAMMABLE MOTION CONTROL PMC SERIES:
PMC-2BOX;PROGRAMMABLE MOTION CONTROL FOR DC SERVOS PMC SERIES AND TSD SERIES:MOTION COMMANDER OPERATOR PANEL
INTERFACE:MC-1L,MC-1V;BALDOR MOTION TERMINAL BMT:DSM SerieS Integrated Stepper MotoR/Driver:DSM34F-175-D10,DSM34F-275-D10,DSM34F-375-D10,DSM17F-148-D10,DSM17F-248-D10,DSM17F-348-D10,DSM23F-148-D10,DSM23F-248-D10,DSM23F-348-D10,DSM34F-175-D5,DSM34F-275-D5,DSM34F-375-D5,DSM17F-148-D5,DSM17F-248-D5,DSM17F-348-D5,DSM23F-148-D5,DSM17F-348-D10,DSM23F-248-D5,DSM23F-348-D5,DSM34P-175-D10,DSM34P-275-D10,DSM34P-375-D10,DSM17P-148-D10,DSM17P-248-D10,DSM17P-348-D10,DSM23P-148-D10,DSM23P-248-D10,DSM23P-348-D10,DSM34P-175-D5,DSM34P-275-D5,DSM34P-375-D5,DSM17P-148-D5,DSM17P-248-D5,DSM17P-348-D5,DSM23P-148-D5,DSM23P-248-D5,DSM23P-348-D5;High Resolution Analog Input/Output Expansion Board:EXBHH005;Ethernet Server Expansion Board:EXBHH001AXX,MN751;
Mint_Expansion Board:EXBHH002AXXMN752,EXBHH003AXX,MN753,EXBHH005AXX,MN754;MasterPulseReference/IsolatedPulseFollower:EXBHH007AXX,MN755,EXBHH012AXX,MN756,EXBHH013AXX,MN757,EXBHH014AXX,MN758,EXBHH016AXX,MN759,EXBHH007A01,EXBHH012;
MINT:SmartMove,I0N001-503,I0N002-503,I0N003-503,I0N004-503,KPD002-502,KPD002-505;EuroSystem,SmartSystem/1,SmartSystem/2,EuroServo/3,SmartSystem/3,SmartMovE1,NextMovEPC,NextMovEBX,128/64KMemoryCard,EncodeRSplitter/BufferBoard;,ServoNode51;
MintDrive:MD1A02xx-xxxx,MD2A02xx-xxxx,MD1A05xx-xxxx,MD2A05xx-xxxx,MD1A07xx-xxxx,MD2A07xx-xxxx,MD1A10xx-xxxx,MD2A10xx-xxxx,MD1A15xx-xxxx,MD2A15xx-xxxx;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MINTInterface:MN00XXX-000,MN00137-008,MN249-000,MN00249-001,MN00249-002,MN00249-003,EXB101Mxx,EXB102Mxx,EXB103Mxx,EXB001A01,

EXB002A01,EXB012A01,EXB005A01,EXB009A01,EXB006A01,EXB003A02,EXB003A03,EXB003A04,EXB003A05,EXB004A01,EXB007A02,EXB007A01,

EXB008A01,EXB010A01,EXB013A01,EXB015A01,EXB014A01;ACB003A01;

BC145,EXBD03,EXBD04,EXBD05,BC245,BC151,BC158,BC157,BCWD140;BC157,BCWD140;BC204,BC211,Mint Drive Servo & Position Control:

MDH1A02TB-RC23,MDH2A02TB-RC23,MDH1A05TB-RC23,MDH2A05TB-RC23,MDH1A07TB-RC23,MDH2A07TB-RC23,MDH4A02TB-RC23,MDH4A05TB-RC23,

MDH4A07TB-RC23,MDH2A15TB-RC23,MDH4A15TB-RC23,MDH4A20TB-RC23,MDH4A27TB-RC23,MDH1A02TR-RC23,MDH2A02TR-RC23,MDH1A05TR-RC23,

MDH2A05TR-RC23,MDH1A07TR-RC23,MDH2A07TR-RC23,MDH4A02TR-RC23,MDH4A05TR-RC23,MDH4A07TR-RC23,MDH2A15TR-RC23,MDH4A15TR-RC23,

MDH4A20TR-RC23,MDH4A27TR-RC23,MDH1A02TB-EC23,MDH2A02TB-EC23,MDH1A05TB-EC23,MDH2A05TB-EC23,MDH1A07TB-EC23,MDH2A07TB-EC23,

MDH4A02TB-EC23,MDH4A05TB-EC23,MDH4A07TB-EC23,MDH2A15TB-EC23,MDH4A15TB-EC23,MDH4A20TB-EC23,MDH4A27TB-EC23,MDH1A02TR-EC23,

MDH2A02TR-EC23,MDH1A05TR-EC23,MDH2A05TR-EC23,MDH1A07TR-EC23,MDH2A07TR-EC23,MDH4A02TR-EC23,MDH4A05TR-EC23,MDH4A07TR-EC23,

MDH2A15TR-EC23,MDH4A15TR-EC23,MDH4A20TR-EC23,MDH4A27TR-EC23;

FlexDrivell/Flex+DrivellServO Controls:FDH1A02TB-RC23,FDH2A02TB-RC23,FDH1A05TB-RC23,FDH2A05TB-RC23,FDH1A07TB-RC23,FDH2A07TB-RC23,

FDH4A02TB-RC23,FDH4A05TB-RC23,FDH4A07TB-RC23,FDH2A15TB-RC23,FDH4A15TB-RC23,FDH4A20TB-RC23,FDH4A27TB-RC23,FDH1A02TR-RC23,

FDH2A02TR-RC23,FDH1A05TR-RC23,FDH2A05TR-RC23,FDH1A07TR-RC23,FDH2A07TR-RC23,FDH4A02TR-RC23,FDH4A05TR-RC23,FDH4A07TR-RC23,

FDH2A15TR-RC23,FDH4A15TR-RC23,FDH4A20TR-RC23,FDH4A27TR-RC23,FDH1A02TB-EC23,FDH2A02TB-EC23,FDH1A05TB-EC23,FDH2A05TB-EC23,

FDH1A07TB-EC23,FDH2A07TB-EC23,FDH4A02TB-EC23,FDH4A05TB-EC23,FDH4A07TB-EC23,FDH2A15TB-EC23,FDH4A15TB-EC23,FDH4A20TB-EC23,

FDH4A27TB-EC23,FDH1A02TR-EC23,FDH2A02TR-EC23,FDH1A05TR-EC23,FDH2A05TR-EC23,FDH1A07TR-EC23,FDH2A07TR-EC23,FDH4A02TR-EC23,

FDH4A05TR-EC23,FDH4A07TR-EC23,FDH2A15TR-EC23,FDH4A15TR-EC23,FDH4A20TR-EC23,FDH4A27TR-EC23;FPH1A02TB-RC23,FPH2A02TB-RC23,

FPH1A05TB-RC23,FPH2A05TB-RC23,FPH1A07TB-RC23,FPH2A07TB-RC23,FPH4A02TB-RC23,FPH4A05TB-RC23,FPH4A07TB-RC23,FPH2A15TB-RC23,

FPH4A15TB-RC23,FPH4A20TB-RC23,FPH4A27TB-RC23,FPH1A02TR-RC23,FPH2A02TR-RC23,FPH1A05TR-RC23,FPH2A05TR-RC23,FPH1A07TR-RC23,

FPH2A07TR-RC23,FPH4A02TR-RC23,FPH4A05TR-RC23,FPH4A07TR-RC23,FPH2A15TR-RC23,FPH4A15TR-RC23,FPH4A20TR-RC23,FPH4A27TR-RC23,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

FPH1A02TB-EC23,FPH2A02TB-EC23,FPH1A05TB-EC23,FPH2A05TB-EC23,FPH1A07TB-EC23,FPH2A07TB-EC23,FPH4A02TB-EC23,FPH4A05TB-EC23,
FPH4A07TB-EC23,FPH2A15TB-EC23,FPH4A15TB-EC23,FPH4A20TB-EC23,FPH4A27TB-EC23,FPH1A02TR-EC23,FPH2A02TR-EC23,FPH1A05TR-EC23,
FPH2A05TR-EC23,FPH1A07TR-EC23,FPH2A07TR-EC23,FPH4A02TR-EC23,FPH4A05TR-EC23,FPH4A07TR-EC23,FPH2A15TR-EC23,FPH4A15TR-EC23,
FPDH4A20TR-EC23,FPH4A27TR-EC23;PCI001-501,PCI001-502,PCI001-503,PCI001-504,PCI001-505,PCI001-510,PCI001-511,PCI001-512,PCI001-508,
PCI001-513;NMX004-501,NMX004-502,NMX004-503;NES001-501,BPL010-501BPL010-502,BPL010-503;
EFL001-501;NES002-501,NES002-502,BPL010-501,BPL010-502,BPL010-503;NST002-501,NST002-502;KPD-KG420-20,KPD-KG420-30,KPD-KG840-10,
KPD-TS03M-10,KPD-TS05C-10;KPD-TS10C-10,KPD-TS12C-10;NSB002-501,NSB002-502,NSB003-501,NSB003-502PCI201-504,PCI201-508,PCI201-514,
PCI201-518;NXE100-1608,NXE100-1608S,NXE100-1612,NXE100-1612S,NXE100-1616,NXE100-1616S,MFE230A003:HMD01-W0012;
芯片级维修力士乐运动控制产品:

REXROTH DRIVE:IndraDriv

EC-HCS02:HCS02.1E-W0012-A-03-NNNN,HCS02.1E-W0012-A-03-NNNV,HCS02.1E-W0028-A-03-NNNN,
HCS02.1E-W0028-A-03-NNNV,HCS02.1E-W0054-A-03-NNNN,HCS02.1E-W0054-A-03-NNNV,HCS02.1E-W0070-A-03-NNNV,HCS02.1E-W0070-A-03-NNNN;

IndraDriv

EC-HCS03:HCS03.1E-W0070-A-05-NNNV,HCS03.1E-W0070-A-05-NNBV,HCS03.1E-W0100-A-05-NNNV,HCS03.1E-W0100-A-05-NNBV,
HCS03.1E-W0150-A-05-NNNV,HCS03.1E-W0150-A-05-NNBV,HCS03.1E-W0210-A-05-NNNV,HCS03.1E-W0210-A-05-NNBV,HCS03.1E-W03.50-A-05-NNNV,
HCS03.1E-W03.50-A-05-NNBV;

IndraDriv EM-HMD01 Dual-Axis Modules:

HMD01.1N-W0020-A-07-NNNN,HMD01.1N-W0036-A-07-NNNN,HMD01.1N-W0036-A-07-NNNN;

IndraDriv EM-HMS01 Single-Axis Modules:

HMS01.1N-W0020-A-07-NNNN,HMS01.1N-W0036-A-07-NNNN,
HMS01.1N-W0036-A-07-NNNN,HMS01.1N-W0054-A-07-NNNN,
HMS01.1N-W0070-A-07-NNNN,HMS01.1N-W0110-A-07-NNNN,HMS01.1N-W0150-A-07-NNNN,
HMS01.1N-W0210-A-07-NNNN,HMS01.1N-W0350-A-07-NNNN,
HMS02.1N-W0028-A-07-NNNN,HMS02.1N-W0054-A-07-NNNN;

IndraDriv

EM-HMV01:HMV01.1E-W0030-A-07-NNNN,HMV01.1E-W0075-A-07-NNNN,HMV01.1E-W0120-A-07-NNNN;HMV01.1R-W0018-A-07-NNNN,

HMV01.1R-W0045-A-07-NNNN,HMV01.1R-W0065-A-07-NNNN,HMV01.1R-W0100-A-07-NNNN,HMV02.1R-W0015-A-07-NNNN;

SYNAX200:Bosch ServodyND:3-phas Emodules:DMA140D1101-D,DMA4K1101-D,DMA8K1101-D,DMA15K1101-D,DMA30K1101-D,DMA30A1101-D,
DMA45A1101-D,DMA85B1101-D,DMA140D1101-D;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

Bosch ServodyND:PowerR modules:VMA70CR001-D,VMA20KR001-D,VMA35BR001-D,VMA90DR001-D,RMA/DM30-D,NAA70/1-D,PMVMA/000-D,
NVA20/1F-D,NE70/A1-D;

DIAX02 DDS021/031 Drive Controller-Basic Unit:DDS021-W015,DDS021-W025,DDS031-W030,DDS031-W050,DDS021-W050,DDS021-A050,DDS021-F050,
DDS021-W100,DDS021-A100,DDS021-F100,DDS021-W150,DDS021-A150,DDS021-F150,DDS021-W200,DDS021-A200,DDS021-F200;CLC-D021A-FW,
CLC-D022A-FW,DAA011,DAE011,DAK011A,DBS021-FW,DBS022-FW,DBS031-FW,DEA041,DEA042,DEA051,DEA052DEA061,DEF011,DEF021,DFF011,DLC011,
DLC021,DLC021-FW,DLF011,DPF051-FW,DRF011,DSE011,DSS011,DSS013-FW,DSS021,DZF011,DZF021;FWC-DIAX02-SSE-02VRS-MS,
FWA-DIAX02-SSE-02VRS-MS;

SYSTEM200 ECO DRIVE 03 Drive Controllers:DKC013-016-7,DKC013-040-7,DKC013-100-7,DKC013-200-7,DKC023-016-7,DKC023-040-7,DKC023-100-7,
DKC023-200-7,DKC033-016-7,DKC033-040-7,DKC033-100-7,DKC033-200-7,DKC043-016-7,DKC043-040-7,DKC043-100-7,DKC043-200-7,DKC053-016-7,
DKC053-040-7,DKC053-100-7,DKC053-200-7,DKC063-016-7,DKC063-040-7,DKC063-100-7,DKC063-200-7,DKC113-040-7,DKC113-100-7,DKC113-200-7,
DKC213-016-7,DKC213-040-7,DKC213-100-7,DKC213-200-7,DOK-ECODR3-FGP-01VRS-WAR1-EN-P,DOK-ECODR3-FGP-03VRS-WA01-DE-P,
DOK-ECODR3-FGP-02VRS-WAR1-EN-P,DOK-DRIVE-FGP-20VRS-FV01-EN-P,DKC033-040-7-FW,DKC033-100-7-FW,DKC033-200-7-FW,DKC043-040-7-FW,
DKC043-100-7-FW,DKC043-200-7-FW,DKC053-040-7-FW,DKC053-100-7-FW,DKC053-200-7-FW,DKC063-040-7-FW,DKC063-100-7-FW,DKC063-200-7-FW,
HDC011-A40N-PB01,HDC011-A100N-PB01,HDC011-A200N-PB01,HDC011-A40N-IB01,HDC011-A100N-IB01,HDC011-A200N-IB01,HDC011-A40N-CN01,
HDC011-A100N-CN01,HDC011-A200N-CN01,HDC011-A40N-DN01,HDC011-A100N-DN01,HDC011-A200N-DN01,HDS022-W040N,HDS022-W040N,
HDS032-W075N,HDS032-W100N;

DIAX04 HVE and HVR2 Generation PowerSupply Units: HVE02.2-W018N,HVE03.2-W030N,HVE04.2-W075N,HVR02.2-W010N,HVR02.2-W025N,
HVR03.2-W045N;

IndrAMotion MLD:MLD-SBASIC,MLD-SADVANCED,MLD-MADVANCED,FWA-INDRV-MPB-0xVRS-D5-x-xxx-TF,FWA-INDRV-MPH-0xVRS-D5-x-xxx-ML,
MLD-SBASIC,MLD-SADVANCEDMLD-MADVANCED;

4WRPH6C3/C5:4WRPH6C3B02L-2X/G24Z4/M,4WRPH6C3B04L-2X/G24Z4/M,4WRPH6C3B12L-2X/G24Z4/M,4WRPH6C3B24L-2X/G24Z4/M,
4WRPH6C3B40L-2X/G24Z4/M,4WRPH6C5B40L-2X/G24Z4/M,4WRPH6C3B15P-2X/G24Z4/M,4WRPH6C3B25P-2X/G24Z4/M,4WRPH6C3B40P-2X/G24Z4/M,
4WRPH6C5B40P-2X/G24Z4/M;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

4WRPH6C2/C4:4WRPH6C4B02L-2X/G24Z4/M,4WRPH6C4B04L-2X/G24Z4/M,4WRPH6C4B12L-2X/G24Z4/M,4WRPH6C4B24L-2X/G24Z4/M,
4WRPH6C4B40L-2X/G24Z4/M,4WRPH6C1B40L-2X/G24Z4/M,4WRPH6C4B15P-2X/G24Z4/M,4WRPH6C4B25P-2X/G24Z4/M,4WRPH6C4B40P-2X/G24Z4/M,
4WRPH6C1B40P-2X/G24Z4/M;
4WRLV/V1:4WRL10V-55M3X/G24Z4/M,4WRL10V-55M3X/G24TZ4/M,4WRL10V-55M3X/G24ETZ4/M,4WRL10V-85M3X/G24Z4/M,4WRL10V-85M3X/G24TZ4/M,
4WRL10V-85M3X/G24ETZ4/M,4WRL10V1-85M3X/G24Z4/M,4WRL10V-70P3X/G24Z4/M,4WRL10V1-70P3X/G24Z4/M;4WRL16V-120M3X/G24Z4/M,
4WRL16V1-120M3X/G24Z4/M,4WRL16V-200M3X/G24Z4/M,4WRL16V1-200M3X/G24Z4/M,4WRL16V-100P3X/G24Z4/M,4WRL16V1-100P3X/G24Z4/M,
4WRL16V-150P3X/G24Z4/M,4WRL16V1-150P3X/G24Z4/M,4WRL25V-370M3X/G24Z4/M,4WRL25V1-370M3X/G24Z4/M,4WRL25V-300P3X/G24Z4/M,
4WRL35V-1000M3X/G24Z4/M;VT-PE-TB2;

REFU drive 500:

RD51.1-4B-001-L,RD51.1-4B-003-L,RD51.1-4B-004-L,RD51.1-4B-005-L,RD51.1-4B-007-L,RD51.1-4B-011-L,RD51.1-4B-015-L,
RD51.1-4B-018-L,RD51.1-4B-022-L,RD51.1-4B-030-L,RD51.1-4B-037-L,RD51.1-4B-045-L,RD51.1-4B-055-L,RD51.1-4B-075-L,RD51.1-4B-090-L,
RD51.1-4B-110-L,RD51.1-5B-001-L,RD51.1-5B-003-L,RD51.1-5B-004-L,RD51.1-5B-005-L,RD51.1-5B-007-L,RD51.1-5B-011-L,RD51.1-5B-015-L,
RD51.1-5B-018-L,RD51.1-5B-022-L,RD51.1-5B-030-L,RD51.1-5B-037-L,RD51.1-5B-045-L,RD51.1-5B-055-L,RD51.1-5B-075-L,RD51.1-5B-090-L,
RD51.1-5B-110-L,RD52.1-4B-001-L,RD52.1-4B-003-L,RD52.1-4B-004-L,RD52.1-4B-005-L,RD52.1-4B-007-L,RD52.1-4B-011-L,RD52.1-4B-015-L,
RD52.1-4B-018-L,RD52.1-4B-022-L,RD52.1-4B-030-L,RD52.1-4B-037-L,RD52.1-4B-045-L,RD52.1-4B-055-L,RD52.1-4B-075-L,RD52.1-4B-090-L,
RD52.1-4B-110-L,RD52.1-5B-001-L,RD52.1-5B-003-L,RD52.1-5B-004-L,RD52.1-5B-005-L,RD52.1-5B-007-L,RD52.1-5B-011-L,RD52.1-5B-015-L,
RD52.1-5B-018-L,RD52.1-5B-022-L,RD52.1-5B-030-L,RD52.1-5B-037-L,RD52.1-5B-045-L,RD52.1-5B-055-L,RD52.1-5B-075-L,RD52.1-5B-090-L,
RD52.1-5B-110-L,RD51.1-4N-001-L,RD51.1-4N-003-L,RD51.1-4N-004-L,RD51.1-4N-005-L,RD51.1-4N-007-L,RD51.1-4N-011-L,RD51.1-4N-015-L,
RD51.1-4N-018-L,RD51.1-4N-022-L,RD51.1-4N-030-L,RD51.1-4N-037-L,RD51.1-4N-045-L,RD51.1-4N-055-L,RD51.1-4N-075-L,RD51.1-4N-090-L,
RD51.1-4N-110-L,RD51.1-5N-001-L,RD51.1-5N-003-L,RD51.1-5N-004-L,RD51.1-5N-005-L,RD51.1-5N-007-L,RD51.1-5N-011-L,RD51.1-5N-015-L,
RD51.1-5N-018-L,RD51.1-5N-022-L,RD51.1-5N-030-L,RD51.1-5N-037-L,RD51.1-5N-045-L,RD51.1-5N-055-L,RD51.1-5N-075-L,RD51.1-5N-090-L,
RD51.1-5N-110-L,RD52.1-4N-001-L,RD52.1-4N-003-L,RD52.1-4N-004-L,RD52.1-4N-005-L,RD52.1-4N-007-L,RD52.1-4N-011-L,RD52.1-4N-015-L,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

RD52.1-4N-018-L,RD52.1-4N-022-L,RD52.1-4N-030-L,RD52.1-4N-037-L,RD52.1-4N-045-L,RD52.1-4N-055-L,RD52.1-4N-075-L,RD52.1-4N-090-L,
RD52.1-4N-110-L,RD52.1-5N-001-L,RD52.1-5N-003-L,RD52.1-5N-004-L,RD52.1-5N-005-L,RD52.1-5N-007-L,RD52.1-5N-011-L,RD52.1-5N-015-L,
RD52.1-5N-018-L,RD52.1-5N-022-L,RD52.1-5N-030-L,RD52.1-5N-037-L,RD52.1-5N-045-L,RD52.1-5N-055-L,RD52.1-5N-075-L,RD52.1-5N-090-L,
RD52.1-5N-110-L,RD51.1-4B-132-F,RD51.1-4B-160-F,RD51.1-4B-200-F,RD51.1-4B-315-F,RD51.1-4B-400-F,RD51.1-5B-132-F,RD51.1-5B-160-F,
RD51.1-5B-200-F,RD51.1-5B-315-F,RD51.1-5B-500-F,RD52.1-4B-132-F,RD52.1-4B-160-F,RD52.1-4B-200-F,RD52.1-4B-315-F,RD52.1-4B-400-F,
RD52.1-5B-132-F,RD52.1-5B-160-F,RD52.1-5B-200-F,RD52.1-5B-315-F,RD52.1-5B-500-F;

Rexroth IndraDrive:

HMx01.1N-W0020,HMx01.1N-W0036,HCS02.1N-W0012,HCS02.1N-W0028,HMS01.1N-W0054,HMS01.1N-W0070,HCS02.1N-W0054,
HCS02.1N-W0070,HMS01.1N-W0070,HCS02.1N-W0054,HCS02.1N-W0070,HMx01.1N-W0150,HMx01.1N-W0210,HMS01.1N-W0070,HCS02.1N-W0054,
HCS02.1N-W0070,
HMS01.1N-W0150,HMS01.1N-W0210,HMS01.1N-W0070,HCS02.1N-W0054,HCS02.1N-W0070,HMS01.1N-W0150,HMS01.1N-W0210,
HMS01.1N-W0150,HMS01.1N-W0210,HMD01-W0012,HMx01.1N-W0020,HMx01.1N-W0036,HCS02.1N-W0012,HCS02.1N-W0028,
HMS01.1N-W0070,
HCS02.1N-W0054,HCS02.1N-W0070,HMD01-W0012,HMx01.1N-W0020,HMx01.1N-W0036,HCS02.1N-W0012,HCS02.1N-W0028,
HMS01.1N-W0070,
HCS02.1N-W0054,HCS02.1N-W0070,HMx01.1N-W0020,HMx01.1N-W0036,HCS02.1N-W0012,HCS02.1N-W0028,HMS01.1N-W0070,HCS02.1N-W0070,HCS02.1N-W0054,
HCS02.1N-W0070,HMx01.1N-W0020,HMx01.1N-W0036,HCS02.1N-W0012,HCS02.1N-W0028,HMS01.1N-W0070,HCS02.1N-W0054,HCS02.1N-W0070,
HMx01.1N-W0150,HMx01.1N-W0210,HMx01.1N-W0020,HMx01.1N-W0036,HCS02.1N-W0012,HCS02.1N-W0028,HMS01.1N-W0070,HCS02.1N-W0054,
HCS02.1N-W0070;

ECO

DRIVE03/DURADRIE:HDC01.1-A40N-PB01,HDC01.1-A100N-PB01,HDC01.1-A200N-PB01,HDC01.1-A40N-IB01,HDC01.1-A100N-IB01,
HDC01.1-A200N-IB01,HDC01.1-A40N-CN01,HDC01.1-A100N-CN01,HDC01.1-A200N-CN01,HDC01.1-A40N-DN01,HDC01.1-A100N-DN01,HDC01.1-A200N-DN01,
DKC03.3-040-7-FW,DKC03.3-100-7-FW,DKC03.3-200-7-FW,DKC04.3-040-7-FW,DKC04.3-100-7-FW,DKC04.3-200-7-FW,DKC05.3-040-7-FW,DKC05.3-100-7-FW,
DKC05.3-200-7-FW,DKC06.3-040-7-FW,DKC06.3-100-7-FW,DKC06.3-200-7-FW;

ECODRIVE03 Drive

Controllers:DKC01.3-016-7,DKC01.3-040-7,DKC01.3-100-7,DKC01.3-200-7,DKC02.3-016-7,DKC02.3-040-7,DKC02.3-100-7,DKC

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

02.3-200-7,

DKC03.3-016-7,DKC03.3-040-7,DKC03.3-100-7,DKC03.3-200-7,DKC04.3-016-7,DKC04.3-040-7,DKC04.3-100-7,DKC04.3-200-7,D
KC05.3-016-7,DKC05.3-040-7,
DKC05.3-100-7,DKC05.3-200-7,DKC06.3-016-7,DKC06.3-040-7,DKC06.3-100-7,DKC06.3-200-7,DKC11.3-040-7,DKC11.3-100-7,D
KC11.3-200-7,DKC21.3-016-7,
DKC21.3-040-7,DKC21.3-100-7,DKC21.3-200-7;

DDS02.1/03.1 Drive Controller -Basic

Unit:DA01-01-FW,DA02-01-FW,DA03-01-FW,DA06-01-FW,DA07-02-FW,DA10-01-FW,DA11-01-FW,DA12-01-FW,
DA14-01-FW,DC01-01-FW,DC02-01-FW,DC03-01-FW,DC04-01-FW,DL01-01-FW,DL02-01-FW,DL03-01-FW,DL04-01-FW,DL05-01
-FW,DL08-01-FW,DL09-01-FW,
DL10-01-FW,DL11-01-FW,DL12-01-FW,DL13-01-FW,DL14-01-FW,DL20-01-FW,DL21-01-FW,DL22-01-FW,DL23-01-FW,DL24-01-
FW,DL25-01-FW,DL26-01-FW,
DL27-01-FW,DL28-01-FW,DL29-01-FW,DL30-01-FW,DL31-01-FW,DL40-01-FW,DL41-01-FW,DL42-01-FW,DL43-01-FW,DL45-01-
FW,DS01-02-FW,DS03-02-FW,
DS04-03-FW,DS05-01-FW,DS06-02-FW,DS08-01-FW,DS09-01-FW,DS13-01-FW,DS22-02-FW,DS24-03-FW,DS25-01-FW,DS37-0
1-FW,DS40-02-FW,DS41-00-FW,
DS45-00-FW,DS46-00-FW,DS46-01-FW,DS47-00-FW,DS47-01-FW,DS48-00-FW,DS50-00-FW,DS51-00-FW,DS51-01-FW,DS53-0
0-FW,DS54-00-FW,DS55-00-FW,
DS56-00-FW,DS57-00-FW,DS57-01-FW,DS58-00-FW,DS58-50-FW,DS59-00-FW,DS59-50-FW,DS60-00-FW,DS60-50-FW,DS61-0
0-FW,DS62-00-FW,DS63-00-FW,
RA01-02-FW,RA02-02-FW,RA11-01-FW,RA12-01-FW,RC01-01-FW,RC02-01-FW,RC03-01-FW,RL01-01-FW,RL02-01-FW,RL03-0
1-FW,RL04-01-FW,RL05-01-FW,
RL08-01-FW,RL09-01-FW,RL10-01-FW,RL20-01-FW,RL21-01-FW,RL22-01-FW,RL23-01-FW,RL24-01-FW,RL25-01-FW,RL26-01-
FW,RL27-01-FW,RL28-01-FW,
RL29-01-FW,RL30-01-FW,RL31-01-FW,RS01-03-FW,RS03-03-FW,RS04-03-FW,RS16-02-FW,RS18-02-FW;

DDS02.1/03.1 Drive Controller - Basic Unit:

CLC-D02.1A-FW,CLC-D02.2A-FW,DAA01.1,DAE01.1,DAK01.1A,DBS02.1-FW,DBS02.2-FW,DBS03.1-FW,
DEA04.1,DEA04.2,DEA05.1,DEA05.2,DEA06.1,DEF01.1,DEF02.1,DFF01.1,DLC01.1,DLC02.1,DLC02.1-FW,DLF01.1,DPF05.1-FW
,DRF01.1,DSE01.1,DSS01.1,
DSS01.3-FW,DSS02.1,DZF01.1,DZF02.1;DDS02.1-W015-,DDS02.1-W025-,DDS03.1-W030-,DDS03.1-W050-,DDS02.1-W050-,DD
S02.1-A050-,DDS02.1-F050-,
DDS02.1-W100-,DDS02.1-A100-,DDS02.1-F100-,DDS02.1-W150-,DDS02.1-A150-,DDS02.1-F150-,DDS02.1-W200-,DDS02.1-A20
0-,DDS02.1-F200-;DAE01.1,
DAA01.1,DAE01.1,DBS02.1-FW,DLC01.1-FW,DLC02.1-FW,DEA04.2,DLF01.1,DZF02.1,DEF01.1,DSE01.1,DRF01.1,DEA04.1,DBS
02.2-FW,DEA05.1,DEF02.1,
DEA04.1,DEA06.1,DZF01.1,DEA05.1,DSM02.1-FW;DM4K1101-D,1070077600,DM4K3301-D,1070077616,DM4K4101-D,10700776
04,DM8K1101-D,1070077601,
DM8K3301-D,1070077617,DM8K4101-D,1070077605,DM15K1101-D,1070077602, DM15K3301-D,1070077618,
DM15K4101-D,1070077606,DM30K1101-D,
1070077603,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

DM30K3301-D,1070077619,DM30K4101-D,1070077607,DM4A1101-D,1070070770,DM4A4101-D,1070078596,DM8A1101-D,1070070771,
DM8A4101-D,1070078597,DM15A1101-D,1070070772,DM15A4101-D,1070078598,DM30A1101-D,1070070773,DM30A1201-D,1070077086,DM30A3301-D,
1070077620,DM30A4101-D,1070077608,DM30A4201-D,1070077612,DM45A1101-D,1070070774,DM45A1201-D,1070077087,DM45A3301-D,1070077621,
DM45A4101-D,1070077609,DM45A4201-D,1070077613,DM85B1101-D,1070070780,DM85B1201-D,1070077088,DM85B3301-D,1070077622,DM85B4101-D,
1070077610,DM85B4201-D,1070077614,DM140D1101-D,1070070782,DM140D1201-D,1070077089,DM140D3301-D,1070077623,DM140D4101-D,1070077611,
DM140D4201-D,1070077615,DM4K5311-D,1070078616,DM4K5111-D,1070078608,DM8K5311-D,1070078617,DM8K5111-D,1070078609,DM15K5311-D,
1070078618,DM15K5111-D,1070078610,DM30K5311-D,1070078619,DM30K5111-D,1070078611;VMA20KB001..D,1070077300,VMA20KE001..D,1070077624,
VMA35BR001..D,1070077785,VMA70CR001..D,1070070783, VMA90DR001..D,1070070784, NAA35/1..D,1070075122, NAA35/2..D,1070075125, NAA70/1..D,
1070075123,NAA70/2..D,1070075126,NAA90/1..D,1070077777,NAA90/2..D,1070077776,NV20/1F..D,1070078431,NV20/3F..D,1070077941,NE35/A..D,1070917639,
NE70/A..D,1070917638,
NE70/A1..D,RMB/VM..D,1070075830,RMC/VM..D,1070075115,RMA/DM8..D,1070077135,RMA/DM30..D,1070075544,RMA/DM45..D,
1070070962,RMB/DM..D,1070070963,RMD/DM..D,1070070965,RMC/VMS..D,1070075248,RMA/DMS..D,1070075244,RMB/DMS..D,1070075245,PMVMA/000..D,
1070075250,PMSMA/000..D,1070075254,PMFOA/000..D,1070075255,MCVMX.XXA00..D,1070077559,MCSMX.XXA00..D,1070078557,MCFOX.XXA00..D,
1070078558,MCOS..D,1070917668;

Automation Systems and Control Components:Controller-based PLC systems:IndraLogic L10,IndraLogic L15,IndraLogic L20,IndraLogic L40;

IndraControl L:

IndraLogic L10 : CML10.1-NN-110-NB-NNNN-NW,FWA-CML10-IL-xxVRS-DO-0003;**IndraLogic**

L15 :CML15.1-NS-110-NB-NNNN-NW;

FWA-CML15-IL-xxVRS-DO-0003,SWA-IWORKS-IL-xxVRS-DO-CD650I;**IndraLogic L20:**

CML20.1-NN-120-NA-NNNN-NW,CML20.1-NP-120-NA-NNNN-NW;

FWA-CML20-IL-xxVRS-DO-0003,SWA-IWORKS-IL-xxVRS-DO-CD650; **IndraControl VCH:** VCH 08;IndraControl VEP: VEP 30, VEP 40, VEP 50, VEP 30 CG;

IndraLogic L40:

CML40.1-NP-220-NA-NNNN-NW,CML40.1-SP-220-NA-NNNN-NW;CML40.2-NP-330-NA-NNNN-NW,CML40.2-SP-330-NA-NNNN-NW,

FWA-CML40-IL-xxVRS-DO-0008,SWA-IWORKS-IL-xxVRS-DO-CD650,CFL01-V1,CFL01-P1,CFL01-Q2,CFL01-R3,CFL01-N1,CFL01-E2,CFL01-Y1;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

IndraControl L45:CML45.1-xx-xxx-NA-NNNN-NW; **IndraControl L65:** CML65.1-xx-xxx-NA-NNNN-NW; IndraControl L Function Modules: Fieldbus interfaces: CFL01.1-P1, CFL01.1-V1; **Relay modules:** R-IB IL 24/230 DOR 1/W ,R-IB IL 24/230 DOR 4/W ,R-IB IL 24/230 DOR 4/W – 2 MBD-PAC;

Communication interfaces: CFL01.1-R3, CFL01.1-Q2; Function interfaces: CFL01.1-N1, CFL01.1-E2, CFL01.1-Y1, CFL01.1-G1;

IndraControl VCP: VCP 02 ,VCP 05 ,VCP 08 ,VCP 11,VCP 20, VCP 25; **IndraControl VEH:** VEH 30; IndraControl VSP: VSP 16 ,VSP 16, VSP 40, VSP 40;

Indra Control VPP: VPP 16 ,VPP 16, VPP 40 ,VPP 40; IndraControl VPP 21; IndraControl VSB, VPB and VDP: VSB 40, VPB 40 ,VDP 16 ,VDP 40;

IndraControl VAK and VAM: IndraControl VAK 10, VAK 11, VAK 40 and VAK 41, IndraControl VAM 10 and VAM 40, IndraControl VAM 11 and VAM 41;

Bus couplers: R-IL PB BK DI8 DO4-PAC ,R-IL S3 BK DI8 DO4-PAC, R-IBS IL 24 BK-T/U ,R-IBS IL 24 BK-DSUB ,R-IL DN BK, R-IL CAN BK-PAC, R-IL SE BK;

Digital inputs: R-IB IL 24 DI 2 ,R-IB IL 24 EDI 2-DES ,R-IB IL 24 DI 2-NPN-PAC, R-IB IL 24 DI 4, R-IB IL 24 DI 8 ,R-IB IL 24 DI 16, R-IB IL 24 DI 16-NPN-PAC,

R-IB IL 24 DI 32/HD ,R-IB IL 24 DI 32/HD-NPN-PAC, R-IB IL 24 DI 8-2MBD-PAC ,R-IB IL 24 DI 16-2MBD-PAC, Digital outputs: R-IB IL 24 DO 2-2A ,

R-IB IL 24 DO 2-NPN-PAC ,R-IB IL 24 DO 4 R-IB IL 24 DO 8, R-IB IL 24 DO 8-2A ,R-IB IL 24 DO 8-NPN-PAC, R-IB IL 24 DO 16, R-IB IL 24 DO 32/HD ,

R-IB IL 24 DO 32/HD-NPN-PAC ,R-IB IL 24 DO 2-2A-2MBD-PAC, R-IB IL 24 DO 4-2MBD-PAC ,R-IB IL 24 DO 8-2MBD-PAC ,R-IB IL 24 DO 16-2MBD-PAC;

Analog inputs: R-IB IL 24 AI 2/SF ,R-IB IL 24 AI 2/SF-230-PAC, R-IB IL AI 8/IS-PAC, R-IB IL 24 AI 8/SF-PAC, R-IB IL SGI 2/F-PAC, R-IB IL 24 AI 8/SF-2MBD-PAC,

R-IB IL SGI 2/F-2MBD-PAC; **Fieldline-Stand-Alone – INTERBUS:** RF-FLS IB M12 DI 8 M12, RF-FLS IB M12 DIO 4 M12 ,RF-FLS IB M12 DO 8 M12-2A;

Temperature modules: R-IB IL TEMP 2 RTD, R-IB IL TEMP 4/8 RTD-2MBD-PAC, R-IB IL TEMP 2 UTH-PAC, R-IB IL TEMP 4/8 RTD-PAC;

Analog outputs: R-IB IL AO 2/U/BP, R-IB IL AO 1/SF, R-IB IL AO 2/SF-PAC, R-IB IL AO 2/SF-2MBD-PAC, R-IB IL AO 4/8/U/BP-2MBD-PAC;

Power supply/segment modules: R-IB IL PWR IN, R-IB IL 24 PWR IN/2F-D-2MBD-PAC, R-IB IL 24 SEG/F, R-IB IL 24 SEG/F-D-2MBD-PAC, R-IB IL PWR IN/R-PAC; **Block I/O modules:** R-ILB PB 24 DI16/DO16 ,R-ILB IB 24 DI16/DO16, R-ILB DN 24 DI16/DO16, R-ILB S3 24 DI16 DIO16, R-ILB S3 AI4 AO2;

Function modules: R-IB IL CNT – counter module, R-IB IL INC-IN-PAC – incremental-encoder module, R-IB IL INC-PAC – incremental-encoder module,

R-IB IL SSI-PAC – SSI module, R-IB IL PWM/2-PAC – PWM output module, R-IB IL CNT-2MBD-PAC – counter module;

Communications modules: R-IB IL RS 232-PRO-PAC, R-IB IL RS485/422-PRO-PAC, R-IB IL RS232-PRO-2MBD-PAC ,R-IB IL RS485/422-PRO-PAC,

R-IBS IL 24 RB-T, R-IB IL 24 FLM-PAC, R-IB IL DDL – for pneumatic valves; **IndraControl V: IndraLogic VP21:** VPP 21: FWA-VPP21-IL-xxVRS-D0-0032,

Fieldline-Stand-Alone – PROFIBUS: RF-FLS PB M12 DI 8 M12 ,RF-FLS PB M12 DIO 4 M12, RF-FLS PB M12 DO 8 M12-2A ,RF-FLS PB M12 DIO 8 M;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

Fieldline-Stand-Alone – DeviceNet:RF-FLS DN M12 DI 8 M12, RF-FLS DN M12 DIO 4 M12,RF-FLS DN M12 DO 8 M12-2A,
Fieldline-Modular M8 – digital inputs and outputs:RF-FLM DI 8 M8 ,RF-FLM DIO 8/4 M8;**Fieldline-Modular M8 – bus couplers:**
RF-FLM BK PB M12 DI 8 M12;
PC-based PLC systems:IndraLogic VE, IndraLogic VS, IndraLogic VP,IndraMotion MLD,IndraMotion MLC,IndraMotion MTX,
IndraLogic VP: FWA-VPXVSX-IL-xxVRS-D0-0024,SWA-IWORKS-IL-xxVRS-D0-CD650; **MLD-S BASIC:**
FWA-INDRV-MPB-xxVRS-xx-x-xxx-TF;
VPP, VPB: FWA-VPXVSX-IL-xxVRS-D0-0024,SWA-IWORKS-IL-xxVRS-D0-CD650;
IndraLogic VE: SWL-VE01-ILC-xxVRS-NN, SWA-IWORKS-IL-xxVRS-D0-CD650;,**MLD-S ADVANCED:**
FWA-INDRV-MPH-xxVRS-xx-x-xxx-ML, MLD-M ADVANCED);
IndraMotion MTX: CML40.2-SP-330-NA-NN-NN-NW,
FWA-CML40-MTX-xxVRS-NN,SWA-IWORKS-MTX-xxVRS-D0-CD650-SIMULATOR,
CFG-VSN01E1-H-NN-NN-NN-NN-NN,CFG-VSN01E1-H-IC-NN-NN-NN-NN,CFG-VSN01E1-GC-NN-NN-NN,CFG-VSN01E1-GC-IC-
NN-NN,
CFG-VPN01A1-GC-NN-NN,CFG-VPN01A1-GC-IC-NN,CFG-VPN01A1-V1-GC-NN,CFG-VPN01A1-V1-GC-IC;IndraControl
VPP,IndraControl VSP,I
ndraControl VDP,IndraControl VEP, IndraControl VEH,IndraControl VCP,IndraControl VAM);
BASIC ANALOG control unit:
CSB01.1N-AN-ENS-NNN-L1-S-NN-FW,CSB01.1N-AN-ENS-NNN-NN-S-NN-FW,CSB01.1N-AN-ENS-NNN-L1-C-NN-FW,
CSB01.1N-AN-ENS-NNN-NN-C-NN-FW; **IndraLogic VS:** FWA-VPXVSX-IL-xxVRS-D0-0024, SWA-IWORKS-ILxxVRS-D0-CD650;
BASIC PROFIBUS control unit: CSB01.1N-PB-ENS-NNN-L1-S-NN-FW,CSB01.1N-PB-ENS-NNN-NN-S-NN-FW,
CSB01.1N-PB-ENS-NNN-L1-C-NN-FW,
CSB01.1N-PB-ENS-NNN-NN-C-NN-FW; **BASIC OPEN LOOP control unit:** CSB01.1N-FC-NNN-NNN-NN-S-NN-FW,
CSB01.1N-FC-NNN-NNN-NN-C-NN-FW;
BASIC SERCOS control unit: CSB01.1N-SE -ENS-NNN-L1-S-NN-FW, CSB01.1N-SE -ENS-NNN-NN-S-NN-FW, CSB01.1N-SE
-ENS-NNN-L1-C-NN-FW,
CSB01.1N-SE -ENS-NNN-NN-C-NN-FW;
BASIC UNIVERSAL single-axis control unit: CSB01.1C-SE-ENS-NNN-L1-S-NN-FW,CSB01.1C-PB-ENS-NNN-L1-S-NN-FW,
CSB01.1C-PL-ENS-NNN-L1-S-NN-FW,CSB01.1C-CO-ENS-NNN-L1-S-NN-FW,CSB01.1C-S3-ENS-NNN-L1-S-NN-FW,
CSB01.1C-NN-ENS-NNN-L1-S-NN-FW,CSB01.1C-SE-ENS-ENS-L1-S-NN-FW,CSB01.1C-PB-ENS-ENS-L1-S-NN-FW,CSB01.1C-P
L-ENS-ENS-L1-S-NN-FW,
CSB01.1C-CO-ENS-ENS-L1-S-NN-FW,CSB01.1C-S3-ENS-ENS-L1-S-NN-FW,CSB01.1C-NN-ENS-ENS-L1-S-NN-FW,CSB01.1C-S
E-EN1-EN1-L1-S-NN-FW,
CSB01.1C-PB-EN1-EN1-L1-S-NN-FW,CSB01.1C-PL-EN1-EN1-L1-S-NN-FW,CSB01.1C-CO-EN1-EN1-L1-S-NN-FW,CSB01.1C-S3-
EN1-EN1-L1-S-NN-FW,
CSB01.1C-NN-EN1-EN1-L1-S-NN-FW,CSB01.1C-SE-EN2-EN2-L1-S-NN-FW,CSB01.1C-PB-EN2-EN2-L1-S-NN-FW,CSB01.1C-PL-
EN2-EN2-L1-S-NN-FW,
CSB01.1C-CO-EN2-EN2-L1-S-NN-FW,CSB01.1C-S3-EN2-EN2-L1-S-NN-FW,CSB01.1C-NN-EN2-EN2-L1-S-NN-FW,CSB01.1C-SE
-MA1-MA1-L1-S-NN-FW,
CSB01.1C-PB-MA1-MA1-L1-S-NN-FW,CSB01.1C-PL-MA1-MA1-L1-S-NN-FW,CSB01.1C-CO-MA1-MA1-L1-S-NN-FW,CSB01.1C-S
3-MA1-MA1-L1-S-NN-FW,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

CSB01.1C-NN-MA1-MA1-L1-S-NN-FW,CSB01.1C-SE-MEM-MEM-L1-S-NN-FW,CSB01.1C-PB-MEM-MEM-L1-S-NN-FW,CSB01.1C-PL-MEM-MEM-L1-S-NN-FW,
CSB01.1C-CO-MEM-MEM-L1-S-NN-FW,CSB01.1C-S3-MEM-MEM-L1-S-NN-FW,CSB01.1C-NN-MEM-MEM-L1-S-NN-FW,CSB01.1C-SE-ENS-NNN-NN-S-NN-FW,
CSB01.1C-PB-ENS-NNN-NN-S-NN-FW,CSB01.1C-PL-ENS-NNN-NN-S-NN-FW,CSB01.1C-CO-ENS-NNN-NN-S-NN-FW,CSB01.1C-S3-ENS-NNN-NN-S-NN-FW,
CSB01.1C-NN-ENS-NNN-NN-S-NN-FW,CSB01.1C-SE-ENS-ENS-NN-S-NN-FW,CSB01.1C-PB-ENS-ENS-NN-S-NN-FW,CSB01.1C-PL-ENS-ENS-NN-S-NN-FW,
CSB01.1C-CO-ENS-ENS-NN-S-NN-FW,CSB01.1C-S3-ENS-ENS-NN-S-NN-FW,CSB01.1C-NN-ENS-ENS-NN-S-NN-FW,CSB01.1C-SE-EN1-EN1-NN-S-NN-FW,
CSB01.1C-PB-EN1-EN1-NN-S-NN-FW,CSB01.1C-PL-EN1-EN1-NN-S-NN-FW,CSB01.1C-CO-EN1-EN1-NN-S-NN-FW,CSB01.1C-S3-EN1-EN1-NN-S-NN-FW,
CSB01.1C-NN-EN1-EN1-NN-S-NN-FW,CSB01.1C-SE-EN2-EN2-NN-S-NN-FW,CSB01.1C-PB-EN2-EN2-NN-S-NN-FW,CSB01.1C-PL-EN2-EN2-NN-S-NN-FW,
CSB01.1C-CO-EN2-EN2-NN-S-NN-FW,CSB01.1C-S3-EN2-EN2-NN-S-NN-FW,CSB01.1C-NN-EN2-EN2-NN-S-NN-FW,CSB01.1C-SE-MA1-MA1-NN-S-NN-FW,
CSB01.1C-PB-MA1-MA1-NN-S-NN-FW,CSB01.1C-PL-MA1-MA1-NN-S-NN-FW,CSB01.1C-CO-MA1-MA1-NN-S-NN-FW,CSB01.1C-S3-MA1-MA1-NN-S-NN-FW,
CSB01.1C-NN-MA1-MA1-NN-S-NN-FW,CSB01.1C-SE-MEM-MEM-NN-S-NN-FW,CSB01.1C-PB-MEM-MEM-NN-S-NN-FW,CSB01.1C-PL-MEM-MEM-NN-S-NN-FW,
CSB01.1C-CO-MEM-MEM-NN-S-NN-FW,CSB01.1C-S3-MEM-MEM-NN-S-NN-FW,CSB01.1C-NN-MEM-MEM-NN-S-NN-FW;
dual-axis control component:CDB01.1C-SE-ENS-En2-NNN-MA1-S1-S-NN-FW,CDB01.1C- PB-ENS-En2-NNN-MA1-S1-S-NN-FW,
CDB01.1C- S3-ENS-En2-NNN-MA1-S1-S-NN-FW,CDB01.1C- NN-ENS-En2-NNN-MA1-S1-S-NN-FW,CDB01.1C-SE-EN1-En2-NNN-MA1-S1-S-NN-FW,
CDB01.1C- PB -EN1-En2-NNN-MA1-S1-S-NN-FW,CDB01.1C- S3-EN1-En2-NNN-MA1-S1-S-NN-FW,CDB01.1C- NN-EN1-En2-NNN-MA1-S1-S-NN-FW,
CDB01.1C-SE-ENS-NNN-NNN-MA1-S1-S-NN-FW,CDB01.1C- PB -ENS- NNN -NNN-MA1-S1-S-NN-FW,CDB01.1C- S3-ENS- NNN-NNN-MA1-S1-S-NN-FW,
CDB01.1C- NN -ENS- NNN -NNN-MA1-S1-S-NN-FW,CDB01.1C-SE-EN1- NNN -NNN-MA1-S1-S-NN-FW,CDB01.1C- PB -EN1- NNN -NNN-MA1-S1-S-NN-FW,
CDB01.1C- S3-EN1- NNN -NNN-MA1-S1-S-NN-FW,CDB01.1C- NN -EN1- NNN -NNN-MA1-S1-S-NN-FW,
ADVANCED control component:CSH01.1C-SE-ENS-EN2-NNN-S1-S-NN-FW,CSH01.1C-SE-ENS-EN2-NNN-S1-S-NN-FW,
CSH01.1C- PB -ENS-EN2-NNN-S1-S-NN-FW,CSH01.1C- PL -ENS-EN2-NNN-S1-S-NN-FW,CSH01.1C- CO-ENS-EN2-NNN-S1-S-NN-FW,
CSH01.1C- S3-ENS-EN2-NNN-S1-S-NN-FW,CSH01.1C- NN-ENS-EN2-NNN-S1-S-NN-FW,CSH01.1C-SE-EN1-EN2-NNN-S1-S-NN-FW,
CSH01.1C-SE-EN1-EN2-NNN-S1-S-NN-FW,CSH01.1C- PB -EN1-EN2-NNN-S1-S-NN-FW,CSH01.1C- PL-EN1-EN2-NNN-S1-S-NN-FW,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

CSH01.1C- CO –EN1-EN2-NNN-S1-S-NN-FW,CSH01.1C- S3-EN1-EN2-NNN-S1-S-NN-FW,CSH01.1C- NN
–EN1-EN2-NNN-S1-S-NN-FW,
CSH01.1C-SE-EN2-EN2-NNN-S1-S-NN-FW,CSH01.1C-SE-EN2-EN2-NNN-S1-S-NN-FW,CSH01.1C- PB
–EN2-EN2-NNN-S1-S-NN-FW,
CSH01.1C- PL –EN2-EN2-NNN-S1-S-NN-FW,CSH01.1C- CO –EN2-EN2-NNN-S1-S-NN-FW,CSH01.1C-
S3-EN2-EN2-NNN-S1-S-NN-FW,
CSH01.1C- NN –EN2-EN2-NNN-S1-S-NN-FW,CSH01.1C-SE-
NNN-EN2-NNN-S1-S-NN-FW,CSH01.1C-SE-NNN-EN2-NNN-S1-S-NN-FW,
CSH01.1C- PB –NNN-EN2-NNN-S1-S-NN-FW,CSH01.1C- PL –NNN-EN2-NNN-S1-S-NN-FW,CSH01.1C- CO
–NNN-EN2-NNN-S1-S-NN-FW,
CSH01.1C- S3-NNN-EN2-NNN-S1-S-NN-FW,CSH01.1C- NN –NNN-EN2-NNN-S1-S-NN-FW,

Rexroth NYCe 4000 Excellence in Motion Control:

NY4010,NYS04.1-ST-01-NNNN,NY4011,NYS04.1-ST-01-MAMO,NY4040,NYS04.1-ST-04-NNNN,NY4050,
NYS04.1-ST-05-NNNN,NY4705,NYS04.1-ST-04-DEMO,NY4110,NYM04.1-CPU-NNN,NY4120,NYM04.1-2PW-NNNN,NY4120/10,N
YM04.1-2PW-LMS,NY4120/20,
NYM04.1-2PW-MAMO,NY4130,NYM04.1-2LD-NNNN,NY4140,NYM04.1-1HV-NNNN,NY4140/10,NYM04.1-1HV-LMS,NY4199,NYM
04.1-ESC-NNNN,NY4900,
NYA04.1-COVRPL-NO-USED,NY4915,NYA04.1-1394B-INT-MOD,NY4950,NYA04.1-1394B-CABLE-B-B-00.5M,NY4950/10,NYA04.
1-1394B-CABLE-B-B-01.0M,
NY4950/20,NYA04.1-1394B-CABLE-B-B-02.0M,NY4950/30,NYA04.1-1394B-CABLE-B-B-04.5M,NY4960/00,NYA04.1-LMS-MUX2-1
Vtt-5V,NY4960/10,
NYA04.1-LMS-MUX2-10Vtt-5V,NY4960/20,NYA04.1-LMS-MUX2-10Vtt-15V;

Rexroth VISUALMOTION Open Control and Drive System for Press Automation:PPC-R01 (Rack),PPC-R02 (Rack),PPC-P (PCI
plug-in card),RMB02.2-04,
RMK02.2-LWL-SER,RME02.2-16-DC024,RME02.2-32-DC024,RME02.2-16-AC115,RMA02.2-16-DC024-200,RMA02.2-32-DC024-0
50,RMA02.2-16-AC230-200,
RMA02.2-16-RE230-200,RMC02.2-2E-1A;

Servo solenoid valves:0 811 401 219,0 811 402 107,0 811 402 113,0 811 402 513,0 811 402 514,0 811 402 611,0 811 402 639,0
811 402 640,0 811 404 033,
0 811 404 034,0 811 404 034,0 811 404 035,0 811 404 035,0 811 404 036,0 811 404 036,0 811 404 037,0 811 404 038,0 811 404
039,0 811 404 041,0 811 404 043,
0 811 404 044,0 811 404 045,0 811 404 046,0 811 404 047,0 811 404 048,0 811 404 058,0 811 404 059,0 811 404 060,0 811 404
061,0 811 404 062,0 811 404 063,
0 811 404 064,0 811 404 065,0 811 404 067,0 811 404 076,0 811 404 077,0 811 404 078,0 811 404 079,0 811 404 093,0 811 404
094,0 811 404 095,0 811 404 106,
0 811 404 111,0 811 404 112,0 811 404 113,0 811 404 118,0 811 404 122,0 811 404 160,0 811 404 162,0 811 404 206,0 811 404
207,0 811 404 250,0 811 404 251,
0 811 404 290,0 811 404 291,0 811 404 405,0 811 404 430,0 811 404 445,0 811 404 560,0 811 404 600,0 811 404 601,0 811 404
601,0 811 404 602,0 811 404 602,
0 811 404 603,0 811 404 603,0 811 404 610,0 811 404 611,0 811 404 612,0 811 404 613,0 811 404 631,0 811 404 632,0 811 404

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

633,0 811 404 634,0 811 404 639,
0 811 404 640,0 811 404 641,0 811 404 642,0 811 404 644,0 811 404 645,0 811 404 646,0 811 404 647,0 811 404 652,0 811 404
653,0 811 404 659,0 811 404 660,
0 811 404 661,0 811 404 662,0 811 404 690,0 811 404 691,0 811 404 720,0 811 404 721,0 811 404 722,0 811 404 723,0 811 404
725,0 811 404 726,0 811 404 738,
0 811 404 741,0 811 404 800,0 811 404 801,0 811 404 802,0 811 404 803,0 811 404 809,0 811 404 817,0 811 404 819,0 811 404
820,0 811 404 821,0 811 404 822,
0 811 404 824,0 811 404 825,0 811 405 060,0 811 405 060,0 811 405 061,0 811 405 061,0 811 405 062,0 811 405 062,0 811 405
063,0 811 405 063,0 811 405 063,
0 811 405 065,0 811 405 065,0 811 405 066,0 811 405 066,0 811 405 067,0 811 405 067,0 811 405 068,0 811 405 068,0 811 405
114,0 811 405 118,0 811 405 123,
0 811 405 123,0 811 405 148,0 811 405 148,0 811 405 163,0 811 405 167,0 811 405 168,1 815 503 147,1 815 503 147,1 815 503
336,1 815 503 336,1 815 503 340,
1 815 503 340,1 815 503 351,1 815 503 351,1 815 503 377,1 815 503 377,1 815 503 378,1 815 503 378,1 815 503 418,1 815 503
418,1 834 463 005,1 834 463 005,
1 834 482 022,1 834 482 022,1 834 482 022,1 834 482 022,1 834 482 022,1 834 482 022,1 834 482 023,1 834 482 023,1 834 482
023,1 834 482 023,1 834 482 023,
1 834 482 023,1 834 482 024,1 834 482 024,1 834 482 024,1 834 482 024,1 834 482 024,1 834 482 024,1 834 482 024,1 834 482 026,1 834 482
026,1 834 482 026,1 834 482 026,
1 834 482 026,1 834 482 026,1 834 484 040,1 834 484 057,1 834 484 058,1 834 484 061,1 834 484 063,1 834 484 142,1 834 484
142,1 834 484 142,1 834 484 252,
1 834 484 252,1 834 484 252,1 834 484 252,1 834 484 252,1 834 486 000,1 834 486 001,2 910 151 166,2 910 151 166,2 910 151
166,2 910 151 166,2 910 151 166,
2 910 151 166,2 910 151 209,2 910 151 209,2 910 151 209,2 910 151 209,2 910 151 209,2 910 151 209,2 910 151 209,2 910 151
209,2 910 151 211,2 910 151 211,
2 910 151 211,2 910 151 211,2 910 151 227,2 910 151 301,2 910 151 301,2 910 151 301,2 910 151 301,2 910 151 354,2 910 151
354,2 910 151 354,2 910 151 354,
2 910 151 532,2 910 151 532,B 810 006 705,B 810 006 708,B 810 006 709,B 810 006 710,B 810 015 459,B 810 015 719,B 810 027
467,B 810 027 468,B 810 027 469,
B 810 027 470,B 810 027 471,B 810 027 475,B 810 035 157,B 810 055 308,B 810 055 310,B 810 055 406,B 810 055 580,B 810 055
581,B 810 055 582,
B 810 055 583,B 810 065 043,B 810 065 104,B 810 065 153,B 810 065 187,B 810 065 208,B 810 065 209,B 810 065 210,B 810 065
211,C 830 306 729,
C 830 306 729,D 831 003 715;

芯片级维修法拉科运动控制产品:

FANUC CONTROL MOTOR AMPLIFIER α SerieS

SERVOAMPLIFIER:SVU1-12,SVU1-20,SVU1-40,SVU1-80,SVU1-130,SVU2-12/12,SVU2-12/20,SVU2-20/20,
SVU2-12/40,SVU2-20/40,SVU2-40/40,SVU2-40/80,SVU2-80/80,SVU2-12/80,SVU2-20/80,SVUC1-4,SVUC1-12,SVUC1-40,SVUC1-
80,SVUC1-130,SVUC2-4/4,
SVUC2-4/12,SVUC2-4/40,SVUC2-12/12,SVUC2-12/40,SVUC2-12/80,SVUC2-40/40,SVUC2-40/80,SVUC2-80/80,A06B-6090-H002,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

A06B-6090-H003,
A06B-6090-H004,A06B-6090-H006,A06B-6090-H008,A06B-6090-H222,,A06B-6090-H223,A06B-6090-H224,A06B-6090-H233,A06B-6090-H234,A06B-6090-H236,
A06B-6090-H244,A06B-6090-H246,A06B-6090-H266,A06B-6089-H101,A06B-6089-H102,A06B-6089-H104,A06B-6089-H105,A06B-6089-H106,A06B-6089-H201,
A06B-6089-H202,A06B-6089-H203,A06B-6089-H204,A06B-6089-H205,A06B-6089-H206,A06B-6089-H207,A06B-6089-H208,A06B-6089-H209,A06B-6089-H210;

S2K Series

ServO Amplifiers: IC800SSD104RD2, IC800SSD104RP2, IC800SSD104RS1, IC800SSD107RD2, IC800SSD107RP2, IC800SSD107RS1,
IC800SSD216RD2, IC800SSD216RP2, IC800SSD228RD2, IC800SSD228RP2, IC800SSD407RD2, IC800SSD407RP2, IC800SSD407RS1, IC800SSD420RD2,
IC800SSD420RP2, IC800SSD104D2, IC800SSD104P2, IC800SSD104S1, IC800SSD107D2, IC800SSD107P2, IC800SSD107S1, IC800SSD216D2, IC800SSD216P2,
IC800SSD228D2, IC800SSD228P2; IC800SSI104S1, IC800SSI104D2, IC800SSI104P2, IC800SSI107S1, IC800SSI107D2, IC800SSI107P2, IC800SSI107RS1, IC800SSI216D2,
IC800SSI216P2, IC800SSI228D2, IC800SSI104RD2, IC800SSI104RP2, IC800SSI104RS1, IC800SSI107RD2, IC800SSI107RP2, IC800SSI107RS1, IC800SSI216RD2,
IC800SSI216RP2, IC800SSI228RD2, IC800SSI228RP2, IC800SSI407RD2, IC800SSI407RP2, IC800SSI407RS1, IC800SSI420RD2, IC800SSI420RP2, IC800STI105D2,
IC800STI105P2, IC800STI105S1;

SL Series

Amplifier: IC800SLA0031, IC800SLA0051, IC800SLA0101, IC800SLA0201, IC800SLA0401, IC800SLA0402, IC800SLA0752, IC800SLA1002,
IC800SLA2502, IC800SLA3502, IC800SLA5002;

B Series

ServO Amplifiers: ZA06B-6093-H101, ZA06B-6093-H102, IC800BPK012, IC800BPK020, IC800BPK020, IC800BPK020, IC800BPK020, IC800BPK020,
A06B-6093-H101, A06B-6093-H101, A06B-6093-H102, A06B-6093-H102, A06B-6093-H102, A06B-6093-H102, A06B-6093-H102; β 05/3000, β 2/3000, β 3/3000, β 6/2000,
 α C12/2000, β M05/4000, β M1/4000;

β I Series

ServO Amplifier: β SVM1-20i, β SVM1-20HV, β SVM1-40i, β SVM1-10HV, β SVM1-20HV, ZA06B-6130-H002, ZA06B-6130-H003, ZA06B-6131-H001,
ZA06B-6131-H002;

CNC SerieS 30i/31i/32i: β SerieS ServOMotor APM300 Series: DSM302 Series: DSM314 Series: Genius I/O blocks Catalog

Numbers for PhaseA Products:

IC660CBB900, IC660FPB900, IC660CBB901, IC660FPB901, IC660HHM500, IC660CBD100, IC660TSD100, IC660ELD100, IC660CBS100, IC660TSS100,
IC660ELS100, IC660CBD020, IC660TSD020, IC660ELD020, IC660CBD021, IC660TSD021, IC660ELD021, IC660CBA020, IC660TSA02

公司地址: 武汉市洪山区雄楚大街 699 号

业务联系电话: 027-63005490 027-51778300 13487094272

网址: <http://www.whz.jk.com> E-MAIL: whz.jkj@163.com

联系人: 汪经理

传真: 027-51778300

邮编: 430074

武汉市中江科技有限公司维修内容列表

0,IC660ELA020,IC660CBA100,IC660TSA100,IC660ELA100;

SVU Series

Servo Amplifiers:SVU1-80,ZA06B-6089-H105,IC800APK080,SVU1-80,IC800APK080,SVU1-80,IC800APK080,SVU1-130,ZA06B-6089-H106,

IC800APK130,SVU1-130,ZA06B-6089-H106,IC800APK130;

β Series Servo

Amplifiers: β 12,ZA06B-6093-H101,IC800BPK012, β 12,ZA06B-6093-H101,IC800BPK012, β 20,ZA06B-6093-H102,IC800BPK020, β 20,

ZA06B-6093-H102,IC800BPK020, β 20,ZA06B-6093-H102,IC800BPK020, β 20,ZA06B-6093-H102,IC800BPK020, β 20,ZA06B-6093-H102,IC800BPK020;

β i Series Servo Amplifier

rPackages: β SVM1-20i,ZA06B-6130-H002,IC800BIK020, β SVM1-20i,ZA06B-6130-H002,IC800BIK020, β SVM1-20i,ZA06B-6130-H002,

IC800BIK020, β SVM1-20i,ZA06B-6130-H002,IC800BIK020, β SVM1-20i,ZA06B-6130-H002,IC800BIK020, β SVM1-20i,ZA06B-6130-H002,IC800BIK020, β SVM1-40i,

ZA06B-6130-H003,IC800BIK040, β SVM1-40i,ZA06B-6130-H003,IC800BIK040, β SVM1-10HVi,ZA06B-6131-H001,IC800BIHV010, β SVM1-10HVi,ZA06B-6131-H001,

IC800BIHV010, β SVM1-10HVi,ZA06B-6131-H001,IC800BIHV010, β SVM1-20HVi,ZA06B-6131-H002,IC800BIHV020, β SVM1-20HVi,ZA06B-6131-H002,IC800BIHV020;

Servo amplifier units SVU and

SVUC:SVU1-12,A06B-6089-H101,A16B-2202-0950,SVU1-20,A06B-6089-H102,A16B-2202-0951,SVU1-40,A06B-6089-H104,

A20B-2002-0040,SVU1-80,A06B-6089-H105,A20B-2002-0041,SVU1-130,A06B-6089-H106,A20B-2002-0050,SVU2-12/12,A06B-6089-H201,A20B-2002-0060,

SVU2-12/20,A06B-6089-H202,A20B-2002-0061,SVU2-20/20,A06B-6089-H203,A20B-2002-0062,SVU2-12/40,A06B-6089-H204,A20B-2002-0063,SVU2-20/40,

A06B-6089-H205,A20B-2002-0064,SVU2-40/40,A06B-6089-H206,A20B-2002-0065,SVU2-40/80,A06B-6089-H207,A20B-2002-0066,SVU2-80/80,A06B-6089-H208,

A20B-2002-0067,SVU2-12/80,A06B-6089-H209,A20B-2002-0068,SVU2-20/80,A06B-6089-H210,A20B-2002-0069,SVUC1-4,A06B-6090-H002,A16B-2202-0955,

SVUC1-12,A06B-6090-H003,A16B-2202-0956,SVUC1-40,A06B-6090-H004,A20B-2002-0045,SVUC1-80,A06B-6090-H006,A20B-2002-0047,SVUC1-130,

A06B-6090-H008,A20B-2002-0055,SVUC2-4/4,A06B-6090-H222,A20B-2002-0151,SVUC2-4/12,A06B-6090-H223,A20B-2002-0152,SVUC2-4/40,A06B-6090-H224,

A20B-2002-0153,SVUC2-12/12,A06B-6090-H233,A20B-2002-0154,SVUC2-12/40,A06B-6090-H234,A20B-2002-0155,SVUC2-12/80,A06B-6090-H236,

A20B-2002-0156,SVUC2-40/40,A06B-6090-H244,A20B-2002-0157,SVUC2-40/80,A06B-6090-H246,A20B-2002-015,SVUC2-80/80,A06B-6090-H266,

A20B-2002-0159;**DeviceNet Network Interface Unit:** IC220DBI001,IC220TBK201;

GE-FANUCCNC:VMC2216FX,VMC3016FX,VMC4020FX,

VMC3016LC,VMC4020LC,VMC4525,VMC6030,VMC6535,VMC6535HTX,VMC4020FX,VMC4525,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

VMC6030,VMC8030,VMC6535,VMC2216FX,VMC3016FX,VMC6535;

Genius I/O blocks Catalog Numbers for PhaseB

Products:IC660CBB902,IC660CBB903,IC660BBD100,IC660TSD100,IC660EBD100,IC660BBS100,
IC660TSS100,IC660EBS100,IC660TSD020,IC660EBD020,IC660BBD021,IC660TSD021,IC660EBD021,IC660TSA020,IC660EBA020,IC660TSA100,
IC660EBA100,IC660ELB906,IC660ELB921,IC697BEM731,IC693CMM301,IC693CMM302,IC655BEM510,IC660BSM120,IC660BBD101,IC660TSD100,
IC660EBD101,IC660BBS101,IC660TSS100,IC660EBS101,IC660ELB904,IC660TBD110,IC660EBD110,IC660TBR100,IC660EBR100,IC660TBR101,IC660EBR101,
IC660BBD022,IC660TBD022,IC660EBD020,IC660TBD023,IC660EBD021,IC660TBD024,IC660EBD024,IC660TBD025,IC660EBD025,IC660TBA104,IC660EBA104,
IC660BBA024,IC660TBA024,IC660EBA024,IC660TBA105,IC660EBA105,IC660TBA025,IC660EBA025,IC660TBA106,IC660EBA106,IC660TBA026,IC660EBA026,
IC660TBA021,IC660EBA021,IC660TSA101,IC660EBA101,IC660TBA023,IC660EBA023,IC660TSA103,IC660EBA103,IC660BBD120,IC660TBS120,IC660EBD120,
IC660BPM100,IC660BDX022;

Genius I/O

blocks:IC660BLC001,IC660BLC003,IC660HHC005,IC660BLM506,IC660BLM508,IC660BPM500,IC660BCM501,IC660MBM503,IC660MPH509,
IC660MKS511,IC660MCA512,IC660MLD100,IC660MLS100,IC660MLD110,IC660MLR101,IC660MLR100,IC660MLD020,IC660MLD021,IC660MLD022,
IC660MLD023,IC660MLD024,IC660MLD025,IC660MLA020,IC660MLA100,IC660MIA021,IC660MLA101,IC660MLA023,IC660MLA103,IC660MLA024,IC660MLA104,
IC660MLA025,IC660MLA105,IC660MLA026,IC660MLA106,IC660MLD120,IC660BDA020,IC660BDA021,IC660BDA100,IC660BDA101,IC660BDD020,IC660BDD101,
IC660BDD110,IC660BDD120,IC660BDR101,IC660BDS110,IC660BLM507;

Whedco

Model:IMJ-313D-X-D,IMJ-313R-X-D,IMJ-313E-X-D,IMJ-317D-X-D,IMJ-317R-X-D,IMJ-317E-X-D,IMJ-31GD-2-D,IMJ-31GR-2-D,IMJ-31TD-2-D,
IMJ-31TR-2-D,IMJ-317D-4-D,IMJ-317R-4-D,IMJ-317E-4-D,IMJ-31LD-4-D,IMJ-31LR-4-D,IMJ-105D-1-D,IMJ-105R-1-D,IMJ-105E-1-D
;

GE-FANUC SERIES 90/70 I/O

MODULES:IC697MDL240,IC697MDL241,IC697MDL250,IC697MDL251,IC697MDL252,IC697MDL253,IC697MDL254,IC697MDL640,
IC697MDL651,IC697MDL652,IC697MDL653,IC697MDL654,IC697MDL671,IC697MDL340,IC697MDL341,IC697MDL350,IC697MDL740,IC697MDL750,
IC697MDL752,IC697MDL753,IC697MDL940,IC697MDL230,IC697MDL440,IC697MDL441,IC697MDL320,IC697VAL216,IC697VAL232,IC697VAL264,IC697VAL314,
IC697VAL318,IC697VAL324,IC697VAL328,IC697VAL304,IC697VAL308,IC697VAL301,IC697VAL348,IC697VAL132,IC697VAL134,IC697VDD100,IC697VDD125,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

IC697VDR150,IC697VDR151,IC697VDQ120,IC697VAL306,IC697VHD100,IC697VAL216,IC697VAL232,IC697VAL264,IC697VAL306,IC697VAL307,IC697VAL301,

IC697VRD008,IC697VHD001,IC697VDD100,IC697VDD125,IC693ACC302;

SERIES90/70 OPTION

MODULES:IC697ADC701,IC697CMM711,IC697CMM712,IC697CMM721,IC697CMM741,IC697CMM742,IC697PCM711,IC697PCM712,

IC697RCM711,IC697SLP711,IC640WMI920,IC640WMI320,IC640WMI910,IC640WMI310;

GE-FANUC

SERIES90/70PLC:IC697HSC700,IC697CHS750,IC697CHS783,IC687BEM731,IC697ACC621,IC697ACC624,IC697ACC644;IC697PWR710,

IC697PWR711,IC697PWR712,IC697PWR713,IC697PWR720,IC697PWR721,IC697PWR722,IC697PWR723,IC697PWR724,IC697PWR731,IC697PWR732,

IC697PWR748,IC697CBL700,IC697ACC715,IC697ACC721,IC697ACC724,IC697ACC744,IC697ACC722,IC697CPM914,IC697CPM915,IC697CPM924,

IC697CPM925,IC697CPU731,IC697CPU732,IC697CPU771,IC697CPU772,IC697CPU780,IC697CPU781,IC697CPU782,IC697CPU788,IC697CPU789,

IC697CPM790,IC697CHS914,IC697CHS924,IC697CHS915,IC697CHS925,IC697CSE784,IC697CSE924,IC697CSE925,IC697CPX772,IC697CPX782,

IC697CPX928,IC697CPX935,IC697CGR772,IC697CGR935,IC697MEM713,IC697MEM715,IC697MEM717,IC697MEM719,IC697MEM731,IC697MEM732,

IC697MEM733,IC697MEM735,IC697BEM711,IC697BEM713,IC697BEM721,IC697BEM731,IC697BEM733,IC697BEM741,IC697BEM763,IC697BEM764,

IC697ACC702,IC697ACC901,IC697ACC903,IC600WDXXX,IC697WMI920,IC697WMI910,IC697CBL701,IC697CBL702,IC697CBL703,IC697CBL704,IC697CBL705,

IC697CBL712,IC697CMM721,IC697CBL741,IC697ADC701,IC697SLP711,IC697VRM015,IC697VSC096,IC697CHS750,IC698CHS009,IC697CHS109;

GE-FANUC SerieS90-30

PLC:AD693SLP300,IC693ACC300,IC693ACC307,IC690ACC900,IC693APU300,IC693APU301,IC693APU302,IC693APU305,

IC693BEM320,IC693BEM321,IC693BEM330,IC693BEM340,IC693CMM301,IC693CMM302,IC693CPU311,IC693CPU313,IC693CPU323,IC693CPU331,

IC693CPU340,IC693CPU341,IC693CPU350,IC693CPU351,IC693CPU352,IC693CPU360,IC693CPU363,IC693CPU364,IC693CPU374,IC693CSE313,

IC693CSE323,IC693CSE340,IC693DSM302,IC693DSM302,IC693DSM314,IC693MAR590,IC693MDL230,IC693MDL231,IC693MDL240,IC693MDL241,

IC693MDL330,IC693MDL340,IC693MDL390,IC693MDL630,IC693MDL632,IC693MDL633,IC693MDL634,IC693MDL640,IC693MDL643,IC693MDL644,

IC693MDL645,IC693MDL646,IC693MDL652,IC693MDL653,IC693MDL654,IC693MDL655,IC693MDL730,IC693MDL731,IC693MDL732,IC693MDL733,

IC693MDL734,IC693MDL740,IC693MDL741,IC693MDL742,IC693MDL750,IC693MDL751,IC693MDL752,IC693MDL753,IC693MDL930,IC693MDL931,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

IC693MDL940,IC693MDR390,IC693PCM300,IC693PCM301,IC693PCM311,IC693PRG300,IC693PTM100,IC693PTM101,IC693TC
M302;PE693BEM350,

PE693BEM351,PE693BEM352;IC660BBD025;

**Genius_I/O μGENI Board:IC660ELB912;CIMPPLICITY_90 ADS Alpha numeric DisplaY System:Field Control DistributeD I/O
anD Control System:**

IC670GBI002,IC670FBI001,IC670BPI001,HE670IBU001,IC670MFP100,IC670CHS001,IC670CHS002,IC670CHS003,IC670CHS004
,IC670TBM001,IC670TBM002,

IC670MDL233,IC670MDL240,IC670MDL241,IC670MDL640,IC670MDL641,IC670MDL642,IC670MDL643,IC670MDL644,IC670MDD
441,HE670ACC100,

HE670DIM300,IC670MDL730,IC670MDL740,IC670MDL742,IC670MDL330,IC670MDL331,IC670MDL930,HE670RLY168,IC670DQ
M125,IC670ALG230,

IC670ALG240,IC670ALG620,IC670ALG630,HE670ADC810,HE670ADC830,HE670ADC840,IC670ALG320,IC670ALG330,IC670AL
G310,HE670DAC830,

HE670DAC840,IC670CBL001,IC670CBL002,IC670CBL003,IC670CBL004,IC670ACC003;

Versa Max

PLC:IC200PBI001,IC200DBI001,IC200BEM102,IC200BEM103IC200BEM104,IC200ETM001,IC200ERM001,IC200ERM002,IC200A
LG230,

IC200ALG240,IC200ALG260,IC200ALG261,IC200ALG262,IC200ALG263,IC200ALG264,IC200ALG320,IC200ALG321,IC200ALG32
2,IC200ALG325,IC200ALG326,

IC200ALG327,IC200ALG328,IC200ALG331,IC200ALG430,IC200ALG431,IC200ALG432,IC200ALG620,IC200ALG630,IC200MDD8
40,IC200MDD841,

IC200MDD842,IC200MDD843,IC200MDD844,IC200MDD845,IC200MDD846,IC200MDD847,IC200MDD848,IC200MDD849IC200M
DD850,,IC200MDD851,

IC200MDL140,IC200MDL141,IC200MDL143,IC200MDL144,IC200MDL240,IC200MDL241,IC200MDL243,IC200MDL244,IC200MDL
329,IC200MDL330,

IC200MDL331,IC200MDL631,IC200MDL632,IC200MDL635,IC200MDL636,IC200MDL640,IC200MDL643,IC200MDL644,IC200MDL
650,IC200MDL730,

IC200MDL740,IC200MDL741,IC200MDL742,IC200MDL743,IC200MDL744,IC200MDL750,IC200MDL930,IC200MDL940;IC200PW
R001,IC200PWR002,

IC200PWR101,IC200PWR102,IC200PWR201,IC200PWR202,IC200PWB001;**Versa Max**

CPUs:IC200CPU001,IC200CPU002,IC200CPU005,IC200CPUE05;

VersA MaX Micro PLC anD Nano PLC

Models:IC200NAL110,IC200NAL211,IC200NDD010,IC200UAL004,IC200UAL005,IC200UAL006,IC200UAR014,

IC200UAR028,IC200UDD104,IC200UDD110,IC200UDD112,IC200UDD120,IC200UDD212,IC200UDD064,IC200UDD164,IC200UD
R001,IC200UDR002,

IC200UDR003,IC200UDR005,IC200UDR006,IC200UDR010,IC200UDR228,IC200UDR064,IC200UDR164,IC200USB001,IC200US
B002,IC200UMB001,

IC200UUB001,IC200UEM001,IC200UEC008,IC200UEC108,IC200UEC208,IC200UEI008,IC200UEI016,IC200UEO008,IC200UEO
16,IC200UEO108,IC200UEO116,

IC200UER008,IC200UER016,IC200UEX009,IC200UEX010,IC200UEX011,IC200UEX012,IC200UEX013,IC200UEX014,IC200UEX0

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

15,IC200UEX122,IC200UEX209,
IC200UEX210,IC200UEX211,IC200UEX212,IC200UEX213,IC200UEX214,IC200UEX215,IC200UEX222,IC200UEX616,IC200UEX624,IC200UEX626,IC200UEX636,

IC200UEX724,IC200UEX726,IC200UEX734,IC200UEX736; **Versa Max**

NIUs:IC200EBI001,IC200PBI001,IC200GBI001,IC200DBI001;

VersA Point I/O

System:IC220MDL641,IC220MDL642,IC220MDL643,IC220MDL644,IC220MDL661,IC220MDL220,IC220MDL230,IC220MDL721,IC220MDL751,IC220MDL752,IC220MDL753,IC220MDL754,IC220MDL761,IC220MDL930,IC220MDL940,IC220ALG220,IC220ALG620,IC220ALG630,IC220ALG320,

IC220ALG321,IC220ALG322,IC220BEM232,IC220BEM485,IC220STR001,IC220STR002,IC220STR003,IC220MDD850,IC220MDD840,IC220MDD841,

IC220MDD842,IC220PWR001,IC220PWR002,IC220PWR003,IC220PWR101,IC220PWR201,IC220PWR011,IC220PWR012,IC220PWR013,IC220PWR014,

C693DNM200,IC694DNM200;

Versa Point I/O System MotoR Starter

ModulesIC220STR001,IC220STR002,IC220STR003,IC220ACC100,IC220ACC101,IC220ACC103,IC220ACC104,IC220ACC105,IC220MDD850,IC220TBK081;

SteppinG MotoR Cube with PulsE and Direction

Interface:IC800MCUB12160XN,IC800MCUB12210XN,IC800MCUB12310XN,IC800MCUB12160XE,IC800MCUB12210XE,IC800MCUB12310XE;

PAC Systems

RX7i:IC698CHS017,IC698CHS217,IC698CHS117,IC698PSA100,IC698PSA350,IC698PSD300,IC698CPE010,IC698CPE020,IC698CRE020,

IC698CPE030,IC698CRE030,IC698CPE040,IC698CRE040,IC698CMX016,IC698RMX016,IC698CRE020,IC698CRE030,IC698CRE040,IC698RMX016;

6" Quick Panel Control & 6" Quick Panel

View":IC754CSL06CTD,IC754CBL06CTD,IC754VSL06CTD,IC754VBL06CTD,IC754OBL06CTD,IC754OTL06CTD,

IC754CSX06CTD,IC754CSF06MTD,IC754CSL06MTD,IC754CBL06MTD,IC754VSL06MTD,IC754VBL06MTD,IC754CSF06CTD,IC754TAN001,IC754PCMCIA001-A,

IC754ACC06BEZ01,IC754ACC06BEZ02,IC754ACC06BEZ03,IC754ACC06BEZ04,IC754ACC12BEZ01;

PAC Systems

RX3i:IC695CPU310,IC695PSA040,IC695PSD040,IC695PSD140,IC695PSA140,IC695LRE001,IC695ETM001,IC695ALG600,IC695HSC304,

IC695HSC308,IC695CMM002,IC695CMM004,IC695ALG608,IC695ALG616,IC695ALG626,IC695ALG628,IC695ALG704,IC695ALG708,IC695ALG728,

IC695PBM300,IC694ACC300,IC694MDL230,IC694MDL231,IC694MDL240,IC694MDL241,IC694MDL250,IC694MDL260,IC694MDL632,IC694MDL634,

IC694MDL645,IC694MDL646,IC694MDL654,IC694MDL655,IC694MDL660,IC694MDL310,IC694MDL330,IC694MDL340,IC694MDL350,IC694MDL390,

IC694MDL732,IC694MDL734,IC694MDL740,IC694MDL741,IC694MDL742,IC694MDL752,IC694MDL753,IC694MDL754,IC694MDL

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

930,IC694MDL931,
IC694MDL940,IC694APU300,IC694ALG220,IC694ALG221,IC694ALG222,IC694ALG223,IC694ALG390,IC694ALG391,IC694ALG392,IC694ALG442,IC694APU305,
IC694BEM320,IC694BEM321,IC694BEM340,IC694BEM341,IC694DNM200,IC694DSM314,IC694DSM324,IC694APU300,IC693ALG220,IC693ALG221,
IC693ALG222,IC693ALG223,IC693ALG390,IC693ALG391,IC693ALG392,IC693ALG442,IC693BEM331,IC693BEM340,IC693APU305,IC693BEM320,
IC693DNM200,IC693DNS301,IC693DSM314,IC693DSM324,IC693TCM303,IC693PTM100,IC693PTM101,IC693ADC311,IC693ADS301,IC693APU301,
IC693APU302,IC693BEM310,IC693BEM330,IC693BEM332,IC693BEM333,IC693BEM334,IC693BEM335,IC693BEM350,IC693CDC200,IC693CMM301,
IC693CMM302,IC693CMM304,IC693CMM305,IC693CMM311,IC693CMM321,IC693DNM200,IC693DSM302,IC693DVM300,IC693MCM001,IC693MCM002,
IC693MCS001,IC693MCS001,IC693MDL232,IC693MDL630,IC693MDL631,IC693MDL633,IC693MDL640,IC693MDL641,IC693MDL643,IC693MDL644,
IC693MDL652,IC693MDL653,IC693MDL750,IC693MDL751,IC693PBM200,IC693PBS201,IC693PCM30,IC693PCM300,IC693PCM301,IC693PCM311,
IC693PMC801,IC693PMI800,IC695CHS016,IC695CHS012,IC694CHS392,IC694CHS398,IC693CHS392,IC693CHS391,IC693CHS397,IC693CHS398,
IC693CHS393,IC693CHS399,IC695PSA040,IC695PSD040,IC695PSD140,IC694PWR321,IC694PWR330,IC694PWR331,IC693PWR321,IC693PWR330,
IC693PWR322,IC693PWR328,IC693PWR331,IC693CPU366,IC693CPU366;
Series 90-20 I/O Modules:IC692MAA541,IC692MDR541,IC692MDR741,IC692CPU211;
芯片级维修摩迪康自动控制产品:
Quantum PLC:140CPU11302,140CPU11303,140CPU11312A,140CPU53414A,140CPU21304,140CPU42402,140CPU43412,140CPU43412A,140CPU53414;
140CRP81100,140EIA92100,140NOA6XXXX,140NOL911X0;140CRA93X00,140NOM21X00,140NOM25200,140NOE2X100,140NOE3X100,140NOE5X100,
140NOE771xx,140EHC10500,140EHC20200,140ESI06210,140HLI34000,140MSC10100,140XBE10000,140CHS11000,140XSM0200,140XSM01000,
140XCP90000,
Quantum automation platform Backplanes:140XBP00200,140XBP00300,140XBP00400,140XBP00600,140XBP01000,140XBP01600;
Quantum automation platform Powersupply modules:140CPS11100,140CPS11410,140CPS12400,140CPS12420,140CPS21100,140CPS21400,
140CPS22400,140CPS41400,140CPS42400,140CPS51100,140CPS52400;
Quantum automation platform Discretel/O:140DAI34000,140DAI35300,140DAI44000,140DAI45300,140DAI54000,140DAI54300,140DAI55300,140DAI74000,
140DAI75300,140DDI15310,140DDI35300,140DDI35310,140DDI36400,140DDI67300,140DDI84100,140DDI85300,140DSI35300,140DAO84000,140DAO84010,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

140DAO84210,140DAO84220,140DAO85300,140DDO15310,140DDO35300,140DDO35301,140DDO35310,140DDO36400,140DDO88500,140DDO84300,

140DRA84000,140DRC83000,140DVO85300,140DAM59000,140DDM39000,140DDM69000;

Quantum Automation Platform Analog I/O:140ACI03000,140ACI04000,140ARI03010,140ATI03000,140AVI03000,140ACO02000,140ACO13000,140AVO02000,

140AMM09000,140XTS00200,140XCP20000,140XTS00500;**SERCOS 141MM SQuantum motion control modules:**141MMS42501,141MMS53502;

Quantum Automation Platform In trinsically safe I/O:140AII33010,140AII33000,140AII33000,140DII33000,140AIO33000,140DIO33000;

Magelis display units with2-line alpha numeric screen:XBT-H002010,XBT-H022010,XBT-H012010,XBT-H012110,XBT-H811050,XBT-H001010,XBT-H021010,

XBT-H011010,XBT-P012010,XBT-P022010,XBT-P022110,XBT-P011010,XBT-P021010,XBT-P021110,XBT-E014010,XBT-E014110,XBT-E016010,XBT-E016110,

XBT-E013010,XBT-E013110,XBT-E015010,XBT-E015110;**Motion control 140 MSB10100 Quantum single-axis motion module:**140MSB10100;

Magelis display yunits and terminals with 8line matrix screen:XBT-HM007010,XBT-HM027010,XBT-HM017010,XBT-HM017110,XBT-HM017010A8(1),

XBT-PM027010,XBT-PM027110,XBT-X000;**MagelisTerminalswithgraphicscreenwithkeypadortouch-sensitive screen:**XBT-F01110,XBT-F011310,

XBT-F023110,XBT-F023310,XBT-F024110,XBT-F024310,XBT-F032110,XBT-F032310,XBT-F034110,XBT-F034310,XBT-FC022310,XBT-FC044310,

XBT-FC084310,XBT-FC064310,XBT-F024510,XBT-F024610,XBT-F034510,XBT-F034610,XBT-FC044510,XBT-FC044610,XBT-FC084510,XBT-FC084610,

XBT-FC064510,XBT-FC064610,TXBTF024510,_TXBTF024710,TFTXRAM516,TFTXRAM532;

TC2000 Industrial PCs:TCCNB011A2E000,TCCNB011A2F000,TCCNB011A3E000,TCCNB021A3E000,TCCB2011A2E0p0,TCCB2011A2F0p0,TCCB2011A3E000,

TCCB2011D2E000,TCCB2011D2F000,TCCB2011D3E000,TCCB5011A2E0p0,TCCB5011A2F0p0,TCCB5011A3E000,TCCB5011D2E000,TCCB5011D2F000,

TCCB5011D3E000,TCCK2011A2E0p0,TCCK2011A2F0p0,TCCK2000A3E000,TCCK2011D2E000,TCCK2011D2F000,TCCK2011D3E000,TCCK5011A2E0p0,

TCCK5011A2F0p0,TCCK5011A3E009,TCCK5021A3E009,TCCK5011D2E000,TCCK5011D2F000,TCCK5011D3E000,TCCT5011A2E0p0,TCCT5011A2F0p0,

TCCT5011A3E000,TCCT5011D2E000,TCCT5011D2F000,TCCT5011D3E000;

Lexium05伺服驱动

器:LXM05AD10F1,LXM05AD17F1,LXM05AD28F1,LXM05AD10M2,LXM05AD17M2,LXM05AD28M2,LXM05AD10M3X,LXM05AD17M3X,

LXM05AD42M3X,LXM05AD14N4,LXM05AD22N4,LXM05AD34N4,LXM05AD57N4; **Lexium17SHP**伺服驱动装

置:MHDS1112N00,MHDS1198N00;

LexiuM 15LP伺服驱动器:LXM15LD13M3,LXM15LD21M3,LXM15LD28M3,LXM15LD13M3,LXM15LD21M3,LXM15LD28M3,LXM15LU60N4,LXM15LD10N4,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

LXM15LD17N4;**Lexium15 MP**伺服驱动器:LXM15MD28N4,LXM15MD40N4,LXM15MD56N4;**Lexium15 HP**伺服驱动器:LXM15HC11N4X,LXM15HC20N4X;

TSXCAY运动控制模块:TSXCANCA100,TSXCANCA300,TSXCANCA50,TSXCANCADDpp,TSXCANCB100,TSXCANCB300,TSXCANCB50,TSXCANCBDDp,

TSXCANCD100,TSXCANCD300,TSXCANCD50,TSXCAPS15,TSXCAPS9,TSXCAY2p,TSXCAY33,TSXCAY4p,TSXCCPS15,TSXCPS15050,TSXCCPS15100,

TSXCDP053,TSXCDP103,,TSXCDP203,TSXCDP30p,TSXCDP50p,TSXCDP611,TSXCPP110,TSXCSY164,TSXCSY8p,TSXCXP213,TSXCXP235,TSXCXP245,

TSXCXP613,TSXCXP635,TSXCXP645,TSXFPACCp,TSXFPACC1p,TSXFPCA100,TSXFPCA200,TSXFPCA500,TSXFPCC100,TSXFPCC200TSXFPCC500,

TSXFPCR100,TSXFPCR200,TSXFPCR500,TSXPBSCA100,TSXPBSCA400,TSXTAPMAS,TSXTAPS1505;

Lexium17D伺服驱动装置:MHDA1004A00,MHDA1004N00,MHDA1008A00,MHDA1008N00,MHDA1017A00,MHDA1017N00,MHDA1028A00,MHDA1028N00,

MHDA1056A00,,MHDA1056N00,MHDA1112A00,MHDA1198A00,ABE7BV20,ABE7CPA01,ABE7CPA11,ABE7H16R20,ABL7RE2402,ABL7RE2403,ABL7RE2405,

ABL7RE2410; **Lexium17S**伺服驱动装置:MHDS1004N00,MHDS1008N00,MHDS1017N00,MHDS1028N00,MHDS1056N00;

Lexium17 drive

typeMDHA1004A00,MDHA1008A00,MDHA1017A00,MDHA1028A00,MDHA1056A00,MDHA1112A11,MDHA1008A00,MDHA10170,

MDHA1004,MDHA1004,MDHA1008,MDHA1028,MDHA1056,MDHA1112,MDHA1198; **Lexium17 DHP**伺服驱动装置:MHDA1112N00,MHDA1198N00;

Lexium运动控制模块:141MMS42501,141MMS53502,TSXCAPS9,TSXCAY21,TSXCAY22,TSXCAY33,TSXCAY41,TSXCAY42,TSXCCPS15050,

TSXCCPS15100,TSXCCPS15,TSXCCT200,TSXCDP053,TSXCDP101,TSXCDP103,TSXCDP203,TSXCDP301,TSXCDP303,TSXCDP501,TSXCDP503,

TSXCDP611,TSXCSY164,TSXCSY84,TSXCSY85,TSXCXP213,TSXCXP223,TSXCXP233,TSXCXP235,TSXCXP243,TSXCXP245,TSXCXP263,TSXCXP273,

TSXCXP283,TSXCXP613,TSXCXP633,TSXCXP635,TSXCXP643,TSXCXP645,TSXCXP663,,TSXCXP673,TSXCXP683,TSXTAPMAS,TSXTAPS1505,

VY1X411CA15;

Modicon TSX Neza可编程控制器:TSX08CD12,TSX08CD08,TSX08CD12,TSX08CD12R8A,TSX08CD12F8A,TSX08CD12M8A,TSX08CD08R6A,TSX08CD08F6A,

TSX08CD12R8D,TSX08CD12F8D,TSX08CD12M8D,TSX08CD12R8A,TSX08CD12F8A,TSX08CD12M8A,TSX08CD08R6A,TSX08CD08F6A,TSX08CD12R8D,

TSX08CD12F8D,TSX08CD12M8D;

Premium处理器和模块单元:TSXACCVA625,TSXAEY1600,TSXAEY1614,TSXAEY414,TSXAEY420,,TSXAEY800,TSXAEY810,TSXASY810,TSXASY410,

TSXBATM02,TSXBATM03;

TSX CAY运动控制模块:TSXCAY21,TSXCAY22,TSXCAY33,TSXCAY41,TSXCAY42;TSXCBRY2500,TSXCBRY2500F,TSXCBRYK5,TSXCBY010K,TSXCBY030K,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

TSXCBY050K,TSXCBY1000,TSXCBY1000K,TSXCBY120K,TSXCBY180K,TSXCBY280K,TSXCBY380K,TSXCBY500K,TSXCBY720K,TSXCBYACC,10TSXCBYK9,
TSXCCY1128,TSXCFY11,TSXCFY21,TSXCPP100/110,TSXCTY2C,TSXCTY4A,TSXDEY08D2,TSXDEY16A2,TSXDEY16A3,TSXD
EY16A4,TSXDEY16A5,
TSXDEY16D2,TSXDEY16D3,TSXDEY16FK,TSXDEY32D2K,TSXDEY32D3K,TSXDEY64D2K;
离散量I/O模块:TSXDYMY28FK,TSXDYMY28RFK,TSXDSY08R5,TSXDSY08T2,TSXDSY08T22,TSXDSY08T31,TSXDSY16R5,TSXDS
Y16T2,TSXDSY16T3,
TSXEED08D2,TSXEED16D2,TSXEMF16DT2,TSXESF08T22,TSXETY110,TSXETY110WS,TSXETY4103,TSXETY5103,TSXFANA4
P,TSXFANA5P,TSXFAND2P,
TSXFPP10,TSXFPP20,TSXJNP112,TSXJNP114,TSXMBP100,TSXMCPC002M,TSXMCPC224K,TSXMCPC512K,TSXMFPP001M,
TSXMFPP002M,TSXMFPP004M,
TSXMFPP128K,TSXMFPP224K,TSXMFPP384K,TSXMFPP512K,TSXMRPC001M,TSXMRPC002M,TSXMRPC003M,TSXMRPC007
M,TSXMRPC01M7,
TSXMRPC448K,TSXMRPC768K,TSXMRPF004M,TSXMRPF008M,TSXMRPP128K,TSXMRPP224K,TSXMRPP384K,TSXPCAP,TS
XP57104M,TSXP57154M,
TSXP57204M,TSXP57254M,TSXP572634M,TSXP5730,TSXP57354M,TSXP573634M,TSXP57454M,TSXP574634M,TSXP57554M,
TSXP575634M,TSXPBY100,
TSXPCI57204M,TSXPCI57354M,TSXPCIAACC1,TSXPCX1031,TSXPCX3030,TSXPLP01,TSXPLP101,TSXPSI2010,TSXPSY1610M,
TSXPSY2600M,TSXPSY3610M,
TSXPSY5500M,TSXPSY5520M,TSXPSY8500M,TSXREY200M,TSXRKA02,TSXRKY12,TSXRKY12EX,TSXRKY4EX,TSXRKY6,TS
XRKY6EX,TSXRKY8,
TSXRKY8EX,TSXSAY100,TSXSAY1000,TSXSACP11p,TSXSCY11601,TSXSCY21601,TSXTLYEX,TSXWMY100,170AAI03000,170
AAI14000,170AAI52040,
170AAO12000,170AAO92100,170ADI34000,170ADI35000,170ADI54050,170ADI74050,170ADM35010,170ADM35011,170ADM350
15,170ADM37010,
170ADM39010,170ADM39030,170ADM54080,170ADM69051,170ADO34000,170ADO35000,170ADO53050,170ADO54050,170AD
O73050,,170ADO74050,
170AEC92000,170AMM09000,170ANR12090,170ANR12091,170ARM37030,170DNT11000,170EDI34600,170EDO34600,170ENT1
1001,170ENT11002,
170FNT11001,170INT12000,170INT11003,170PNT11020,170INT16020,174CEV20030,174CEV30020,499NEH10410,499NEH141
00,499NES27100,499NES18100,
499NOH10510,499NOS27100,499NTR10010,499NTR10100,499NES25100;
Modicon TSX Premium 自动化平台:**TSX57** 处理器:TSXP57103M,TSXP57153M,TSXP57203M,TSXP572623M,TSXP57253M,TSX
P572823M,TSXP57303M,
TSXP573623M,TSXP57353M,TSXP57453M,TSXP574823M;内存模块:TSXMRP032P,TSXMRP232P,TSXMRP064P,TSXMRP264P,
TSXMRP0128P,TSXMRP2128P,
TSXMRP0256P,TSXMRP3256P,TSXMRP3384P,TSXMRP0512P,TSXMFP032P,TSXMFP232P,TSXMFP064P,TSXMFP264P,TSX
MFP0128P,TSXMFPBAK032P,
TSXMRPDS2048P,TSXBATM01,TSXPCAP,TPCX57203M,TPCX57353M,TSXMRP032P,TSXMRP232P,TSXMRP064P,TSXMRP26
4P,TSXMRP0128P,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

TSXMRP2128P,TSXMRP0256P,TSXMRP3256P,TSXMFP032P,TSXMFP232P,TSXMFP064P,TSXMFP264P,TSXMFP0128P,TSXMFPBAK032P,TSXBATM01;

TSX PSY电源模块: TSXPSY1610M,TSXPSY3610M,TSXPSY5520M,TSXPSY2600M,TSXPSY5500M,TSXPSY8500M;TSXPLP01,TSXPLP101;

离散量输入模块:TSXDEY08D2,TSXDEY16D2,TSXDEY16D3,TSXDEY16A2,,TSXDEY16A3,TSXDEY16A4,TSXDEY16A5;TSXDEY16FK,TSXDEY32D2K,

TSXDEY64D2K,TSXDEY32D3K,TSXDMY28FK,TSXDMY28RFK;

离散量输出模块:TSXDSY08T2,TSXDSY08T22,TSXDSY16T2,TSXDSY08T31,TSXDSY16T3,TSXDSY08R5,TSXDSY16R5,TSXDSY08R5A,TSXDSY08R4D,

TSXDSY08S5; TSXDSY16S5,TSXDSY16S4,TSXDSY32T2K,TSXDSY64T2K;

TSXPAY安全模块:TSXPAY262,TSXPAY282;ABE-7CPA13,TSXCPP102,TSXCPP202,TSXCPP302,TSXCPP301,ABE-7H08R,ABE-7H08S21,ABE-7H12R,

ABE-7H12S21,ABE-7H16R,ABE-7H16S21,ABE-7H16R23,ABE-7H16F43,ABE-7H16S43,ABE-7S16E2,ABE-7P16F3,ABE-7S08S2,ABE-7R08S,ABE-7P08T330,

ABE-7S16S,ABE-7R16S,ABE-7R16T,ABE-7P16T,ABE-7CPA01,ABE-7CPA11,ABE-7CPA02,ABE-7CPA21,ABE-7CPA03,ABE-7CPA31,ABE-7CPA12;

TBX分布式I/O模块:TBXCEP1622,TBXCSP1622,TBXCSP1625,TBXDES1622,TBXDES16C22,TBXDES16F22,TBXDES1633,TBXDES16S04,TBXDSS1622,

TBXDSS16C22,TBXDSS1235,TBXDSS1625,TBXDMS16C22,TBXDMS16C222,TBXDMS16P22,TBXDMS1025,TBXDMS1625,TBXDMS16S44,TBXLEP030,

TBXLEP020,TBXBLP01;TBXSUP10,TBXCBS010,TBXGND015,TBXR015,TBXSEP08,TBXSSP08,TBXEEP08C22,TBXEEP1622,TBXESP08C22,TBXESP1622,

TSXFPACC4,TBXFPACC10,TBXBLP10,TBXBAS10,TBXAES400,TBXASS200,TBXAMS620,TBXLEP030,TBXBLP01,TSX_AAK2;

模拟量I/O模块:TSXAEY420,TSXAEY414,TSXAEY800,TSXAEY1600,TSXAEY810,TSXAEY1614,TSXASY410,TSXASY800,TSXAEY420,TSXAEY414,TSXAEY800,

TSXAEY1600,TSXAEY810,TSXAEY1614,TSXASY410,TSXASY800;TSXCTY2A,TSXCTY4A,TSXCAPS15,TSXCAPS9,TSXTAPS1505,TSXTAPMAS,ABE-7CPA01,

ABE-7H16R20,ABE-7H16R20,ABE-7CPA11,TSXCCPS15050,TSXCCPS15100,TSXCCPS15,TSXCXP213,TSXCXP613,TSXCFY11,TSXCFY21,TSXCAPS15,

TSXISPY101,TSXISPY101C1,TSXISPY111,TSXISPY111C1,TBXSUP10,TSXSUP1011,TSXSUP1021,TSXSUP1051,TSXSUP1101,TSXETY110,TSXETY210,

TSXETY110WS,TSXETY4102,TSXETY5102,TCCEH01,TSXETHPC101,TLXCDDR13M,TSXSAY100TSXSAY1000,TSXMBP100,990NAD23000,990NAD23010,

170XTS02000,ASMBKT185,990NAD23011,170XTS02100,AUTC101272123FR,TSXSCY21601,TSXSCY11601,010TSXSCP114,TSXSCP111,TSXSCP112,

TSXSACA50,TSXSACA64,TSXSACA72,TSXPACC01,TSXSACA10,TSXFPP20,TSXSCY21601,TLXCDDR12M,TSXFPP10,TSXFACC3,TSXFACC4,TSXFACC2,

TSXFACC12,TSXFACC14,TSXFACC3,TSXFACC4,TSXEFACC99,TSXFACC7,TSXFACC6,TSXFACC8M,TSXFACC9,T SXFPC10M,AUTC101272123EN,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

TSXSCY21601,TSXSACP111,TSXSACP114,TSXSACP112,TSXCDDR12M,TSXSCY21601,TSXSACP111,TSXSACP114,TSXSACP112,T
SXPACC01,TSXSACPXC4030,
TSXSCYCU6030,TSXPCD1031,TSXSACPCC1030,TSXSACPDC1030,TSXSACPDC1100,TSXSACPXC2030,TSXSACPDC1030,TSXSACP
CD1100,TSXSACPCC1030,
TSXSACPUC4030,TSXSACPUCM4030,TSXSACPUC4530,TSXSACPXC4030,TSXSACPXC4030,TSXSACPXC2030,TSXPACC01,TFTXCB10
20,TFTXCB1050,TSXPCD1030,
TSXPCX1031,TSXPCX1130(2),XBT-Z968,TSXSCYCM6030,TSXSCYCU6530,TSXSCYCM6030,TSXCTC07,TSXCTC10,TSXIBY10
0,TSXIBX100,TLXLIBSCNVF,
170INT11000,TSXPBY100,TLXLFBC10M;
TwidO可编程控制器:TWDLCAA10DRF,TWDLCAA16DRF,TWDLCAA24DRF,TWDLCAA40DRF,
TWDLCAA40DRF,
TWDLCAE40DRF,TWDLMDA20DTK,TWDLMDA20DUK,TWDLMDA20DRT,TWDLMDA40DTK,TWDLMDA40DUK,TWDDDI8DT,TW
DDAI8DTTWDDDI16DT,
TWDDDI16DK,TWDDDI32DK,TWDDMM8DRT,TWDDMM24DRF,TWDDRA8RT,TWDDDO8TT,TWDDDO8UT,TWDDRA16RT,TW
DDO16TK,TWDDDO16UK,
TWDDDO32TK,TWDDDO32UK,TWDAMI2HT,TWDAMM3HT,TWDALM3LT,TWDAMO1HT,TWDAMI4LT,TWDAVO2HT,TWDAMI8H
T,TWDARI8HT,TWDNOZ485D,
TWDNOZ232D,TWDNOZ485T,TWDNAC485T,TWDNAC485D,TWDNAC232D,TWDNCO1M,499TWD01100,TWDNOI10M3,TWDXC
PODM,TWDXCPODC,
TWDXCPRTC,TWDXCPMFK32,TWDXCPMFK64,TSX08PRG,TSXPCX3030-C,TSXPCX1031-C,ABE7B20MPN20,ABE7B20MRM20,
ABE7B20MPN22,
ABE7E16EPN20,ABE7E16SPN20,ABE7E16SRM20,ABE7E16SPN22,ABFT26B050,ABFT26B100,ABFT26B200,ABFT20E050,ABF
T20E100,ABFT20E200,
ABE7BV20,ABE7BV20TB,ABE7FU012,ABE7FU030,ABE7FU100,ABE7FU200,ABFC20R200,XBTN200,XBTN400,XBTN401,XBTZ9
78,XBTZ945,TSX08H02M,
TSX08H04M,TSX08HMRUNCAB,TSX08HMPRGAB,ABL1REM12050,ABL1REM24025,ABL1RPM12083,ABL1REM24042,ABL1R
PM24042,ABL1REM24062,
ABL1RPM24062,ABL1REM24100,ABL1RPM24100,ABL7CEM24003,ABL7CEM24006,ABL7CEM24012,ABL7RM1202,ABL7RM240
1;
ABL7RE电源:ABL7RE2402,ABL7RE2403,ABL7RE2405,ABL7RE2410;**ABL7RP**电源:ABL7RP1205,ABL7RP2403,ABL7RP2405,AB
L7RP2410,ABL7RP4803;
AdvantysABE7:ABE7H16C11,ABE7H16C21,ABE7H16C31,ABE7H20E100,ABE7H20E200,ABE7H16R10,ABE7H16R11,ABE7H16
R50,ABE7H16R20,ABE7H16R21,
ABE7H16R31,ABE7CPA01,ABE7CPA02,ABE7CPA03,ABE7R16T111,ABE7R16T212,ABE7R16T210,ABE7R16T230,ABE7R16T33
0,ABE7R16T370,
ABE7B20MPN20,ABE7B20MPN22,ABE7B20MRM20,ABE7E16EPN20,ABE7E16SPN20,ABE7E16SPN22,ABE7E16SRM20,OTB1C
0DM9LP,OTB1E0DM9LP,
OTB1S0DM9LP,STBNCO2212,STBNFP2212,STBNIB2212,STBNDP2212,STBNCO1010,STBNIB1010,STBNDP1010,STBNMP221
2,STBNND2212,STBNND1010;
AS-Interface:ASI20MA2VU,ASI20MA2VI,ASI20MT4I4OR,ASI20MT4I4OS,ASI20MT4I4OSA,ASI20MT4IE,ASI20MT2I1OTE,ASI20M

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

T4I3ORE,ASI20MT4I3OSE,
ASI20MT4I3OSAE,TWDNOI10M3,TSXSAY1000,TSXSAZ10140EIA92100,ASIABLB3002,ASIABLB3004,ASIABLM3024,TSXSUPA0
5,ASIABLD3002,
ASIABLD3004,XPSMC16X,XPSMC16X,XPSMP11123P,XPSLCM1150;
触摸屏图形终端MageliS XBTGT系列:XBTGT1100,XBTGT1130,XBTGT2110,XBTGT2120,XBTGT2130,XBTGT2220,XBTGT2330,X
BTGT4230,XBTGT4330,
XBTGT4340,XBTGT5230,XBTGT5330,XBTGT5340,XBTGT6330,XBTGT6340,XBTGT7340,XBTZGM128,XBTZGM256,MPCYN00C
FE00N,MPCYN00CF100N,
XBTZG61,XBTZG62,XBTZG64,XBTZG65,XBTZG66,MPCYK5OSPSKIT,XBTZ3002,ABL7RM2401,ABL7RM24025;
Preventa安全PLC:XPSMF31222,XPSMF3022,XPSMF3502,XPSMF3522,XPSMF3542,ABL7RE2403,ABL7RE2405,ABL7RE2410,A
BL1REM24042,XBTG2130,
XBTG2330,XBTG4330,,XBTG5230,XBTG5330,XBTG6330,XBTZG915,XPSMF60,XPSMFAO801XPSMFAI801,XPSMFCIO2401,XP
SMFDIO241601,XPSMFDI3201,
XPSMFDI2401,XPSMFCPU22,XPSMFPS01,XPSMFGEH01,XPSMF2DO401,XPSMF2DO1601,XPSMF2DO801,XPSMF2DO1602,X
PSMF3DIO8801,
XPSMF3DIO16801,XPSMF3DIO20802,XPSMF3AIO8401;
ZeliO LogiC逻辑控制器SR3扩展型逻辑控制器:SR2B121JD,SR2B201JD,SR2A101BD,SR2B121BD,SR2B122BD,SR2A201BD,SR2
B201BD,SR2B202BD,
SR2B121B,SR2B201B,SR2A101FU,SR2B121FU,SR2A201FU,SR2B201FU,SR2D101BD,SR2E121BD,SR2D201BD,SR2E201BD,S
R2E121B,SR2E201B,
SR2D101FU,SR2E121FU,SR2D201FU,SR2E201FU,SR3B101BD,SR3B102BD,SR3B261BD,SR3B262BD,SR3B101B,SR3B261B,,
SR3B101FU,SR3B261FU,
SR3XT61BD,SR3XT101BD,SR3XT141BD,SR3XT61FU,SR3XT101FU,SR3XT141FU,SR3XT61B,SR3XT101B,SR3XT141B,ABL7R
M1202,ABL7RM2401;
Micro Automation Platform TSX37-10 PLCs:TSX3705028DR1,TSX3708056DR1,TSX3710001,TSX3710028AR1,TSX3710028D
R1,TSX3710101,
TSX3710128DR1,TSX3710128DT1,TSX3710128DTK1,TSX3710164DTK1,TSX3721001,TSX3721101,TSX3722001,TSX3722101,T
SXDEZ08A4,TSXDEZ08A5,
TSXDEZ12D2,TSXDEZ12D2K,TSXDEZ32D2,TSXDMZ16DTK,TSXDMZ28AR,TSXDMZ28DR,TSXDMZ28DT,TSXDMZ28DTK,TSX
DMZ64DTK,TSXDSZ04T22,
TSXDSZ08R5,TSXDSZ08T2,TSXDSZ08T2K,XDSZ32R5,TSXDSZ32T2,TSXAEZ414,TSXAEZ801,TSXAEZ802,TSXAMZ600,TSXA
SZ200,TSXASZ401,TSXCTZ1A,
TSXCTZ1B,TSXCTZ2A,TSXCTZ2AA,TSXETZ410,TSXETZ510,TSXSAZ10,TSXCPP110,TSXSACP111,TSXSACP112,TSXSACP114,TS
XMBP100,TSXFPP20,
TSXSTZ10,TSXFPP10,TSXMRPP128K,TSXMRP032P,TSXMRPP384K,TSXMRP232P,TSXMRPP224K,TSXMRP064P,TSXMRPP3
84K,TSXMRP264P,
TSXMRPPC448K,TSXMRP0128P,TSXMRPPC768K,TSXMRP2128P,TSXMFP128K,TSXMFP032P,TSXMCPC224K,TSXMFP232
P,TSXMFP224K,TSXMFP64,
TSXMCPC224K,TSXMFP264P,TSXMFP384K,TSXMFP0128P,TSXMFPB096K,TSXMFPBAK032P;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

STB分布式I/O:STBD AI5260,STBDDI3230,STBDDI3420,STBDDI3425,STBDDI3610,STBDDI3615,STBDDI3725,STBDDI5230,STBD AI5260,STBD AI7220,
STBDDO3200,STBDDO3230,STBDDO3410,STBDDO3415,STBDDO3600,STBDDO3605,STBDDO3705,STBDAO8210,STBDRC32
10,STBDRA3290,STBDAO5260,
STBAVI1270,STBAVI1275,STBAVI1255,STBACI1230,STBACI1225,STBART0200,STBAVO1250,STBAVO1265,STBAVO1255,STB
ACO1210,STBACO1225,
STBEPI1145,STBEPI2145,STBEHC3020,STBNIP2212,STBNCO2212,STBNCO1010,STBNMP2212,STBNFP2212,STBNIB2212,ST
BNIB1010,STBNDP2212,
STBNDP1010,STBNND2212,STBNND1010,STBXBE1200,STBCPS2111,PDT3100,PDT3105;
PhaseO开关电源:ABL-7CEM24003,ABL-7CEM24006,ABL-7CEM24012,ABL-7RE2402,ABL-7RE2403,ABL-7RE2405,ABL-7RE2410,
ABL-7RP1205,ABL-7RP2403,
ABL-7RP2405,ABL-7RP2410,ABL-7RP4803,ABL-7REQ24050,ABL-7REQ24100,ABL-7UEQ24100,ABL-7UEQ24200,ABL-7UES240
50,ABL-7UPS24100,
ABL-7UPS24200,ABL-7UPS24400; **AS-i**总线供电模块:TSXSUP1011,TSXSUP1021,TSXSUP1051,TSXSUP1101,TSXSUPA02,TSX
SUPA05;
PCI208 Motion Coordinator:PCI208:P180,P181,P182,P183,P184,P185,P187,P315,P325,P315-CAN-16I/O,P325-CAN-8AnalogIn
puts,CAN16-I/OModule(P315),
MC202,Euro205,MC206,MC216,MC224;800Series RIODrop:ASP890300;
Logic master S/WI:C641SWP701,IC641SWP704,IC641SWP751,IC641SWP706,IC641SWP711,IC641SWP713,IC641SWP715,IC
641SWP716,IC641SWP731,
IC641SWP745,,IC641LAF706; **Genius BusController**:IC697CMM731,IC697CMM798,IC651ENS040,IC651ENS042,IC651ENS00
3;
CIMPLICITY CONTROL:IC641CTL970IC641CTL971,IC647WMI920,IC697BEM715;**Analog I/O**:IC697ALG230,IC697ALG320,IC69
7ALG440,IC697ALG441;
Fanuc I/O Link:IC641SWP708B,IC697BEM721;**Plug&Play Coprocessors**:IC697VPC462,IC697VPC463,IC697VPC464,IC697VP
C494;
VME Boards:EPC-1GE,SMCC-VME,VMIVME-3230; **InterBus modules**:AS-BBKF-201,AS-BBKF-202,AS-BDEA-202,AS-BDEA-20
3;
Compact Automation Platform CPUs:AS-HDTA-200,AS-HDTA-201,AS-HDTA-202,AS-HDTA-200C,AS-HDTA-201C,AS-HDTA-2
02C,PC-E984-258R,
PC-E984-258,PC-E984-258C,PC-E984-265,PC-E984-265C,PC-E984-275,PC-E984-275C,PC-E984-285,PC-E984-285C,AS-FLSH-0
04;
Compact Automation Platform DiscreteI/OModules:AS-BDEP-214,AS-BDEP-215,AS-BDEP-216,AS-BDEP-217,AS-BDEP-220,
AS-BDEP-254,AS-BDEP-256,
AS-BDEP-257,AS-BDEP-254C,AS-BDEP-256C,AS-BDEP-257C,AS-BDEO-216,AS-BDEP-297,AS-BDEP-296,AS-BDEP-208,AS-BD
EP-210,AS-BDEP-211,
AS-BDEP-218,AS-BDAO-216,AS-BDAP-216N,AS-BDAP-217,AS-BDAP-204,AS-BDAP-208,AS-BDAP-210,AS-BDAP-218,AS-BDAP
-258,AS-BDEP-258C,
AS-BDAP-211,AS-BDAP-212,AS-BDAP-292,AS-BDAP-220,AS-BDAP-250,AS-BDAP-252,AS-BDAP-253,AS-BDAP-250C,AS-BDAP
-252C;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

Compact Automation Platform Analog/I/O modules:AS-BADU-205,AS-BADU-206,AS-BADU-210,AS-BADU-211,AS-BADU-212,AS-BADU-216,AS-BADU-204,AS-BADU-214,AS-BADU-254,AS-BADU-254C,AS-BADU-256,AS-BADU-256C,AS-BADU-257,AS-BDAU-202,AS-BDAU-204,AS-BDAU-208,AS-BDAU-252,AS-BDAU-252C;**Intelligent modules:**AS-BZAE-201,AS-BZAE-204,AS-BFRQ-204,AS-BFRQ-254,AS-BVRC-200,AS-BCTR-205,212,224;

芯片级维修OPTO22奥普图运动控制产品:

SNAP工业控制器:SNAP-LCE,SNAP-LCM4,SNAP-LCSX-PLUS,SNAP-LCSX,SNAP-UP1-ADS,SNAP-UP1-D64,SNAP-UP1-M64,SNAP-PAC-S1,SNAP-PAC-R1,SNAP-PAC-R2;

SNAP I/O智能处理器:SNAP-ODC5-32-SNK,SNAP-UP1-D64,SNAP-UP1-M64,SNAP-B3000-ENET,SNAP-ENET-S64,SNAP-ENET-D64,B3000,SNAP-BRS,SNAP-PAC-R2,SNAP-ENET-RTC,B3000-HA,SNAP-B3000-MODBUS,SNAP-BRS-HA,SNAP-B4,SNAP-B6;

SNAP-模拟量输入模块:SNAP-AIARMS,SNAP-AICTD,SNAP-AICTD-4”,SNAP-AIMA,SNAP-AIMA-4,SNAP-AIMA-i”,SNAP-AIMA-ISR C,SNAP-AIMV2-4,SNAP-AIMV-4,SNAP-AIRATE,SNAP-AIRATD,SNAP-AITM,SNAP-AITM-i,SNAP-AITM-2,SNAP-AITM-2-1,SNAP-AIV,SNAP-AIV-4,SNAP-AIV-i,SNAP-AIV2-i,SNAP-AIVRMS,SNAP-AIPM,SNAP-PH/ORP,SNAPUltimatEI/O,SNAP-LCM4,SNAP-LCSX,SNAP-LCSX-PLUS;

SNAP-模拟量输出模块:SNAP-AOA-23-iSRC,SNAP-AOA-23,SNAP-AOA-3,SNAP-AOV-5,SNAP-AOV-7,SNAP-AOA-23,SNAP-AOA23-iSRC,SNAP-AOV-25,SNAP-AOV-27,SNAP-AOA-28,SNAP-AOD-29;

SNAP-数字量输入模块:SNAP-IAC5,SNAP-IAC5A,SNAP-IAC5MA,SNAP-IAC5FM,SNAP-IAC5AFM,SNAP-IDC5,SNAP-IDC5D,SNAP-IDC5-FAST,SNAP-IDC5-FAST-A,SNAP-IDC5G,SNAP-IDC5-HT,SNAP-IDC5MA,SNAP-IDC5Q,SNAP-IDC5-SW,SNAP-IDC5-SW-NC,SNAP-IDC5FM,SNAP-IDC5DFM,SNAP-IDC-32,SNAP-IDC-HDB,SNAP-IDC-BF6,SNAP-IDC-CBF6;

SNAP-数字量输出模块:SNAP-OAC5,SNAP-OAC5FM,SNAP-OAC5MA,SNAP-OAC5-i,SNAP-OAC5-iFM,SNAP-ODC5SRC,SNAP-ODC5SRCFM,SNAP-ODC5SRCSNK,SNAP-ODC5SRCSNKFM,SNAP-ODC5R,SNAP-ODC5RFM,SNAP-ODC5R5,SNAP-ODC5R5FM,SNAP-ODC5MA,SNAP-ODC5-I,SNAP-ODC5-IFM,SNAP-ODC5A-I,SNAP-ODC5A-IFM,SNAP-ODC-32-SRC,SNAP-ODC-32-SINK,SNAP-IDC-32,SNAP-HD-CBF6,SNAP-HD-BF6,SNAP-IDC-HDB,SNAP-ODC-HDB,OPTOTERMINAL-G20;**SNAP特殊用途模块:**SNAP-SCM-232,SNAP-SCM-485-232,SNAP-SCM-W2,SNAP-PID-V,SNAP-SCM-PROFI;

SNAP电源:SNAP-PS5,SNAP-PS5U,SNAP-PS5-24VDC,SNAP-PS24,SNAP-PS24U,SNAP-PS5C10,SNAP-PS24C10,M4PS12DM4PS24D,M4PS48D,M4PS125D,M4PS120A,M4PS240A;SNAPDNP I/O:SNAP-DNP-ASDS;

OPTO Terminals终端显示器:OPTO Terminal-G70,OPTO Terminal-G75;OPTO-IT系统:OPTO-IT-PM-ADS,OPTO-IT-PM-ADS-PLUS,OPTO-IT-PM-ADS-PLUS24V,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

OPTO-IT-PM-UADS,OPTO-IT-PM-UADS-PLUS,OPTO-IT-PMC-XX,OPTO-IT-RM-D64,OPTO-IT-RM-WLAN-FH,OPTO-IT-RM-UADS,
OPTO-IT-RMC-XX,
SNAP-IT-RM-ADS;

SNAP Digital Output Modules:SNAP-OAC5,SNAP-OAC5MA,SNAP-OAC5FM,SNAP-OAC5-I,SNAP-OAC5-lfm,SNAP-ODC5SR
C,SNAP-ODC5SRCFM,
SNAP-ODC5SNK,SNAP-ODC5SNKFM,SNAP-ODC5ASNK,SNAP-ODC5R,SNAP-ODC5RFM,SNAP-ODC5R5,SNAP-ODC5R5FM,S
NAP-ODC5MA,

SNAP-ODC5-I,SNAP-ODC5-iFM,SNAP-ODC5A-I,SNAP-ODC5A-iFM,SNAP-RETN4,SNAP-RETN4B,SNAP-RETN6,SNAP-RETN6B,
SNAP-FUSE4AB,

SNAP-MODFUSEH;**SNAP powersupplies:**SNAP-PSDIN,SNAP-PSUDIN;

SNAP M4 Controller:M4SSER,M4SARC,M4SENET-100,M4SARCF,M4SARCFR,M4PS12D,M4PS24D,M4PS48D,M4PS125D,M4
PS120A,M4PS240A,M4PSF;

M4SENET-100,M4DUALARC,M4SARC,M4SARCF,M4SARCFR;

芯片级维修百格拉自动控制产品:**BergeRLahR position stepping motor:**WD5-008,WDP5-118,WDP5-228,WDP5-318,WP-111,WP
-231,WP-311;

芯片级维修贝加莱运动控制产品:

B&R SYSTEM2000 B&R2010:0AC0019,0AC2009,0AC2019,0AC4019,0AC4109,0AC9129,0AC91392,0G000100-090,0G001000-0
90,0G001200-090,0G100000-090,2AI3006,2AI7006,2AI7306,2AO3006,2AO7256,2AO9006,2AT3006,2AT6106,2BM1009,2BP1013,
2BP1103,2BP2004,2BP2014,

2BP2024,2BP2104,2BP3004,2CP10060-1,2CP10460-1,2CP20060-1,2DI4006,2DI4256,2DI4266,2DI7256,2DI8256,2DO4286,2DO4
306,2DO6006,2DO7006,

2DO7106,2DS10060-1,2DS10160-1,2EX10050-1,2EX20050-1,2EX3015,2EX3025,2IF10060-1,2IF10160-1,2ME91090-1,2ME91390-
1,2MP1005,2NC30360-1,

2NW10050-1,2PS4259,2PS7409,2TB1209,2TB1409,2UM9006,7AC9119;

APROL过程控制系统 (Process Control System) :AP:SV4-SYS-CMI-01,AP:OT4-OTIF-NO-01,AP:OT4-OTIF-NO-02,AP:SV4-STI
-NROE-01,

AP:SV4-STI-NROE-02,AP:SV4-STI-NRO-01,AP:SV4-STI-NRO-01,AP:SV4-STI-NOE-01,AP:SV4-STI-NOE-02,AP:SV4-EXI-NROE-0
1,AP:SV4-EXI-NRO-01,

AP:SV4-EXI-NOE-01,AP:OT4-OTO-NO-01,AP:SV4-STO-NROE-01,AP:SV4-STO-NRO-01,AP:SV4-STO-NOE-01,AP:SV4-GWI-NG-
01,AP:SV4-GWI-NG-02,

APHW0-DIS-21-01,APHW0-DIS-19-01,APHW0-DIS-19-02,APZUB-DIS-15-02,APZUB-DIS-18-02,AP:ZUB-RED-OPB-01,AP:ZUB-RE
D-SRV-01,

AP:ZUB-RED-SRV-02,AP:ZUB-GPS-SER-01,AP:ZUB-GPS-ETH-01,AP:ZUB-UPS-24-01,AP:ZUB-UPS-1500-01,AP:ZUB-UPS-1000
-02,AP:ZUB-TOW-KBD-01,

AP:ZUB-TOW-EXT-01,AP:ZUB-TOW-CRD-01,0AC8089,0TB7049,AP:ZUB-ETH-LWL-01,5E960001-10,AP:ZUB-WLS-KBMO-01,AP:
ZUB-VIS-MUL-02,

AP:ZUB-VIS-XTERM-01,AP:ZUB-VIS-XTERM-05,FG115-230VAC,FG24VDC;

B&R Motion SystemS系列产品:,7TB7129,7TB71291,7TB712:90-02,7TB712:91-02,8CE00512-1,8CE00712-1,8CE01012-1,8CE01
512-1,8CE02012-1,8CE02512-1,

8CM00512-1,8CM00512-3,8CM00512-5,8CM00512-8,8CM00712-1,8CM00712-3,8CM00712-5,8CM00712-8,8CM01012-1,8CM010

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

12-3,8CM01012-5,8CM01012-8,
8CM01512-1,8CM01512-3,8CM01512-5,8CM01512-8,8CM02012-1,8CM02012-3,8CM02012-5,8CM02012-8,8CM02512-1,8CM02512-3,8CM02512-5,8CM02512-8,
8CR00512-1,8CR00712-1,8CR01012-1,8CR01512-1,8CR02012-1,8CR02512-1,8MSA2,8MSA3,8MSA4,8MSA5,8MSA6,8MSA7,8MSA8,8MSC4,8MSC5,8MSC6,
8MSC7,8PE00100-1,8PM00100-1,8PM00200-1,8PM00300-1,8PR00100-1,AC110,AC112,AC120,,AC122,AC123,AC130,AC131,AC OPOS1022,ACOPOS1045,
ACOPOS1090,ACOPOS1180,ACOPOS1320,ACOPOS1640,ACOPOS128M,MAACP2-0,MAACP2-E,MAMSKAT-0,MAMSKAT-E;
贝加莱(B&R)高性能可编程计算机控制器(PCC)2005系列:3CP38260-1,3CP38060-1,3CP36060-1,3CP34060-1,3CP26060-1,3IF26060-1,3AI3756,3AI7756,3AI7806,
3AM0506,3AM0516,3AM0556,3AM3746,3AO3506,3AO36060-1,3AO7756,3AT3506,3AT4506,3AT6606,3DI45060-9,3DI4756,3DI4766,3DI4776,3DI4866,3DI4866-1,
DI6956,3DI8756,3AI3756,3AI7756,3AI7806,3AM0506,3AM0516,3AM0556,3AM3746,3AO3506,3AO36060-1,3AO7756,3AT3506,3AT4506,3AT6606,3DI45060-9,
3DI4756,3DI4766,3DI4776,3DI4866,3DI6956,3DI8756,3DM45560-2,3DM4766,3DM4866,3DO4796,3DO4806,3DO4866,3DO4876,3DO6506,3DO6906,3DO7506,
3DO7606,3EX2826,3EX3506,3EX45066-1,3EX45076-1,3EX45077-1,3IF0606,3IF26060-1,3IF6139,3IF6219,3IF6229,3IF6619,3IF6719,3IF6729,3IF68186,3IF6869,
3IP16160-1,3NC1506,3NC3526,DO486,3PS4779,3PS4659,CP360,AT350,AM050,AM050,DI450,DI486,DI486,DI486,DO486,3UM1616;
B&R2005高性能可编程计算机控制器:**CPU**模块:3CP382.60-1,3CP380.60-1,3CP360.60-1,3CP340.60-1,3CP260.60-1,3IF260.60-1;
总线控制器模块:3EX282.6,3EX350.6;**通讯模块**:3IF060.6,3IF613.9,3IF621.9,3IF622.9,3IF661.9,3IF671.9,3IF672.9,3IF681.86,3IF686.9;**电源模块**:3PS465.9,3PS477.9;
现场总线模块:3EX450.66-1,3EX450.76-1,3EX450.77-1;**数字量输入模块**:3DI450.60-9,3DI475.6,3DI476.6,3DI477.6,3DI486.6,3DI486.6-1,3DI695.6,
3DI875.6,3DM476.6,3DM486.6,3UM161.6;**数字量输出模块**:3DO479.6,3DO480.6,3DO486.6,3DO487.6,3DO650.6,3DO690.6,3DO750.6,3DO760.6,3DM476.6,
3DM486.6,3UM161.6;**数字量输入/输出模块**:3DM476.6,3DM486.6,3UM161.6;**模拟量输入模块**:3AI350.6,3AI375.6,3AI775.6,3AI780.6,3AM050.6,
3AM051.6,3AM055.6,3AM374.6,3UM161.6;**模拟量输出模块**:3AO350.6,3AO360.60-1,3AO775.6,3AM050.6,3AM051.6,3AM055.6,3AM374.6,3UM161.6;**模拟量输入/输出模块**:3AM050.6,3AM051.6,3AM055.6,3AM374.6,3UM161.6;3DM455.60-23IP161.60-13UM161.6;**计数和定位模块**:3NC150.6,3NC352.6,3DI450.60-9,3DM455.60-2,
3UM161.6;

B&R 2010 系列产品:
2AI300.6,3AI700.6,2AI730.6,2AO300.6,2AO725.6,2AO900.6,2AT300.6,2AT610.6,2BM100.9,2BP101.3,2BP110.3,2BP200.4,2BP201.4,
2BP202.4,2BP210.4,2BP300.4,2CP100.60-1,2CP104.60-1,2CP200.60-1,2CP210.60-1,2DI400.5,2DI425.6,2DI426.6,2DI725.6,2DI825.6,2DO428.6,2DO430.6,

公司地址:武汉市洪山区雄楚大街 699 号
业务联系电话:027-63005490 027-51778300 13487094272
网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理
传真:027-51778300
邮编:430074

武汉市中江科技有限公司维修内容列表

2DO600.6,2DO700.6,2DO710.6,2DS100.60-1,2DS101.60-1,2EX100.50-1,2EX200.50-1,2EX301.5,2EX302.5,2IF100.60-1,2IF101.60-1,2ME910.90-1,2ME913.90-1,
2ME915.90-1,2MP100.5,2NC303.60-1,2NW100.50-1,2PS425.9,2PS740.9,2TB120.9,2TB140.9,2UM900.5,2BP101.3,2BP110.3,2BP200.4,2BP201.4,2BP202.4,
2BP210.4,2BP300.4,2PS425.9,2PS740.9,2EX100.50-1,2EX200.50-1,2EX301.5,2EX302.5,2CP100.60-1,2CP104.60-1,2CP200.60-1,2CP210.60-1,2DS100.60-1,
2DS101.60-1,2MP100.5,2ME910.90-1,2ME913.90-1,2ME915.90-1,2DI400.5,DI425.6,2DI426.6,2DI725.6,2DI825.6,2DO428.6,2DO430.6,2DO600.6,2DO700.6,
2DO710.6,2AI300.6,3AI700.6,2AI730.6,2AO300.6,2AO725.6,2AO900.6,2AT300.6,2AT610.6,2UM900.5,2IF100.60-1,2IF101.60-1,2NW100.50-1,2NC303.60-1,
2BM100.9,2TB120.9,2TB140.9;APC620:5PC600.SX01-00,5PC600.SX02-00,5PC600.SX02-01,5PC600.SX05-00,5PC600.SX05-01,5PC600.E815-00,
5PC600.E815-02,5PC600.E815-03,5MMSDR.0128-01,5MMSDR.0256-01,5MMSDR.0512-01,5C600.HS01-00,5PC600.E855-00,5PC600.E855-01,5PC600.E855-02,
5PC600.E855-04,5MMDDR.0256-00,5MMDDR.0512-00,5MMDDR.1024-00,5AC600.HS01-01,5AC600.HS01-02,5AP920.1043-01,5AP951.1043-01,5AP952.1043-01,
5AP980.1043-01,5AP981.1043-01,5AP982.1043-01,5AP920.1505-01,5AP951.1505-01,5AP980.1505-01,5AP981.1505-01,5AP920.1706-01,5AP920.1906-01,
5AP920.2138-01,5DLDVI.1000-01,5DLSDL.1000-00,5DLSDL.1000-01,5DLLDL.1000-00,5DLLDL.1000-01,5PC720.1043-00,5PC720.1043-01,5PC720.1505-00,
5PC720.1505-01;0AC808.9;
20System:X20standardCPUs:Intelceleron266comp,Intelceleron400,Intelceleron650,X20compactCPUs:embeddedup16,embeddedup25;Expandablebuscontrollers:x20IF1072-1,x20IF1061-1,x20IF1091-1,X20BC1083,X20BB81,X20PS9400,X20TB12;X20CS2770, 5PC600.SE00-01,
Inputandoutputmodules:X20DI2653,X20DI4653,X20DI6553,X20DI2623,X20DI4623;Steppermotormodules:X20SM1426,X20SM1436;
PWMmodules:X20MM2426,X20MM2436;Multi-measurementtransformer:X20CM0985;Safeinputmodules:X20SI4100,X20SI2100;Safeoutputmodules:X20SO4120,
X20SO2120,X20SO4110,X20SO2110,X20SO1130;X67module:X67AI2744,X67DO9332.L12;5PC600.SL02-00,5PC600.SF03-005AC600.HS02-01,
5AC600.HS02-02,5AC600.UPSI-00,5AC600.UPSB-00,5CAUPS.0008-00,5CAUPS.0030-00,5AC600.SRAM-00,5PC600.SE00-00,5AC600.HS03-01,
APC810:5PC800.SX02-00,
5PC800.E945-00,5PC800.E945-01,5PC800.E945-02,5MMDDR.0512-00,5MMDDR.1024-00,5MMDDR.2048-00,5AC800.HS00-00,5AC900.1000-00,5AC600.CANI-00,5AC600.485I-00,5PC600.FA02-00,5AC600.UPSI-00,4PP045.0571-042,4PP045.0571-062,4PP045.0571-L42,4PP045.IF10-1,
4PP045.IF23-1,4PP045.IF24-1,5PP320.0571-29,5PP320.0573-39,5PP320.1043-39,5PP320.1214-39,5PP320.1505-39,4PP420.0571-45,4PP420.0573-75,
4PP420.0571-65,4PP420.0571-A5,4PP451.0571-65,4PP452.0571-65,4PP420.1043-75,4PP420.1043-B5,4PP480.1043-75,4PP481.1043-75,4PP481.1043-B5,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

4PP482.1043-75,4PP420.1505-75,4PP420.1505-B5,4PP480.1505-75,4PP481.1505-75;

aPCI communication modules:

3IF722.9,3IF761.9,3IF762.9,3IF771.9,3IF772.9,3IF779.9,3IF781.9,3IF782.9,3IF786.9,3IF787.9,3IF789.9,3IF791.9,
3IF792.9,3IF797.9-15AC900.057X-00,5AC900.057X-01,5AC900.104X-00,5AC900.104X-01,5AC900.104X-02,5AC900.150X-00,5AC
900.150X-00,5PC310.L800-00,
5AP920.1043-01,5AP951.1043-01,5AP981.1043-01,5AP980.1043-01,5AP982.1043-01,5AP920.1214-01,5AP920.1505-01,5AP951.
1505-01,5AP981.1505-01,

5AP980.1505-01; Power supply

modules:8BVP0110HC00.000-1,8BVP0440HC00.000-1,8BVP0880HC00.000-1,8BVP1650HC00.000-1;

ACOPOS multi Drive System:Axis modules:8BVI0007HWS0.000-1,8BVI0007HWD0.000-1,
8BVI0007HCS0.000-1,8BVI0007HCD0.000-1;

Regeneration chokes:8BVR0110H000.000-1,8BVR0440H000.000-1,8BVR0880H000.000-1,8BVR1650H000.000-1;

24 V auxiliary

supply:8B0C0160HC00.000-1,8B0C0320HC00.000-1,8B0C0160HC00.001-1,8B0C0320HC00.002-1,8B0C0160HW00.000-1,
8B0C0320HW00.000-1,8B0C0160HW00.001-1,8B0C0320HW00.002-1; **Mounting plates:**8B0MnnnnHW00000-1;

Auxiliary supply

modules:8B0C0160HW00.000-1,8B0C0320HW00.000-1,8B0C0160HW00.001-1,8B0C0320HW00.002-1,8B0C0160HC00.000-1,
8B0C0320HC00.000-1,8B0C0320HC00.002-1; **Mounting plates:**8B0MnnnnHC00.000-1,8B0MnnnnHF00.000-1;

Inverter

modules:8BVI0014HWS0.000-1,8BVI0028HWS0.000-1,8BVI0055HWS0.000-1,8BVI0110HWS0.000-1,8BVI0220HWS0.000-1,8BVI
0440HWS0.000-1,

8BVI0014HWD0.000-1,8BVI0028HWD0.000-1,8BVI0055HWD0.000-1,8BVI0110HWD0.000-1;

8BVI0014HCS0.000-1,8BVI0028HCS0.000-1,8BVI0055HCS0.000-1,

8BVI0110HCS0.000-1,8BVI0220HCS0.000-1,8BVI0440HCS0.000-1,8BVI0880HCS0.000-1,8BVI1650HCS0.000-1,8BVI0014HCD0.
000-1,8BVI0028HCD0.000-1,8BVI0055HCD0.000-1,8BVI0110HCD0.000-1;

8BVP0110HC00.000-1,8BVP0440HC00.000-1,8BVP0880HC00.000-1,8BVP1650HC00.000-1;

8BVP0110HW00.000-1,8BVP0440HW00.000-1; **Plug-in**

modules:8BAC0120.000-1,8BAC0120.001-1,8BAC0122.000-1,8BAC0124.000-1;

芯片级维修罗克韦尔运动控制产品:

罗克韦尔可编程控制器**MicroLogix1100/1763:**1761-L16AWA,1761-L32AWA,1761-L20AWA-5A,1761-L10BWA,1761-L16BWA,1761-
L20BWA-5A,1761-L32BWA,

1761-L32AAA,1761-L16NWA,1761-L10BWB,1761-L16BWB,1761-L20BWB-5A,1761-L32BWB,1761-L10BWB,1761-L16BBB,1761-L3
2BBB,1761-L16NWB,

1762-L24AWA,1762-L24AWAR,1762-L40AWA,1762-L40AWAR,1762-L24BWA,1762-L24BWAR,1762-L40BWA,1762-L40BWAR,17
62-L24BWB,1762-L24BWB,

1762-L40BWB,1762-L40BWB,1762-IA8,1762-IQ8,1762-IQ16,1762-OA8,1762-OB8,1762-OB16,1762-OW8,1762-OW16,1762-OX6I,
1762-IF4,1762-OF4,

1762-IF2OF2,1762-IR4,1762-IT4,1764-24AWA,1764-24BWA,1764-28BWB,1764-RTC,1764-MM1,1764-MM1RTC,1764-MM2,1764-
MM2RTC,1769-IA8I,1769-IA16,

1769-IM12,1769-OA8,1769-OA16,1769-IQ16,1769-IQ16F,1769-IQ32,1769-OB8,1769-OB16,1769-OB16P,1769-OB32,1769-OV16,1

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

769-OW8,1769-OW8I,
1769-OW16,1769-IQ6XOW4,1769-IF4,1769-IF8,1769-OF2,1769-OF8C,1769-OF8V,1769-IF4OF2,1769-PA2,1769-PB2,1769-PA4,1769-PB4,1769-CRR1,
1769-CRR3,1769-CRL1,1769-CRL3,1769-ECR,1769-ECL,1761-NET-AIC,1761-NET-DNI,1761-NET-ENI,1761-NET-ENIW,1761-CBL-AM00,1761-CBL-HM02,
2711-CBL-HM05,2711-CBL-HM10,1761-CBL-AC00,1747-CP3,1761-CBL-AP00,1761-CBL-PM02,2711-CBL-PM05,2711-CBL-PM10,1790D-0B16,1790D-0V16,
1790D-0W6,1790D-16BV0,1790D-8BV8B,1790D-8BV8V,1790D-T0A6,1790D-T0B16,1790D-T0V16,1790D-T0W6,1790D-T16BV0,1790D-T8A0,1790D-T8BV8B,
1790D-T8BV8V,1790P-T0W6,1790P-T8BV8V,1790P-T8BV8B,1790-0B16X,1790-0V16X,1790-0W8X,1790-16BV0X,1790-8BV8BX,1790-8BV8VX,1790-T0A8X,
1790-T0B16X,1790-T0V16X,1790-T0W8X,1790-T16BV0X,1790-T8A0X,1790-T8BV8BX,1790-T8BV8VX;
Control Logix:1756-L55,1756-L61,1756-L62,1756-L63:1756ControlLogix,1769CompactLogix,1789SoftLogix5800,1794FlexLogix,PowerFlex700S,1756-IA8D,
1756-IA16,1756-IA16I,1756-IM16I,1756-IN16,1756-OA8,1756-OA8D,1756-OA8E,1756-OA16,1756-OA16I,1756-ON8,1756-IB16,1756-IB16D,1756-IB16I,1756-IB32,
1756-IC16,1756-IG16,1756-IH16I,1756-IV16,1756-IV32,1756-OB8EI,1756-OB16D,1756-OB16E,1756-OB16I,1756-OB16IS,1756-OB32,1756-OC8,1756-OG16,
1756-OH8I,1756-OV16E,1756-OV32E,1756-OW16I,1756-OX8I,1756-IF8,1756-IF6CIS,1756-IF6I,1756-IF16,1756-IF4FxOF2F,1756-IR6I,1756-IT6I,1756-IT6I2,
1756-OF4,1756-OF6CI,1756-OF6VI,1756-OF8,1756CFM,1756HSC,1756PLS,1756-L55M12,1756-L55M13,1756-L55M14,1756-L55M16,1756-L55M22,1756-L55M23,
1756-L55M24,1756-L61,1756-L62,1756-L63,1756-M12,1756-M13,1756-M14,1756-M16,1756-M22,1756-M23,1756-M24,1784-CF64,1756ControlLogixI/O,
1794FLEXI/O,1793FLEXIntegrAI/O,1797FLEXEXI/O,1734POINTI/O,1734DPOINTBlockI/O,1769CompactI/O,1790CompactLDXI/O,1791BlockI/O,1791DCompactBlockI/O,1792ArmorBlockI/O,1798FlexArmoRI/O,1799Machine-EmbeddeDI/O,1747SLCI/O,1771I/O,2711PPanelViewPlus,6182HVersaViewWCE,2711PanelView,
2711EPanelView,2705RediSTATION/RediPANEL,2706InView,2706DL40Dataliner,2706DL,DL50Dataliner,2707DTAMPlus,1756ControlLogix,1769CompactLogix,
1789SoftLogix5800,1794FlexLogix,DriveLogix,5720PowerFlex700S,1785PLC-5,1747SLC,1761MicroLogix,1762MicroLogix,1769MicroLogix,1772PLC-2,1775PLC-3,
5250PLC-5/250,1784-KTC,-KTCx,-KTCx15,-PCIC(S),-PCC,1784-PCIDS,-PCD,1784-KTX,-KTXD,-PCMK,1788-CN2DN,1788-EN2DN,1788-CN2FF,
1203-CN1ControlNet,1203-FM1/FB1SCANport,1394GMC,1398ULTRA100,2098Ultra3000DeviceNet,2098Ultra5000,1305,1336,1395,FlexPaK3000,WebPaK3000,
GV3000,PowerFlex40,PowerFlex70,700,700S,7000;**SLC™500:**1747-L511,1747-L514,1747-L524,1747-L531,1747-L532,1747-L541,1747-L542,1747-L543,
1747-L551,1747-L552,1747-L553,1747-L511,1747-L514,1747-L524,1747-L531,1747-L532,1747-L541,1747-L542,1747-L543,1747-L551,1747-L552,1747-L553,
1746-IA4,1746-IA8,1746-IA16,1746-IB8,1746-IB16,1746-IB32(1),1746-IC16,1746-IG16,1746-IH16,1746-IM4,1746-IM8,1746-IM16,1

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

746-IN16,1746-ITB16,
1746-ITV16,1746-IV8,1746-IV16,1746-IV32(1),1746-OA8,1746-OA16,1746-OAP12,1746-OB6EI,1746-OB8,1746-OB16,1746-OB16
E,1746-OB32(1),1746-OB32E,
1746-OBP8,1746-OBP16,1746-OG16,1746-OV8,1746-OV16,1746-OV32(1),1746-OVP16,1746-OW4,1746-OW8,1746-OW16,1746-
OX8,1746-IO4,1746-IO8,
1746-IO12,1746-IO12DC,1746-NI4,1746-NI8,1746-NI16I,1746-NI16V,1746-NO4I,1746-NO4V,1746-NO8I,1746-NO8V,1746-FIO4I,1
746-FIO4V,1746-NIO4I,
1746-NIO4V,1746-BAS(-T),1746-BLM,1746-BTM,1746-HSCE,1746-HSCE2,1746-HSRV,1746-HSTP1,1746-INT4,1746-NR4,1746-N
R8,1746-NT4,1746-NT8,
1746-QS,1746-QV,1747-ACN15,1747-ACNR15,1747-ASB,1747-BSN,1747-DCM,1747-KE,1747-KFC15,1747-SCNR,1747-SDN,174
7-SN,1747-AIC,1747-DTAM,
1747-PIC,1747-PSD,11747-UIC(6),1761-NET-AIC(7),1746-P1,1746-P2,1746-P3,1746-P4,1746-P5,1746-P6,1746-P7,1746-P1,1746
-P2,1746-P3,1746-P4,1746-P5,
1746-P6,1746-P7;
FlexLogix:1794-L33,1794-L34,1794-IA8,1794-IA8I,1794-IA16,1794-IM8,1794-OA8,1794-OA8I,1794-OA16,1794-OM8,1794-IB8,17
94-IB16,1794-IB32,1794-IV16,
1794-IC16,1794-OB8,1794-OB8EP,1794-OB16,1794-OB16P,1794-OB32P,1794-OV16,1794-OV16P,1794-OC16,1794-IB10OB6,17
94-IB16OB16P,1794-OW8,
1794-IE4OE2,1794-IF2OF2I,1794-IE8,1794-IF4I,1794-IR8,1794-IRT8,1794-IT8,1794-OE4,1794-OF4I,1794-ID2,1794-IJ2,1794-IP4,1
794-VHSC,1797-OB4D,
1797-IE8,1797-IE8H,1797-IE8NF,1797-IRT8,1797-OE8,1797-OE8H,1797-IJ2,1794-FLA,1794-AENT,1797-BIC,1797-CEC,1756Cont
rolLogiXI/O,1794FIEXI/O,
1793FLEXIntegrAl/O,1797FIEXEXI/O,1734POINTI/O,1734DPOINTBlockI/O,1769CompacTI/O,1790CompacTLDXI/O,1791BlockI/O,
1791DCompactBlockI/O,
1792ArmorBlockI/O,1798FlexArmoRI/O,1799EmbeddeDI/O,1747SLCI/O,1771I/O,2711PanelVieWPlus,6182HVersaVieWCE,2711P
anelView,2711EPanelView,
2705RediSTATION/RediPANEL,2706InView,2706DL40Dataliner,2706DL,DL50Dataliner,2707DTAMPlus,1756ControlLogix,1769Co
mpactLogix,x1789SoftLogix5800,
1794FlexLogix,5270PowerFlex700SDriveLogix,1785PLC-5,1747SLC,1761MicroLogix,1762MicroLogix,1769MicroLogix,1772PLC-2,
1775PLC-3,5250PLC-5/250;;
罗克韦尔控制器PicOGFX-70:1760-IB12XOW4IF,1760-IB12XOW4IOF,1760-IB12XOB4IF,1760-IB12XOB4IOF,1760-IA12XOW6I,17
60-IB12XOB8,1760-OW2,
1760-LDF,1760-LDFC,1760-PICOSOFTPRO,1760-CBLPC02,1760-PICOPROPC02,1760-DUB,1760-DU,1760-MM3,1760-CBL-2M,
1760-CBL-5M,1760-CBL-INT01,
1760-CBL-INT03,1760-CBL-INT05,1760-CBL-INT300,1760-CONN-RJ45,1760-TERM1,1760-NDC,1760-NDM,1760-NMF;
罗克韦尔SLC500处理器:2706-P22R,2706-P43R,2706-P42R/C,2706-P72CN2,2706-P92C,2706-P43C,2706-P44R/Cf,2706-P74CN2f,
2706-P94Cf,2711-M,
2711-K,2711P,2711P,2706-P22R,2706-P42R,2706-P42C,2706-P43R,2706-P43C,2706-P44R,2706-P44C,2706-P72CN2,2706-P74C
N2,2706-P72CN1,2706-P74CN1,2706-P92C,2706-P94C,2706-PDNETP,2706-PDNETM,2706-PDNETK,2706-PCNETP,2706-PCNE
TM,2706-PCNETK,2706-PENETP,2706-PENETM,2706-PENETK,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

2706-PRIOP,2706-PRIOM,2706-PRIOK,2706-PDHPP,2706-PDHPM,2706-PDHPK,2706-PDH485P,2706-PDH485M,2706-PDH485K,2706-PENET1,2711P-K4M5D,2711P-K4M5A,2711P-K4M20D,2711P-K4M20A,2711P-K4M3D,2711P-K4M3A,2711P-K6M5D,2711P-K6M5A,2711P-K6M20D,2711P-K6M20A,2711P-K6M3D,2711P-K6M3A,2711P-K6M8D,2711P-K6M8A,2711P-K6M1D,2711P-K6M1A,2711P-T6M5D,2711P-T6M5A,2711P-T6M20D,2711P-T6M20A,2711P-T6M3D,2711P-T6M3A,2711P-T6M8D,2711P-T6M8A,2711P-T6M1D,2711P-T6M1A,2711P-B6M5D,2711P-B6M5A,2711P-B6M20D,2711P-B6M20A,2711P-B6M3D,2711P-B6M3A,2711P-B6M8D,2711P-B6M8A,2711P-B6M1D,2711P-B6M1A,2711P-K6C5D,2711P-K6C5A,2711P-K6C20D,2711P-K6C20A,2711P-K6C3D,2711P-K6C3A,2711P-K6C8D,2711P-K6C8A,2711P-K6C1D,2711P-K6C1A,2711P-T6C5D,2711P-T6C5A,2711P-T6C20D,2711P-T6C20A,2711P-T6C3D,2711P-T6C3A,2711P-T6C8D,2711P-T6C8A,2711P-T6C1D,2711P-T6C1A,2711P-B6C5D,2711P-B6C5A,2711P-B6C20D,2711P-B6C20A,2711P-B6C3D,2711P-B6C3A,2711P-B6C8D,2711P-B6C8A,2711P-B6C1D,2711P-B6C1A;

Kinetix 6000 servodrive:2094-AC05-M01,2094-AC16-M03,2094-BC01-M01,2094-BC04-M03,2094-AMP5,2094-AM02,2094-AM03,2094-AM05,2094-BM01,2094-BM03,2094-BM05,2094-AC05-MP5,2094-AC09-M02,2094-AC32-M05,2094-BC01-MP5,2094-BC02-M02,2094-BC07-M05,2094-4-AM01,2094-BMP5,2094-BM02,2094-BM03,2094-PRS1,2094-PRS2,2094-PRS3,2094-PRS4,2094-PRS5,2094-PRS6,2094-PRS7,2094-PRS8,2094-AL09,2094-AL75S,2094-BL02,2094-BL75S,2094-XL75S-C1,2094-XL75S-C2,2094-AL75S,2094-XL75S-C1,2094-XL75S-C2,2094-BSP2,2094-PR1,2094-PR2,2094-PR4,2094-PR6,2094-PR8,2094-BSP2,2094-PRF;**1756-L60M03 SESERCOS Interface Module:**1756-M03SE,1756-M08SE,1756-M16SE,1756-L60M03SE;1756-M02AE,1756-HYD02,1756-M02AS;

Ultra3000 Digital ServoDrive:2098-DSD-005,2098-DSD-010,2098-DSD-020,2098-DSD-030,2098-DSD-075,2098-DSD-150,2098-DSD-HV030,2098-DSD-HV050,2098-DSD-HV100,2098-DSD-HV150,2098-DSD-HV220;

Ultra1500全数字伺服驱动器:2092-DA1,2092-DA2,2092-DA3,2092-DA4,2092-DA5;1394C-AM03,1394C-AM04,1394C-AM07,1394C-AM50,1394C-AM50-IH,1394C-AM75,1394C-AM75-IH,8720MC-D065,8720MC-D078,8720MC-D097,8720MC-D120,8720MC-D149,8720MC-D180,8720MC-RPS027,8720MC-RPS065,8720MC-RPS190;2098-IPD-005,2098-IPD-010,2098-IPD-020,2098-IPD-030,2098-IPD-030-DN,2098-IPD-075,2098-IPD-075-DN,2098-IPD-150,2098-IPD-150-DN,2098-IPD-HV030,2098-IPD-HV030-DN,2098-IPD-HV050,2098-IPD-HV050-DN,2098-IPD-HV100,2098-IPD-HV100-DN,2098-IPD-HV150,2098-IPD-HV150-DN,2098-IPD-HV220,2098-IPD-HV220-DN;

芯片级维修罗克韦尔**BulletiN900-TC**温控器:900-TC8RTZ25,900-TC8RTHZ25,900-TC8VTZ25,900-TC8VTHZ25,900-TC8ACTZ25,900-TC8RTU25,900-TC8RTHU25,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

900-TC8VTU25,900-TC8VTHU25,900-TC8ACTU25,900-TC16RTZ25,900-TC16VTZ25,900-TC16ACTZ25,900-TC16RTU25,900-TC16VTU25,900-TC16ACTU25,
900-TC32RTZ25,900-TC32VTZ25,900-TC32RTU25,900-TC32VTU25,900-TC32CRTZ25,900-TC32CVTZ25,900-TC32CRTU25,900-TC32CVTU25,900-TC8RPZ25,
900-TC8RPHZ25,900-TC8VPZ25,900-TC8VPHZ25,900-TC8ACPZ25,900-TC8RPU25,900-TC8RPHU25,900-TC8VPU25,900-TC8VPHU25,900-TC8ACPU25,
900-TC16RPZ25,900-TC16VPZ25,900-TC16ACPZ25,900-TC16RPU25,900-TC16VPU25,900-TC16ACPU25,900-TC32RPZ25,900-TC32VPZ25,900-TC32RPU25,
900-TC32VPU25,900-TC32CRPZ25,900-TC32CVPZ25,900-TC32CRPU25,900-TC32CVPU25,900-TC8232,900-TC8COM,900-TC8EIM,900-TC16COM,
900-TC16EIM,900-TC16ACEIM,900-TC16ACCOM;
罗克韦尔电源Bulletin1606:1606-XLP25A,1606-XLP30B,1606-XLP30E,1606-XLP36C,1606-XLP50B,1606-XLP50E,1606-XLP50EZ,1606-XLP50F,1606-XLP72E,
1606-XLP90B,1606-XLP100E,1606-XLP100F,1606-XL60D,1606-XL120D,1606-XL180B,1606-XL240E,1606-XL240EP,1606-XL240FP,1606-XL480E,1606-XL480EP,
1606-XL480EPT,1606-XL480GP,1606-XL480F,1606-XL120E-3,1606-XL240E-3,1606-XL480E-3,1606-XL480E-3W,1606-XL480F-3H,1606-XL720E-3,
1606-XL960E-3,1606-XL960E-3S,1606-XLBUFFER,1606-XLDC40A,1606-XLDNET4,1606-XLDNET8,1606-XL60DR,1606-XL120DR,1606-XL240DR,1606-XLPRED,
1606-XLRED20-30,1606-XLRED40;

PM3000 及 **PMII** 电 力 监 视
器 :1403-MM05A,1403-MM05B,1403-MM01A,1403-MM01B,1403-DMA,1403-DMB,1403-CF000,1403-CF001,1403-CF003,1403-CF005,

1403-CF010,1403-CF020,1403-CF050,1403-CF100,1403-CF250,1403 - NSC,1403 - NENET,1403 - NDNET;

芯片级维修路斯特 (Lust) 运动控制:

CDA3000-PLC:VT05000000N,VT050000CNN,VT150W00000N,VT150W000CNN,VT505W00000N,VT505W000CNN,VT155W00000N,VT155W000CNN,VTWINCD,

CVCOM11102,CVCOM25F8M,OPK-RS03,OPK-RS05;CD_0031,CD_0071,CD_0032,CD_0072,CDF30008,CDE3000,CDF3000,CD D3000,CDB3000,CDA3000,

CDA3000-HF,CDD3000-HF,CDS4000; **Amplifier Module:**CD_003.1,CD_007.1,CD_003.2,CD_007.2; ED12.005,ED12.005, C x.x,BC1300;

Lust VideoTerminal VTWIN:VT05000000,VT050000CN,VT06000000,VT060000CN,VT150W00000,VT150W000DP,VT150WA000CN,VT160W00000,

VT160W000DP,VT170WA0000,VT190WA0000,VT190WAP000,VT300WA0000,VT300WAP000,VT300W000CN,VT310WA0000,VT310WAP000,VT320WA0000,

VT320WAP000,VT330WAPM00,VT330WAPS00,VT330WAPT00,VT155W00000,VT155W000DP,VT155W000CN,VT505W00000,VT505W000DP,VT505W000CN,

VT505W000ET,VT525W00000,VT525W000ET,VT555W00000,VT555WA0000,VT555WAP000,VT555WA00DP,VT555WAP0DP,VT555W000CN,VT565WA0000,

VT565WAP000,VT565WA0M00,VT565WAPM00,VT585WAPS00,VT585WAPT00,VT585W0PSCN;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

Inverter Systems CDA3000:

CDD32.003,Cx.x,CDD32.004,Cx.x,CDD32.006,Cx.x,CDD32.008,Cx.x,CDD34.003,Cx.x,CDD34.005,Cx.x,CDD34.006,Wx.x,
CDD34.008,Wx.x,CDD34.010,Wx.x,CDD34.014,Wx.x,CDD34.017,Wx.x,CDD34.024,Wx.x,CDD34.032,Wx.x,CDD34.045,Wx.x,CDD3
4.060,Wx.x,CDD34.072,Wx.x,CDD34.090,Wx.x,CDD34.110,Wx.x,CDD34.143,Wx.x,CDD34.170,Wx.x; KP200 S,CP200,
UM-8140,CM-CAN1,CM-CAN2,CM-DPV1;CDE32.003,CDB32.003,
CDE32.004,CDB32.004,CDE32.008,CDB32.008,CDE34.003,CDB34.003,CDE34.005,CDB34.005,CDE34.006,CDB34.006,CDE34.0
08,CDB34.008,CDE34.010,CDB34.010,CDE34.014,CDB34.014,CDE34.017,CDB34.017,CDE34.024,CDB34.024,CDE34.032,CDB3
4.032,CDE34.044,CDB34.044,CDE34.058,CDB34.058,CDE34.070,CDB34.070,CDE34.088,CDB34.088,CDE34.108,CDB34.108,CD
E34.140,CDB34.140,CDE34.168,CDB34.168;

CDD3000-HF Inverter Drive

System:CDD32.003-HF,Cx.x,CDD32.004-HF,Cx.x,CDD32.006-HF,Cx.x,CDD32.008-HF,Cx.x,CDD34.003-HF,Cx.x,CDD34.005-HF,
Cx.x,
CDD34.006-HF,Cx.x,CDD34.008-HF,Wx.x,CDD34.010-HF,Wx.x,CDD34.014-HF,Wx.x,CDD34.017-HF,Wx.x,CDD34.024-HF,Wx.x,C
DD34.032-HF,Wx.x;
CDE3000,CDF3000,CDD3000,CDB3000,CDA3000,CDA3000-HF,CDD3000-HF,CDS4000,CDA32.003.C,HF,CDD32.003.C,HF,CDA
32.004.C,HF,CDD32.004.C,HF,CDA32.006.C,HF,CDD32.006.C,HF,CDA32.008.C,HF,CDD32.008.C,HF,CDA34.003.HF,CDD34.003
.HF,CDA34.005.HF,CDD34.005.HF,CDA34.006.HF,CDD34.006.HF,CDA34.008.HF,CDD34.008.HF,CDA34.010.HF,CDD34.010.HF,
CDA34.014.HF,CDD34.014.HF,CDA34.017.HF,CDD34.017.HF,CDA34.024.HF,CDD34.024.HF,CDA34.032.HF,CDD34.032.HF,CD
A34.044.HF,CDD34.044.HF,CDA34.058.HF,CDD34.058.HF,CDA34.070.HF,CDD34.070.HF,CDA34.088.HF,CDD34.088.HF,CDA34.
108.HF,CDD34.108.HF,CDA34.140.HF,CDD34.140.HF,CDA34.168.HF,CDD34.168.HF,CDS44.017,CDS44.032,

CDS4000 drive

controllers:CDS44.017.Wx.x,NF,CDS44.032.Wx.x,NF,CDS44.017.Wx.x.,CDS44.032.Wx.x,CDS44.017.LCx.x,CDS44.032.LCx.x;

MASTERCONTROL MC7000 POSMOD:MC7402; MC7404; MC7408; MC7412; MC7416; MC7432,MC7464; **Power pack**

DriveStar:R-DS125.1,R-DS160.1;

Servo system

SO8000:SO84.004,SO84.006,SO84.008,SO84.012,SO84.016,SO84.020,SO84.024,SO84.032,SO84.045,SO84.060,SO84.072,SO8
4.090,SO84.110,

SO84.143,SO84.170;**Drive star:**U-DS006.1,U-DS012.1,U-DS020.1,U-DS035.1,U-DS045.1;

芯片级维修三菱运动控制产品:

Q-PLC系列控制器:Q00JCPU,Q173CPUN,Q172CPUN,Q172LX,Q172EX,Q173PX,MR-HENC,MR-JHSCBL□M-HL,Q173DV,Q170BA
T,MR-BAT/A6BAT,MR-HDP01,
Q00CPU,Q01CPU,Q02CPU,Q02HCPU,Q06HCPU,Q12HCPU,Q25HCPU,Q33B,Q35B,Q38B,Q312B,Q63B,Q65B,Q68B,Q612B,QC□
B,Q61P-A1,Q61P-A2,Q63P,
Q64PQX10,QX28,QX40,QX40-S1,QX41,QX42,QX70,QX71,QX72,QX80,QX81,QY10,QY18A,QY40P,QY41P,QY42P,QY22,QY50,Q
Y68A,QY70,QY71,QY80,QY81P,
QH42P,QX48Y57,QI60,Q64AD,Q68ADV,Q68ADI,Q62DA,Q64DA,Q68DAV,Q68DAI,Q64AD-GH,Q62DA-DGH,Q62DA-FG,Q64RD,Q
64TCTT,Q64TCTTBW,
Q64TCRT,Q64TCRTBW,QD75P1,QD75P2,QD75P4,QD75D1,QD75D2,QD75D4,QD75P1,QD75M1,QD75M2,QD75M4,QD70P4,QD
70P8,QJ71E71,QJ71E71-B2,
QJ71E71-100,QJ71LP21-25,QJ71LP21G,QJ71LP25-25,QJ71LP25G,QJ71BR11,QJ71BR15,Q80BD-J71LP21-25,Q80BD-J71LP21

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

G,Q80BD-J71BR11,QJ61BT11,
QJ71C24,QJ71C24-R2,QJ71CMO,QD51,QD51-R24,QJ71FL71,QJ71FL71-B2;
MR-J2S-A伺服放大器:MR-J2S-10A,MR-J2S-20A,MR-J2S-40A,MR-J2S-60A,MR-J2S-70A,MR-J2S-100A,MR-J2S-2000A,MR-J2S-350A,MR-J2S-500A,MR-J2S-700A,
MR-J2S-10A1,MR-J2S-20A1,MR-J2S-40A1;**FX2N**程控器:FX2N-4AD,FX2N-4DA,FX2N-1PG,FX2N-1HC,FX2N-232AF;
MR-J2S-B伺服放大器:MR-J2S-10B,MR-J2S-20B,MR-J2S-40B,MR-J2S-60B,MR-J2S-70B,MR-J2S-100B,MR-J2S-200B,MR-J2S-350B,MR-J2S-500B,MR-J2S-700B,
MR-J2S-500B,MR-J2S-700B; **Q4AR**程控器:Q4ARCPU,A61RP,AJ71QBR11,AS92R,A6RAF,AS92R;
MELSERVO J3-B伺服放大器:MR-J3-10B,MR-J3-20B,MR-J3-40B,MR-J3-10B1,MR-J3-20B1,MR-J3-40B1,MR-J3-60B,MR-J3-70,MR-J3-100B,MR-J3-200B,
MR-J3-350B,MR-J3-500B,MR-J3-700B;**MR-E-A**伺服放大器:MR-E-10A,MR-E-20A,MR-E-40A,MR-E-70A,MR-E-100A,MR-E-200A;
MR-H系列交流伺服驱动系统:MR-H10AN,MR-H20AN,MR-H40AN,MR-H60AN,MR-H100AN,MR-H020AN,MR-H350AN,MR-H500AN,MR-H700AN,MR-H11K,
MR-H15K,MR-H22K;MR-J2S-11KB,MR-J2S-15KB,MR-J2S-22KB,MR-J2S-30KB,MR-J2S-37KB,MR-J2S-30KB4MR-J2S-37KB4,MR-J2S-45KB4,MR-J2S-55KB4;
三菱运动控制器**MELDAS**系列:MELDAS64AS,MELDAS64S,M64ASM,M64SM,M64ASL,M64SL,MELDAS65S,MELDAS66S,M615,M635,M655,M610,M630,M650,
M65SM,M66SM,M615M,M635M,M655M,M635M-V,M655M-V,M610M,M630M,M650M,M65SL,M66SL,M615L,M635L,MELDASC5,MELDASC6,M64ASC64,
M64ASMAGIC64; **ANS/QNAS**程控器:Q4ACPU,Q3ACPU,Q4ACPU,Q2ACPU-S1,Q2ACPU,A3ACPU,A3ACPU-S1,A2ACPU;
EZ MOTION-NCE60 CNC系统:FCAE60,FCU6-MU071,FCU6-DUE71-1,FCU6-DUT11-1,FCU6-KB071-1,FCU6-HR341,FCU6-HR351,FCUA-DX100,FCUA-DX110,
FCUA-DX120,FCUA-DX140,FCUA-DX101,FCUA-DX111,FCUA-DX121,FCUA-DX141,HD60,OLM-01-2Z1;
FX2NC程控器:**FX1N**程控器:FX1N-8AV-BD,FX1N-232-BD,FX1N-485-BD,FX1N-422-BD,FX1N-4EX-BD,FX1N-2EYT-BD,FX1N-2AD-BD,FX1N-1DA-BD;
FX1S程控器:**FX1NC**程控器:**F900**系列人机界面:F920GOT-BBD5-K-C,F930GOT-BBD-K-C,FX-5DM-E,FX-10DU-E,FX-20DU-E,F930GOT-BWD-C,F940GOT-SWD-C,
F940GOT-LWD-C,F940WGOT,A985GOT-TBA,A985GOT-TBD,A985GOT-TBA-V,A985GOT-TBD-V,A975GOT-TBA-B,A975GOT-TBD-B,A970GOT-TBA-B,
A970GOT-TBD-B,A970GOT-SBA,A970GOT-SBD,A960GOT-EBA,A960GOT-EBD,A950GOT-TBD,A951GOT-QTBD,A950GOT-TBD-M3,A951GOT-QTBD-M3;
芯片级维修默勒自动控制系统:
MOELLER AUTOMATION SYSTEMS:PS4-100COMPACT PLC:PS4-101-DD1,PS4-111-DR1,PS4-111-DR5;
PS4-141 COMPACT PLC,PS4-151 COMPACT PLC:PS4-141-MM1,PS4-151-MM1,PS4-201-MM1,PS4-271-MM1,PS4-341-MM1;
EM4-100 REMOTE EXPANSION MODULE:EM4-101-DD2,EM4-111-DR2,EM4-101-AA2,EM4-102-AA1,EM4-101-TX1,EM4-101-TX2;
EM4-200 REMOTE EXPANSION MODULE:EM4-201-DX2,EM4-202-DX1,EM4-202-DX1; **LE4 ANALOG MODULE**:LE4-206-AA1,LE4-206-AA;
LE4 DIGITAL MODULE:LE4-116-DD1,LE4-116-DX1,LE4-116-XD1,LE4-108-XD1,LE4-108-XR1,LE4-104-XP1,LE4-308-HX1,LE4-308-XH1;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

LE4 NETWORK MODULE:LE4-501-BS1,LE4-503-BS1,LE4-504-BS1,LE4-505-BS1,LE4-509-BS1,LE4-504-BT1,LE4-501-BS1,LE4-622-CX1,LE4-633-CX1;

PS416 MODULAR PLC:PS416-INP-400,PS416-INP-401,PS416-OUT-400,PS416-OUT-401,PS416-AIN-400,PS416-AIO-400,PS416-CNT-200,PS416-NET-220,

PS416-NET-230,PS416-NET-400,PS416-NET-440,PS416-NET-441,PS416-COM-200,PS416-MOD-200;

CPUCARD:PS416-CPU-200,PS416-CPU-300,PS416-CPU-400;**POWERSUPPLY CARD:**PS416-POW-400,PS416-POW-410,PS416-POW-420;

SERIAL INTERFACE CONVERTER:ZB4-501-UM3,ZB4-501-UM4;**TELECONTROL MODULE:**ZB4-501-TC1,ZB4-501-TC2,PS416-TCS-200;

X I/ONMODULES:XN-2DI-24VDC-P,XN-4DI-24VDC-P,XN-1AI-I,XN-1AI-U,XN-2DO-24VDC-2A-P,XN-2DO-24VDC-05A-P,XN-1AO-I,XN-1AO-U,XN-2DO-R-NC,

XN-2DO-R-NO,XN-2DO-R-CO,XN-BR-24VDC-D,XN-PF-24VDC-D; **GW4 POWERSUPPLY UNIT:**GW4-030-BA3,GW4-050-BA3,GW4-080-BA3,GW4-100-BA3;

MV4 DISPLAY AND OPERATOR UNITS:MV4-150-TA1,MV4-450-TA1,MV4-170-TA1,MV4-470-TA1,MV4-570-TA1,MV4-670-TA1,MV4-690-TA1,MV4-570-TA2,

MV4-670-TA2,MV4-690-TA2; **AS-INTERFACE MOTORSTARTERS:AS-INTERFACE MASTER:**CM4-505-GS1,SN4-024-D17,EM2-105-DX1,EM2-105-XD1;

MI4 DISPLAY AND OPERATOR UNITS:MI4-100-KC1,MI4-101-KC1,MI4-100-KE1,MI4-101-KE1,MI4-110-KE1,MI4-111-KE1,MI4-130-KH1,MI4-131-KH1,

MI4-151-KF1,MI4-451-KF1,MI4-151-TA1,MI4-451-TA1,MI4-161-TC1,MI4-471-TC1; **SWITCHED-MODEPOWERSUPPLY UNIT:**SN4-025-BI7,SN4-050-BI7;

SEMICONDUCTOR CONTACTORS:DILSM1V-K,DILSM5V-K,DILSM9V-K,DILSM16V-K,DILSH10Z,DILSH25Z,DILSH25V,DILSH40V,DILSH50V,DILSH18V-K,

DILSH30V-K,DILSH45V-K,DIULSM1V-K; **GD4 POWERSUPPLY UNIT:**GD4-050-BD3,GD4-100-BD3,GD4-150-BD3,GD4-200-BD3,GD4-300-BD3;

芯片级维修台达运动控制产品:

台达可编程控制器**DVP:**DVP20PM00D,DVP28SV11R,DVP28SV11T,DVPNET01-SL,DVPEN01-SL,DVPMDM-SL,DVP04AD-SL,DVP04DA-SL,DVP06XA-SL,

DVP04PT-SL,DVP04TC-SL,DVP01PU-SL,DVP08SM11N,DVP06SN11R,DVP08SN11R/T,DVP08SP11R/T,DVP16SP11R/T,DVP04AD-S,DVP06AD-S,DVP04DA-S,

DVP02DA-S,DVP06XA-S,DVP04PT-S,DVP04TC-S,DVPPF01-S,DVPDT01-S,DVP01PU-S,DVPPS01,DVPPS02,DVP16EH00R2,DVP16EH00T2,DVP20EH00R2,

DVP20EH00T2,DVP32EH00R2,DVP32EH00T2,DVP40EH00R2,DVP40EH00T2,DVP48EH00R2,DVP48EH00T2,DVP64EH00R2,DVP64EH00T2,DVP80EH00R2,

DVP80EH00T2,DVP08HM11N,DVP16HM11N,DVP32HP00R/T,DVP48HP00R/T,DVP08HN11R/T,DVP32HN00R/T,DVP08HP11R/T,DVP16HP11R/T,DVP04AD-H2,

DVP04DA-H2,DVP06XA-H2,DVP04PT-H2,DVP04TC-H2,DVP01PU-H2,DVP14ES00R2,DVP14ES00T2,DVP24ES00R2,DVP24ES00T2,DVP32ES00R2,

DVP32ES00T2,DVP40ES00R2,DVP40ES00T2,DVP60ES00R2,DVP60ES00T2,DVP20EX00R2,DVP20EX00T2,DVP20EX11R2,DVP08XM11N,DVP16XM11N,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

DVP08XN11R/T,DVP16XN00R/T,DVP24XN11R/T,DVP24XN00R/T,DVP08XP11R/T,DVP24XP11R/T,DVP24XP00R,DVP32XP00R/
T,DVP14SS11R2,
DVP14SS11T2,DVP10SX11R,DVP10SX11T,DVP12SA11R,DVP12SA11T,DVP12SC11R,DVP12SC11T,DVP08SM11N,DVP06SN1
1R,DVP08SN11R/T,
DVP08SP11R/T,DVP16SP11R/T,DVP04AD-S,DVP06AD-S,DVP04DA-S,DVP02DA-S,DVP06XA-S,DVP04PT-S,DVP01PU-S,DVPP
F01-S,DVPDT01-S,DVP01PU-S,
DVPPS01,DVPPS02;
台达**DOPA**系列人机界面:TP02G-AS1,TP04G-AS2,DOP-A(E)57BSTD,DOP-A(E)57GSTD,DOP-A(E)57CSTD,DOP-AE80THTD,DOP
-A10TCTD,DOP-AE10THTD,
DOP-A75CSTD;
芯片级维修西门子运动控制产品:
西门子**SIMATIC PCS7**过程控制系统:6ES7654-2BA02-0XX0,6ES7654-2BB02-0XX0,6ES7654-5BA02-0XX0,6ES7654-5BB02-0XX0,
6ES7654-2BA32-0XX0,
6ES7654-2BB32-0XX0,6ES7654-5BA32-0XX0,6ES7654-5BB32-0XX0,6ES7654-2DA02-0XX0,6ES7654-2DB02-0XX0,6ES7654-5D
A02-0XX0,
6ES7654-5DB02-0XX0,6ES7654-2DA32-0XX0,6ES7654-2DB32-0XX0,6ES7654-5DA32-0XX0,6ES7654-5DB32-0XX0,6ES7654-2E
A02-0XX0,
6ES7654-2EB02-0XX0,6ES7654-5EA02-0XX0,6ES7654-5EB02-0XX0,6ES7654-2EA32-0XX0,6ES7654-2EB32-0XX0,6ES7654-5E
A32-0XX0,6ES7654-5EB32-0XX0,
6ES7654-2GA02-0XX0,6ES7654-2GB02-0XX0,6ES7654-5GA02-0XX0,6ES7654-5GB02-0XX0,6ES7654-2GA32-0XX0,6ES7654-2
GB32-0XX0,
6ES7654-2GB32-0XY0,6ES7654-5GA32-0XX0,6ES7654-5GB32-0XX0,6ES7414-3XJ00-0AB0,6ES7416-2XK02-0AB0,6ES7416-3X
L00-0AB0,6ES7417-4XL00-0AB0,
6ES7955-2AL00-0AA0,6ES7955-2AM00-0AA0,6ES7952-1KM00-0AA0,6GK7443-1EX11-0XE0,6GK7443-5DX03-0XE0,6GK7964-2
AA01-0AB0,
6ES7407-0KA01-0AA0,6ES7407-0DA00-0AA0,6ES7400-1TA01-0AA0,6ES7400-1JA01-0AA0,6ES7971-0BA00,6ES7952-1AK00-0A
A0,6ES7952-1AL00-0AA0,
6ES7952-1AM00-0AA0,6ES7952-1AP00-0AA0,6ES7653-2BD05-0XX0,6ES7653-2BB05-0XX0,6ES7653-2BC05-0XX0,6ES7653-2B
E05-0XX0,
6ES7654-2UA04-0XX0,6ES7654-2UB04-0XX0,6ES7654-2UR04-0XX0,6ES7654-5UA04-0XX0,6ES7654-5UB04-0XX0,6ES7654-5U
R04-0XX0,
6ES7654-2UA34-0XX0,6ES7654-2UB34-0XX0,6ES7654-2UR34-0XX0,6ES7654-5UA34-0XX0,6ES7654-5UB34-0XX0,6ES7654-5U
R34-0XX0,
6ES7654-2VR04-0XX0,6ES7654-5VR04-0XX0,6ES7654-2VR34-0XX0,6ES7654-5VR34-0XX0,6ES7658-6AX04-0YD0,6ES7654-2S
A04-0XX0,
6ES7654-2SB04-0XX0,6ES7654-2SR04-0XX0,6ES7654-5SA04-0XX0,6ES7654-5SB04-0XX0,6ES7654-5SR04-0XX0,6ES7654-2S
A34-0XX0,
6ES7654-2SB34-0XX0,6ES7654-2SR34-0XX0,6ES7654-5SA34-0XX0,6ES7654-5SB34-0XX0,6ES7654-5SR34-0XX0,6ES7654-2V
R04-0XX0,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6ES7654-5VR04-0XX0,6ES7654-2VR34-0XX0,6ES7654-5VR34-0XX0,6ES7-658-6AX04-0YD0,6ES7414-4HJ00-0AB0,6ES7417-4HL01-0AB0,
6ES7960-1AA00-0XA0,6ES7960-1AA00-5AA0,6ES7960-1AA00-5BA0,6ES7960-1AA00-5KA0,6ES7952-1KM00-0AA0,6GK7443-1EX11-0XE0,
6GK7443-5DX03-0XE0,6ES7407-0KR00-0AA0,6ES7405-0KA01-0AA0,6ES7400-1TA01-0AA0,6ES7400-1JA01-0AA0,6ES7400-2JA00-0AA0,6ES7971-0BA00,
6ES7952-1AK00-0AA0,6ES7952-1AL00-0AA0,6ES7952-1AM00-0AA0,6ES7952-1AP00-0AA0,6ES7653-2BD05-0XX0,6ES7653-2BB05-0XX0,
6ES7653-2BE05-0XX0,6ES7421-1BL01-0AA0,6ES7421-1EL00-0AA0,6ES7421-7BH00-0AB0,6ES7421-7DH00-0AB0,6ES7421-1FH00-0AA0,
6ES7421-1FH20-0AA0,6ES7421-5EH00-0AA0,6ES7422-1BL00-0AA0,6ES7422-7BL00-0AB0,6ES7422-1BH10-0AA0,6ES7422-1HH00-0AA0,
6ES7422-5EH00-0AB0,6ES7422-5EH10-0AB0,6ES7422-1FH00-0AA0,6ES7431-0HH00-0AB0,6ES7431-1KF00-0AB0,6ES7431-1KF10-0AB0,
6ES7431-1KF20-0AB0,6ES7431-7QH00-0AB0,6ES7431-7KF00-0AB0,6ES7431-7KF10-0AB0,6ES7432-1HF00-0AB0,6ES7492-1AL00-0AA0,6ES7492-1BL00-0AA0,
6ES7492-1CL00-0AA0,6ES7307-1EA00-0AA0,6ES7307-1EA80-0AA0,6ES7307-1KA00-0AA0,6ES7153-1AA03-0XB0,6ES7153-1AA83-0XB0,6ES7153-2AA02-0XB0,
6ES7195-7HA00-0XA0,6ES7195-7HB00-0XA0,6ES7195-7HC00-0XA0,6ES7195-7HD00-0XA0,6ES7195-7HG00-0XA0,6ES7195-1GA00-0XA0,
6ES7195-1GF30-0XA0,6ES7195-1GG30-0XA0,6ES7195-1JA00-0XA0,6ES7392-1AJ00-0AA0,6ES7392-1BJ00-0AA0,6ES7392-1AM00-0AA0,
6ES7392-1BM01-0AA0,6ES7654-0XX01-1XA0,6ES7654-0XX03-1XA0,6ES7305-1BA80-0AA0,6ES7153-2AB01-0XB0,6ES7195-1KA00-0XA0,
6ES7370-0AA01-0AA0,6ES7393-4AA00-0AA0,6ES7195-7KF00-0XA0,6ES7153-2AR00-0XA0,6ES7321-1BH02-0AA0,6ES7321-1BH82-0AA0,
6ES7321-1BH50-0AA0,6ES7321-1BL00-0AA0,6ES7321-1BL80-0AA0,6ES7321-1CH80-0AA0,6ES7321-1EL00-0AA0,6ES7321-1FF01-0AA0,6ES7321-1FF81-0AA0,
6ES7321-1FH00-0AA0,6ES7321-7BH00-0AB0,6ES7321-7BH80-0AB0,6ES7321-7TH00-0AB0,6ES7322-8BF00-0AB0,6ES7322-8BF80-0AB0,
6ES7322-8BH00-0AB0,6ES7322-5RD00-0AB0,6ES7322-1BF01-0AA0,6ES7322-1BH01-0AA0,6ES7322-1BH81-0AA0,6ES7322-1BL00-0AA0,
6ES7322-1CF80-0AA0,6ES7322-1FF01-0AA0,6ES7322-1FF81-0AA0,6ES7322-1FH00-0AA0,6ES7322-1EH01-0AA0,6ES7322-1EL00-0AA0,6ES7322-1HF01-0AA0,
6ES7322-1HF10-0AA0,6ES7322-1HF20-0AA0,6ES7322-1HF80-0AA0,6ES7322-1HH00-0AA0,6ES7331-7KF02-0AB0,6ES7331-7KB02-0AB0,
6ES7331-7KB82-0AB0,6ES7332-7NF00-0AB0,6ES7332-7PF00-0AB0,6ES7332-7PF10-0AB0,6ES7332-7ND00-0AB0,6ES7332-5HB81-0AB0,
6ES7332-5RD00-0AB0,6ES7331-7TB00-0AB0,6ES7326-1BK00-0AB0,6ES7326-1RF00-0AB0,6ES7326-2BF00-0AB0,6ES7326-1HE00-0AB0,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6ES7355-0VH10-0AE0,6ES7355-1VH10-0AE0,6AV3607-1JC20-0AX1,6AV3617-1JC20-0AX1,6ES7332-5TB00-0AB0,6ES7195-7KF00-0XA0,6ES7195-7HG00-0XA0,
6GK7343-2AH00-0XA0,6ES7307-1EA00-0AA0,6ES7307-1EA00-0AA0,6ES7307-1KA00-0AA0,6ES7305-1BA80-0AA0,6ES7157-0A81-0XA0,
6ES7157-0AD81-0XA0,6ES7307-1AC80-0XA0,6ES7157-0BA00-8AA0,6ES7157-0BA00-8BA0,6ES5195-7HE80-0XA0,6ES7195-7HF80-0XA0,
6GK1500-0AB00,6GK1500-0AA10,6ES7972-0AA01-0XA0,6ES7972-0DA00-0AA0;
SIMATIC PCS7 BOX:6ES7650-2HA06-0YX0G,6ES7650-2HB06-0YX0G,6ES7658-5AB06-0YD0,6ES7658-2AB06-0YD0,6ES7658-3PX05-0YC0C,6GK1151-2AA00,
6GF6710-1AA,6GF6710-1BA,6ES7648-0CB00-0YA0,6EP1334-2AA00,6EP1931-2EC31,6EP1935-6ME21;
AS414-3 自动化系统:6ES7654-3QD47-0XX0,6ES7654-6QD47-0XX0,6ES7654-1QD57-0XX0,6ES7654-4QD57-0XX0,6ES7654-3JE47-0XX0,6ES7654-6JE47-0XX0,
6ES7654-1JE57-0XX0,6ES7654-4JE57-0XX0,6ES7654-3KF47-0XX0,6ES7654-6KF47-0XX0,6ES7654-1KF57-0XX0,6ES7654-4KF57-0XX0,6ES7654-3LE47-0XX0,
6ES7654-3LG47-0XX0,6ES7654-6LE47-0XX0,6ES7654-6LG47-0XX0,6ES7654-1LE57-0XX0,6ES7654-1LG57-0XX0,6ES7654-4LE57-0XX0,6ES7654-4LG57-0XX0,
6ES7414-3XJ04-0AB0,6ES7416-2XK04-0AB0,6ES7416-3XL04-0AB0,6ES7417-4XL04-0AB0,6ES7952-1AL00-0AA0,6ES7952-1AM00-0AA0,6ES7952-1AP00-0AA0,
6ES7952-1AS00-0AA0,6ES7952-1KM00-0AA0,6GK7443-1EX11-0XE0,6GK7443-5DX03-0XE0,6ES7964-2AA04-0AB0,6ES7407-0RA01-0AA0,
6ES7405-0KA01-0AA0,6ES7405-1KR00-0AA0,6ES7405-1RA01-0AA0;
自动化系统AS414-4-1H:6ES7654-2UA34-0XX0,6ES7654-2UB34-0XX0,6ES7654-2UR34-0XX0,6ES7654-5UA34-0XX0,6ES7654-5UB34-0XX0,
6ES7654-5UR34-0XX0,6ES7654-2VR34-0XX0,6ES7654-5VR34-0XX0,6ES7654-2SA34-0XX0,6ES7654-2SB34-0XX0,6ES7654-2SR34-0XX0,
6ES7654-5SA34-0XX0,6ES7654-5SB34-0XX0,6ES7654-5SR34-0XX0,6ES7654-2TR34-0XX0,6ES7654-5TR34-0XX0;6ES7460-1BA01-0AB0,
6ES7461-1BA01-0AA0,6ES7460-3AA01-0AB0,6ES7461-3AA01-0AA0,6ES7400-1TA01-0AA0,6ES7400-1JA01-0AA0,6ES7460-1BA01-0AB0,6ES7461-1BA01-0AA0,
6ES7460-3AA01-0AB0,6ES7461-3AA01-0AA0,6ES7400-1TA01-0AA0,6ES7400-1JA01-0AA0;6ES7321-7BH01-0AB0,6AG1321-7BH01-2AB0,
6ES7321-7TH00-0AB0;
SIMATIC
S5:6ES5090-8MA01,6ES5100-8MA02,6ES5252-5BB11,6ES5385-8MB11,6ES5441-8MA11,6ES5455-7LA11,6ES5456-7LB11,6ES5465-7LA13,
6ES5466-3LA11,6ES5490-7LB21,6ES5700-2LA12,6ES5734-1BD20,6ES5752-0AA12,6ES5752-0AA22,6ES5752-0AA42,6ES5921-3WB15,6ES5922-3UA11,
6ES5944-7UB11,6ES5944-7UB21;
SIMATIC
S7:6ES7132-0BL01-0XB0,6ES7153-1AA02-0XB0,6ES7153-1AA03-0XB0,6ES7212-1BB21-0XB0,6ES7214-1AD21-0XB0,6ES7214-

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

1BC01-0XB0,
6ES7214-1BD20-0XB0,6ES7216-2AD00-0XB0,6ES7216-2AD21-0XB0,6ES7216-2AD22-0XB0,6ES7216-2BD00-0XB0,6ES7221-1B
F00-0XA0,
6ES7222-1BF00-0XA0,6ES7222-1HF00-0XA0,6ES7223-1PH00-0XA0,6ES7223-1PL20-0XA0,6ES7231-0HC00-0XA0,6ES7232-0H
B00-0XA0,
6ES7235-0KD00-0XA0,6ES7291-8GC00-0XA0,6ES7307-1BA00-0AA0,6ES7307-1EA00-0AA0,6ES7307-1KA00-0AA0,6ES7307-1K
A01-0AA0,
6ES7313-5BE00-0AB0,6ES7314-1AE01-0AB0,6ES7315-1AF02-0AB0,6ES7315-1AF03-0AB0,6ES7315-2AF03-0AB0,6ES7315-2A
G10-0AB0,
6ES7316-2AG00-0AB0,6ES7321-1BH00-0AA0,6ES7321-1BH01-0AA0,6ES7321-1BH02-0AA0,6ES7321-1BH50-0AA0,6ES7321-1B
L00-0AA0,
6ES7321-1EH00-0AA0,6ES7321-1EH01-0AA0,6ES7322-1BF01-0AA0,6ES7322-1BH00-0AA0,6ES7322-1BH01-0AA0,6ES7322-1B
L00-0AA0,
6ES7322-1EH00-0AA0,6ES7322-1HF10-0AA0,6ES7322-1HH00-0AA0,6ES7323-1BL00-0AA0,6ES7331-7KB02-0AB0,6ES7331-7K
F00-0AB0,
6ES7331-7KF02-0AB0,6ES7332-5HD01-0AB0,6ES7334-0CE00-0AA0,6ES7350-1AH03-0AE0,6ES7354-1AH00-0AE0,6ES7354-1A
H00-7BG0,
6ES7360-3AA00-0AA0,6ES7360-3AA01-0AA0,6ES7361-3CA00-0AA0,6ES7361-3CA01-0AA0,6ES7368-3BB01-0AA0,6ES7368-3B
C51-0AA0,
6ES7368-3BF01-0AA0,6ES7368-3CB01-0AA0,6ES7390-1AF30-0AA0,6ES7390-1AJ30-0AA0,6ES7390-1BC00-0AA0,6ES7390-5AA
00-0AA0,6ES7390-5BA00-0AA0,
6ES7390-5CA00-0AA0,6ES7390-6BA00-0AA0,6ES7392-1AJ00-0AA0,6ES7392-1AM00-0AA0,6ES7392-1BJ00-0AA0,6ES7392-1B
M01-0AA0,6ES7400-1TA01-0AA0,
6ES7407-0KA01-0AA0,6ES7414-2XG03-0AB0,6ES7421-1BL01-0AA0,6ES7422-1BL00-0AA0,6ES7431-0HH00-0AB0,6ES7432-1H
F00-0AB0;
西门子S7-200PLC:SIMATIC S7-200中央处理单元:CPU:CPU221:6ES7211-0AA23-0XB0,6ES7211-0BA23-0XB0;CPU222:6ES7212-
1AB23-0XB0;
6ES7212-1BB23-0XB0;CPU224:6ES7214-1AD23-0XB0;6ES7214-1BD23-0XB0;CPU224XP:6ES7214-2AD23-0XB0;6ES7214-2BD2
3-0XB0;CPU226:
6ES7216-2AD23-0XB0;6ES7216-2BD23-0XB0;
S7-200CN中央处理单元CPU:CPU222CN:6ES7212-1AB23-0XB8;CPU222CN:6ES7212-1BB23-0XB8;CPU224CN:6ES7214-1AD23-
0XB8;CPU224CN:
6ES7214-1BD23-0XB8;CPU224XPCN:6ES7214-2AD23-0XB8;CPU224XPCN:6ES7214-2BD23-0XB8;CPU226CN:6ES7216-2AD23-
0XB8;CPU226CN:
6ES7216-2BD23-0XB8;
S7-200CN扩展模块EMCN:EM221CN:6ES7221-1BF22-0XA8;6ES7221-1BH22-0XA8;EM222CN:6ES7222-1BF22-0XA8,6ES7222-1
HF22-0XA8;EM223CN:
6ES7223-1BF22-0XA8;6ES7223-1HF22-0XA8;6ES7223-1BH22-0XA8;6ES7223-1PH22-0XA8;6ES7223-1BL22-0XA8;6ES7223-1PL
22-0XA8;EM231CN:

公司地址:武汉市洪山区雄楚大街 699 号
业务联系电话:027-63005490 027-51778300 13487094272
网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理
传真:027-51778300
邮编:430074

武汉市中江科技有限公司维修内容列表

6ES7231-0HC22-0XA8;6ES7231-7PB22-0XA8;6ES7231-7PD22-0XA8;EM232CN:6ES7232-0HB22-0XA8;EM235CN:6ES7235-0KD22-0XA8;

SIMATIC S7-200扩展模块EM:EM221:6ES7221-1BF22-0XA0,6ES7221-1EF22-0XA0,6ES7221-1BH22-0XA0;EM222:6ES7222-1BF22-0XA0,6ES7222-1HF22-0XA0,

6ES7222-1EF22-0XA0;6ES7222-1BD22-0XA0,6ES7222-1HD22-0XA0,6ES7223-1BF22-0XA0;EM223:6ES7223-1HF22-0XA0,6ES7223-1BH22-0XA0,

6ES7223-1PH22-0XA0,6ES7223-1BL22-0XA0,6ES7223-1PL22-0XA0;EM231:6ES7231-0HC22-0XA0,6ES7231-7PB22-0XA0,6ES7231-7PD22-0XA0;EM232:

6ES7232-0HB22-0XA0;EM235:6ES7235-0KD22-0XA0;EM241:6ES7241-1AA22-0XA0;EM253:6ES7253-1AA22-0XA0;EM277:6ES7277-0AA22-0XA0;CP243-1:

6GK7243-1EX00-0XE0;CP243-1:6GK7243-1GX00-0XE0;CP243-2:6GK7243-2AX01-0XA0;CP5411:6GK1541-1AA00;CP5511:6GK1551-1AA00;CP5611:

6GK1561-1AA00;

SIMATIC S7-200显示操作面板HMI:6ES7272-0AA30-0YA0,6ES7272-1AA10-0YA0,6ES7272-1AF00-7AA0,6AV3017-ANE30-0AX0,6AV3017-1NE30-0AX0;

OP3操作员面板:6AV3503-1DB10;OP7操作员面板:6AV3607-1JC00-0AX1;OP77B操作员面板:6AV6641-0CA01-0AX0;OP17操作员面板:6AV3617-1JC00-0AX1;

TP070触摸屏:6AV6545-0AA15-2AX0;TP170Micro操作员面板:6AV6640-0CA01-0AX0;TP170A触摸屏:6AV6545-0BA15-2AX0;TP170B触摸屏:6AV6545-0BB15-2AX0;

TP170B触摸屏:6AV6545-0BC15-2AX0;OP170B操作员面板:6AV6542-0BB15-2AX0;K-TP178micro触摸屏:6AV6640-0DA11-0AX0;OP270-6操作员面:

6AV6542-0CA10-0AX0;OP270-10操作员面板:6AV6542-0CC10-0AX0;TP270-6触摸屏:6AV6545-0CA10-0AX0;TP270-10触摸屏:6AV6545-0CC10-0AX0;

MP270B触摸屏:6AV6545-0AH10-0AX0;MP270B触摸 多功能面板:6AV6545-0AG10-0AX0;MP270B键控多功能面板:6AV6542-0AG10-0AX0;MP370触摸多功能面板:

6AV6545-0DA10-0AX0;MP370键控多功能面板:6AV6542-0DA10-0AX0;

西门子S7-300PLCCPU模块:CPU312C:6ES7312-5BD01-0AB0;CPU313C:6ES7313-5BE01-0AB0,313C-2PtP:6ES7313-6BE01-0AB0,CPU313C-2DP:

6ES7313-6CE01-0AB0;CPU314C-2PtP:6ES7314-6BF01-0AB0;CPU314C-2DP:6ES7314-6CF01-0AB0;CPU312A:6ES7312-1AD10-0AB0;CPU314:

6ES7314-1AF10-0AB0;CPU315-2DP:6ES7315-2AG10-0AB0;CPU317-2DP:6ES7317-2AJ10-0AB0;CPU317-2PN/DP:6ES7317-2EJ10-0AB0;CPU317T-2DP:

6ES7317-6TJ10-0AB0;CPU318-2DP:6ES7318-2AJ00-0AB0;CPU315F-2DP:6ES7315-6FF01-0AB0;CPU317F-2DP:6ES7317-6FF00-0AB0;SIPLUSCPU312CA:

6AG1312-5BD01-2AB0,SIPLUSCPU313CA:6AG1313-5BE01-2AB0;SIPLUSCPU314A:6AG1314-1AF10-2AB0;SIPLUSCPU315-2DPA:6AG1315-2AG10-2AB0;

I/O模块:SM323数字量I/O模块:6ES7323-1BH01-0AA0,6ES7323-1BL00-0AA0;SM327数字量I/块:6ES7327-1BH00-0AB0,6ES7327-1BH00-0AB;SIPLUSSM321:

6AG1321-1BH02-2AA0,6AG1321-1BL00-2AA0,6AG1321-1CH20-2AA0,6AG1321-7BH01-2AB0,6AG1321-1FF01-2AA0;SIPLUSSM322:6AG1322-1BH01-2AA0,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6AG1322-8BF00-2AB0,6AG1322-1CF00-2AA0,6AG1322-1HF10-2AA0,6AG1322-1FF01-2AA0;SM323数字量I/O模块:6AG1323-1BH01-2AA0模拟量输入模块SM331:
6ES7331-1KF01-0AB0,6ES7331-7NF00-0AB0,6ES7331-7NF10-0AB0,6ES7331-7HF01-0AB0,6ES7331-7PF00-0AB0,6ES7331-7PF10-0AB0,
6ES7974-0AA00-0AA0;SM332模拟量输出模块:6ES7332-5HD01-0AB0,6ES7332-7ND01-0AB0,6ES7332-5HB01-0AB0,6ES7332-5HF00-0AB0,
6ES7392-1AJ00-0AA0,6ES7392-1AJ00-1AB0,6ES7392-1BJ00-0AA0,6ES7392-1AM00-0AA0,6ES7392-1AM00-1AB0,6ES7392-1BM01-0AA0,6ES7328-0AA00-7AA0;
SM334模拟量输入/输出模块:6ES7334-0CE01-0AA0,6ES7334-0KE00-0AB0,6ES7392-1AJ00-0AA0,6ES7392-1AJ00-1AB0,6ES7392-1BJ00-0AA0,
6ES7328-0AA00-7AA0;SM335模拟量输入/输出模块:6ES7335-7HG01-0AB0;SIPLUSM331模拟量输入模块:6AG1331-7KB02-2AB0;SIPLUSM332模拟量输出模块:
6AG1332-5HB01-2AB0;SIPLUSM334:6AG1334-0KE00-2AB0;SM326故障安全型数字量输入模块:6ES7326-1BK00-0AB0;6ES7326-1RF00-0AB0;
SM326故障安全型数字量输出模块:6ES7326-2BF01-0AB0;SM326故障安全型模拟量输入模块:6ES7336-1HE00-0AB0;SIPLUSM326F数字量输入模块:
6AG1326-1BK00-2AB0;SIPLUSM326F数字量输出模块:6AG1326-2BF01-2AB0;EX数字量输入模块:6ES7321-7RD00-0AB0;EX数字量输出模块:
6ES7322-5SD00-0AB0;EX模拟量输入模块:6ES7331-7RD00-0AB0;8/4点输入,电气隔离,用于热电偶和Pt100,Pt200,Ni100:6ES7331-7SF00-0AB0;EX模拟量输出板:
6ES7332-5RD00-0AB0;FM350-1计数器模块:6ES7350-1AH03-0AE0;模拟量输入所用的编码连接器-量程卡:6ES7974-0AA00-0AA0;FM350-2计数器模块:
6ES7350-2AH00-0AE0;FM351定位模块:6ES7351-1AH01-0AE0;FM352电子凸轮控制器:6ES7352-1AH01-0AE0;FM353定位模块:6ES7353-1AH01-0AE0;
FM354定位模块:6ES7354-1AH01-0AE0;FM357-2定位模块:6ES7357-4AH01-0AE0;FMSTEPDRIVE用于SIMOSTEP步进电机的电源模块:6SN1227-2ED10-0HA0;
SIMOSTEP步进电机1FL3:1FL3061-0AC31-0BG0,1FL3062-0AC31-0BG0,1FL3042-0AC31-0BJ0,1FL3043-0AC31-0BH0,1FL3061-0AC31-0BH0,
1FL3062-0AC31-0BH0,FM355C控制器模块:6ES7355-0VH10-0AE0;FM355S控制器模块:6ES7355-1VH10-0AE0;FM355-2C温度控制器:6ES7355-2CH00-0AE0;
SM338超声波位置编码器模块:6ES7338-7UH01-0AC0;8XIQ-SensE传感器模块:6ES7338-7XF00-0AB0;C40IQ-SeNsE模块:3SF7240-3JQ00;K80IQ-SensE模块:
3SF7210-3JQ00;K80IQ-SensE模块:3SF7214-3JQ00;C40IQ-SeNsE模块:3SF7241-3JQ00;K80IQ-SensE模块:3SF7211-3JQ00;M18IQ-Sense:3SF6232-3JA00,
3SF6233-3JA00;C40IQ-传感器:3SF7240-3JQ00,3SF7241-3JQ00;K80IQ检测:3SF7210-3JQ00,3SF7214-3JQ00,3SF7211-3JQ00;M18IQSense:3SF6232-3JA00,
3SF6233-3JA00;DM370占位模块:6ES7370-0AA01-0AA0;SIPLUS7-300CP340:6AG1340-1AH01-2AE0;CP341通讯处理器:6ES7341-1AH01-0AE0;
CP343-2通讯处理器:6GK7343-2AH00-0XA0;CP343-2通讯处理器:6GK7343-2AH10-0XA0;CP342-5通讯处理器:6GK7342-5DA02-0XE0;CP342-5FO通讯处理器:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6GK7342-5DF00-0XE0;CP343-5通讯处理器:6GK7343-5FA01-0XE0;CP343-1Lean通讯处理器:6GK7343-1CX00-0XE0;CP343-1通讯处理器:6GK7343-1EX20-0XE0;
CP343-1IT通讯处理器:6GK7343-1GX20-0XE0;CP343-1PN通讯处理器:6GK7343-1HX00-0XE0;IM360接口模块:6ES7360-3AA01-0AA0;IM365接口模块:
6ES7365-0BA01-0AA0;SIPLUSIM365接口模块:6AG1365-0BA01-2AA0;负载电压PS307:6ES7307-1BA00-0AA0,6ES7305-1BA80-0AA0,6AG1305-1BA80-2AA0,
6ES7307-1EA00-0AA0,6ES7307-1EA80-0AA0,6AG1307-1EA80-2AA0,6ES7307-1KA01-0AA0;
SINUMERIK&SIMODRIVE用于机床的自动化系统:SIMODRIVE611,SINUMERIKPCU,SIMODRIVE611digital,SIMODRIVE611universalLHR,
SIMODRIVE611universalLEHR,SIMODRIVEPOSMOA/SI/CD/CA,SIMODRIVEbasEline,FMSTEPDRIVE,NCU5714/NCU5724/NCU5734/NCU5735,
SINUMERIK操作前面板OP010:6FC5203-0AF00-0AA1;SINUMERIK操作前面板OP010S:6FC5203-0AF04-0AA0;SINUMERIK操作前面板OP010C:
6FC5203-0AF01-0AA0,6FC5248-0AF00-0AA0;SINUMERIK操作前面板OP012:6FC5203-0AF02-0AA0;SINUMERIK触摸前面板TP012:6FC5203-0AF07-0AA0;
SINUMERIK操作前面板OP0156FC5203-0AF03-0AA0SINUMERIK操作前面板OP015A:6FC5203-0AF05-0AA0,6FC5247-0AF30-0AA0;
SINUMERIK直接控制按键模板:6FC5247-0AF11-0AA0;SINUMERIK触摸前面板TP015A:6FC5203-0AF08-0AA0;SINUMERIKPCU20:
6FC5210-0DF00-0AA1,
6FC5210-0DF00-1AA1;SINUMERIKPCU50:6FC5210-0DF20-0AA0,6FC5210-0DF21-2AA0,6FC5210-0DF22-0AA0,6FC5210-0DF22-2AA0;SINUMERIKPCU70:
6FC5210-0DF04-0AA0,6FC5210-0DF24-0AA0,6FC5210-0DF24-2AA0;手持单元SINUMERIKHT6:6FC5403-0AA10-0AA0;SINUMERIK机床控制面板MCP483C:
6FC5203-0AF22-0AA0;SINUMERIKMCP483机床控制面板:6FC5203-0AF22-1AA1;SINUMERIK机床控制面板MCP:6FC5203-0AF22-1AA0;OP032S机床控制面板:
6FC5203-0AD10-1AA0,6FC5247-0AA34-0AA1;PP012/PP031-MC按钮面板:6FC5203-0AF24-0AA0,6FC5203-0AF25-1AA0,6FC5203-0AD24-0AA0,
6FC5203-0AD25-0AA0,6FC5203-0AD25-1AA0;馈电模块/再生反馈模块和功率模块:6SN1162-0EA00-0AA0,6SN1162-0EA00-0BA0,6SN1162-0EA00-0CA0,
6SN1162-0EA00-0JA0,6SN1162-0EA00-0DA0,6SN1162-0EB00-0AA0,6SN1162-0EB00-0BA0,6SN1162-0EB00-0CA0,6SN1162-0EB00-0JA0,
6SN1162-0EB00-0DA0;SINUMERIKMCP310机床控制面板:6FC5252-0AF00-0AA06FC5203-0AF23-1AA0;MPI接口用于客户操作面板:
6FC5203-0AE00-0AA0;
电子手轮:6FC9320-5DB00,6FC9320-5DC00,6FC9320-5DH00;SINUMERIK802SbasEline:6FC5500-0AA00-1AA0;SINUMERIK802CbasEline:
6FC5500-0AA11-1AA0;SINUMERIK802D basEline:6FC5600-0AB01-0AA0;SINUMERIK 802D basElinE数控:6FC5610-0BB10-0AA1;PP72/48I/O模块:
6FC5611-0CA01-0AA0;SINUMERIK802D数控程序操作控制板(PCU):6FC5610-0BA10-0AA1;机床控制面板MCP:6FC5603-0AD00-0AA1;进给轴扩展插入单元:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6FC5412-0FA10-0AA0;标准型840Di:6FC5258-AX10-A;出口840DiE:6FC5258-AY10-A;SINUMERIK840Di:16FC5220-0AA20-0AA0;MCI板:
6FC5222-0AA00-1AA0;MCI扩展板,槽型:6FC5222-0AA00-0AA1;NCU5614:6FC5356-0BB12-0AE0;NCU5714:6FC5357-0BB12-0AE0;NCU5724:
6FC5357-0BB23-0AE0;NCU5734:6FC5357-0BB34-0AE1;NCU5735:6FC5357-0BB35-0AE0;单I/O模块EFP:6FC5411-0AA00-0AA0;DMP紧凑型,16点数字量输入:
6FC5111-0CA01-0AA0;DMP紧凑型,16点数字量输出:6FC5111-0CA02-0AA2;DMP紧凑型,8点数字量输出:6FC5111-0CA03-0AA2;DMP紧凑型,1点模拟量输入:
6FC5111-0CA04-0AA0;DMP紧凑型,1点模拟量输入:6FC5211-0AA10-0AA0;DMP紧凑型,1点模拟量输出:6FC5111-0CA05-0AA0;终端器,用于驱动总线:
6FX2003-0DA00;ADI4:6FC5211-0BA01-0AA1;后备电池:6ES7971-1AA00-0AA0;存储器FEPROM:6ES7951-0KD00-0AA0,6ES7951-0KD80-0AA0,
6ES7951-0KE00-0AA0,6ES7951-0KE80-0AA0,6ES7951-0KF00-0AA0,6ES7951-0KF80-0AA0,6ES7951-0KG00-0AA0,6ES7951-1KH00-0AA0,6ES7951-0KJ00-0AA0,
6ES7951-1KK00-0AA0,6ES7951-1KL00-0AA0,6ES7951-1KM00-0AA0;存储器卡RAM:6ES7951-0AG00-0AA0,6ES7951-1AH00-0AA0,6ES7951-1AJ00-0AA0,
6ES7951-1AK00-0AA0,6ES7951-1AL00-0AA0;HF输入滤波器套件:6SL3000-0FE21-6AA0,6SL3000-0FE23-6AA0,6SL3000-0FE25-5AA0,6SL3000-0FE28-0AA0,
6SL3000-0FE31-2AA1;HFD输入滤波器套件:6SL3000-0FE23-6BA0,6SL3000-0FE25-5BA0,6SL3000-0FE28-0BA0,6SL3000-0FE31-2BA0;用于UI模块的输入滤波器:
6SN1111-0AA01-1BA0,6SN1111-0AA01-1AA0,6SN1111-0AA01-1CA0;用于I/RF模块的输入滤波器:6SL3000-0BE21-6AA0,6SL3000-0BE23-6AA0,
6SL3000-0BE25-5AA0,6SL3000-0BE28-0AA0,6SL3000-0BE31-2AA0;内部冷却的电源模块:6SN1146-1AB00-0BA1,6SN1145-1AA00-0CA0,6SN1145-1BA01-0BA1,
6SN1145-1BA02-0CA1,6SN1145-1BA01-0DA1,6SN1145-1BB00-0EA1,6SN1145-1BB00-0FA1;外部冷却的电源模块:6SN1146-1AB00-0CA0,6SN1146-1BB01-0BA1,
6SN1146-1BB02-0CA1,6SN1146-1BB00-0DA1,6SN1146-1BB00-0EA1;风道冷却的电源模块:6SN1145-1BB00-0DA1;用于SIMODRIVE611的监控模块:
6SN1112-1AC01-0AA1;过电压限制模块:6SN1111-0AB00-0AA0;SIMODRIVE611脉冲电阻模块:6SN1113-1AB01-0BA1;分布式电容器模块:6SN1112-1AB00-1AA0;
6SN1112-1AB00-1BA0;集中式电容模块:6SN1112-1AB00-0BA0;6SN1112-1AB00-0CA0;内部冷却功率模块:6SN1123-1AA00-0HA1,6SN1123-1AA00-0AA1,
6SN1123-1AA00-0BA1,6SN1123-1AA00-0CA1,6SN1123-1AA00-0DA1,6SN1123-1AA00-0LA1,6SN1123-1AA00-0EA1,6SN1123-1AA01-0FA1,
6SN1123-1AA00-0JA1,6SN1123-1AA00-0KA1,6SN1123-1AB00-0HA1,6SN1123-1AB00-0AA1,6SN1123-1AB00-0BA1,6SN1123-1AB00-0CA1;外部散热功率模块:
6SN1124-1AA00-0HA1,6SN1124-1AA00-0AA1,6SN1124-1AA00-0BA1,6SN1124-1AA00-0CA1,6SN1124-1AA00-0DA1,6SN1124-1AA00-0LA1,
6SN1124-1AA00-0EA1,6SN1124-1AA01-0FA1,6SN1124-1AA00-0JA1,6SN1124-1AA00-0KA1,6SN1124-1AB00-0HA1,6SN1124-1AB00-0AA1,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6SN1124-1AB00-0BA1,6SN1124-1AB00-0CA1;风道冷却电源模块:6SN1123-1AA00-0JA1;SIMODRIVE611universalLEHR:6SN1118-0NH11-0AA0;高标准闭环控制:
6SN1118-0DM3-0AA0,6SN1118-0DJ2-0AA1,6SN1118-0DK2-0AA1;带有数字整定值接口的控制器:6SN1115-0BA11-0AA1;直流电源管理模块DC-PMM/24V:
9AL2137-1AA00-1AA0;直流电源管理模块DC-PMM/48V:9AL2137-1BA00-1AA0;分布式变频器SIMODRIVEPOSMOCD/CA:6SN2703-2AA0-0BA0,
6SN2703-2AA0-0CA0,6SN2703-3AA1-0BA0;SIMODRIVE basEline变频器:FM STEPDRIVE:6SN1227-2ED10-0HA0;SINUMERIK 802S baseline&Stepdrive:
SINUMERIK802C basElinE&SimodrivE basEline:SINUMERIK 802D&SimodrivE 611Ue:SINUMERIK 802D basElinE&Simodriv E 611Ue:
SINUMERIK802D 面板控制单元:6FC5610-0BA10-0AA0;STEPDRIVEC,单轴驱动器:6FC5548-0AA00-0AA0;STEPDRIVEC+,单轴驱动器:6FC5548-0AA02-0AA0;
SIMODRIVEbasEline双轴模块V3:6FC5548-0AC13-0AA0;双轴模块V2:6FC5548-0AC12-0AA0;单轴模块V1:6FC5548-0AC11-0AA0;SIMODRIVE611脉冲电阻器模块:
6SN1113-0AB01-0BA1;外部脉冲电阻器:6SN1113-1AA00-0CA0,6SN1113-1AA00-0DA0;过电压限制模块:6SN1111-0AB00-0AA0;SIMODRIVE611U控制模块:
6SN1118-0NK01-0AA0,6SN1118-0NJ01-0AA0,6SN1118-0NH11-0AA0,6SN1118-1NJ010AA0,6SN1118-1NK01-0AA0,6SN1118-0NH01-0AA0,
6SN1118-1NH01-0AA0,6SN1114-0NA00-0AA0,6SN1114-0NB00-0AA1,6SN1114-0NB01-0AA0;SIMODRIVE611U电源模块:6SN1145-1AA01-0AA1,
63N1145-1BA01-0BA1,6SN1114-0NB01-0AA0;SIMODRIVE611功率模块:6SN112,-1AA00-0HA1,6SN112,-1AA00-0AA1,6SN112,-1AA00-0BA1,
6SN112-1AA00-0CA1,6SN112-1AA00-0DA1,6SN112-1AA00-0LA1,6SN112-1AA00-0EA1,6SN112-1AA01-0FA1,6SN112-1AA00-0JA1,6SN112-1AA00-0KA1,
6SN112-1AB00-0HA1,6SN112-1AB00-0AA1,6SN112-1AB00-0BA1,6SN112-1AB00-0CA1;SITOP电源:6EP1333-2BA0,6EP1334-2BA0;SINUMERIK 810D powerline,SINUMERIK 840D powerline,SINUMERIK 840Di,机床数控系统:SINUMERIK 802Dsl:数控操作面板:6FC5370-0AA00-2AA0,6FC5370-0AA00-3AA0,
6FC5370-0AA00-2BA0,6FC5370-0AA00-3BA0,6FC5303-0DT12-1AA0,6FC5303-0DM13-1AA0,6FC5603-0AD00-0AA2;MCP802Dsl:6FC5303-0AF30-1AA0;
MCPA模块:6FC5312-0DA01-0AA0;MCPA模块:6FC5312-0DA01-0AA0;电源滤波器和电源电抗器:6SL3130-6AE15-0AB0,6SL3000-0GE15-0AA0,
6SL3130-6AE21-0AB0,6SL3000-0GE21-0AA0,6SL3130-7TE21-6AB0,6SL3000-0FE21-6AA0,6SL3130-7TE23-6AB0,6SL3000-0FE23-6AA0,6SL3130-7TE25-5AB0,
6SL3000-0FE25-5AA0,6SL3130-7TE28-0AB0,6SL3000-0FE28-0AA0,6SL3130-7TE31-2AB0,6SL3000-0FE31-2AA1,6SL3000-0FE21-6AA0,6SL3000-0FE23-6AA0,
6SL3060-1FE21-6AA0,6SN1162-0GA00-0CA0;单轴电机模块:6SL3120-1TE13-0AB0,6SL3120-1TE15-0AB0,6SL3120-1TE21-0AB0,6SL3120-1TE21-8AB0,
6SL3120-1TE23-0AB0,6SL3120-1TE24-5AB0,6SL3120-1TE26-0AB0,6SL3120-1TE28-5AB0,6SL3120-1TE31-3AB0,6SL3120-1TE32-0AB0;双轴电机模块:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6SL3120-2TE13-0AB0,6SL3120-2TE15-0AB0,6SL3120-2TE21-0AB0,6SL3120-2TE21-8AB0,6SL3162-2BD00-0AA0,6SL3162-2BM00-0AA0,6SL3162-2BM01-0AA0,
6SL3162-2AA00-0AA0;制动模块:6SL3100-1AE31-0AB0电容模块:6SL3100-1CE14-0AA0机柜安装式编码器模块SMC20:6SL3055-0A00-5BA1,
6SL3055-0AA00-5CA1;S6SN1118-0AD11-0AA1,S6SN1118-0AA11-0AA1,6SN1118-0AE11-0AA1,6SN1114-0AA01-0AA0,6SN1114-0AA02-0AA0,
6SN1118-0BJ11-0AA0,6SN1118-0BK11-0AA0,6SN1121-0BA11-0AA1,6SN1122-0BA11-0AA1,6SN1118-0DM1-0AA0,6SN1118-0DM3-0AA0,6SN1118-0DG1-0AA1,
6SN1118-0DG2-0AA1,6SN1118-0DG3-0AA1,6SN1118-0DH1-0AA1,6SN1118-0DH2-0AA1,6SN1118-0DH3-0AA1,6SN1118-0DK23-0AA0,6SN1115-0BA11-0AA1,
6SN1115-0AA12-0AA0,6SN1161-1AA01-0BA0,6SN1161-1AA01-0AA0,9AL2173-1AA00-1AA0,9AL2173-1BA00-1AA0,6FC5220-0A00-1AA0,
SIMODRIVE611进给模块:6SN1146-1AA01-0AA1,6SN1146-1AA00-0CA1,6SN1146-1BA01-0BA1,6SN1146-1BA02-0CA1,6SN1146-1BA01-0DA1,
6SN1146-1BB00-0FA1;SIMOTION运动控制系统:SIMOTIONC230-2运动控制器:6AU1230-2AA01-0AA0;SIMOTION32MB:6AU1700-0AA02-0AA0,
6AU1700-0AA02-0CA0;SIMOTIONP012T:6AU1300-0CA00-0AA0SIMOTIONP012K:6AU1300-0DA00-0AA0;SIMOTIONP015K:6AU1300-0FA00-0AA0;
SIMOTIONP015T:6AU1300-0EA00-0AA0;标准PC键盘:6FC5203-0AC01-2AA0;SIMOTIOND425:6AU1425-0AA00-0AA0;SIMOTIOND435:6AU1435-0AA00-0AA1;
SIMOTIOND445:6AU1445-0AA00-0AA0;SIMOTIONCX32:6SL3040-0NA00-0AA0;CP5512:6GK1551-2AA00;CP5611:6GK1561-1AA00;CP5613:6GK1561-3AA01;
CP5614:6GK1561-4AA01;CP1613:6GK1161-3AA01;电源模板:6EP1333-3BA00,6EP1334-3BA00,6EP1336-3BA00,6EP1337-3BA00,6EP1436-3BA00,
6EP1437-3BA00,6EP1961-3BA00,6EP1961-3BA10,6EP1961-3BA20,6EP1961-2BA00;6EP1331-2BA00,6EP1333-2AA00,6EP1334-2AA00,6EP1333-1AL12,
6EP1334-1AL12,6EP1334-2CA00,6EP1971-2CA00,6EP1931-2DC21,6EP1931-2DC31,6EP1931-2DC41,6EP1931-2EC21,6EP1931-2EC31,6EP1931-2EC41,
6EP1931-2FC21,6EP1931-2FC41,6EP1935-6MC01,6EP1935-6MD31,6EP1935-6MD11,6EP1935-6ME21,6EP1935-6MF01;SM338 POS:6ES7338-4BC01-0AB0;
SubD连接器:6ES7570-2AA21;FM352-5高速布尔处理器:6ES7352-5AH00-0AE0,6ES7352-5AH10-0AE0;CP340通讯模板:6ES7340-1AH01-0AE0,
6ES7340-1BH00-0AE0,6ES7340-1CH00-0AE0;CP341通讯模板:6ES7341-1AH01-0AE0,6ES7341-1BH01-0AE0,6ES7341-1CH01-0AE0;IM151-1基本型接口模板:
6ES7151-1CA00-0AB0;IM151-1标准接口模板:6ES7151-1AA04-0AB0;IM151-1高性能接口模板:6ES7151-1BA00-0AB0;IM151-1FO接口模板:6ES7151-1AB03-0AB0;
IM151-7CPU接口模板:6ES7151-7AA11-0AB0;IM151-7CPUFO接口模板:6ES7151-7AB00-0AB0;主站接口模板:6ES7138-4HA00-0AB0;微存储卡(MMC):
6ES7953-8LF11-0AA0,6ES7953-8LG11-0AA0,6ES7953-8LJ11-0AA0,6ES7953-8LL11-0AA0,6ES7953-8LM11-0AA0,6ES7953-8LP11-0AA0;电源模板PM-E24VDC:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6ES7138-4CA01-0AA0,PM-E24V~48VDC;6ES7138-4CA50-0AB0,PM-E24V~48VDC;6ES7138-4CB10-0AB0;数字量电子模板:6ES7131-4BB01-0AA0,
6ES7131-4BD01-0AA0,6ES7131-4BD51-0AA0,6ES7131-4RD01-0AB0,6ES7131-4EB01-0AB0,6ES7131-4FB01-0AB0,6ES7131-4B
B01-0AB0,
6ES7131-4BD01-0AB0,6ES7131-4CD00-0AB0,6ES7132-4BB01-0AA0,6ES7132-4BD01-0AA0,6ES7132-4BB31-0AA0,6ES7132-4B
D31-0AA0,
6ES7132-4BB01-0AB0,6ES7132-4BB31-0AB0,6ES7132-4FB01-0AB0,6ES7132-4HB01-0AB0,6ES7132-4HB11-0AB0;模拟量电子模
板:6ES7134-4FB01-0AB0,
6ES7134-4FB51-0AB0,6ES7134-4LB00-0AB0,6ES7134-4GB01-0AB0,6ES7134-4GD00-0AB0,6ES7134-4GB11-0AB0,6ES7134-4G
B51-0AB0,
6ES7134-4GB61-0AB0,6ES7134-4MB00-0AB0,6ES7134-4JB00-0AB0,6ES7134-4NB01-0AB0,6ES7134-4JB50-0AB0,6ES7134-4N
B51-0AB0;
6ES7135-4FB01-0AB0,6ES7135-4LB01-0AB0,6ES7135-4GB01-0AB0,6ES7135-4MB01-0AB0,6ES7138-4DD00-0AB0,6ES7138-4D
A04-0AB0,
6ES7138-4DE02-0AB0,6ES7138-4GA00-0AB0,6ES7138-4DF01-0AB0,6ES7138-4DC00-0AB0,6ES7138-4DL00-0AB0;DS1e-x直接
起动机:3RK1301-0AB10-0AA3;
RS1e-x反向起动机:3RK1301-0BB10-1AA3;RS1e-x软起动机:3RK1301-0CB20-0AA3;SIGUARD电源模板:3RK1903-1BA00,3RK1903-
1BB00,3RK1903-1BD00,
3RK1903-1BC00,3RK1903-1BE00,3RK1903-1CB00;SIMOTIONTM121C:6AU1121-2CA00-0AA0,6AU1121-3CA00-0AA0,6AU1121-
3CA00-1AA0;ADI4:
6FC5211-0BA01-0AA1;CP343-2P通讯处理器:6GK73432AH10-0XA0;面板型PC-R:6AU1355-1FF13-0AB0,6AU1355-1EF13-0AB0,6A
U1360-3FH26-0AD0,
6AU1360-3EH26-0AD0;辊轮进给:6AU1830-0AC10-0AB06/5,6AU1830-0AC10-0AB06/5,6AU1830-0AC10-0AB06/5;SIMOTIONP350:
6AU1350-2AH21-1BE1,
6AU1350-2AH23-1BE1,6ES7648-2AC10-0CA0,6ES7648-2AC20-0CA0;SIMODRIVE6SN11功率模块:6SN112-1AA00-0HA1,6SN112
-1AA00-0AA1,
6SN112-1AA00-0BA1,6SN112-1AA00-0CA1,6SN112-1AA00-0DA1,6SN112-1AA00-0LA12,6SN112-1AA00-0EA1,6SN112-1AA01-0
FA1,6SN112-1AA00-0JA1,
6SN112-1AA00-0KA1,6SN1123-1AA02-0FA1,6SN112-1AB00-0HA1,6SN112-1AB00-0AA1,6SN112-1AB00-0BA1,6SN112-1AB00-0
CA1;
SIMATIC DPET200:6ES7151-1AA01-0AB0,6ES7138-4CA00-0AA0,6ES7193-4CD30-0AA0,6ES7131-4BD00-0AA0,6ES7132-4BD3
0-0AA0,6ES7193-4CB30-0AA0;
S7-400PLC: 基板:6ES7401-2TA01-0AA0,6ES7400-1TA01-0AA0,6ES7403-1TA01-0AA0,PS407电
源,16ES7407-0DA00-0AA0,6ES7407-0KA01-0AA0,
6ES7407-0RA00-0AA0,中央处理
器,CPU412,6ES7412-1XF02-0AB0,CPU413,6ES7413-1XG02-0AB0,CPU413-2DP,76ES7413-2XG02-0AB0,CPU414,
6ES7414-1XG02-0AB0,CPU414-2DP,6ES7414-2XG03-0AB0,CPU416,6ES7416-1XJ02-0AB0,存储器
卡,6ES7952-0KF00-0AA0,6ES7952-0KH00-0AA0,
6ES7952-1KK00-0AA0,6ES7952-1AL00-0AA0,SM421 数字量输入模板,6ES7421-1BL01-0AA0,6ES7421-7DH00-0AB0,SM422 数字量
输出模板,6ES7422-1BL00-0AA0,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6AV6381-1BF05-0AV0,6AV6381-1BQ05-0AV0,6AV6381-1BM05-0AV0,6AV6381-1BN05-0AV0,HMI 操作面板,6AV3503-1DB10,OP5/A2 4 行液晶显示,
MPI/SINEC L2-DP,6AV3505-1FB12,OP7/DP-1.5 4 行液晶显示, MPI/SINEC L2-DP/RS422, 485,6AV3607-1JC20-0AX1,OP7/DP-12 4 行液晶显示,
MPI/SINEC L2-DP/RS422,485,6AV3607-1JC30-0AX1,OP15 4 行液晶显示, 2 个 TTY, 1 个 MPI/PPI/SINEC L2-DP 口,6AV3515-1MA22-1AA0,OP17/DP-1.5,
6AV3617-1JC20-0AX1,OP17/DP-12,6AV3617-1JC30-0AX1,OP276AV3627-1JK00-0AX0,OP276AV3627-1LK00-1AX0,OP37,6AV3637-1LL00-0AX1,
6AV3637-1ML00-0FX0,TD17 4 行液晶显示,
6AV3017-1NE30-0AX0,TP7,6AV3607-1NH00-0AX0,TP27,MONO,6AV3627-1NK00-0AX0,TP27 ,
6AV3627-1QK00-0AX0,TP27 ,6AV3627-1QL01-0AX0,TP37,6AV3637-1PL00-0AX0,PROFIBUS 的 RS485 总线终端,6GK1500-0AA00, PROFIBUS 的 RS485 总线终端,6GK1500-0AA10,PROFIBUS 的 RS485 总线终端,6GK1500-0AB00,PROFIBUS 的 RS485 总线终端,6GK1500-0EA02,
PROFIBUS 卡
CP5412,6GK1541-2BA00,P6SE3290-0XX87-8PB0,6SX7010-0FF00,6ES7422-1BH10-0AA0,6ES7422-1FH00-0AA0,6ES7422-1HH00-0AA0,
6ES7422-1FF00-0AA0,SM431,6ES7431-1KF00-0AB0,6ES7431-1KF10-0AB0,6ES7431-1KF20-0AB0,6ES7431-7QH00-0AB0,SM432,6ES7432-1HF00-0AB0,
接口模板,6ES7460-0AA00-0AB0,6ES7461-0AA01-0AA0,
6ES7460-1BA01-0AB0,6ES7461-1BA01-0AA0,6ES7460-3AA01-0AB0,6ES7461-3AA01-0AA0,
通讯处理器:CP441-1,6ES7441-1AA03-0AE0,CP441-1, 6ES7441-2AA03-0AE0,通讯卡,CP5412 (AT ISA) ,6GK1541-2BA00,CP5411 (AT ISA) ,6GK1541-1AA00,
CP5511 (PCMCIA, TYPE II) ,6GK1551-1AA00, CP5611 (PCI) ,6GK1561-1AA00,
SITOP 稳压电源:
6EP1331-2BA00,6EP1333-2AA00,6EP1334-2AA00,6EP1336-2BA00,6EP1434-2BA00,6EP1436-2BA00,6EP1437-2BA00,6EP1437-2BA10; 6EP1331-1SL11,6EP1434-2BA00,6EP1436-2BA00,6EP1437-2BA10,6EP1536-1SL01,6EP5306-5BG00,6EP5406-5AA00;
S7-200:CPU221 (本机6I/4O) :6ES7211-0AA21-0XB0,6ES7211-0BA21-0XB0,CPU222 (本机8I/6O) ,6ES7212-1AB21-0XB0,6ES7212-1BB21-0XB0,
CPU224 (本机14I/10O) ,6ES7214-1AD21-0XB0,6ES7214-1BD21-0XB0,CPU226 (本机24I/16O) ,6ES7216-2AD21-0XB0,6ES7216-2BD21-0XB0,
EM221 数字输入模板,6ES7221-1BF21-0XA0,EM222 数字输出模板,6ES7222-1BF21-0XA0,6ES7222-1HF21-0XA0,EM223 数字输入/输出模板,6ES7223-1BF21-0XA0,
6ES7223-1HF21-0XA0,6ES7223-1BH21-0XA0,6ES7223-1PH21-0XA0,6ES7223-1BL21-0XA0,6ES7223-1PL21-0XA0,EM231/232/235 模拟量输入输出模板,
6ES7231-0HC21-0XA0,6ES7232-0HB21-0XA0,6ES7235-0KD21-0XA0,MC291, CPU22X 存储器卡,6ES7291-8GE20-0XA0,CC292, CPU22X 带电池的时钟/日历卡,6ES7297-1AA20-0XA0,BC293, CPU22X 电池卡,6ES7291-8BA20-0XA0,TD-200 文本显示器,6ES7272-0AA21-0YA0,
Profibus-DP 模块,6ES7277-0AA21-0XA0,EM231 AI4X 热电偶,6ES7231-7PD21-0XA0,EM231 AI2X 热电阻,6ES7231-7PB21-0XA0,
S7300:PS307 电源:6ES7307-1BA00-0AA0,6ES7307-1EA00-0AA0,6ES7307-1KA00-0AA0,CPU312 IFM 集成功能模块,6ES7312-5AC02-0AB0,CPU313,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6ES7313-1AD03-0AB0,CPU314,6ES7314-1AE04-0AB0,CPU314 IFM 模
块,6ES7314-5AE03-0AB0,CPU315,46ES7315-1AF03-0AB0,CPU315-2DP 模块,
6ES7315-2AF03-0AB0,CPU316-2DP 模块,6ES7316-2AG00-0AB0,CPU318,6ES7318-2AJ00-0AB0,SM321 数字输入模
板,6ES7321-1BL00-0AA0,
6ES7321-1BH02-0AA0,6ES7321-1BH50-0AA0,6ES7321-1FF01-0AA0,SM322 数字输出模
板,6ES7322-1BL00-0AA0,6ES7322-1BH01-0AA0,6ES7322-1HH00-0AA0,
6ES7322-1BF01-0AA0,6ES7322-1FF01-0AA0,6ES7322-1HF01-0AA0,6ES7322-1HF10-0AA0,SM323 数字量输入/输出模
板,6ES7323-1BH01-0AA0,
6ES7323-1BL00-0AA0,SM331 模拟量输入模板,6ES7331-7KF01-0AB0,8AI/4AI
PT100,6ES7331-7SF00-0AB0,6ES7331-7KB01-0AB0,量程卡(2输入通道),
6ES7974-0AA00-0AA0,SM332 模拟量输出模板,6ES7332-5HD01-0AB0,2通道隔离输出,12位精度,6ES7332-5HB01-0AB0,SM334
模拟量输入/输出模板,
6ES7334-0CE01-0AA0,4入/2出,0-10V,PT100,6ES7334-0KE00-0AA0,SM374 开关模拟器,6ES7374-2XH01-0AA0,FM350-1 单通
道计数模块,
6ES7350-1AH01-0AE0,FM350-2 8通道计数模块,6ES7350-2AH00-0AE0,FM351 位控模块,
8DI/8DO,6ES7351-1AH01-0AE0,6ES7351-1AH00-8BG0,
FM352 电子凸轮控制模块,6ES7352-1AH01-0AE0,FM353 步进电机控制模块,6ES7353-1AH01-0AE0,FM354 闭环位控模
块,6ES7354-1AH01-0AE0,
FM355 闭环控制模块(4AI+8DI+4AO),6ES7355-0VH10-0AE0,FM357 定位和连续路径控制模块(基本模块),6ES7357-4AH01-0AE0,
IM178-4 接口模块(将定位驱动器连接到 Profibus-DP),6ES7178-4BH00-0AE0,PROFIBUS 通讯模板,CP 342-5 通讯处理
器,6GK7342-5DA02-0XE0,
CP 343-5 通讯处理器,6GK7343-5FA00-0XE0,CP343-1 TCP/IP 通讯处理器,6GK7343-1GX00-0XE0,CP340 点对点通讯模
板,CP340-1A,
带 RS232 接口 V2.4,6ES7340-1AH01-0AE0,CP340-1B,带 20 mA TTY 接口,6ES7340-1BH00-0AE0,CP340-1C,带 RS422/485 接
口,6ES7340-1CH00-0AE0,
FLASH EPROM 内存
卡,6ES7951-0KD00-0AA0,6ES7951-0KE00-0AA0,6ES7951-0KF00-0AA0,6ES7951-0KG00-0AA0,6ES7951-0KJ00-0AA0;
SIMODRIVE610/611A/611D/611U/611Ue/POSMO:
6SN1114-0NA00-0AA0,6SN1114-0NB00-0AA0,6SN1114-0NB00-0AA1,6SN1114-0NB01-0AA0,
6SN1115-0AA11-0AA0,6SN1115-0AA12-0AA0,6SN1115-0BA11-0AA1,6SN1117-0DG21-0AA0,6SN1118-0AA11-0AA0,6SN1118-0A
A11-0AA1,
6SN1118-0AD11-0AA1,6SN1118-0AE11-0AA0,6SN1118-0DG22-0AA0,6SN1118-0DG23-0AA1,6SN1118-0DH21-0AA0,6SN1118-0
DH21-0AA1,
6SN1118-0DH22-0AA1,6SN1118-0DH23-0AA1,6SN1118-0DK21-0AA0,6SN1118-0DK23-0AA0,6SN1118-0DM13-0AA1,6SN1118-0
DM21-0AA0,
6SN1118-0DM23-0AA0,6SN1118-0DM31-0AA0,6SN1118-0DM33-0AA0,6SN1118-0NH00-0AA1,6SN1118-0NH00-0AA2,6SN1118-0
NH01-0AA0,
6SN1118-0NH10-0AA0,6SN1118-0NH11-0AA0,6SN1118-0NJ00-0AA1,6SN1118-1NH00-0AA0,6SN1118-1NH01-0AA0,6SN1118-1
NJ00-0AA0,
6SN1118-1NJ00-0AA1,6SN1118-1NJ00-0AA2,6SN1118-1NJ01-0AA0,6SN1118-1NK00-0AA2,6SN1122-0BA11-0AA0,6SN1122-0B

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

A12-0AA0,
6SN1123-1AA00-0AA0,6SN1123-1AA00-0BA0,6SN1123-1AA00-0DA0,6SN1123-1AA00-0JA0,6SN1123-1AA00-0JA1,6SN1123-1A
A01-0FA0,
6SN1123-1AB00-0AA0,6SN1123-1AB00-0BA0,6SN1123-1AB00-0HA0,6SN1124-1AA00-0DA1,6SN1124-1AA00-0EA1,6SN1124-1A
A00-0JA1,
6SN1124-1AA00-0LA1,6SN1124-1AB00-0BA1,6SN1124-1AB00-0CA1,6SN1145-1AA00-0AA0,6SN1145-1BA00-0CA0,6SN1145-1B
A01-0BA0,
6SN1145-1BA01-0DA0,6SN1145-1BA02-0CA0,6SN1145-1BB00-0DA0,6SN1145-1BB00-0FA1,6SN1146-1BB00-0DA1,6SN1146-1B
B00-0EA1,
6SN1146-1BB01-0BA1,6SN1146-1BB02-0CA1,6SN1161-1AA00-0AA0,6SN1161-1AA01-0AA0;6SC6100-0AB00,6SC6100-0GA00,6
SC6100-0GB11,
6SC6100-0GB12,6SC6100-0GC15,6SC6100-0GC12,6SC6100-0GC10,6SC6100-0GA12,6SC6100-0GB00,6SC6100-0GC08,6SC61
00-0GE01,6SC6100-0NA01,
6SC6100-0NA11,6SC6100-0NA21,6SC6103-0SN30,6SC6108-0SE01,6SC6101-2B-Z,6SC6108-0SE02,6SC6108-0SG02,6SC6108-
0SN00,6SC6120-0FE01,
6SC6130-0FE01,6SC6140-0FE01,6SC6170-0FC00,6SC6170-0FC01,6SC6110-0GA00,6SC6110-0GB00,6SC6110-0HF01,6SC6110
-3AA00,6SC6110-7VA01,
6SC6111-1VA01,6SC6111-2AA00,6SC6112-0AA00,6SC6170-0FC51,6SC6190-0FB01,6SC6500-0NA44,6SC6608-4AA00;6SC6112
-2VA01,6SC6112-4DA00,
6SC6114-0AA00,6SC6114-5HA00,6SC6114-5HA00,6SC6115-5VA01,6SC6116-0AA00,6SC6116-0HA00,6SC6120-0FE00,6SC6500
-0UC01,6SC6502-0AB02,
6SC6503-4AA02,6SC6504-0AF01,6SC6504-4AA02,6SC6506-0AF02,6SC6508-0AA02,6SC6508-4AA02,6SC6600-4GA00,6SC6600
-4NU00,6SC6901-0VR05,
6SC6901-0VR07,6SN1111-0AA01-0BA2,6SN1111-0AA01-0CA1,6SN1111-0AA01-0CA2,6SN1111-0AA01-0DA0,6SN1111-0AA01-2
BA0,6SN1111-0AA01-2CA0,
6SN1111-0AA01-2DB0,6SN1111-0AA01-2EA0,6SN1118-0AD11-0AA0,6SN1118-0DA11-0AA0,6SN1118-0DA13-0AA0,6SN1118-0
DG11-0AA0,
6SN1118-0DG21-0AA0,6SN1118-0DG21-0AA1,6SN1118-0DG23-0AA0,6SN1118-0DH11-0AA0,6SN1118-0DH12-0AA0,6SN1118-0
DH22-0AA0,
6SN1118-0DH23-0AA0,6SN1118-0DJ21-0AA0,6SN1118-0DJ23-0AA0,6SN1118-0DM11-0AA0,6SN1118-0DM11-0AA1,6SN1118-1
NK00-0AA0,
6SN1118-1NK00-0AA1,6SN1121-0BA11-0AA0,6SN1121-0BA12-0AA0,6SN1121-0BA13-0AA0,6SN1123-1AA00-0CA0,6SN1123-1A
A00-0EA0,
6SN1123-1AA00-0GA0,6SN1123-1AA00-0HA0,6SN1123-1AA00-0KA0,6SN1123-1AA00-0LA0,6SN1123-1AB00-0CA0,6SN1124-1A
B00-0BA0,
6SN1130-1DA11-0CA0,6SN1130-1DA13-0DA0,6SN1135-1BA13-0GA0,6SN1140-1BA12-0EA0,6SN1145-1AA01-0AA0,6SN1146-1
BB02-0CA0,
6SN1145-1BA00-0BA0,6SN1145-1BA00-0DA0,6SN1145-1BB00-0EA0,6SN1145-1BB00-0FA0,6SN1146-1AB00-0BA0;
SINUMERIK
800:6EV3034-0BC,6EV3054-0DC,6EV3054-0FC,6EV3054-0GC,6EV3055-0DC,6EW1861-3AB,6EW1861-3BA,6FC3478-3EF20,6F

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

C3538-3EF20,
6FC3551-1AC-Z,6FC3981-3HM01,6FC3981-7AC,6FC3984-7CL01,6FC3984-7CL02,6FC3984-7CL05,6FC3984-7DK01,6FC3984-7DK23,6FC3984-7DL03,
6FC3988-7AF01,6FC4600-0AR04,6FC4700-0BB10,6FC5095-0AA50-0BP0,6FC5095-0AA80-0BP0,6FC5100-0AA01-0AA1,6FC5100-0AB01-0AA1,
6FC5103-0AB01-0AA2,6FC5103-0AB03-1AA2,6FC5103-0AD03-0AA0,6FC5103-0AD21-0AA0,6FC5103-0AE01-0AA1,6FC5110-0BA01-0AA0,
6FC5110-0BB02-0AA1,6FC5110-0BB04-0AA1,6FC5110-0CB01-0AA0,6FC5110-0DB02-0AA4,6FC5110-0DB03-0AA3,6FC5111-0BA01-0AA0,
6FC5111-0BA04-0AA0,6FC5111-0BA06-0AA0,6FC5111-0CA01-0AA0,6FC5111-0CA02-0AA2,6FC5111-0CA03-0AA2,6FC5111-0CA04-0AA0,
6FC5111-0CA05-0AA0,6FC5111-0CA70-0AA0,6FC5111-0CA73-0AA1,6FC5112-0DA01-0AA0,6FC5114-0AA02-0AA0,6FC5114-0AB01-0AA1,
6FC5135-0AA01-0AA0,6FC5147-0AA00-0AA0,6FC5147-0AA00-0AA1,6FC5147-0AA02-0AA0,6FC5147-0AA03-0AA0,6FC5147-0AA10-0AA0,6FC5147-0AA14-0AA2,
6FC5147-0AA15-0AA1,6FC5147-0AA20-0AA0,6FC5147-0AB01-0AA0,6FC5148-0AA01-0AA0,6FC5148-0AA13-0AA0,6FC5148-0AA14-0AA0,6FC5148-0AA20-0AA0;

SINUMERIK

840D/840Di/810D/802D:6FC5203-0AB00-0AA0,6FC5203-0AB10-0AA1,6FC5203-0AB11-0AA1,6FC5203-0AB11-0AA2,6FC5203-0AB20-0AA1,
6FC5203-0AB20-1AA0,6FC5203-0AC00-0AA2,6FC5203-0AC00-1AA0,6FC5203-0AD10-0AA0,6FC5203-0AD10-1AA0,6FC5203-0AE00-0AA0,
6FC5203-0AF00-0AA0,6FC5203-0AF00-0AA1,6FC5203-0AF01-0AA0,6FC5203-0AF03-0AA0,6FC5203-0AF04-0AA0,6FC5210-0DA00-0AA0,6FC5210-0DA00-1AA1,
6FC5210-0DA20-2AA0,6FC5210-0DA21-2AA1,6FC5210-0DF00-0AA1,6FC5210-0DF05-0AA0,6FC5210-0DF05-0AA1,6FC5210-0DF22-0AA0,
6FC5210-0DF22-2AA0,6FC5211-0AA00-0AA0,6FC5211-0AA10-0AA0,6FC5211-0BA01-0AA0,6FC5211-0BA01-0AA1,6FC5220-0AA00-1AA0,6FC5220-0AA20-0AA0,
6FC5222-0AA00-1AA0,6FC5235-0AA05-0AA1,6FC5247-0AA00-0AA2,6FC5247-0AA02-1AA0,6FC5247-0AA06-0AA0,6FC5247-0AA11-0AA1,6FC5247-0AA11-0AA2,
6FC5247-0AA15-0AA0,6FC5247-0AA16-0AA0,6FC5247-0AA16-0AA1,6FC5247-0AA17-0AA0,6FC5247-0AA17-0AA1,6FC5247-0AA18-0AA0,6FC5247-0AA20-0AA0,
6FC5247-0AA21-0AA0,6FC5247-0AA22-0AA0,6FC5247-0AA28-0AA0,6FC5247-0AA30-0AA0,6FC5247-0AA31-0AA0,6FC5247-0AA33-0AA0,6FC5247-0AA34-0AA1,
6FC5247-0AA35-0AA0,6FC5247-0AA36-0AA1,6FC5247-0AF08-0AA0,6FC5247-0AF08-0AA1,6FC5248-0AA00-0AA0,6FC5248-0AA02-0AA0,6FC5248-0AF20-2AA0,
6FC5250-0AA06-0AA0,6FC5250-0AC10-0AA0,6FC5250-0AC11-0AA0,6FC5250-6AX30-4AH0,6FC5250-6BX30-3AH3,6FC5250-6BX30-4AH0,
6FC5251-0AA03-0AA0,6FC5251-0AA07-0AA0,6FC5252-0AX22-0AB0,6FC5252-5AY00-2AG0,6FC5252-6AX21-4AG3,6FC5253-0AF00-0AA0,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6FC5253-0BX10-0AG0,6FC5253-6BX10-3AF0,6FC5253-6BX10-3AG0,6FC5258-0AX10-0AF0,6FC5260-6FX08-1AG0,6FC5260-6FX16-1AG0,
6FC5263-5AA04-1AG3,6FC5263-6AY20-0AB0,6FC5270-0BX30-0AH0,6FC5270-4AX20-4AH0,6FC5270-6BX30-3AH0,6FC5357-0BA20-0AE0,
6FC5357-0BA21-0AE0,6FC5357-0BA21-1AE1,6FC5357-0BB11-0AE0,6FC5357-0BB21-0AE0,6FC5357-0BB22-0AE0,6FC5357-0BB23-0AE0,6FC5357-0BB33-0AE2,
6FC5357-0BB34-0AE0,6FC5357-0BH00-0XE0,6FC5357-0BH00-0XE1,6FC5410-0AX02-1AA0,6FC5410-0AY01-0AA0,6FC5410-0AY03-0AA0,
6FC5410-0AY03-0AA1,6FC5411-0AA00-0AA0,6FC5411-0AA80-0AA0,6FC5412-0FA10-0AA0,6FC5447-0AA00-0AA1,6FC5447-0AA01-0AA0,6FC5463-5AF00-3AG0,
6FC5500-0AA11-0AA0,6FC5598-3AA00-0BP1,6FC5598-3AA10-0BP1,6FC5603-0AC13-1AA0,6FC5603-0AD00-0AA1,6FC5611-0CA01-0AA0;

SINUMERIK

810T/M:6FC9301-0AE20,6FC9301-0CC20,6FC9301-0DC20,6FC9301-0EC20,6FC9307-1AA,6FC9307-1AB,6FM1723-3CA10,6FM1725-3AA00,
6FX1111-0AN02,6FX1111-1AA01,6FX1111-4AB00,6FX1112-0AA01,6FX1115-0AA02,6FX1118-1AA02,6FX1118-4AB01,6FX1120-2CA02,6FX1120-4BA02,
6FX1120-4BD03,6FX1120-5BA01,6FX1120-5BB01,6FX1120-7BA01,6FX1120-7BB01,6FX1121-2BA03,6FX1121-2BB02,6FX1121-3BA01,6FX1121-4BA03,
6FX1121-4BB03,6FX1121-8BA03,6FX1122-1AA02,6FX1122-2AA02,6FX1122-2AD02,6FX1122-8BC04,6FX1122-8BD01,6FX1122-8BD04,6FX1123-2AA00,
6FX1123-7AA01,6FX1123-7AA02,6FX1124-0BA03,6FX1124-6AD02,6FX1125-1AA01,6FX1125-7AA02,6FX1125-7BA01,6FX1125-8AB01,6FX1125-8AB04,
6FX1126-1AA03,6FX1126-4AA00,6FX1126-5AA01,6FX1126-7BA01,6FX1126-8BA00,6FX1126-8BB00,6FX1128-1BA00,6FX1128-1BB00,6FX1130-2BA03,
6FX1130-6BA00,6FX1132-8BB01,6FX1134-2BC01,6FX1138-5BB03,6FX1138-5BB04,6FX1138-6BB01,6FX1145-3BA00,6FX1151-1BA01,6FX1151-1BD01,
6FX1154-8BB01,6FX1190-1AE00;

SIMOTION:6AU1230-2AA00-0AA0,6AU1700-0AA01-0AA0,6AU1810-0XA10-0XA0;

COROS

OP/PROTOOL:6AV3505-1FB01,6AV3607-1JC20-0AX1,6AV3617-1JC20-0AX1,6AV3627-1QL01-0AX0,6AV3972-1XB00-0AA0,6AV6371-1BD10-0BX0,

6AV6545-0BA15-2AX0,6AV6545-0BC15-2AX0,6AV6581-3BX06-0CX0,6AV6584-1AB05-0AX0,6BQ1310-0AA20-0AG0;

SYMADIN:6DD1606-0AD0,6DD1801-5DA2,6DD1843-0AA0;

SIEMENS

ENCODER:6FX2001-2AA50,6FX2001-2AC50,6FX2001-2CA50,6FX2001-2CB00,6FX2001-2CB02,6FX2001-2CB25,6FX2001-2CB50,6FX2001-2CC00,
6FX2001-2CC50,6FX2001-2CD60,6FX2001-2CF00,6FX2001-2EA50,6FX2001-2EC00,6FX2001-2EC50,6FX2001-2EF00,6FX2001-2FB25,6FX2001-2GB02,
6FX2001-3CB02,6FX2001-3CC50,6FX2001-3EC50,6FX2001-5FE25,6FX2001-5FS24,6FX2001-7KF10,6FX2001-7KP01,6GK1500-

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

0EA02,6GK1551-1AA00,

6GK1561-1AA00,6GK1704-5CW61-3AA0,6GK7342-5DA02-0XE0;

维修百格拉公司导轨:LM-P404-R,LM-P608-R,LM-P608B-R,LM-P608-K,LM-P608B-K,LM-P812-R-At5,LM-P812-R-AT10,LM-P812-K-AT10,LM-A0K-Z,LM-A1K-T5,

LM-A2K-Z,LM-A2K-T5,LM-A3K-T5,LM-A404,LM-A608,LM-A608,LM-A812,LM-A812,LM-A812,LM-A812;

芯片级维修海德汉控制产品:

HEIDENHAIN-Motoren:QSY96A,QSY96G,QSY116C,QSY116E,QSY116J,QSY116J,QSY130C,QSY130E,QSY155B,QSY155C,QSY155D,QSY155F,QSY155B,

QSY155C,QSY155D,QSY155F,QSY190C,QSY190D,QSY190F,QSY190K,QSY96,QSY116,QSY116,QSY130C,QSY130E,QSY155B,QSY155C,QSY155D,QSY155B,

QSY155C,QSY155D,QSY155F,QSY155F,QSY190C,QSY190D,QSY190F,QSY96,QSY116,QSY130,QSY155,QSY190,QAN200,QAN200L,QAN200U,QAN260M,

QAN260L,QAN260U,QAN260W,QAN320M,QAN320W,QAN200M,QAN200L,QAN200U,QAN260W,QAN260M,QAN260L,QAN320W,QAN260U,QAN320M;

EXE600SERIES:EXE602E,EXE612,EXE610C,EXE650B,EXE660B;EXE914,EXE922,EXE924,EXE932,EXE934,EXE935;

Harmonic Drive AG:FPA-14-L,FPA-14-H,FPA-20B-L,FPA-20B-H,FPA-32B-L,FPA-32B-H;FPA-20-L,FPA-20-H,FPA-32-L,FPA-32-H;

ITNC530数控系统:MC420, MC422B,带双处理器的MC422B; 控制单元:CC420,CC424,TE530B, TE520B,BF510,

BF150,MB420,PL510,PL550,HR410, HR420,

HR130, HR150;HRA110; **HEIDENHAIN**数控系统: TNC124,TNC320,TNC410,TNC426,TNC430,TNC310;

IBV600SERIES:IBV600,IBV606,IBV610,IBV650,IBV660,IBV600; **Digital**

Readouts:ND710,D750,D720,ND760,D730,D770,ND221B,ND281B,ND282B;

HEIDENHAIN变频器系统:UR240D, UR242D,UE110,UE112,UE210B,UE211B,UE240B,UE212B,UE242B,UVR120D, UVR130D,UVR140D, UVR150D, UV130D,

UM111D, UM111BD,UM112D, UM113D, UM114D, UM115D, UM121D, UM121BD, UM122D,UV105; **power pack**

DriveStar:B-DS060.1, B-DS125.1, B-DS160.1;

A-DS 006.1 Servoconverter:A-DS006.1,A-DS012.1,A-DS020.1,A-DS035.1,A-DS045.1,A-DS055.1,A-DS075.1;

Series ASM asynchronous servomotors:ASM33-20R21-0,ASM34-20R21-0,ASM41-20R21-0,ASM42-20R21-0,ASM43-20R21-0;

百格拉公司机器人:LP-4/2,LP-4/2,LP-6/2,LP-8/2,PR-4/2,PR-6/2,PR-8/2,LR-4/2,LR-6/2,LR-8/2,PR-4/2,PR-6/2,PR-8/2;

芯片级维修美国哈雷 (**HARMONIC**) 公司产品:

哈雷伺服阀**Harmonic DC servo**

actuator:RHS-14-XX03,RHS-17-XX06,RHS-20-XX07,RHS-20-XX12,RHS-25-XX12,RHS-25-XX18,RHS-32-XX18,RHS-32-XX30,

RFS-20-XX07,RFS-20-XX12,RFS-25-XX12,RFS-25-XX18,RFS-32-XX18,RFS-32-XX30;**RSF BRUSHLESS SERVO ACTUATOR:**

Driver:HA-680-4-24,HA-680-6-24;

Actuator:RSF-8B30,RSF-8B50,RSF-8B100,RSF-11B30,RSF-11B50,RSF-11B100,RSF-14B30,RSF-14B50,RSF-14B100,;

FHA-17C,FHA-25C,FHA-32C,FHA-40C,

HKM-20-60,HKM-20-30,HKM-25-60,HKM-25-30,RSF-5A30,RSF-5A50,RSF-5A100,HHA-10-080,HHA-14-080,LSA-10A-30,LSA-50A-30,

ACTUATOR:RH-5A-8802,RH-5A-5502,RH-5A-4402,RH-8D-6006,RH-8D-3006,RH-11D-6001,RH-11D-3001,RH-14D-6002,RH-14D-3002,RH-14-6003,RH-14-3003,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

RH-17-6006,RH-17-3006,RHS-20-6007,RHS-20-3007,RHS-20-6012,RHS-20-3012,RHS-25-6012,RHS-25-3012,RFS-20-6007,RFS-20-3007,RFS-20-6012,

RFS-20-3012,RFS-25-6012,RFS-25-3012; **HS-360DRIVERS:**HS-360-1A,HS-360-1B,HS-360-1C,HS-360-1D,HS-360-3,HS-360-1A;

AC Servo Digita Drivers

HA-655Series:HA-655-1-200,HA-655-1B-200,HA-655-2-200,HA-655-2B-200,HA-655-2A-200,HA-655-4-200,HA-655-4B-200,HA-655-4A-200,HA-655-2-100,HA-655-2B-100,HA-655-2A-100,HA-655-4-100,HA-655-4B-100,HA-655-4A-100,HA-655-1-100,HA-655-1B-100;

AC Servo Mono-Shaft Controller

DriversHA-675Series:HA-675-1-200,HA-675-2-200,HA-675-2A-200,HA-675-4-200,HA-675-4A-200,HA-675-2-100,HA-675-2A-100,HA-675-4-100,HA-675-4A-100,HA-675-1-100; **HA-720-:**

KDU-13-S-D,KDU-13-W-D,KDU-13SA-E08-100,KDU-13WA-E08-100,HA-720-5-100;

AC Servo Drivers HA-520Series:HA-520-1M-100,HA-520-1N-100,HA-520-1P-100,HA-520-1R-200,HA-520-3-200;

HA-675 driver:HA-675-1-200, HA-675-2-200, HA-675-4-200, HA-675-2A-200, HA-675-4A-200, HA-675-2-100, HA-675-4-100, HA-675-4A-100, HA-675-4A-100;

FHA-C

actuators:FHA-8C-xx-E200,FHA-11C-xx-E200,FHA-14C-xx-E200,FHA-17C-xx-E250,FHA-25C-xx-E250,FHA-32C-xx-E250,FHA-40C-xx-E250,

FHA-17C-xx-S248,FHA-25C-xx-S,FHA-8C-xx-E200-A,FHA-11C-xx-E200-A,FHA-14C-xx-E200-A,FHA-17C-xx-E250-A,

FHA-25C-xx-E250-A,FHA-32C-xx-E250-A,

FHA-17C-xx-S248-A, FHA-25C-xx-S248-A,FHA-32C-xx-S248-A; N20010,N20010-SW2,N34010,

维修各种伺服电机

维修各种**ABB**电机:

交流伺服电机: 8C1.1.30M,8C1.1.60M,8C1.2.30M,8C1.2.60M,8C1.3.30M,8C1.3.60M,8C1.4.30M,8C1.4.60M,8C1.1.30E,8C1.1.60E,8C1.2.30E,

8C1.2.60E,8C1.3.30E,8C1.3.60E,8C1.4.30E,8C1.4.60E,8C4.0.15M,8C4.0.30M,8C4.1.15M,8C4.1.30M,8C4.2.15M,8C4.2.30M,8C4.3.15M,8C4.3.30M,8C4.4.15M,

8C4.4.30M,8C4.0.15E,8C4.0.30E,8C4.1.15E,8C4.1.30E,8C4.2.15E,8C4.2.30E,8C4.3.15E,8C4.3.30E,8C4.4.15E,8C4.4.30E,8C5.0.15M,8C5.0.30M,8C5.1.15M,

8C5.1.30M,8C5.2.15M,8C5.2.30M,8C5.3.15M,8C5.3.30M,8C5.4.15M,8C5.4.30M,8C5.6.15M,8C5.6.30M,8C5.0.15E,8C5.0.30E,8C5.1.15E,8C5.1.30E,8C5.2.15E,

8C5.2.30E,8C5.3.15E,8C5.3.30E,8C5.4.15E,8C5.4.30E,8C5.6.15E,8C5.6.30E;

ABB感应交流伺服电机:CH1,CH2,CH3,CH4,CH5,CH6,CM1,CM2,CM3,CM4,CM5,CN1,CN2,CN3,CN4,CN5,CR1,CR2,CR3,CR4,CR5,VH1,VH2,VH3,VH4,VH5,VH6,

VM1,VM2,VM3,VM4,VM5,VN1,VN2,VN3,VN4,VN5,VR1,VR2,VR3,VR4,VR5;

DSM SerieS Integrated SteppeR MotoR/Driver:DSM17,DSM23,DSM34,DSM17x-148,DSM17x-248,DSM17x-348,DSM23x-148,DSM23x-175,DSM23x-248,

DSM23x-275,DSM23x-348,DSM23x-375,DSM34F-175,DSM34F-275,DSM34F-375;

BALDOR保德伺服电机:

BALDOR BRUSHLESS DC MOTOR:BSM4F2-75-D,BSM4F2-38-D,BSM4F3-75-D,BSM4F3-38-D,BSM4F4-75-D,BSM4F4-38-D,BSM4F5-75-D,BSM4F5-38-D,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

BSM4F6-75-D,BSM4F6-38-D,BSM4F12-75-D,BSM4F-17-2-20-D,BSM4F-17-4-20-D,BSM4F-35-2-20-D,BSM4F-35-4-20-D,BSM4F-53-2-20-D,BSM4F-53-4-20-D,

BSM4F-71-2-20-D,BSM4F-71-4-20-D,BSM4F-16-2-20-C,BSM4F-16-4-20-C,BSM4F-32-2-20-C,BSM63,BSM804,BSM90,BSM100,BSM4F,BSM6F,BSM8F,BSM2R,

BSM3R,BSM4R,BSM6R;

Brushless Servo MotorS-BSMC-series:BSM80C-275A,BSM80C-2150A,BSM80C-375A,BSM80C-3150A,BSM90C-275A,BSM90C-2150A,BSM90C-375A,

BSM90C-3150A;

维修博世力士乐伺服电机:

Rexroth (力士乐) 2AD AC Motor:2AD100B-B05OB1-AS03-A2N1,2AD100C-B05OB1-AS03-A2N1,2AD100D-B05OB1-AS03-A2N1,2AD101C-B05OB1-AS03-A2N1,

2AD101D-B05OB1-AS03-A2N1,2AD104C-B05OB1-AS03-A2N1,2AD104D-B05OB1-AS03-A2N1,2AD132B-B35OB1-BS03-A2N1,2AD132C-B35OB1-BS03-A2N1,

2AD132D-B35OB1-BS03-A2N1,2AD134B-B35OC1-DS06-A2N1,2AD134C-B35OC1-DS06-A2N1,2AD134D-B35OC1-DS06-A2N1,2AD160B-B05OB1-BS03-A2N1,

2AD160C-B05OB1-BS03-A2N1,2AD164B-B05OB1-DS06-A2N1,2AD180C-B35OB1-BS03-A2N1,2AD200C-B35OB1-AS03-A2N1,2AD225C-B35OB1-AS03-A2N1;

Servo motors SF,SR:SF-A4012501552,SR-A4012501552,SF-A50250020,SR-A50250020,SF-B50250020,SR-B50250020,SF-A50700020,SR-A50700020,

SF-A20013030,SR-A20013030,SF-A20020030,SR-A20020030,SF-A20026030,SR-A20026030,SF-A20041030,SR-A20041030,SF-A30042030,SR-A30042030,

SF-A30068030,SR-A30068030,SF-A30093030,SR-A30093030,SF-A40091030,SR-A40091030,SF-A40125030,SR-A40125030,SF-A40172030,SR-A40172030,

SF-A40230030,SR-A40230030,SF-A50250030,SR-A50250030,SF-B50250030,SR-B50250030,SF-A50460030,SR-A50460030,SR-A50700030,SR-A50700030,

SR-A00002060,SR-A00004060,SR-A00008060,SR-A00009060,SF-A10008060,SR-A10008060,SF-A10012060,SR-A10012060,SF-A10016060,SR-A10016060,

SF-A10023060,SR-A10023060,SF-A20013060,SR-A20013060,SF-A20020060,SR-A20020060,SF-A20026060,SR-A20026060,SF-A20041060,SR-A20041060,

SF-A30042060,SR-A30042060,SF-A30068060,SR-A30068060,SF-A30093060,SR-A30093060,SF-A40091060,SR-A40091060,SF-B40091060,SR-B40091060,

SF-A40125060,SR-A40125060,SF-B40125060,SR-B40125060,SF-A40172060,SR-A40172060,SR-B40172060,SF-B40172060,SF-A40230060,SR-A40230060,

SR-A40230060,SR-B40230060,

Rexroth (力士乐) MKD Motor:MKD025A,MKD025B,MKD041B,MKD071B,MKD090B,MKD112A,MKD112B,MKD112D,MKE035B,MKE037B,MKE045B,MKE047B

MKE096B,MKE098B,MKE116B;

MDD Digital AC Servo MotorS with LiquiD Cooling:MDD090A-F-020,MDD090A-F-030,MDD090A-F-040,MDD090B-F-020,MDD090B-F-030,MDD090B-F-040,

MDD090C-F-020,MDD090C-F-030,MDD090C-F-040,MDD093A-F-020,MDD093A-F-030,MDD093A-F-040,MDD093A-F-060,MDD09

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

3B-F-020,MDD093B-F-030,
MDD093B-F-040,MDD093B-F-060,MDD093C-F-020,MDD093C-F-030,MDD093C-F-040,MDD093C-F-060,MDD093D-F-015,MDD093D-F-020,MDD093D-F-030,
MDD093D-F-040,MDD112A-F-015,MDD112A-F-020,MDD112A-F-030,MDD112A-F-040,MDD112B-F-015,MDD112B-F-020,MDD112B-F-030,MDD112B-F-040,
MDD112C-F-015,MDD112C-F-020,MDD112C-F-030,MDD112C-F-040,MDD112D-F-015,MDD112D-F-020,MDD112D-F-030,MDD112D-F-040,MDD115A-F-015,
MDD115A-F-020,MDD115A-F-030,MDD115B-F-015,MDD115B-F-020,MDD115B-F-030,MDD115C-F-015,MDD115C-F-020,MDD115C-F-030,MDD115D-F-015,
MDD115D-F-020;
MDD Digital AC ServOMotors:MDD021A-N-100,MDD021B-N-100,MDD025A-N-100,MDD025B-N-100,MDD025C-N-100,MDD041A-N-100,MDD041B-N-100,
MDD041C-N-100,MDD065A-N-040,MDD065A-N-060,MDD065B-N-040,MDD065B-N-060,MDD065C-N-040,MDD065C-N-060,MDD065D-N-040,MDD065D-N-060,
MDD065B-N-040,MDD065B-N-060,MDD065C-N-040,MDD065C-N-060,MDD065D-N-040,MDD065D-N-060,MDD071A-N-030,MDD071A-N-040,MDD071A-N-060,
MDD071B-N-030,MDD071B-N-040,MDD071B-N-060,MDD071C-N-030,MDD071C-N-040,MDD071C-N-060,MDD071B-N-030,MDD071B-N-040,MDD071B-N-060,
MDD071C-N-030,MDD071C-N-040,MDD071C-N-060,MDD090A-N-020,MDD090A-N-030,MDD090A-N-040,MDD090B-N-020,MDD090B-N-030,MDD090B-N-040,
MDD090C-N-020,MDD090C-N-030,MDD090C-N-040,MDD090A-N-020,MDD090A-N-030,MDD090A-N-040,MDD090B-N-020,MDD090B-N-030,MDD090B-N-040,
MDD090C-N-020,MDD090C-N-030,MDD090C-N-040,MDD093A-N-020,MDD093A-N-030,MDD093A-N-040,MDD093A-N-060,MDD093B-N-020,MDD093B-N-030,
MDD093B-N-040,MDD093B-N-060,MDD093C-N-020,MDD093C-N-030,MDD093C-L-030,MDD093C-N-040,MDD093C-N-060,MDD093D-N-015,MDD093D-N-020,
MDD093D-N-030,MDD093D-N-040,MDD093A-N-020,MDD093A-N-030,MDD093A-N-040,MDD093A-N-060,MDD093B-N-020,MDD093B-N-030,MDD093B-N-040,
MDD093B-N-060,MDD093C-N-020,MDD093C-N-030,MDD093C-L-030,MDD093C-N-040,MDD093C-N-060,MDD093D-N-015,MDD093D-N-020,MDD093D-N-030,
MDD093D-N-040,MDD112A-N-015,MDD112A-N-020,MDD112A-N-030,MDD112A-N-040,MDD112B-N-015,MDD112B-N-020,MDD112B-N-030,MDD112B-L-030,
MDD112B-N-040,MDD112C-N-015,MDD112C-N-020,MDD112C-L-020,MDD112C-N-030,MDD112C-N-040,MDD112C-N-060,MDD112D-N-015,MDD112D-L-015,
MDD112D-N-020,MDD112D-N-030,MDD112D-N-040,MDD112A-N-015,MDD112A-N-020,MDD112A-N-030,MDD112A-N-040,MDD112B-N-015,MDD112B-N-030,
MDD112B-L-030,MDD112B-N-040,MDD112C-N-015,MDD112C-N-020,MDD112C-L-020,MDD112C-N-030,MDD112C-N-040,MDD112C-N-060,MDD112D-N-015,
MDD112D-L-015,MDD112D-N-020,MDD112D-N-030,MDD112D-N-040,MDD115A-N-015,MDD115A-N-020,MDD115A-L-020,MDD115A-N-030,MDD115B-N-015,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MDD115B-L-015,MDD115B-N-020,MDD115B-N-030,MDD115C-N-015,MDD115C-N-020,MDD115C-N-030,MDD115D-N-015,MDD115D-N-020,MDD115A-N-015,

MDD115A-N-020,MDD115A-L-020,MDD115A-N-030,MDD115B-N-015,MDD115B-L-015,MDD115B-N-020,MDD115B-N-030,MDD115C-N-015,MDD115C-N-020,

MDD115C-N-030,MDD115D-N-015,MDD115D-N-020;

Digital MKE AC Motors foR potentially explosive Eareas:MKE037B-144,MKE047B-144,MKE098B-047,MKE098B-058,MKE118B-024,MKE118B-058,MKE118D-012,MKE118D-027,MKE118D-035;MKE098B-047,MKE035,MKE096,MKE047B-144,MKE037B-144;

Rexroth IndraDyN motors:IndraDyNS MSK servomotors:MSK030B-0900,MSK030C-0900,MSK040B-0600,MSK040C-0600,MSK050B-0300,MSK050B-0600,

MSK050C-0300,MSK050C-0600,MSK060B-0300,MSK060B-0600,MSK060C-0300,MSK060C-0600,MSK070C-0150,MSK070C-0300,MSK070C-0450,

MSK070D-0150,MSK070D-0300,MSK070D-0450,MSK070E-0150,MSK070E-0300,MSK070E-0450,MSK071D-0200,MSK071D-0300,MSK071D-0450,

MSK071E-0200,MSK071E-0300,MSK071E-0450,MSK100B-0200,MSK100B-0300,MSK100B-0400,MSK100B-0450,MSK100C-0200,MSK100C-0300,MSK100C-0450,

MSK100D-0200,MSK100D-0300,MSK101D-0200,MSK101D-0300,MSK101D-0450,MSK101E-0200,MSK101E-0300,EMSK101-0450;

IndraDyN A-MAD asynchronous servomotors:MAD100B-0050,MAD100B-0100,MAD100B-0150,MAD100-0200B,MAD100B-0250,MAD100C-0050,

MAD100C-0100,MAD100C-0150,MAD100C-0200C,MAD100-0250,MAD100D-0050,MAD100D-0100,MAD100D-0150,MAD100D-0200,MAD100D-0250,

MAD130B-0050,MAD130B-0100,MAD130B-0150,MAD130B-0200,BMAD130-0250,MAD130C-0050,MAD130C-0100,MAD130C-0150,MAD130C-0200,

MAD130C-0250,MAD130D-0050,MAD130D-0100,MAD130D-0150,MAD130D-0200,MAD130D-02,0,MAD160B-0050,MAD16B-0100,MAD16B-0150,MAD16B-0200,

MAD16C-0050,MAD16C-0100,MAD16C-0150,MAD16C-0200,MAD180C-0050,MAD180C-0100C,MAD180-0150,MAD180C-0200,MAD180D-0050,MAD180D-0100,

MAD180D-0150,MAD180D-0200;

IndraDyN A-MAF asynchronous servomotors:MAF100B-0050,MAF100B-0100,MAF100B-0150,MAF100-0200B,MAF100B-0250,MAF100C-0050,MAF100C-0100,

MAF100C-0150,MAF100C-0200C,MAF100-0250,MAFD100D-0050,MAF100D-0100,MAFD100D-0150,MAF100D-0200,MAF100D-0250,MAF130B-0050,

MAF130B-0100,MAFD130B-0150,MAF130B-0200,BMAD130-0250,MAF130C-0050,MAF130C-0100,MAF130C-0150,MAF130C-0200,MAF130C-0250,

MAF130D-0050,MAF130D-0100,MAF130D-0150,MAF130D-0200,MAF130D-02,0,MAF160B-0050,MAF16B-0100,MAF16B-0150,MAF16B-0200,MAF16C-0050,

MAF16C-0100,MAF16C-0150,MAF16C-0200,MAF180C-0050,MAF180C-0100C,MAF180-0150,MAF180C-0200,MAF180D-0050,MAF180D-0100,MAF180D-0150,

MAF180D-0200,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

IndraDyN L-linear motors:MLP040A-0300,MLP040B-0150,MLP040B-0250,MLP040B-0300,MLP070A-0150,MLP070A-0220,MLP070A-0300,MLP070B-0100,MLP070B-0120,MLP070B-0150,MLP070B-0250,MLP070B-0300,MLP070C-0120,MLP070C-0150,MLP070C-0240,MLP070C-0300,MLP100A-0090,MLP100A-0120,MLP100A-0150,MLP100A-0190,MLP100B-0120,MLP100B-0250,MLP100C-0090,MLP100C-0120,MLP100C-0190,MLP140A-0120,MLP140B-0090,MLP140B-0120,MLP140C-0050,MLP140C-0120,MLP140C-0170,MLP200A-0090,MLP200A-0120,MLP200B-0040,MLP200B-0120,MLP200C-0090,MLP200C-0120,,MLP200C-0170,MLP200D-0060,MLP200D-0100,MLP200D-0120,MLP300A-0090,MLP300A-0120,,MLP300B-0070,MLP300B-0120,MLP300C-0060,MLP300C-0090;

IndraDyN H-hig,h-speed frameless(kit) motors:MSS102B-0800,MSS102D-0800,MSS102F-0800,MSS142B-0700,MSS142D-0700,MSS142F-0700,MSS162B-0400,MSS162D-0400,MSS162F-0310,MSS162J-0200,MSS182A-0100,MSS182A-0250,MSS182B-0280,MSS182D-0260,MSS182F-0200,MSS202A-0200,MSS202B-0150,MSS202B-0210,MSS202D-0170,MSS202F-0120,MSS242B-0100,MSS242D-0070,MSS242F-0060,MSS272B-0065,MSS272D-0050,MSS272F-0040,MSS312B-0035,MSS312D-0028,MSS312F-0028,MSS312H-0025,MSS312H-0085,MSS382B-0025,MSS382D-0020,MSS382F-0018;

IndraDyN T-frameless (kit)torque motors:MST130A-0200,MST130C-0050,MST130E-0020,MST16A-0050,MST16C-0050,MST16E-0050,MST210A-0027,MST210C-0027,MST210C-0050,MST210D-0070,MST210E-0027,MST290B-0018,MST290D-0002,MST290D-0004,MST290D-0018,MST290E-0004,MST290E-0018,MST360B-0018,MST360D-0012,MST360D-0018,MST360E-0018,MST450B-0012,MST450D-0006,MST450D-0012,MST450E-0006,MST450E-0012,MST530B-0010,MST530C-0010,MST530E-0010,MST530G-0007,MST530L-0006;

Bosch Servodyn D: SF and SR servo

motors:SF-A5.0250.020,SF-A5.0460.020,SF-A5.0700.020,SF-A2.0013.030,SF-A2.0020.030,SF-A2.0026.030,SF-A2.0041.030,SF-A3.0042.030,SF-A3.0068.030,SF-A3.0093.030,SF-A4.0091.030,SF-A4.0125.030,SF-A4.0172.030,SF-A4.0230.030,SF-A5.0250.030,SF-A5.0460.030,SF-A5.0700.030,SR -A0.0002.060,SR -A0.0004.060,SR -A0.0008.060,SR -A0.0009.060,SR -A1.0008.060,SR -A1.0012.060,SR -A1.0016.060,SR -A1.0023.060,SF-A2.0013.060,SF-A2.0020.060,SF-A2.0026.060,SF-A2.0041.060,SF-A3.0042.060,SF-A3.0068.060,SF-A3.0093.060,SF-A4.0091.060,SF-A4.0125.060,SF-A4.0172.060,SF-A4.0230.060,SR-A5.0250.020,SR-A5.0460.020,SR-A5.0700.020,SR-A2.0013.030,SR-A2.0020.030,SR-A2.0026.030,SR-A2.0041.030,SR-A3.0042.030,SR-A3.0068.030,SR-A3.0093.030,SR-A4.0091.030,SR-A4.0125.030,SR-A4.0172.030,SR-A4.0230.030,SR-A5.0250.030,SR-A5.0460.030,SR-A5.0700.030,SR -A0.0002.060,SR -A0.0004.060,SR -A0.0008.060,SR -A0.0009.060,SR -A1.0008.060,SR -A1.0012.060,SR -A1.0016.060,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

SR

-A1.0023.060,SR-A2.0013.060,SR-A2.0020.060,SR-A2.0026.060,SR-A2.0041.060,SR-A3.0042.060,SR-A3.0068.060,SR-A3.0093.060,SR-A4.0091.060,
SR-A4.0125.060,SR-A4.0172.060,SR-A4.0230.060;SF-A4.0125.015,SF-A5.0250.020,SF-B5.0250.020,SF-A5.0460.020,SF-B5.0460.020,SF-A5.0700.020,
SF-A2.0013.030,SF-A2.0020.030,SF-A2.0026.030,SF-A2.0041.030,SF-A3.0042.030,SF-A3.0068.030,SF-A3.0093.030,SF-A4.0091.030,SF-A4.0125.030,
SF-A4.0172.030,SF-A4.0230.030,SF-A5.0250.030,SF-B5.0250.030,SF-A5.0460.030,SF-A5.0700.030,SF-A1.0008.060,SF-A1.0012.060,SF-A1.0016.060,
SF-A1.0023.060,SF-A2.0013.060,SF-A2.0020.060,SF-A2.0026.060,SF-A2.0041.060,SF-A3.0042.060,SF-A3.0068.060,SF-A3.0093.060,SF-A4.0091.060,
SF-A4.0125.060,SF-A4.0172.060,SF-A4.0230.060,SF-B4.0091.060,SF-B4.0125.060,SF-B4.0172.060,SF-B4.0230.060,SR-A4.0125.015,SR-A5.0250.020,
SR-B5.0250.020,SR-A5.0460.020,SR-B5.0460.020,SR-A5.0700.020,SR-A2.0013.030,SR-A2.0020.030,SR-A2.0026.030,SR-A2.0041.030,SR-A3.0042.030,
SR-A3.0068.030,SR-A3.0093.030,SR-A4.0091.030,SR-A4.0125.030,SR-A4.0172.030,SR-A4.0230.030,SR-A5.0250.030,SR-B5.0250.030,SR-A5.0460.030,
SR-A5.0700.030,SR-A0.0002.060,SR-A0.0004.060,SR-A0.0008.060,SR-A0.0009.060,SR-A1.0008.060,SR-A1.0012.060,SR-A1.0016.060,SR-A1.0023.060,
SR-A2.0013.060,SR-A2.0020.060,SR-A2.0026.060,SR-A2.0041.060,SR-A3.0042.060,SR-A3.0068.060,SR-A3.0093.060,SR-A4.0091.060,SR-A4.0125.060,
SR-A4.0172.060,SR-A4.0230.060,SR-B4.0091.060,SR-B4.0125.060,SR-B4.0172.060,SR-B4.0230.060;

Digital AC-Motors

MHD:MHD041A-144,MHD041B-144,MHD071A-061,MHD071B-035,MHD071B-061,MHD090B-035,MHD090B-047,MHD090B-058,MHD093A-024,
MHD093A-035,MHD093A-058,MHD093B-035,MHD093B-058,MHD093C-035,MHD093C-05,MHD112A-024,MHD112A-058,MHD112B-024,MHD112B-035,
MHD112B-048,MHD112B-058,MHD112C-024,MHD112C-035,MHD112C-058,MHD112D-027,MHD115A-024,MHD115A-058,MHD115B-024,MHD115B-058,
MHD115C-024,MHD115C-058;

MDD Digital AC Servo

Motors:MDD021A-N-100,MDD021B-N-100,MDD025A-N-100,MDD025B-N-100,MDD025C-N-100,MDD041A-N-100,MDD041B-N-100,
MDD041C-N-100,MDD065A-N-040,MDD065A-N-060,MDD065B-N-040,MDD065B-N-060,MDD065C-N-040,MDD065C-N-060,MDD065D-N-040,MDD065D-N-060,
MDD065B-N-040,MDD065B-N-060,MDD065C-N-040,MDD065C-N-060,MDD065D-N-040,MDD065D-N-060,MDD071A-N-030,MDD071A-N-040,MDD071A-N-060,
MDD071B-N-030,MDD071B-N-040,MDD071B-N-060,MDD071C-N-030,MDD071C-N-040,MDD071C-N-060,MDD071B-N-030,MDD071B-N-040,MDD071B-N-060,
MDD071C-N-030,MDD071C-N-040,MDD071C-N-060,MDD090A-N-020,MDD090A-N-030,MDD090A-N-040,MDD090B-N-020,MDD090B-N-030,MDD090B-N-040,MDD090B-N-060;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

90B-N-030,MDD090B-N-040,
MDD090C-N-020,MDD090C-N-030,MDD090C-N-040,MDD090A-N-020,MDD090A-N-030,MDD090A-N-040,MDD090B-N-020,MDD0
90B-N-030,MDD090B-N-040,
MDD090C-N-020,MDD090C-N-030,MDD090C-N-040,MDD093A-N-020,MDD093A-N-030,MDD093A-N-040,MDD093A-N-060,MDD0
93B-N-020,MDD093B-N-030,
MDD093B-N-040,MDD093B-N-060,MDD093C-N-020,MDD093C-N-030,MDD093C-L-030,MDD093C-N-040,MDD093C-N-060,MDD0
93D-N-015,MDD093D-N-020,
MDD093D-N-030,MDD093D-N-040,MDD093A-N-020,MDD093A-N-030,MDD093A-N-040,MDD093A-N-060,MDD093B-N-020,MDD0
93B-N-030,MDD093B-N-040,
MDD093B-N-060,MDD093C-N-020,MDD093C-N-030,MDD093C-L-030,MDD093C-N-040,MDD093C-N-060,MDD093D-N-015,MDD0
93D-N-020,MDD093D-N-030,
MDD093D-N-040,MDD112A-N-015MDD112A-N-020,MDD112A-N-030,MDD112A-N-040,MDD112B-N-015,MDD112B-N-020,MDD1
12B-N-030,MDD112B-L-030,
MDD112B-N-040,MDD112C-N-015,MDD112C-N-020,MDD112C-L-020,MDD112C-N-030,MDD112C-N-040,MDD112C-N-060,MDD1
12D-N-015,MDD112D-L-015,
MDD112D-N-020,MDD112D-N-030,MDD112D-N-040,MDD112A-N-015,MDD112A-N-020,MDD112A-N-030,MDD112A-N-040,MDD1
12B-N-015,MDD112B-N-020,
MDD112B-N-030,MDD112B-L-030,MDD112B-N-040,MDD112C-N-015,MDD112C-N-020,MDD112C-L-020,MDD112C-N-030,MDD1
12C-N-040,MDD112C-N-060,
MDD112D-N-015,MDD112D-L-015,MDD112D-N-020,MDD112D-N-030,MDD112D-N-040,MDD115A-N-015,MDD115A-N-020,MDD1
15A-L-020,MDD115A-N-030,
MDD115B-N-015,MDD115B-L-015,MDD115B-N-020,MDD115B-N-030,MDD115C-N-015,MDD115C-N-020,MDD115C-N-030,MDD1
15D-N-015,MDD115D-N-020,
MDD115A-N-015,MDD115A-N-020,MDD115A-L-020,MDD115A-N-030,MDD115B-N-015,MDD115B-L-015,MDD115B-N-020,MDD11
5B-N-030,MDD115C-N-015,
MDD115C-N-020,MDD115C-N-030,MDD115D-N-015,MDD115D-N-020;

Servomotori DBL DBK:

DBL1-0010,DBL1-0020,DBL2-0040,DBL2-0080,DBL3-0065,DBL3-0130,DBL3-0250,DBL3-0300,DBL4-0260,DBL4-0530,DBL4-0750,
DBL4-0950,DBL5-0660,DBL5-1050,DBL5-1350,DBL5-1700,DBL5-2200,DBL6-1900,DBL6-2200,DBL6-2900,DBL7-2600,DBL7-3200,
DBL7-4000,DBL8-4000,
DBL8-6800,DBL8-9300,DBL8-11500,DBK4-0100,DBK4-0160,DBK5-0210,DBK5-0430,DBK6-0350,DBK6-0700,DBK7-0650,DBK7-12
00,DBK7-1950;

同步伺服电机

AKM:AKM11-B,AKM11-C,AKM11-E,AKM12-C,AKM13-D,AKM13-C,AKM12-E,AKM21-C,AKM21-E,AKM21-G,AKM22-C,AKM22-E,A
KM22-G,
AKM23-C,AKM23-D,AKM23-F,AKM24-C,AKM24-D,AKM24-F,AKM31-C,AKM31-E,AKM31-H,AKM32-C,AKM32-H,AKM32-D,AKM33-
C,AKM33-E,AKM33-H,AKM41-C,
AKM41-E,AKM41-H,AKM42-C,AKM42-E,AKM42-G,AKM42-J,AKM43-E,AKM43-G,AKM43-K,AKM44-E,AKM44-G,AKM44-J,AKM51-
E,AKM51-G,AKM51-K,AKM52-E,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

AKM52-G,AKM52-K,AKM52-M,AKM54-G,AKM54-K,AKM54-L,AKM54-N,AKM64-G,AKM64-K,AKM64-L,AKM64-P,AKM65-K,AKM65-M,AKM65-N,AKM72-P,AKM72-K,

AKM72-M,AKM73-P,AKM73-M,AKM74-L,AKM74-P;

asynchronous frameless (kit) motors for compact drive solutions:

1MS140B-4A,1MS140B-4B,1MS140D-4B,1MS140F-4A,1MS140H-4B,1MS160B-4A,

1MS160D-4A,1MS160D-4B,1MS160E-4B,1MS160F-4A,1MS160F-4B,1MS160F-4D,1MS160H-4A,1MS160N-4A,1MS160N-4B,1MS160N-4C,1MS200C-4A,

1MS200D-4B,1MS200D-4C,1MS200D-4D,1MS200D-4E,1MS200D-4F,1MS200E-4B,1MS200E-4C,1MS200H-4B,1MS200H-4D,1MS240B-4A,1MS240F-4A,

1MS240H-4B,1MS241D-6A,1MS241D-6C,1MS241H-6C,1MS241H-6D,1MS241H-6G,1MS242 N-4B,1MS270

C-4B,1MS310B-6B,1MS310B-6D,1MS310B-6E,

1MS310D-6B,1MS310F-6A,1MS310F-6B,1MS375B-6B,1MS375D-6B,1MS375D-6D;

DANAHER MOTION 数字伺服放大器: SERVOSTAR200, SERVOSTAR300, SERVOSTAR400, SERVOSTAR600, SERVOSTAR303, SERVOSTAR306,

SERVOSTAR310, SERVOSTAR341, SERVOSTAR343, SERVOSTAR346, SERVOSTAR601, SERVOSTAR603, SERVOSTAR606, SERVOSTAR610,

SERVOSTAR614, SERVOSTAR620, SERVOSTAR640, SERVOSTAR670; **Digital Servodrive digifas7100 series:**7103, 7105, 7108, 7112, 7116, 7133, 7150;

维修各种科勒摩根同步伺服电机:

AKM:AKM11-B,AKM11-C,AKM11-B,AKM11-E,AKM12-C,AKM12-E,AKM13-D,AKM13-C,AKM11-E,AKM21-C,AKM21-E,AKM21-G,AKM22-C,AKM22-E,AKM22-G,

AKM23-C,AKM23-D,AKM23-F,AKM24-C,AKM24-D,AKM24-F,AKM31-C,AKM31-E,AKM31-H,AKM32-C,AKM32-D,AKM32-H,AKM33-C,AKM33-E,AKM33-H,AKM41-C,

AKM41-E,AKM41-H,AKM42-C,AKM42-E,AKM42-G,AKM42-J,AKM43-E,AKM43-G,AKM43-K,AKM44-E,AKM44-G,AKM44-J,AKM52-E,AKM52-G,AKM52-K,AKM53-G,

AKM53-K,AKM53-M,AKM53-P,AKM54-G,AKM54-K,AKM54-L,AKM54-N,AKM62-G,AKM62-K,AKM62-M,AKM62-P,AKM63-G,AKM63-K,AKM63-M,AKM63-N,

AKM64-K,AKM64-L,AKM64-P,AKM65-K,AKM65-M,AKM65-N,AKM72-K,AKM72-M,AKM72-P,AKM73-M,AKM73-P,AKM74-L,AKM74-P;

EXLAR GSX SerieS linear

actuators:GSX20-0301,GSX20-0302,GSX20-0304,GSX20-0601,GSX20-0602,GSX20-0604,GSX20-1001,GSX20-1002,GSX20-1004,

GSX20-1201,GSX20-1202,GSX20-1204,GSX30-0301,GSX30-0302,GSX30-0305,GSX30-0601,GSX30-0602,GSX30-0605,GSX30-1001,GSX30-1002,GSX30-1005,

GSX30-1201,GSX30-1202,GSX30-1205,GSX30-1402,GSX30-1405,GSX30-1802,GSX30-1805,GSX40-0601,GSX40-0602,GSX40-0605,GSX40-0608,GSX40-0801,

GSX40-0802,GSX40-0805,GSX40-0808,GSX40-1001,GSX40-1002,GSX40-1005,GSX40-1008,GSX40-1201,GSX40-1202,GSX40-1205,GSX40-1208,GSX40-1802,

GSX40-1805,GSX50-0601,GSX50-0602,GSX50-0605,GSX50-0610,GSX50-1001,GSX50-1002,GSX50-1005,GSX50-1010,GSX50-1402,GSX50-1405,GSX60-0603,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

GSX60-0605,GSX60-0610,GSX60-1003,GSX60-1005,GSX60-1010;

EXLAR SR SerieS Of linear

actuators:SR21-0301,SR21-0302,SR21-0304,SR21-0601,SR21-0602,SR21-0604,SR31-0301,SR31-0302,SR31-0305,SR31-0601,SR31-0602,SR31-0605,SR31-1001,SR31-1002,SR31-1005,SR31-1201,SR31-1202,SR31-1205,SR31-1802,SR31-1805,SR41-0601,SR41-0602,SR41-0605,

SR41-0608,SR41-1001,SR41-1002,SR41-1005,SR41-1008,SR41-1201,SR41-1202,SR41-1205,SR41-1208,SR41-1802,SR41-1805;

EXLAR EL SerieS EXPLOSION linear actuators:EL30-0301,EL30-0302,EL30-0305,EL30-0601,EL30-0602,EL30-0605;

EXLAR FT SerieS

actuators:FT35-0605,FT35-0610,FT35-0620,FT35-1205,FT35-1210,FT35-1220,FT35-1805,FT35-1810,FT35-1820,FT35-2405,FT35-2410,

FT35-2420,FT35-3605,FT35-3610,FT35-3620,FT35-4805,FT35-4810,FT35-4820,FT60-1206,FT60-1212,FT60-1230,FT60-2406,FT60-2412,FT60-2430,FT60-3606,

FT60-3612,FT60-3630,FT60-4806,FT60-4812,FT60-4830,FT80-1206,FT80-1212,FT80-1230,FT80-2406,FT80-2412,FT80-2430,FT80-3606,FT80-3612,FT80-3630,

FT80-4806,FT80-4812,FT80-4830; **ER SerieS RotarY MotoR anD Gearmotor:**ER115;**Festo**伺服马达

MTR-AC:MTR-AC-40,MTR-AC-55,MTR-AC-70,MTR-AC-100;

Exlar'S SLM anD SLG SerieS IntegrateD

Gearmotors:SLM060,SLG060,SLM090,SLG090,SLM115,SLG115,SLM060,SLG060,SLM090,SLG090,SLM115,SLG115;

维修各种**GE-FANUCS**伺服电机:

GE-FANUC S-Series ServOMotors:SLM003,SLM005,SLM010,SLM020,SLM040,SLM075,SLM100,SDM100,SLM250,SDM250,SLM350,SLM500,SDM500,

SGM450,IC800SLM003N3NE25,IC800SLM003N3BE25,IC800SLM005N3NE25,IC800SLM005N3BE25,IC800SLM010N1NE25I,C800SLM010N1BE25,

IC800SLM010N2NE25I,C800SLM010N2BE25,IC800SLM020N1KE25I,C800SLM020N1XE25,IC800SLM020N2KE25I,C800SLM020N2XE25,IC800SLM040N1KE25I,

C800SLM040N1XE25,IC800SLM040N2KE25I,C800SLM040N2XE25,IC800SLM075N2KE25I,C800SLM075N2XE25,IC800SLM100N2KE25I,C800SLM100N2XE25,

IC800SDM100M2KE25,IC800SDM100M2XE25,IC800SLM250M2KE25,IC800SLM250M2XE25,IC800SDM250M2KE25,IC800SDM250M2XE25,

IC800SLM350M2KE25,IC800SLM350M2XE25,IC800SLM500M2KE25,IC800SLM500M2XE25,IC800SDM500M2KE25,IC800SDM500M2XE25,

IC800SGM450M2KE25,IC800SGM450M2XE25;

MTR-3S SerieS ServOMotors:MTR-3S22-G-R-0-N-S,MTR-3S23-G-R-0-N-S,MTR-3S32-G-R-0-E-S,MTR-3S32-G-R-B-E-S,MTR-3S33-G-R-0-E-S,

MTR-3S33-G-R-B-E-S,MTR-3S34-G-R-0-E-S,MTR-3S34-G-R-B-E-S,MTR-3S35-G-R-0-E-S,MTR-3S35-G-R-B-E-S,MTR-3T11-G-R-0-M-S,MTR-3T11-G-R-BM-S,

MTR-3T12-G-R-0-M-S,MTR-3T12-G-R-B-M-S,MTR-3T13-G-R-0-M-S,MTR-3T13-G-R-B-M-S,MTR-3T21-G-R-0-M-S,MTR-3T21-G-R-B-M-S,MTR-3T22-G-R-0-M-S,

MTR-3T22-G-R-B-M-S,MTR-3T23-G-R-0-M-S,MTR-3T23-G-R-B-M-S,MTR-3T24-H-R-0-M-S,MTR-3T24-H-R-B-M-S,MTR-3T42-H-R-0-M-0,MTR-3T42-H-R-B-M-0,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MTR-3T43-H-R-0-M-0,MTR-3T43-H-R-B-M-0,MTR-3S45-G-R-0-E-S,MTR-3S45-G-R-B-E-S,MTR-3T42-H-R-0-M-0,MTR-3T42-H-R-B-M-0,MTR-3T43-J-R-0-M-0,
MTR-3T43-J-R-B-M-0,MTR-3T44-J-R-0-M-0,MTR-3T44-J-R-B-M-0,MTR-3T45-H-R-0-M-0,MTR-3T45-H-R-B-M-0,MTR-3S63-G-R-0-E-S,MTR-3S63-G-R-B-E-S,
MTR-3S65-G-R-0-E-S,MTR-3S65-G-R-B-E-S,MTR-3T54-H-R-0-M-0,MTR-3T54-H-R-B-M-0,MTR-3T55-H-R-0-M-0,MTR-3T55-H-R-B-M-0,MTR-3S67-H-R-0-E-S,
MTR-3S67-H-R-B-E-S,MTR-3T57-H-R-0-M-0,MTR-3T57-H-R-B-M-0,MTR-3T66-H-R-0-M-0,MTR-3T66-H-R-B-M-0,MTR-3T67-G-R-0-M-0,MTR-3T67-G-R-B-M-0,
MTR-3T69-G-R-0-M-0,MTR-3T69-G-R-B-M-0,MTR-3T42-H-R-0-M-0,MTR-3T42-H-R-B-M-0,MTR-3T43-J-R-0-M-0,MTR-3T43-J-R-B-M-0,MTR-3T44-J-R-0-M-0,
MTR-3T44-J-R-B-M-0,MTR-3T45-H-R-0-M-0,MTR-3T45-H-R-B-M-0,MTR-3T54-H-R-0-M-0,MTR-3T54-H-R-B-M-0,MTR-3T55-H-R-0-M-0,MTR-3T55-H-R-B-M-0,
MTR-3T67-G-R-0-M-0,MTR-3T67-G-R-B-M-0,MTR-3T69-G-R-0-M-0,MTR-3T69-G-R-B-M-0;
A SerieS ServOMotors:A06B-0128-B575#7008,A06B-0128-B675#7008,A06B-0128-B575#7076,A06B-0128-B675#7076,A06B-0141-B075#7008,
A06B-0141-B175#7008,A06B-0143-B075#7008,A06B-0143-B175#7008,A06B-0143-B075#7076,A06B-0143-B175#7076,A06B-0147-B075#7008,
A06B-0147-B175#7008,A06B-0147-B075#7076,A06B-0147-B175#7076,A06B-0153-B075#7008,A06B-0153-B175#7008,A06B-0153-B075#7076,
A06B-0158-B075#7008,A06B-0158-B175#7008; **CompumotoR Plus system:**CPLX,CPHX;
β SerieS ServOMotors:A06B-0115-B075#0008,A06B-0115-B175#0008,A06B-0116-B075#0008,A06B-0116-B175#0008,A06B-0113-B075#7008,
A06B-0113-B175#7008,A06B-0032-B075#7008,A06B-0032-B175#7008,A06B-0033-B075#7008,A06B-0033-B175#7008,A06B-0034-B075#7008,
A06B-0034-B175#7008; **βHVIS SerieS ServOMotors:**β2/4000HVis,β4/4000HVis,β8/3000HVis,β12/3000HVis,β22/2000HVis;
MTR-SerieS SteppinG Motors:MTR-1216-E-D-E-0,MTR-1216-N-D-E-0,MTR-1220-E-D-E-0,MTR-1220-N-D-E-0,MTR-1221-E-D-E-0,MTR-1221-N-D-E-0,
MTR-1231-E-D-E-0,MTR-1231-N-D-E-0,MTR-1235-E-D-E-0,MTR-1235-N-D-E-0,MTR-1324-E-D-E-0,MTR-1324-E-D-E-S,MTR-1324-N-D-E-0,MTR-1324-N-D-E-S,
MTR-1331-J-E-D-E-0,MTR-1331-J-E-D-E-S,MTR-1331-J-N-D-E-0,MTR-1331-J-N-D-E-S,MTR-1337-E-D-E-0,MTR-1337-E-D-E-S,MTR-1337-N-D-E-0,
MTR-1337-N-D-E-S,MTR-1350-E-A-E-0,MTR-1350-E-A-E-S,MTR-1350-E-D-E-0,MTR-1350-E-D-E-S,MTR-1350-N-A-E-0,MTR-1350-N-A-E-S,MTR-1350-N-D-E-0,
MTR-1350-N-D-E-S,MTR-1N31-I-E-D-S-0,MTR-1N31-I-N-D-S-0,MTR-1N32-I-E-D-S-0,MTR-1N32-I-N-D-S-0,MTR-1N41-G-E-A-E-0,MTR-1N41-G-N-A-E-0,
MTR-1N42-H-E-A-E-0,MTR-1N42-H-N-A-E-0; **βi SSeries ServOMotors:**β04/5000is,β05/6000is,β1/6000is,β2/4000is,β4/4000is,β8/3000is,β12/3000is,β22/2000is;
α SerieSMotors:α6/3000,α12/3000,α22/2000,α30/3000,α40/2000;**β SerieSMotors:**β05/3000,β2/3000,β3/3000,β6/2000,αC12/2000,βM05/4000,βM1/4000;
维修KEB伺服电机:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

S4 SERVOMOTOR:A1SM000-6200,A1SM000-6400,A2SM000-6200,A2SM000-6400,A3SM000-6200,A3SM000-6400,A4SM000-6200,A4SM000-6400,
B1SM000-4200,B1SM000-4400,B1SM000-6200,B1SM000-6400,B2SM000-4200,B2SM000-4400,B2SM000-6200,B2SM000-6400,B3SM000-4200,B3SM000-4400,
B3SM000-6400,C1SM000-3200,C1SM000-3400,C1SM000-4200,C1SM000-4400,C1SM000-6200,C1SM000-6400,C2SM000-3200,C2SM000-3400,C2SM000-4200,
C2SM000-4400,C2SM000-6200,C2SM000-6400,C3SM000-3200,C3SM000-3400,C3SM000-4400,C3SM000-6400,C4SM000-3400,C4SM000-4400,C4SM000-6400,
D1SM000-3200,D1SM000-3400,D1SM000-4400,D1SM000-6400,D2SM000-3400,D2SM000-4400,D2SM000-6400,D3SM000-3400,D3SM000-4400,D3SM000-6400,
D4SM000-3400,D4SM000-4400,E1SM000-2200,E1SM000-2400,E1SM000-3400,E1SM000-4400,E2SM000-2400,E2SM000-3400,E2SM000-4400,E3SM000-2400,
E3SM000-3400,E3SM000-4400,E4SM000-2400,E4SM000-3400,F1SM000-1400,F1SM000-2400,F1SM000-3400,F1SM000-4400,F2SM000-1400,F2SM000-2400,
F2SM000-3400,F3SM000-1400,F3SM000-2400,F3SM000-3400;

维修各种**LENZE**电机:

Lenze Three-phase AC motors:

MDXMA71-12,MDXMA71-32,MDXMA80-12,MDXMA80-32,MDXMA90-12,MDXMA90-32,MDXMA100-12,MDXMA100-32,
MDXMA112-12,MDXMA132-12,MDXMA132-22,MDXMA160-12,MDXMA160-22,MDXMA180-12,MDXMA180-22;

MCS

servomotors:MCS06C,MCS06F,MCS06I,MCS09F,MCS09H,MCS12H,MCS12L,MCS14D,MCS14H,MCS14L,MCS14P,MCS19F,MCS19J,MCS19P;

L-force servomotors:MCS synchronous

servomotors:MCS06C41,MCS06C60,MCS06F41,MCS06F60,MCS06I41,MCS06I60,MCS09F41,MCS09F60,MCS09H41,
MCS09H60,MCS12H15,MCS12H35,MCS12L20,MCS06C41,MCS06C60,MCS06F41,MCS06F60,MCS06I41,MCS06I60,MCS09F41,
MCS09F60,MCS09H41,
MCS09H60,MCS12H15,MCS12H35,MCS12L20,MCS12L41,MCS14D15,MCS14D36,MCS14H15,MCS14H32,MCS14L15,MCS14L32,MCS14P14,MCS14P32,
MCS19F14,MCS19F30,MCS19J14,MCS19J30,MCS19P14,MCS19P30; SDGARS056-22,SDGARS063-22,SDGABS056-22,SDGABS063-22;

安邦信伺服电机:

Asynchronous MCA

servomotors:MCA10I40...S00,MCA13I41...S00,MCA14L20...S00,MCA14L41...S00,MCA17N23...S00,MCA17N41...S00,
MCA19S23...S00,MCA19S42...S00,MCA21X25...S00,MCA21X42...S00,MCA13I34...F10,MCA14L16...F10,MCA14L35...F10,MCA17N17...F10,MCA17N35...F10,
MCA19S17...F10,MCA19S35...F10,MCA21X14...F10,MCA21X35...F10;

MDFQA asynchronous servomotors:MDFQA100-22,MDFQA112-22,MDFQA132-32,MDFQA160-32;

JVL Servo Motors:MAC050,MAC095,MAC140,MAC141,MAC400-D1,MAC800-D1,MAC800-D4;

维修路斯特伺服电机:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

LSH-050-1-45-320,LSH-050-2-45-320,LSH-050-3-45-320,LSH-074-1-30-320,LSH-074-1-30-560,LSH-074-2-30-320,LSH-074-2-30-560,LSH-074-3-30-320,
LSH-074-3-30-560,LSH-097-1-30-320,LSH-097-1-30-560,LSH-097-2-30-320,LSH-097-2-30-560,LSH-097-3-30-320,LSH-097-3-30-560,LSH-127-1-30-560,
LSH-127-2-30-560,LSH-127-3-30-560,LSH-127-4-30-560;LST-037-1-60-320,LST-037-2-60-320,LST-050-1-45-320,LST-050-2-45-320,LST-050-3-45-320,
LST-050-4-45-320,LST-074-1-30-320,LST-074-2-30-320,LST-074-3-30-320,LST-074-4-30-320,LST-074-5-30-320,LST-074-1-30-560,LST-074-2-30-560,
LST-074-3-30-560,LST-074-4-30-560,LST-074-5-30-560,LST-097-1-30-320,LST-097-2-30-320,LST-097-3-30-320,LST-097-4-30-320,LST-097-1-30-320,
LST-097-2-30-320,LST-097-3-30-320,LST-097-4-30-320,LST-097-1-30-560,LST-097-2-30-560,LST-097-3-30-560,LST-097-4-30-560,LST-127-1-30-560,
LST-127-2-30-560,LST-127-3-30-560,LST-127-4-30-560,LST-158-1-30-560,LST-158-2-30-560,LST-158-3-30-560,LST-158-4-30-560,LST-037-1-80-24,
LST-037-2-60-24,LSH-050-1-30-48,LSH-050-2-30-48,LSH-050-3-30-48,LSH-074-1-15-24,LSC-080-1-30-320,LSC-080-2-30-320,LSC-080-2-45-320,
LSC-080-3-30-320,LSC-110-1-30-320,LSC-110-1-30-560,LSC-110-2-30-320,LSC-110-2-30-560,LSC-110-3-30-320,LSC-110-3-30-560,LSC-130-6-30-560,
LSC-130-5-30-560,LSC-130-4-30-560,LSC-130-3-30-560,LSC-130-2-30-560,LSC-130-1-30-560,LSC-180-1-20-560,LSC-180-1-30-560,LSC-180-2-30-560,
LSC-180-3-30-560,LSC-180-4-30-560,LSC-180-5-30-560,LSC-180-6-30-320,LSC-180-7-30-560,ASM-12-20R23-0,ASM-22-20R23-0,ASM-25-20R22-0,
ASM-32-20R21-0,ASM-34-20R21-0,ASM-43-20R21-0,PSM-M4-20R86-4,PSM-N4-20R84-4,PSM-N6-20R84-4,PSM-03-20R83-4,PSM-04-20R83-4,PSM-13-20R83-4,
PSM-23-20R83-0,ASM(H)-11-2xxx3,ASM(H)-12-2xxx3,ASM(H)-13-2xxx3,ASM(H)-14-2xxx3,ASM(H)-15-2xxx3,ASM(H)-21-2xxx3,ASM(H)-22-2xxx3,
ASM(H)-23-2xxx3,ASM(H)-24-2xxx2,ASM(H)-25-2xxx2,ASM(H)-31-2xxx1,ASM(H)-32-2xxx1,ASM(H)-33-2xxx1,ASM(H)-34-2xxx1,ASH-41-2xxx1,ASH-42-2xxx1,
ASH-43-2xxx1,ASF(V)-11-2xxx3,ASF(V)-12-2xxx3,ASF(V)-13-2xxx3,ASF(V)-14-2xxx3,ASF(V)-15-2xxx3,ASF(V)-21-2xxx3,ASF(V)-22-2xxx3,ASF(V)-23-2xxx3,
ASF(V)-24-2xxx2,ASF(V)-25-2xxx2,ASF(V)-31-2xxx1,ASF(V)-32-2xxx1,ASF(V)-33-2xxx1,ASF(V)-34-2xxx1,ASV-41-2xxx1,ASV-42-2xxx1,ASV-43-2xxx1,
PSM-M1-2xxx2,PSM-M1-2xxx6,PSM-M2-2xxx6,PSM-M3-2xxx2,PSM-M3-2xxx6,PSM-M4-2xxx2,PSM-M4-2xxx6,PSM-N4-2xxx4,PSM-N4-2xxx6,PSM-N5-2xxx4,
PSM-N5-2xxx6,PSM-N6-2xxx4,PSM-N6-2xxx6,PSM-01-2xxx3,PSM-01-2xxx4,PSM-01-2xxx6,PSM-02-2xxx3,PSM-02-2xxx4,PSM-02-2xxx6,PSM-03-2xxx3,
PSM-03-2xxx4,PSM-03-2xxx6,PSM-04-2xxx3,PSM-04-2xxx4,PSM-04-2xxx6,PSM(H)-11-2xxx3,PSM(H)-11-2xxx4,PSM(H)-11-2xxx6,PSM(H)-12-2xxx3,
PSM(H)-12-2xxx4,PSM(H)-12-2xxx6,PSM(H)-13-2xxx3,PSM(H)-13-2xxx4,PSM(H)-13-2xxx6,PSM(H)-14-2xxx3,PSM(H)-14-2xxx4,PSM(H)-21-2xxx2,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

PSM(H)-21-2xxx3,PSM(H)-21-2xxx4,PSM(H)-22-2xxx2,PSM(H)-22-2xxx3,PSM(H)-22-2xxx4,PSM(H)-23-2xxx2,PSM(H)-23-2xxx3,PSM(H)-23-2xxx4,
PSM(H)-24-2xxx2,PSM(H)-24-2xxx3,PSF(V)-11-2xxx3,PSF(V)-11-2xxx4,PSF(V)-11-2xxx6,PSF(V)-12-2xxx3,PSF(V)-12-2xxx4,PSF(V)-12-2xxx6,PSF(V)-13-2xxx3,
PSF(V)-13-2xxx4,PSF(V)-13-2xxx6,PSF(V)-14-2xxx3,PSF(V)-14-2xxx4,PSF(V)-21-2xxx2,PSF(V)-21-2xxx3,PSF(V)-21-2xxx4,PSF(V)-22-2xxx2,PSF(V)-22-2xxx3,
PSF(V)-22-2xxx4,PSF(V)-23-2xxx2,PSF(V)-23-2xxx3,PSF(V)-23-2xxx4,PSF(V)-24-2xxx2,PSF(V)-24-2xxx3,LSH-050-1,LSH-050-2,LSH-050-3,LSH-074-1,LSH-074-2,
LSH-074-3,LSH-097-1,LSH-097-2,LSH-097-3,LSH-127-1,LSH-127-2,LSH-127-3,LSH-127-4,LST-037-1,LST-037-2,LST-050-1,LST-050-2,LST-050-3,LST-050-4,
LST-074-1,LST-074-2,LST-074-3,LST-074-4,LST-074-5,LST-097-1,LST-097-2,LST-097-3,LST-097-4,LST-127-1,LST-127-2,LST-127-3,LST-127-4,LST-158-1,
LST-158-2,LST-158-3,LST-158-4,LSC-080-1-30-320,LSC-080-2-30-320,LSC-080-2-45-320,LSC-080-3-30-320,LSC-110-1-30,LSC-110-2-30,LSC-110-3-30,
LSC-180-1-20-560,LSC-180-1-30-560,LSC-180-2-30-560,LSC-130-1-30-560,LSC-130-2-30-560,LSC-130-3-30-560,LSC-130-4-30-560,LSC-130-5-30-560,
LSC-130-6-30-560,LSC-180-3-30-560,LSC-180-4-30-560,LSC-180-5-30-560,LSC-180-6-30-560,LSC-180-7-30-560;
Servo motors ASM:ASM33-20R21-0,ASM34-20R21-0,ASM41-20R21-0,ASM42-20R21-0,ASM43-20R21-0;
MTC torque motors:MTC1-145-2-G7,MTC1-145-3-G7MTC1-200-2-G7,MTC1-200-3-G7,MTC1-200-2-G7-LC,MTC1-200-3-G7-LC;
维修各种MAVILOR伺服电机:
BLT-55,BLT-71,BLT-72,BLT-73,BLT-74,BLT-111,BLT-112,BLT-113,BLT-114,BLT-115,BLT-141,BLT-142,BLT-143,BLT-144,
BLS40,BLS55,BLS71,BLS72,BLS73,BLS74,BLS111,BLS112,BLS113,BLS114,BLS115,BLS141,BLS142,BLS143,BLS144,BLS191,BLS192,MA-3,MA-6,MA-10,
MA-20,MA-30,MA-45,MA-55,MA-3EEXDIIC,MA-6EEXDIIC,MA-10EEXDIIC,MA-20EEXDIIC,MA-30EEXDIIC,MS-2EEXDIIC,MS-4EEXDIIC,MS-6EEXDIIC,
MS-8EEXDIIC,MS-12EEXDIIC,MS-22EEXDIIC,MSS-2,MSS-4,MSS-6,MSS-8,MSS-12,MSS-22,MSS-35,MSS-45,MSS-12,MSK-08;
维修各种OEMAX伺服电机:
CSMD-15,CSMD-20,CSMD-25,CSMD-30,CSMD-35,CSMD-40,CSMD-45,CSMD-50,CSMF-15,CSMF-25,CSMF-35,CSMF-45,CSMH-15,CSMH-20,CSMH-30,
CSMH-40,CSMH-50,CSMK-12,CSMK-20,CSMK-30,CSMK-45/60,CSMS-15,CSMS-20,CSMS-25,CSMS-30,CSMS-35,CSMS-40,CSMS-45,CSMS-50,RSMD-15,
RSMD-20,RSMD-25,CSMS-/30,RSMD-40,RSMD-45,CSMS-50,RSMF-15,RSMF-25R,SMF-35,RSMF-45,RSMH-15,RSMH-20,RSMH-30,RSMH-40,RSMH-50,
RSMK-12,RSMK-20,RSMK-30,RSMK-45,RSMK-60,RSML-12,RSML-20,RSML-30,RSML-45/60,RSMN-12,RSMN-20,RSMN-30,RSMN-45,RSMS-15,RSMS-20,RSMS-25,
RSMS-30,RSMS-35,RSMS-40,RSMS-45,RSMS-50,RSMX-13,RSMX-20,RSMX-30,RSMX-45;
Telecanique伺服电机:
BDH伺服电机:BDH0401Bp5A2p,BDH0402Cp5A2p,BDH0403Cp5A2p,BDH0582Cp5A2p,BDH0582Eppp2p,BDH0583Cp5A2p,BDH0583Dp5A2p,BDH0583Fp5A2p,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

BDH0584Cppp2p,BDH0584Dppp2p,BDH0584Fppp2p,BDH0701Cppp2A,BDH0701Eppp2A,BDH0702Cppp2A,BDH0702Dppp2A,BDH0702Hppp2A,BDH0703Cppp2A,
BDH0703Eppp2A,BDH0703Hppp2A,BDH0841Cppp2p,BDH0841Eppp2p,BDH0841Hppp2p,BDH0842Cppp2p,BDH0842Eppp2p,BDH0842Gppp2p,BDH0842Jppp2p,
BDH0843Eppp2p,BDH0843Gppp2p,BDH0843Kppp2p,BDH0844Eppp2p,BDH0844Gppp2p,BDH0844Jppp2p,BDH1081Eppp2p,BDH1081Gppp2p,BDH1081Kppp2p,
BDH1082Eppp2p,BDH1082Gppp2p,BDH1082Kppp2p,BDH1082Mppp2p,BDH1083Gppp2p,BDH1083Kppp2p,BDH1083Mppp2p,BDH1083Pppp2p,BDH1084Gppp2p,
BDH1084Kppp2p,BDH1084Lppp2p,BDH1084Nppp2p,BDH1382Gppp2p,BDH1382Kppp2p,BDH1382Mppp2p,BDH1382Pppp2p,BDH1383Gppp2p,BDH1383Kppp2p,
BDH1383Mppp2p,BDH1383Nppp2p,BDH1384Kppp2p,BDH1384Lppp2p,BDH1384Pppp2p,BDH1385Kppp2p,BDH1385Mppp2p,BDH1385Nppp2p,BDH1882Kppp2p,
BDH1882Mppp2p,BDH1882Pppp2p,BDH1883Mppp2p,BDH1883Pppp2p,BDH1884Lppp2p,BDH1884Pppp2p,BSH0551PppppA,BSH0551TppppABSH0552MppppA,
BSH0552PppppA,BSH0552TppppA,BSH0553MppppA,BSH0553PppppA,BSH0701PppppA,BSH0701TppppA,BSH0702MppppA,BSH0702PppppA,BSH0702TppppA,
BSH0703PppppA,BSH0703TppppA,BSH1001PppppA,BSH1001TppppA,BSH1002PppppA,BSH1002TppppA,BSH1003MppppA,BSH1003PppppA,BSH1004MppppA,
BSH1004PppppA,BSH1004TppppA,BSH1401MppppA,BSH1401PppppA,BSH1401TppppA,BSH1402MppppA,BSH1402PppppA,BSH1403MppppA,
BSH1403PppppA,BSH1404MppppA,BSH2051MppppA,BSH2051PppppA,BSH2052Mppp3A,BSH2052Pppp3A,BSH2053Mppp3A,BSH2053Pppp3A;BMHQ101,
BPH0552S5PA2p0p,BPH0552S5PF2p0p,BPH0751N5PA2pAp,BPH0751N5PF2pAp,BPH0752N5PA2pAp,BPH0752N5PF2pAp,BPH0952N5PA2pAp,
BPH0952N5PF2pAp,BPH0953N5PA2pAp,BPH0953N5PF2pAp,BPH1152N5PA2pAp,BPH1152N5PF2pAp,BPH1153N5PA2pAp,BPH1153N5PF2pAp,
BPH1422N5PA2pAp,BPH1422N5PF2pAp,BPH1423N5PA2pAp,BPH1423N5PF2pAp,BPH1902N5PA2pAp,BPH1902N5PF2pAp,BPH1903K5PA2pAp,
BPH1903K5PF2pAp,BPH1904K5PA2pAp,BPH1904K5PF2pAp,BPH1907K5PA2pAp,BPH1907K5PF2pAp,BPH190AK5PA2pAp,BPH190AK5PF2pAp,
SER39A4L7SpPp23,SER39A4L7SpPp25,SER39A4L7SpPp28,SER39A4L7SpPpOO,SER39B4L3SpPp23,SER39B4L3SpPp25,SER39B4L3SpPp28,
SER39B4L3SpPpOOSER39C4L3SpPp23,SER39C4L3SpPp25,SER39C4L3SpPp28,SER39C4L3SpPp38,SER39C4L3SpPpOO,SE
R3BA4L3SpPp23,
SER3BA4L3SpPp25,SER3BA4L3SpPp35,SER3BA4L3SpPp38,SER3BA4L3SpPpOO,SER3BA4L5SpPp23,SER3BA4L5SpPp25,SE
R3BA4L5SpPp35,
SER3BA4L5SpPp38,SER3BA4L5SpPp48,SER3BA4L5SpPpOO,SER3BB4L3SpPp23,SER3BB4L3SpPp25,SER3BB4L3SpPp33,SE
R3BB4L3SpPp35,
SER3BB4L3SpPp38,SER3BB4L3SpPp48,SER3BB4L3SpPpOO,SER3BB4L3SpPpOO,SER3BB4L5SpPp33,SER3BB4L5SpPp35,SE
R3BB4L5SpPp38,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

SER3BB4L5SpPpOO,SER3BC4L5SpPp33,SER3BC4L5SpPp35,SER3BC4L5SpPp38,SER3BC4L5SpPp45,SER3BC4L5SpPp48,SE
R3BC4L5SpPpOO,
SER3BC4L7SpPp33,SER3BC4L7SpPp35,SER3BC4L7SpPp38,SER3BC4L7SpPp45,SER3BC4L7SpPp48,SER3BC4L7SpPpOO,S
ER3BD4L5DpPp33,
SER3BD4L5DpPp45,SER3BD4L5DpPp48,SER3BD4L5DpPpOO,,SER3BD4L7SpPp33,SER3BD4L7SpPp35,SER3BD4L7SpPp43,S
ER3BD4L7SpPp45,
SER3BD4L7SpPp48,SER3BD4L7SpPpOO;

SER brushless motors for

Lexium05:DCX1701F10S1,DCX1702F10S1,DCX1701F17S2,DCX1702F17S2,DCX1701F28S3,DCX1702F28S3,DCX1703N10S1,
DCX1703N17S2,DCX1703N42S3,DCX1704F14S2,DCX1704F34S3,MDHA1004p00,MDHA1008p00,MDHA1017p00,MDHA1028p00
;

维修各种安川伺服电机:

Σ-II系列伺服电机SGMAH型:SGMAH-A3□□AJ1□,SGMAH-A3□□AJ3□,SGMAH-A3□□AJC□,SGMAH-A3□□AJ7□,SGMAH-A5□□AJ
1□,SGMAH-A5□□AJ3□,
SGMAH-A5□□AJC□,SGMAH-A5□□AJ7□,SGMAH-01□□AJ1□,SGMAH-01□□AJ3□,SGMAH-01□□AJC□,SGMAH-01□□AJ7□,SG
MAH-02□□AJ1□,
SGMAH-02□□AJ3□,SGMAH-02□□AJC□,SGMAH-02□□AJ7□,SGMAH-04A□AJ1□,SGMAH-04A□AJ3□,SGMAH-04A□AJC□,SGM
AH-04A□AJ7□,
SGMAH-08A□AJ1□,SGMAH-08A□AJ3□,SGMAH-08A□AJC□,SGMAH-08A□AJ7□;

Sigma II ServoSystem伺服电

机:SG05SA-PE01AA,SG10SA-PE01AA,SG25SA-PE01AA,SG50SA-PE01AA,SG1ASA-PE01AA,SG05SA-PE02AA,SG10SA-PE02A
A,
SG25SA-PE02AA,SG50SA-PE02AA,SG1ASA-PE02AA,SG05SA-PE04AA,SG10SA-PE04AA,SG25SA-PE04AA,SG50SA-PE04AA,S
G1ASA-PE04AA,
SG05SA-PE08AA,SG10SA-PE08AA,SG25SA-PE08AA,SG50SA-PE08AA,SG05SA-PE15AA,SG10SA-PE15AA,SG25SA-PE15AA,S
G50SA-PE15AA,
SG05SA-PE01BA,SG10SA-PE01BA,SG25SA-PE01BA,SG50SA-PE01BA,SG1ASA-PE01BA,SG05SA-PE02BA,SG10SA-PE02BA,S
G25SA-PE02BA,
SG50SA-PE02BA,SG1ASA-PE02BA,SG05SA-GA05AC,SG10SA-GA05AC,SG25SA-GA05AC,SG50SA-GA05AC,SG05SA-GA09AC
,SG10SA-GA09AC,
SG25SA-GA09AC,SG50SA-GA09AC,SG05SA-GA13AC,SG10SA-GA13AC,SG25SA-GA13AC,SG05SA-GA20AC,SG10SA-GA20A
C,SG05SA-GA30AC,
SG05SA-GA44AC,SG05SA-GA55AC,SG05SA-GA75AC,SH04SA-GA05AC,SH05SA-GA05AC,SH07SA-GA05AC,SH10SA-GA05AC
,SH16SA-GA05AC,
SH20SA-GA05AC,SH28SA-GA05AC,SH40SA-GA05AC,SH50SA-GA05AC,SH70SA-GA05AC,SH04SA-GA09AC,SH05SA-GA09AC,
SH07SA-GA09AC,
SH10SA-GA09AC,SH16SA-GA09AC,SH20SA-GA09AC,SH28SA-GA09AC,SH40SA-GA09AC,SH50SA-GA09AC,SH04SA-GA13AC,
SH05SA-GA13AC,
SH07SA-GA13AC,SH10SA-GA13AC,SH16SA-GA13AC,SH20SA-GA13AC,SH28SA-GA13AC,SH40SA-GA13AC,SH50SA-GA13AC,
SH04SA-GA20AC,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

SH05SA-GA20AC,SH07SA-GA20AC,SH10SA-GA20AC,SH16SA-GA20AC,SH20SA-GA20AC,SH28SA-GA20AC,SH40SA-GA20AC,SH50SA-GA20AC,
SH04SA-GA30AC,SH05SA-GA30AC,SH07SA-GA30AC,SH10SA-GA30AC,SH16SA-GA30AC,SH20SA-GA30AC,SH28SA-GA30AC,SH40SA-GA30AC,
SH50SA-GA30AC,SH04SA-GA44AC,SH05SA-GA44AC,SH07SA-GA44AC,SH10SA-GA44AC,SH16SA-GA44AC,SH20SA-GA44AC,SH28SA-GA44AC,
SH40SA-GA44AC,SH50SA-GA44AC,SH04SA-GA55AC,SH05SA-GA55AC,SH07SA-GA55AC,SH10SA-GA55AC,SH16SA-GA55AC,SH20SA-GA55AC,
SH28SA-GA55AC,SH40SA-GA55AC,SH50SA-GA55AC,SH04SA-GA75AC,SH05SA-GA75AC,SH07SA-GA75AC,SH10SA-GA75AC,SH16SA-GA75AC,
SH20SA-GA75AC,SH28SA-GA75AC,SG05SA-GA05AC,SG10SA-GA05AC,SG25SA-GA05AC,SG50SA-GA05AC,SG05SA-GA09AC,SG10SA-GA09AC,
SG25SA-GA09AC,SG0150SA--GA13AC,SG25SA-GA13AC,SG0150SA--GA20AC,SG05SA-GA30AC,SG05SA-GA44AC,SG05SA-GA55AC,SG05SA-GA75AC,
SH04SA-GA05AC,SH05SA-GA05AC,SH07SA-GA05AC,SH10SA-GA05AC,SH16SA-GA05AC,SH20SA-GA05AC,SH28SA-GA05AC,SH450SA--GA05AC,
SH70SA-GA05AC,SH04SA-GA09AC,SH05SA-GA09AC,SH07SA-GA09AC,SH10SA-GA09AC,SH16SA-GA09AC,SH20SA-GA09AC,SH28SA-GA09AC,
SH450SA-GA09AC,SH04SA-GA13AC,SH05SA-GA13AC,SH07SA-GA13AC,SH10SA-GA13AC,SH16SA-GA13AC,SH208SA-GA13AC,SH450SA--GA13AC,
SH04SA-GA20AC,SH05SA-GA20AC,SH07SA-GA20AC,SH10SA-GA20AC,SH16SA-GA20AC,SH20SA-GA20AC,SH28SA-GA20AC,SH450SA-GA20AC,
SH04SA-GA30AC,SH05SA-GA30AC,SH07SA-GA30AC,SH10SA-GA30AC,SH16SA-GA30AC,SH20SA-GA30AC,SH28SA-GA30AC,SH40SA-GA30AC,
SH50SA-GA30AC,SH04SA-GA44AC,SH05SA-GA44AC,SH07SA-GA44AC,SH10SA-GA44AC,SH16SA-GA44AC,SH20SA-GA44AC,SH28SA-GA44AC,
SH450SA-GA44AC,SH04SA-GA55AC,SH05SA-GA55AC,SH07SA-GA55AC,SH10SA-GA55AC,SH16SA-GA55AC,SH20SA-GA55AC,SH28SA-GA55AC,
SH450SA-GA55AC,SH04SA-GA75AC,SH05SA-GA75AC,SH07SA-GA75AC,SH10SA-GA75AC,SH16SA-GA75AC,SH20SA-GA75AC,SH28SA-GA75AC,
SGMAH-A3B,SGMAH-A5B,SGMAPH-01B,SGMAH-02B,SGMPH-02B,SGMAH-A3A,SGMAH-A5A,SGMAPH-01,ASGMPAH-02A,SGMAH-04A,SGMPH-04A,
SGMAH-08,SGMPH-08,SGMPH-15,SGMGH-05AOA,SGMAH-08A,SGMPH-08A,SGMSGH-109AOA,SGMPH-15A,SGMGH-13AOA,SGMSH-15A,SGMGH-20AOA,
SGMSH-20A,SGMGH-30AOA,SGMSH-30A,SGMGH-44,SGMSH-50,SGMGH-55,SGMGH-75,SGMGH-1A,SGMGH-1E;
Σ-V系列伺服电机
机:SGMJV-A5A,SGMJV-01A,SGMJV-02A,SGMJV-04A,SGMJV-08A,SGMAV-A5A,SGMAV-01A,SGMAV-02A,SGMAV-04A,SGMAV-08A,
SGMAV-06A;
Σ-III系列SGMAS,SGMPS,SGMSS,SGMCS型伺服电机

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

机:SGMMJ-A1B,SGMMJ-A2B,SGMMJ-A3B,SGMAS-A5A,SGMAS-01A,SGMAS-C2A,SGMAS-02A,SGMAS-04A,SGMAS-06A,SGMAS-08A,SGMAS-12A,SGMPS-01A,SGMPS-02A,SGMPS-04A,SGMPS-08A,SGMPS-15A,SGMSS-10A,SGMSS-15A,SGMSS-20A,SGMSS-25A,SGMSS-30A,SGMSS-40A,SGMSS-50A,SGMSS-70A,SGMGH-05A,SGMGH-09A,SGMGH-13A,SGMGH-20A,SGMGH-30A,SGMGH-44A,SGMGH-55A,SGMGH-75A,SGMGH-03A,SGMGH-06A,SGMGH-09A,SGMGH-12A,SGMGH-20A,SGMGH-30A,SGMGH-40A,SGMGH-55A,SGMCS-02B,SGMCS-05B,SGMCS-07B,SGMCS-04C,SGMCS-08D,SGMCS-10C,SGMCS-14C,SGMCS-17D,SGMCS-25D,SGMCS-16E,SGMCS-35E,SGMCS-45M,SGMCS-80M,SGMCS-1AM,SGMCS-80N,SGMCS-1EN,SGMCS-2ZN;

SGMPH伺服电机:SGMPH-01□□AJ1□,SGMPH-01□□AJ3□,SGMPH-01□□AJC□,SGMPH-01□□AJ7□,SGMPH-02□□AJ1□,SGMPH-02□□AJ3□,SGMPH-02□□AJC□,SGMPH-02□□AJ7□,SGMPH-04A□AJ1□,SGMPH-04A□AJ3□,SGMPH-04A□AJC□,SGMPH-04A□AJ7□,SGMPH-08A□AJ1□,SGMPH-08A□AJ3□,SGMPH-08A□AJC□,SGMPH-08A□AJ7□,SGMPH-15A□AJ1□,SGMPH-15A□AJB□,SGMPH-15A□AJC□,SGMPH-15A□AJ7□;

SGMGH伺服电机:SGMGH-05A□A□A6,SGMGH-05A□A□B6,SGMGH-05A□A□C6,SGMGH-05A□A□76,SGMGH-09A□A□A6,SGMGH-09A□A□B6,SGMGH-09A□A□C6,SGMGH-09A□A□76,SGMGH-13A□A□A6,SGMGH-13A□A□B6,SGMGH-13A□A□C6,SGMGH-13A□A□76,SGMGH-20A□A□A6,SGMGH-20A□A□B6,SGMGH-20A□A□C6,SGMGH-20A□A□76,SGMGH-30A□A□A6,SGMGH-30A□A□B6,SGMGH-30A□A□C6,SGMGH-30A□A□76,SGMGH-44A□A□A6,SGMGH-44A□A□B6,SGMGH-44A□A□C6,SGMGH-44A□A□76,SGMGH-55A□A□A6,SGMGH-55A□A□B6,SGMGH-55A□A□C6,SGMGH-55A□A□76,SGMGH-75A□A□B6,SGMGH-75A□A□C6,SGMGH-75A□A□76;

SGMSH伺服电机:SGMSH-10A□AL14,SGMSH-10A□AL24,SGMSH-10A□AL54,SGMSH-10A□AL74,SGMSH-10A□AL84,SGMSH-15A□AL14,SGMSH-15A□AL24,SGMSH-15A□AL54,SGMSH-15A□AL74,SGMSH-15A□AL84,SGMSH-20A□AL14,SGMSH-20A□AL24,SGMSH-20A□AL54,SGMSH-20A□AL74,SGMSH-20A□AL84,SGMSH-30A□AL14,SGMSH-30A□AL24,SGMSH-30A□AL54,SGMSH-30A□AL74,SGMSH-30A□AL84,SGMSH-40A□AL14,SGMSH-40A□AL24,SGMSH-40A□AL54,SGMSH-40A□AL74,SGMSH-50A□AL14,SGMSH-50A□AL24,SGMSH-50A□AL54;**SGMDH**伺服电机:SGMDH-22A,SGMDH-32A,SGMDH-40A;

SGMAS伺服电机:SGMAS-A5A,SGMAS-01A,SGMAS-C2A,SGMAS-02A,SGMAS-04A,SGMAS-06A,SGMAS-08A,SGMAS-12A,SGMPS-01A,SGMPS-02A,SGMPS-04A,SGMPS-08A,SGMPS-15A,SGMSS-10A,SGMSS-15A,SGMSS-20A,SGMSS-25A,SGMSS-30A,SGMCS-02B,SGMCS-05B,SGMCS-07B,SGMCS-04C,SGMCS-10C,SGMCS-14C,SGMCS-08D,SGMCS-17D,SGMCS-25D,SGMCS-16E,SGMCS-35E,SGMCS-45M,SGMCS-80M,SGMCS-1AM,SGMCS-80N,SGMCS-1EN,SGMCS-2ZN;**SJME**伺服电机: SJME-01A,SJME-02A,SJME-04A,SJME-08A;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

直线电机:SGLGW-30A050,SGLGW-30A080,SGLGW-40A140,SGLGW-40A253,,SGLGW-40A365,SGLGW-60A140,SGLGW-60A253,SGLGW-60A365,
SGLGW-90A200,SGLGW-90A370,SGLGW-90A535,SGLFW-20A090,SGLFW-20A120,SGLFW-35A120,SGLFW-35A230,SGLFW-50A200,SGLFW-50A380,
SGLFW-1ZA200,SGLFW-1ZA380,SGLTW-20A170,SGLTW-20A320,SGLTW-20A460,SGLTW-35A170,SGLTW-35A320,SGLTW-35A460,SGLTW-40A400,
SGLTW-40A600,SGLTW-80A400,SGLTW-80A600,SGLGW-30A050,SGLGW-30A080,SGLGW-40A140,SGLGW-40A253,SGLGW-40A365,SGLGW-60A140,
SGLGW-60A253,SGLGW-6A365,SGLGW-90A200,SGLGW-90A370,SGLGW-90A535,SGLFW-20A090,SGLFW-20A120,SGLFW-35A120,SGLFW-35A230,
SGLFW-50A200,SGLFW-50A380,SGLFW-1ZA200,SGLFW-1ZA380,SGLTW-20A170,SGLTW-20A320,SGLTW-20A460,SGLTW-35A170,SGLTW-35A320,
SGLTW-35A460,SGLTW-40A400,SGLTW-40A600,SGLTW-80A400,SGLTW-80A600;

维修各种百格拉电机:

BergeRLahr Motors:SER397(3S),SER397(3S),SER397(7S),SER397(7S),SER3910(3S),SER3910(3S),SER3910(7S),SER3910(7S),SER3913(3S),SER3913(3S),
SER3913(5S),SER3913(5S),SER3913(7S),SER3913(7S),SER3916(5S),SER3916(5S),SER31112(3S),SER31112(3S),SER31112(5S),SER31112(5S),
SER31112(7S),SER31112(7S),SER31117(3S),SER31117(3S),SER31117(5S),SER31117(5S),SER31117(7S),SER31117(7S),SER31122(5S),SER31122(5S),
SER31122(7S),SER31122(7S),SER31127(5D),SER31127(7S),SER31127(7S),SER397withHPL50,SER3910withHPL50,SER3913withHPL50,SER3916withHPL50,
SER31112withHPL100,SER31117withHPL100,SER31122withHPL100,SER31127withHPL100,DSM4-051-1xxx6,DSM4-051-2xxx6,DSM4-052-1xxx6,DSM4-052-2xxx6,
DSM4-053-1xxx6,DSM4-053-2xxx6,DSM4-054-1xxx6,DSM4-054-2xxx6,DSM4-071-1xxx4,DSM4-071-2xxx4,DSM4-071-1xxx6,DSM4-071-2xxx6,DSM4-072-1xxx4,
DSM4-072-2xxx4,DSM4-072-1xxx6,DSM4-072-2xxx6,DSM4-073-1xxx4,DSM4-073-2xxx4,DSM4-073-1xxx6,DSM4-073-2xxx6,DSM4-091-1xxx3,DSM4-091-2xxx3,
DSM4-091-1xxx4,DSM4-091-2xxx4,DSM4-091-1xxx6,DSM4-091-2xxx6,DSM4-092-1xxx3,DSM4-092-2xxx3,DSM4-092-1xxx4,DSM4-092-2xxx4,DSM4-092-1xxx6,
DSM4-092-2xxx6,DSM4-093-2xxx3,DSM4-093-2xxx4,DSM4-093-2xxx6,DSM4-094-2xxx3,DSM4-094-2xxx4,DSM4-094-2xxx6,DSM4-111-2xxx3,DSM4-111-2xxx4,
DSM4-111-2xxx6,DSM4-112-2xxx3,DSM4-112-2xxx4,DSM4-112-2xxx6,DSM4-113-2xxx3,DSM4-113-2xxx4,DSM4-113-2xxx6,DSM4-114-2xxx3,
DSM4-114-2xxx4,DSM4-141-2xxx2,DSM4-141-2xxx3,DSM4-141-2xxx4,DSM4-142-2xxx2,DSM4-142-2xxx3,DSM4-142-2xxx4,DSM4-143-2xxx2,DSM4-143-2xxx3,
DSM4-143-2xxx4,DSM4-144-2xxx2,DSM4-144-2xxx3,DSM4-191-2xxx1,DSM4-191-2xxx2,DSM4-191-2xxx3,DSM4-191-2xxx4,DSM4-192-2xxx1,DSM4-192-2xxx2,
DSM4-192-2xxx3,

维修各种富士伺服电机:

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

FALDIC-β:GYS500DC1-C8B,GYS101DC1-CB,GYS201DC1-CA,GYS401DC1-CA,GYS751DC1-CA,GYS500DC1-C8B,GYS101DC1-C6B,GYS201DC1-C6B,
GYC101DC1-SA,GYC201DC1-SA,GYC401DC1-SA,GYC751DC1-SA,GYC102DC1-SA,GYC152DC1-SA,GYC202DC1-SA,GYC101DC1-SA-B,GYC201DC1-SA-B,
GYC401DC1-SA-B,GYC751DC1-SA-B,GYC102DC1-SA-B,GYC152DC1-SA-B,GYC202DC1-SA-B,GYS500DC1-S8B,GYS101DC1-SB,GYS201DC1-SA,
GYS401DC1-SA,GYS751DC1-SA,GYS102DC1-SA,GYS152DC1-SA,GYS202DC1-SA,GYS302DC1-SA,GYS402DC1-SA,GYS502DC1-SA,GYS500DC1-S8B-B,
GYS101DC1-SB-B,GYS201DC1-SA-B,GYS401DC1-SA-B,GYS751DC1-SA-B,GYS102DC1-SA-B,GYS152DC1-SA-B,GYS202DC1-SA-B,GYS302DC1-SA-B,
GYS402DC1-SA-B,GYS502DC1-SA-B,GYS101DC1-S6B,GYS201DC1-S6B,GYS101DC1-S6B-B,GYS201DC1-S6B-B,GYN101CAG-G09,GYN201CAG-G09,
GYN401CAG-G09,GYN751CAG-G09,GYN102CAG-G09,GYN152CAG-G09,GYN202CAG-G09,GYN101CAG-G25,GYN201CAG-G25,GYN401CAG-G25,
GYN751CAG-G25,GYN102CAG-G15,GYN152CAG-G15,GYN202CAG-G15,GYN500SAG-G09,GYN101SAG-G09,GYN201SAG-G09,GRN20SAG-G09,
GYN401SAG-G09,GRN40SAG-G09,GYN751SAG-G09,GYN102SAG-G09,GYN152SAG-G09,GYN202SAG-G09,GYN500SAG-G25,GYN101SAG-G25,
GYN201SAG-G25,GRN20SAG-G25,GYN401SAG-G25,GRN40SAG-G25,GYN751SAG-G25,GYN102SAG-G15,GYN152SAG-G15,GYN202SAG-G15;

维修各种海德汉同步电机:

QSY系列:QSY96A,QSY96G,QSY116C,QSY116E,QSY116JEcoDyn,QSY130CECODYN,QSY130EECODYN,QSY155B,QSY155C,QSY155D,QSY155F,
QSY155BEcoDyn,QSY155CEcoDyn,QSY155DEcoDyn,QSY155EcoDyNF,QSY190FEcoDyn,QSY190CEcoDyn,QSY190DEcoDyn,QSY190KcoDyNF,
1F7042-5AF71,1F7060-5AF71,1F7063-5AF71,1F7080-5AF71,1F7083-5AF71,1F7100-5AF71,1F7101-5AF71,1F7103-5AF71;

维修各种科勒-摩根电机(Kollmorgen):

U-Series,S-Series,FerritESeries,FerritEKITSeries,N-Series,JR-Series,GearmotoRSeries;U9BL-C/RES/CVR/CONN,U9BL-C/RES/CVR/CBL,
U9BL-C/ENC/CVR/CONN,U9BL-C/ENC/CVR/CBL,U9BL-C/ENC/CBL,U12BL-C/RES/CVR/CONN,U12BL-C/RES/CVR/CBL,U12BL-C/ENC/CVR/CONN,
U12BL-C/ENC/CVR/CBL,U12BL-C/ENC/CBL,U16BL-D/RES/CVR/CONN,U16BL-D/RES/CVR/CBL,U16BL-D/ENC/CVR/CONN,U16BL-D/ENC/CVR/CBL,
U16BL-D/ENC/CBL,U9M4LR,U9M4,U9M4A,U9M4H,U9M4HA,U9M4HA-1,U9M4HA-2,U12M4LR,U12M4,U12M4A,U12M4H,U12M4HA,U16M4,U16M4H,
S6M4H/GH6-10,U9M4T/GH9-10,U9M4/GH9-10,N9M4/GH9-10,U9M4HT/GH9-10,S9M4H/GH9-10,U12M4T/GH12-10,U12M4/GH12-10,U12M4HT/GH12-10,
U12M4H/GH12-10,JR12M4CH/GH12-10,JR16M4CH/GH16-10,S6M4H/GH6-20,U9M4T/GH9-20,U9M4/GH9-20,N9M4/GH9-20,U9M4HT/GH9-20,S9M4H/GH9-20,
U12M4T/GH12-20,U12M4/GH12-20,U12M4HT/GH12-20,U12M4H/GH12-20,JR12M4CH/GH12-20,JR16M4CH/GH16-20,S6M4H/GH

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

6-40,U9M4T/GH9-40,
U9M4/GH9-40,N9M4/GH9-40,U9M4HT/GH9-40,S9M4H/GH9-40,U12M4T/GH12-40,U12M4/GH12-40,U12M4HT/GH12-40,U12M4H/
GH12-40,JR12M4CH/GH12-40,
JR16M4CH/GH16-40,S6M4H/GH6-60,U9M4T/GH9-60,U9M4/GH9-60,N9M4/GH9-60,U9M4HT/GH9-60,S9M4H/GH9-60,U12M4T/G
H12-60,U12M4/GH12-60,
U12M4HT/GH12-60,U12M4H/GH12-60,JR12M4CH/GH12-60,JR16M4CH/GH16-60,S6M4H/GH6-100,U9M4T/GH9-100,U9M4/GH9-
100,N9M4/GH9-100,
U9M4HT/GH9-100,S9M4H/GH9-100,U12M4T/GH12-100,U12M4/GH12-100,U12M4HT/GH12-100,U12M4H/GH12-100,JR12M4CH/
GH12-100,JR16M4CH/GH16-100,
9FGCHD/10:1,9FGCHDT/10:1,9FGT/15:1,9FG/15:1,9FGHDT/15:1,9FGHD/15:1,9FGCHD/15:1,9FGCHDT/15:1,12FGT/15:1,12FG/1
5:1,9FGT/25:1,9FG/25:1,
9FGHDT/25:1,9FGHD/25:1,9FGCHD/25:1,9FGCHDT/25:1,12FGT/25:1,12FG/25:1,12FGT/37:1,12FG/37:1,9FGHDT/50:1,9FGHD/50:
1,9FGT/50:1,9FG/50:1,
9FGCHD/50:1,9FGCHDT/50:1,12FGT/50:1,12FG/50:1,9FGT/80:1,9FGHDT/80:1,9FG/80:1,9FGHD/80:1,9FGCHD/80:1,9FGCHDT/8
0:1,12FGT/80:1,12FG/80:1,
9FGT/100:1,9FG100:1,9FGHDT/100:1,9FGHD/100:1,9FGCHD/100:1,9FGCHDT/100:1,12FGT/100:1,12FG/100:1,9FG/150:1,9FGT/
150:1,9FGHD/150:1,
9FGHDT/150:1,9FGCHD/150:1,9FGCHDT/150:1,12FG/150:1,12FGT/150:1;H-232-G,H-234-F,H-234-G,H-234-H,H-342-H,H-344-H,
H-348-H;

维修各种松下伺服电机:松下交流伺服电机:

MSMA伺服电机:MSMA3AZA,,MSMA5AZA,MSMA011A,MSMA021A,MSMA041A,MSMA3AZA,MSMA5AZA,MSMA012A,MSMA022A,
MSMA042A,MSMA082A,MSMA102A; **MQMA**伺服电机:MQMA01,MQMA02,MQMA04,MQMA01,MQMA02,MQMA04,MQMA01,MQ
MA02,MQMA04,MQMA01,MQMA02,MQMA04;

MSMA152A,MSMA202A,MSMA252A,MSMA302A,MSMA352A,MSMA402A,MSMA452A,MSMA502A,MSMA3AZC,MSMA5AZC,MS
MA011C,MSMA021C,MSMA041C,

MSMA3AZC,MSMA5AZC,MSMA012C,MSMA022C,MSMA042C,MSMA082C,MSMA102D,MSMA152D,MSMA202D,MSMA252D,MS
MA302D,MSMA352D,

MSMA402D,MSMA452D,MSMA502D;

MDMA伺服电机:MDMA082A1,MDMA102A1,MDMA152A1,MDMA202A1,MDMA252A1,MDMA302A1,MDMA352A1,MDMA402A1,M
DMA452A1,MDMA502A1,

MDMA082D1,MDMA102D1,MDMA152D1,MDMA202D1,MDMA252D1,MDMA302D1,MDMA352D1,MDMA402D1,MDMA452D1,MD
MA502D1,MDMA082A1,

MDMA102A1,MDMA152A1,MDMA202A1,MDMA252A1,MDMA302A1,MDMA352A1,MDMA402A1,MDMA452A1,MDMA502A1,MDM
A082D1,MDMA102D1,

MDMA152D1,MDMA202D1,MDMA252D1,MDMA302D1,MDMA352D1,MDMA402D1,MDMA452D1,MDMA502D1;

MHMA伺服电机:MHMA052A1,MHMA102A1,MHMA152A1,MHMA202A1,MHMA302A1,MHMA402A1,MHMA502A1,MHMA052D1,M
HMA102D1,MHMA152D1,

MHMA202D1,MHMA302D1,MHMA402D1,MHMA502D1,MHMA052A1,MHMA102A1,MHMA152A1,MHMA202A1,MHMA302A1,MHM
A402A1,MHMA502A1,

MHMA052D1,MHMA102D1,MHMA152D1,MHMA202D1,MHMA302D1,MHMA402D1,MHMA502D1;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MFMA伺服电机:MFMA042A1,MFMA082A1,MFMA152A1,MFMA252A1,MFMA352A1,MFMA452A1,MFMA042D1,MFMA082D1,MFMA152D1,MFMA252D1,

MFMA352D1,MFMA452D1,MFMA042A1,MFMA082A1,MFMA152A1,MFMA252A1,MFMA352A1,MFMA452A1,MFMA042D1,MFMA082D1,MFMA152D1,

MFMA252D1,MFMA352D1,MFMA452D1;

MGMA伺服电机:MGMA032A1,MGMA062A1,MGMA092A1,MGMA122A1,MGMA202A1,MGMA302A1,MGMA452A1,MGMA032D1,MGMA062D1,MGMA092D1,

MGMA122D1,MGMA202D1,MGMA302D1,MGMA452D1,MGMA032A1,MGMA062A1,MGMA092A1,MGMA122A1,MGMA202A1,MGMA302A1,MGMA452A1,

MGMA032D1,MGMA062D1,MGMA092D1,MGMA122D1,MGMA202D1,MGMA302D1,MGMA452D1;

MSMD伺服电机:MSMD5AZP1,MSMD5AZS1,MSMD011P1,MSMD011S1,MSMD012P1,MSMD012S1,MSMD022P1,MSMD022S1,MSMA012P1,MSMA012S1,

MSMD021P1,MSMD021S1,MSMD042P1,MSMD042S1,MSMA022P1,MSMA022S1,MSMD041P1,MSMD041S1,MSMD082P1,MSMD082S1;

维修各种西门子伺服电机:

西门子**SIMODRIV**电机:**1FK6 SERIES**:1FK6032-6AK71-1TH0,1FK6040-6AK71-1AA0,1FK6040-6AK71-1TG0,1FK6042-6AF71-1AA0,1FK6042-6AF71-1AB0,

1FK6042-6AF71-1AG0,1FK6042-6AF71-1SB0,1FK6042-6AF71-1TA0,1FK6060-6AF71-1AA0,1FK6061-7AF71-1SG0,1FK6063-6AF71-1AG0,1FK6063-6AF71-1SB0,1FK6063-6AF71-1TB0,1FK6063-6AF71-1TH0,1FK6083-6AF71-1AG0,1FK6083-6AF71-1EB0,1FK6083-6AF71-1TB0,1FK6103-8AF71-1SA0;1FT6102-1AC71,

1FT6105-1AC71,1FT6044-1AF71,1FT6062-1AF71,1FT6064-1AF71,1FT6082-1AF71,1FT6084-1AF71,1FT6086-1AF71,

1K6063-6AF7,1FK6080-6AF7,

1FK6083-6AF7,1FK6100-8AF7,1FK6101-8AF7,1FK6103-8AF7,1FK6032-6AK71,1FK6032-6AK71,1FK6040-6AK71,1FK6042-6AF71,1FK6060-6AF7;

1FK7

SERIES:1FK7032-5AK71-1SA2,1FK7032-5AK71-1SB2,1FK7033-7AK71-1AG0,1FK7033-7AK71-1SG0,1FK7042-5AF71-1AG0,1FK7042-5AF71-1SB3,

1FK7042-5AF71-1SG0,1FK7060-5AF71-1AA0,1FK7060-5AF71-1SG0,1FK7063-5AF71-1EG0,1FK7063-5AF71-1SG0,1FK7064-7AF71-1SH0,1FK7080-5AF71-1SA0,

1FK7080-5AF71-1SG0,1FK7082-7AF71-1AG0,1FK7083-5AF71-1AG0,1FK7083-5AF71-1EB0,1FK7083-5AF71-1SG0,1FK7100-5AF71-1EA0,1FK7100-5AF71-1SA0,

1FK7103-5AF71-1EG0,1FK7103-5AF71-1SG0;1FK7105-5AC71-1,1FK7042-5AF71-1,1FK7060-5AF71-1,1FK7063-5AF71-1,1FK7080-5AF71-1,1FK7083-5AF71-1,

1FK7100-5AF71-1,1FK7101-5AF71-1,1FK7103-5AF71-1,1FK7105-5AF71-1,1FK7060-5AH71-1,1FK7063-5AH71-1,1FK7080-5AH71-1,1FK7083-5AH71-1,

1FK7022-5AK71-1,1FK7032-5AK71-1,1FK7040-5AK71-1,1FK7042-5AK71-1,1FK7044-7AF71-1,1FK7061-7AF71-1,1FK7064-7AF71-1,1FK7082-7AF71-1,

1FK7085-7AF71-1,1FK7043-7AH71-1,1FK7044-7AH71-1,1FK7061-7AH71-1,1FK7064-7AH71-1,1FK7033-7AK71-1,1FK7043-7AK71-1;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

1FT5交流伺服电机:1FT5102-0AA71-1,1FT5104-0AA71-1,1FT5106-0AA71-1,1FT5108-0AA71-1,1FT5132-0AA71-1,1FT5134-0AA71-1,1FT5136-0AA71-1,
1FT5138-0AA71-1,1FT5062-0AC71-1,1FT5064-0AC71-1,1FT5066-0AC71-1,1FT5072-0AC71-1,1FT5074-0AC71-1,1FT5076-0AC71-1,1FT5102-0AC71-1,
1FT5104-0AC71-1,1FT5106-0AC71-1,1FT5108-0AC71-1,1FT5132-0AC71-1,1FT5134-0AC71-1,1FT5136-0AC71-1,1FT5042-0AF71-1,1FT5044-0AF71-1,
1FT5046-0AF71-1,1FT5062-0AF71-1,1FT5064-0AF71-1,1FT5066-0AF71-1,1FT5072-0AF71-1,1FT5074-0AF71-1,1FT5076-0AF71-1,1FT5102-0AF71-1,
1FT5104-0AF71-1,1FT5106-0AF71-1,1FT5108-0AF71-1,1FT5132-0AF71-1,1FT5062-0AG71-1,1FT5064-0AG71-1,1FT5066-0AG71-1,1FT5072-0AG71-1,
1FT5074-0AG71-1,1FT5076-0AG71-1,1FT5102-0AG71-1,1FT5034-0AK71-1,1FT5036-0AK71-1,1FT5042-0AK71-1,1FT5044-0AK71-1,1FT5046-0AK71-1,
1FT5062-0AK71-1,1FT5064-0AK71-1,1FT5066-0AK71-1,1FT5072-0AK71-1,1FT5074-0AK71-1,1FT5076-0AK71-1,1FT5132-0SA71-1,1FT5134-0SA71-1,
1FT5136-0SA71-1,1FT5138-0SA71-1,1FT5132-0SC71-1,1FT5134-0SC71-1,1FT5136-0SC71-1,1FT5102-0SF71-1,1FT5104-0SF71-1,1FT5106-0SF71-1,
1FT5132-0SF71-1,1FT5074-0SG71-1,1FT5076-0SG71-1,1FT5102-0SG71-1,1FT5074-0SK71-1,1FT5076-0SK71-1,1FT5070-0AC71-1,1FT5071-0AC71-1,
1FT5073-0AC71-1,1FT5100-0AC71-1,1FT5101-0AC71-1,1FT5102-0AC71-1,1FT5070-0AF71-1,1FT5171-0AF71-1,1FT5173-0AF71-1,1FT5100-0AF71-1,
1FT5101-0AF71-1,1FT5103-0AF71-1;1FT5046-1AF71-3EA0,1FT5062-0AC71-1,1FT5064-0AC71-2,1FT5064-0AF71-1-Z,1FT5064-1AF71-3EA0,
1FT5064-1AF71-4EA0,1FT5066-1AC71-3EG0,1FT5066-1AF71-4EA0,1FT5071-0AC71-2,1FT5072-1AF71-1EB0,1FT5074-0AC71-1,1FT5074-1AF71-3EG0,
1FT5076-0AF71-1,1FT5102-1AA71-1EA0,1FT5108-1AC71-1EG0;

1FT6

SERIES:1FT6034-1AK71-3AG1,1FT6044-4AF71-3EG2,1FT6044-4AF71-4AA0,1FT6044-4AF71-4AA6,1FT6044-4AF71-4AB6,1FT6044-4AF71-4AD2,
1FT6064-6AF71-4SG2,1FT6082-1AF71-1AG1,1FT6082-1AH71-1AG1,1FT6082-8AC71-1AA2,1FT6082-8AC71-1AG2,1FT6082-8AC71-1EH2,
1FT6082-8AC71-3EA0-Z,1FT6082-8AC71-4AG2,1FT6082-8AF71-1EG2,1FT6084-8AF71-1AG2,1FT6084-8AK71-1AG2,1FT6102-8AB71-1AA2,
1FT6102-8AB71-1AA2-Z,1FT6105-1AC71-1AG1,1FT6132-6AF71-1AG2,1FT6134-6AB71-1AA0,1FT6134-6AC71-1EB0,FT6062-1AH71,1FT6064-1AH71,
1FT6084-1AH71,1FT6086-1AH71,1FT6034-1AK71,1FT6084-1AK71,1FT6102-8AB7,1FT6105-8AB7,1FT6108-8AB7,1FT6132-6AB71,1FT6134-6AB71,
1FT6136-6AB71,1FT6041-4AF71,1FT6044-4AF71,1FT6061-6AF7,1FT6062-6AF7,1FT6064-6AF7,1FT6081-8AF7,1FT6082-8AF7,1FT6084-8AF7,1FT6086-8AF7,
1FT6102-8AF7,1FT6105-8AF7,1FT6108-8AF7,1FT6132-6AF71,1FT6021-6AK71,1FT6024-6AK71,1FT6031-4AK71,1FT6034-4AK71,1FT6041-4AK71,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

1FT6044-4AK71,1FT6061-6AK7,1FT6062-6AK7,1FT6064-6AK7,1FT6081-8AK7,1FT6082-8AK7,1FT6084-8AK7,1FT6105-8SB7,1FT6108-8SB7,1FT6132-6SB71,
1FT6134-6SB71,1FT6136-6SB71,1FT6105-8SC7,1FT6108-8SC7,1FT6132-6SC71,1FT6134-6SC71,1FT6136-6SC71,1FT6084-8SF7,1FT6086-8SF7,1FT6105-8SF7,
1FT6108-8SF7,1FT6132-6SF71,1FT6134-6SF71,1FT6136-6SF71,1FT6084-8SH7,1FT6086-8SH7,1FT6105-8SH7,1FT6084-8SK7,1FT6086-8SK7,1FT6108-8WB7,
1FT6105-8WC7,1FT6108-8WC7,1FT6062-6WF7,1FT6064-6WF7,1FT6084-8WF7,1FT6086-8WF7,1FT6105-8WF7,1FT6108-8WF7,1FT6062-6WH7,1FT6064-6WH7,
1FT6084-8WH7,1FT6086-8WH7,1FT6062-6WK7,1FT6064-6WK7,1FT6084-8WK7,1FT6086-8WK7,1FT6132-6WB7,1FT6134-6WB7,1FT6136-6WB7,1FT6138-6WB7,
1FT6132-6WD7,1FT6134-6WD7,1FT6136-6WD7,1FT6138-6WD7;

1PH7

SERIES:1PH7105-2NF20-0BD0,1PH7107-2NF00-0BA2,1PH7107-2NF02-0BA0,1PH7107-2NF20-0BD0,1PH7131-2NF02-0CK0,1PH7133-2ND02-0CJ0,
1PH7135-2NF00-0BA0,1PH7135-2NF03-0BA0,1PH7137-2ND00-0BJ0,1PH7137-2NG02-0CA0,1PH7163-2ND03-0BA0,1PH7184-2NT30-0GJ0,
1PH7186-2ND00-0AA0,1PH7186-2NF00-0AA0-,1PH7224-2NC00-0GJ0,1PH7224-2NC30-0GJ0;1PH7101-F,1PH7103-D,1PH7103-F,1PH7103-G,1PH7105-F,
1PH7107-D,1PH7107-F,1PH7107-G,1PH7131-F,1PH7133-D,1PH7133-F,1PH7133-G,1PH7135-F,1PH7137-D,1PH7137-F,1PH7137-G,1PH7163-B,1PH7163-D,
1PH7163-F,1PH7163-G,1PH7167-B,1PH7167-D,1PH7167-F,1PH7167-G,1PH7184-T,1PH7184-D,1PH7184-E,1PH7184-F,1PH7184-L,1PH7186-T,1PH7186-D,
1PH7186-E,1PH7224-C,1PH7224-D,1PH7224-F,1PH4103,1PH4105,1PH4107,1PH4133,1PH4135,1PH4137,1PH4138,1PH4163,1PH4167,1PH4168,1PH4103-4F26;

1FN LINEAR

MOTOR:1FN1120-0AA00-0AA0,1FN1120-0AA00-1AA0,1FN1124-5AC71-0AA0,1FN1910-0AA00-0AA0,1FN3000-0TM00-0AA0,1FN3002-0PH00-0AA0,
1FN3002-4TK00-0AA0,1FN3050-0TC00-0AA0,1FN3050-2WC00-0AA0,1FN3050-4SA00-0AA0,1FN3100-0TB00-1BG0,1FN3100-0TB00-1BH0,
1FN3100-0TC00-0AA0,1FN3100-2WC00-0AA1,1FN3100-4SA00-0AA0,1FN3100-4WC00-0AA1,1FN3300-0TC00-0AA0,1FN3300-2WB00-0AA1,
1FN3300-3WC00-0AA0,1FN3300-4SA00-0AA0,1FN3300-4WC00-0AA1;1FN1070-0AA00-0AA0,1FN1070-0AA00-1AA0,1FN1120-0AA00-0AA0,
1FN1120-0AA00-1AA0,1FN1180-0AA00-0AA0,1FN1180-0AA00-1AA0,1FN1240-0AA00-0AA0,1FN1240-0AA00-1AA0,1FN3050-2WC00-0AA0,
1FN3100-1WC00-0AA1,1FN3100-2WC00-0AA1,1FN3100-2WE00-0AA1,1FN3100-3WC00-0AA1,1FN3100-3WE00-0AA1,1FN3100-4WC00-0AA1,
1FN3100-5WC00-0AA1,1FN3150-1WC00-0AA1,1FN3150-2WC00-0AA1,1FN3150-3WC00-0AA1,1FN3150-4WC00-0AA1,1FN3150-5WC00-0AA1,
1FN3300-1WC00-0AA1,1FN3300-2WB00-0AA1,1FN3300-2WC00-0AA1,1FN3300-3WC00-0AA1,1FN3300-4WB00-0AA1,1FN3300-

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

4WC00-0AA1,
1FN3450-2WA50-0AA1,1FN3450-2WC00-0AA1,1FN3450-3WB00-0AA1,1FN3450-3WC00-0AA1,1FN3450-4WB00-0AA1,1FN3450-4WC00-0AA1,
1FN3450-4WE00-0AA1,1FN3600-2WA50-0AA1,1FN3600-3WB00-0AA1,1FN3600-3WC00-0AA1,1FN3600-4WB00-0AA1,1FN3600-4WB50-0AA1,
1FN3600-4WC00-0AA1,1FN3900-2WB00-0AA1,1FN3900-2WC00-0AA1,1FN3900-3WB00-0AA1,1FN3900-4WB00-0AA1,1FN3900-4WC00-0AA1;

1FW6

SERIES:1FW6090-0PA05-0KC2,1FW6090-0PA07-0KC2,1FW6090-0PA07-1JC2,1FW6090-0PA10-0KC2,1FW6090-0PA10-1JC2,1FW6090-0PA15-1JC2,
1FW6090-0PA15-2JC2,1FW6130-0PA05-0KC2,1FW6130-0PA05-1JC2,1FW6130-0PA07-0KC2,1FW6130-0PA07-1JC2,1FW6130-0PA10-1JC2,
1FW6130-0PA10-2JC2,1FW6130-0PA15-1JC2,1FW6130-0PA15-2JC2,1FW6160-0A05-1JC2,1FW6160-0A05-2JC2,1FW6160-0A07-1JC2,1FW6160-0A07-2JC2,
1FW6160-0A10-1JC2,1FW6160-0A10-2JC2,1FW6160-0A15-2JC2,1FW6160-0A15-5GC2,1FW6190-0A05-1JC2,1FW6190-0A05-2JC2,1FW6190-0A07-1JC2,
1FW6190-0A07-2JC2,1FW6190-0A10-1JC2,1FW6190-0A10-2JC2,1FW6190-0A15-2JC2,1FW6190-0A15-5GC2,1FW6230-0A05-1JC2,1FW6230-0A05-2JC2,
1FW6230-0A07-1JC2,1FW6230-0A07-2JC2,1FW6230-0A10-2JC2,1FW6230-0A10-5GC2,1FW6230-0A15-4CC2,1FW6230-0A15-5GC2;

1FE1 SERIES:FE1042-6WN,1FE1042-6WR,1FE1051-6WN,1FE1051-6WK,1FE1052-6WN,1FE1052-6WK,1FE1054-6WN,1FE1061-6WH,1FE1061-6WY,
1FE1064-6WN,1FE1064-6WQ,1FE1082-6WP,1FE1082-6WS,1FE1082-6WQ,1FE1082-6WW,1FE1084-6WU,1FE1084-6WR,1FE1091-6WN,1FE1092-6WN,
1FE1093-6WN,1FE1093-6WS,1FE1093-6WV,1FE1113-6WU,1FE1113-6WX,1FE1114-6WR,1FE1114-6WT,1FE1114-6WW,1FE1116-6WR,1FE1116-6WT,
1FE1116-6WW,1FE1145-8WN,1FE1145-8WS,1FE1147-8WN,1FE1147-8WS,1FE1051-4HC,1FE1051-4WN,1FE1052-4HG,1FE1052-4WN,1FE1052-4WK,
1FE1053-4HH,1FE1053-4WN,1FE1072-4WN,1FE1072-4WH,1FE1073-4WN,1FE1074-4WN,1FE1074-4WM,1FE1082-4WN,1FE1082-4WR,1FE1083-4WN,
1FE1084-4WN,1FE1084-4WQ,1FE1085-4WN,1FE1085-4WT,1FE1085-4WQ,1FE1092-4WP,1FE1093-4WN,1FE1093-4WH,1FE1094-4WL,1FE1094-4WK,
1FE1094-4WS,1FE1095-4WN,1FE1096-4WN,1FE1103-4WN,1FE1104-4WN,1FE1105-4WN,1FE1106-4WN,1FE1106-4WY,1FE1112-4WN,1FE1125-4WN,
1FE1125-4WP,1FE1126-4WN,1FE1126-4WP,1FE1126-4WQ,1FE1042-6W,1FE1051-6W,1FE1052-6W,1FE1054-6W,1FE1061-6W,1FE1064-6W,1FE1082-6W,
1FE1084-6W,1FE1091-6W,1FE1092-6W,1FE1093-6W,1FE1113-6W,1FE1114-6W,1FE1116-6W,1FE1145-8W,1FE1147-8W;
2SP1202-1HA,2SP1202-1HB,2SP1204-1HA,2SP1204-1HB,2SP1253-8HA0,-2SP1253-8HA0,-2SP1255-8HA0,2SP1255-8HA0,2SP1253-1HA,2SP1253-1HB,
2SP1255-1HA,2SP1255-1HB;1PH4105-4F26,1PH4107-4F26,1PH4133-4F26,1PH4135-4F26,1PH4137-4F26,1PH4138-4F26,1PH41

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

63-4F26,1PH4167-4F26,
1PH4168-4F26,1PM4101-2LF86-1S1;1PM4105-2LF86-1S1,1PM6101-2LF8-11,1PM6105-2LF8-11,1PM4133-2LF86-1S1,1PM4137-2LF86-1S1,1PM6133-2LF8-11,
1PM6137-2LF8-11,1PM6138-2LF8-11,1PM4101-2LW26-1S1,1PM4105-2LW26-1S1,1PM4133-2LW26-1S1,1PM4137-2LW26-1S1,1
PH2093-6WF4,1PH2095-6WF4,
1PH2113-6WF4,1PH2115-6WF4,1PH2117-6WF4,1PH2118-6WF4,1PH2182-6WC41,1PH2184-6WP41,1PH2186-6WB41,1PH2188-6WB41,1PH2254-6WB41,
1PH2256-6WB41;

SIMODRIVE POSMOA75W智能定位电机:6SN2132-0AA11-1BA0,6SN2132-1BC11-1BA0,6SN2132-1BF11-1BA0,6SN2132-1CK11-1BA0,6SN2132-1CR11-1BA0,
6SN2132-1CU11-1BA0,6SN2132-1DE11-1BA0,6SN2132-1DH11-1BA0,6SN2132-5KD11-1BA0,6SN2132-5KM11-1BA0,6SN2132-5KW11-1BA0,
6SN2155-07AA0-1BA0,6SN2155-2BD10-1BA0,6SN2155-2BF10-1BA0,6SN2155-2CH10-1BA0,6SN2155-2CK10-1BA0,6SN2155-2CM10-1BA0,
6SN2155-2CP10-1BA0,6SN2155-07AA1-1BA0,6SN2155-2BD11-1BA0,6SN2155-2BF11-1BA0,6SN2155-2CH11-1BA0,6SN2155-2CK11-1BA0,
6SN2155-2CM11-1BA0,6SN2155-2CP11-1BA0,6SN2460-2BF00-0G,6SN2463-2BF00-0G,6SN2480-2BF00-0G,6SN2483-2BF00-0G,
6SN2500-2BF00-0G,
6SN2703-2AA00-0BA0,6SN2703-2AA00-0CA0,6SN2703-3AA00-0BA0,6SN2703-2AA03-0BA0,6SN2703-2AA03-0CA0,6SN2703-3AA10-0BA0,
6SN2132-0AA11-1BA1,6SN2132-1BC11-1BA1,6SN2132-1BF11-1BA1,6SN2132-1CK11-1BA1,6SN2132-1CR11-1BA1,6SN2132-1CU11-1BA1,
6SN2132-1DE11-1BA1,6SN2132-1DH11-1BA1,6SN2132-5KD11-1BA1,6SN2132-5KM11-1BA1,6SN2132-5KW11-1BA1,6SN2155-0AA-1BA1,6SN2155-1AA-1BA1,
6SN2155-2BD-1BA1,6SN2155-2BF-1BA1,6SN2155-2CH-1BA1,6SN2155-2CK-1BA1,6SN2155-2CM-1BA1,6SN2155-2CP-1BA1,6SN2155-2DU-1BA1;

步进电机:6FC5548-0AB03-0AA0,6FC5548-0AB06-0AA0,6FC5548-0AB08-0AA0,6FC5548-0AB12-0AA0,6FC5548-0AB18-0AA0,6FC5548-0AB25-0AA0;

1FL3041-0AC31-0Bk0,1FL3042-0AC31-0Bk0,1FL3041-0AC31-0Bj0,1FL3042-0AC31-0Bj0,1FL3043-0AC31-0BG0,
1FL3061-0AC31-0BG0,1FL3062-0AC31-0BG0,1FL3043-0AC31-0BH0,1FL3061-0AC31-0BH0,1FL3062-0AC31-0BH0;

维修罗克韦尔伺服电机 (Rockwell Automation) :

MP-Series LowInertia Motors:MPL-A310P,MPL-A310F,MPL-A320P,MPL-A320H,MPL-A330P,MPL-A420P,MPL-A430P,MPL-A430H,MPL-A4520P,MPL-A4520K,
MPL-A4530K,MPL-A4530F,MPL-A4540C,MPL-A4540F,MPL-A520K,MPL-A540K,MPL-A560F,MPL-B310P,MPL-B320P,MPL-B330P,
MPL-B420P,MPL-B430P,
MPL-B4520P,MPL-B4530F,MPL-B4530K,MPL-B4540F,MPL-B4560F,MPL-B520K,MPL-B540D,MPL-B540K,MPL-B560F,MPL-B580F,MPL-B580J,MPL-B640F,
MPL-B660F,MPL-B680D,MPL-B680F,MPL-B860D,MPL-B880C,MPL-B880D,MPL-B960B,MPL-B960C,MPL-B960D,MPL-B980B,MPL-B980C,MPL-B980D;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

MP-Series lowinertia servomotor:MPF-A310P,MPF-A320P,MPF-A320H,MPF-A330P,MPF-A430P,MPF-A430H,MPF-A4530K,MPF-A4540F,MPF-A540K,
MPF-B310P,MPF-B320P,MPF-B330P,MPF-B430P,MPF-B4530K,MPF-B4540F,MPF-B540K;MPG-A004-031,MPG-MPG-A004-091,
MPG-MPG-A010-031,
MPG-MPG-A010-091,MPG-MPG-A025-031,MPG-MPG-A025-091,MPG-MPG-A050-031,MPG-MPG-A050-091,MPG-MPG-A110-031,
MPG-MPG-A110-091,
MPG-MPG-B010-031,MPG-MPG-B010-091,MPG-MPG-B025-031,MPG-MPG-B025-091,MPG-MPG-B050-031,MPG-MPG-B050-091,
MPG-MPG-B110-031,
MPG-MPG-B110-091;TL-A110P,TL-A120P,TL-A130P,TL-A220P,TL-A230P,TL-A2530P,TL-A2540P,TL-A410M;1326AB-B410G,132
6AB-B410J,1326AB-B420E,
1326AB-B420H,1326AB-B430E,1326AB-B430G,1326AB-B515E,1326AB-B515G,1326AB-B520E,1326AB-B520F,1326AB-B530E,13
26AB-B720E,1326AB-B720F,
1326AB-B730E,1326AB-B740C,1326AB-B740E,F-4030,F-4050,F-4075,F-6100,F-6200,F-6300,N-2302,N-2304,N-3406,N-3412,N-42
14,N-4220,N-5630,N-5637,
N-5647,Y-1002,Y-1003,Y-2006,Y-2012,Y-1002,Y-1003,Y-2006,Y-2012,Y-3023;8720SM-030,8720SM-037,8720SM-045,8720SM-05
5,8720SM-063,8720SM-075,
8720SM-093;8720SM-005,8720SM-007,8720SM-011,8720SM-015,8720SM-018,8720SM-022,8720SM-030,8720SM-037,8720SM-0
45,8720SM-055,8720SM-063,
8720SM-075,8720SM-093;

Maxon电机: Maxon motor:订货号:250521,型号:LSC30/24-Q-DC,订货号:145391,型号:ADS50/54-Q-DC,订货号:201583,型号:ADS50
/104-Q-DC,订货号:235811,型号:
DSR70/30,订货号:166143,型号:ADS_E50/54-Q-DC,订货号:168049,型号:ADS_E50/104-Q-DC,订货号:167850,型号:3HE,5TEtoADS_
E50/5,订货号:168910,型号:3HE,
7TEtoADS_E50/10,订货号:343253,型号:DECS50/51-Q-EC,订货号:318305,型号:DEC24/11-Q-EC,订货号:249630,型号:DEC24/11-Q-
EC,订货号:249631,
型号:DEC24/11-Q-EC,订货号:249632,型号:DEC24/11-Q-EC,订货号:230572,型号:DEC50/51-Q-EC,订货号:336286,型号:DEC24/31-Q
-EC,订货号:336287,
型号:DEC24/31-Q-EC,订货号:305259,型号:DECV50/54-Q-EC,订货号:309687,型号:DSR50/5订货号:306089,型号:DEC70/104-Q-EC,
订货号:235811,型号:DSR70/30,
订货号:205679,型号:DES50/5,订货号:228597,型号:DES70/10,订货号:235811,型号:DSR70/30,订货号:280937,型号:EPOS24/1,订货号:
317270,型号:EPOS24/1,订货号:
302267,型号:EPOS24/1,订货号:302287,型号:EPOS24/1,订货号:275512,型号:EPOS24/5,订货号:300583,型号:EPOS70/10,订货号:30
9687,型号:DSR50/5,订货号:
235811,型号:DSR70/30,订货号:323232,型号:EPOSP24/5,订货号:309687,型号:DSR50/5,CSDP-15BX2;

FESTO伺服马达MTR-AC:MTR-AC-40,MTR-AC-55 ,MTR-AC-70 ,MTR-AC-100;I / P Converter :DSV-100;

芯片级维修各种DCS系统:OVATION DCS系统,霍利韦尔DCS系统,新华DCS系统,和利时DCS系统,新华DCS系统,

芯片级维修ABB DCS系统:AC800M:CPU模块:PM851,PM856,PM860,PM861A,PM864A,PM865; 电源模块:SD821,SD822,SD823,S
S822;

通讯模块:CI830A,CI840A,CI854A,CI860,CI853,CI855,CI857,CI858,CI856,CI862,S800I/O:脉冲计数模块:DP820,DP840;

开关量输入模块:DI801,DI802,DI803,DI810,DI811,DI814,DI820,DI821,DI830,DI831,DI840,DI880,DI88,DI890;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

开关量输出模件:DO801,DO802,DO810,DO811,DO814,DO815,DO820,DO821,DO840,DO880,DO890;

模拟输入模件:AI801,AI810,AI820,AI830,AI835,AI843,AI845,AI880,AI890,AI893,AI895;模拟输出模件:AO801,AO810,AO820,AO845,AO890,AO895;

S900-CB220I/O防爆产品:Flowserve:ValteKStarPaCIntelligenTControlSystem:ValteKStarPaCIIIntelligenTControlSystem;

芯片级维修**GEFANUC**控制产品:

CIMPLICITY Open process混合控制系统:**Open ProcesS-PA-30**过程自动控制器:IC660BBA021,IC660BBA023,IC660BBA101,IC660BBA103,IC660BSM021,

IC660BSM120,IC660HHM501,IC660BBA020,IC660BBA025,IC660BBA026,IC660BBA100,IC660BBA104,IC660BBA105,IC660BBA106,IC660BBD020,IC660BBD023,

IC660BBD024,IC660BBD110,IC660BBR100,IC660BBR101,IC660ELB931;DSM324j;

芯片级维修**SIXNET**高端**DCS**控制系统:SCS(ScalabIEControlSystem);ET-GT-3ES-2SC,ET-GT-3ES-2ST,ET-GT-3ES-3SC,ET-GT-3ES-3ST,

ET-GT-5ES-1,ET-GT-5ES-2SC,ET-GT-5ES-2ST,ET-GT-5ES-3SC,ET-GT-5ES-3ST,ET-GT-5ES-4SC,ET-GT-5ES-4ST,ET-GT-5ES-5SC,ET-GT-5ES-5ST,

ET-GT-9ES-1,ET-GT-9ES-2SC,ET-GT-9ES-2ST,ET-GT-9ES-3SC,ET-GT-9ES-3ST,ET-9MS-1,ET-9MS-2SC,ET-9MS-2ST,ET-9MS-3SC,ET-9MS-3ST,ET-9MS-4SC,

ET-9MS-4ST,ET-9MS-5SC,ET-9MS-5ST,EB-GT-8ES-1EB-GT-8ES-1EP,EB-CP-RJ45-F1,EB-CC-CAT5-M4,EB-CC-CAP-L4,EB-CC-PS-F1,ET-GT-232-1,

ET-GT-485-1,ST-IPM-6350,ST-IPM-2350,ST-IPM-1350,ST-GT-1210,ET-GT-ST-3,ET-GT-ST-2,ET-GT-ST-1,VT-IPM-2410,VT-IPM-1410,VT-MIPM-241-D,

VT-MIPM-131-D,ST-GT-1210,SR-4160-1E-1,SR-4160-1T-1,SR-4160-1S-1,SR-4160-1SL-1,RM-RTU-8440-F,ST-DI-005-08F,ST-DI-005-08,

ST-DI-024-08U,ST-DI-048-08F,ST-DI-048-08U,ST-DI-120-08F,ST-DI-120-08U,ST-DI-240-08F,ST-DI-240-08U,ST-DI-024-16H,ST-MIX16880-D,ST-MIX12884-D,

ST-DI-024-32D,ST-DI-CNT-08U,ST-DO-DC1-08F,ST-DO-DC1-08UST-DO-DC3-08F,ST-DO-DC3-08U,ST-DO-AC1-08F,ST-DO-AC1-08U,ST-DO-AC2-08F,

ST-DO-AC2-08U,ST-DO-DC2-16H,ST-DO-RLY-06U,ST-AI-INS-08U,ST-AI-20M-08F,ST-AI-20M-16H,ST-AI-10V-08F,ST-AI-RTD-06U,ST-AI-RTC-06U,

ST-AO-20M-04F,ST-AO-20M-08F,ST-AO-10V-08F,ST-EX-001-20U,ST-CL-20M-16H,PAK#####-##,ST-IPM-#####,VT-IPM-#####,VT-MIPM-###-D,ST-GT-1210,

ET-GT-ST-3,ET-GT-ST-2,SR-4160-1E-1,SR-4160-1T-1,SR-4160-1S-1,SR-4160-1SL-1,RM-RTU-8440-F,SXIPM-SAFE,SXIPM-SNMP,SXIPM-PPP,SR-4160-1T-1,

SR-4160-1E-1,SR-4160-1S-1,SR-4160-1SL-,RM-PS-024-01F,ST-CABLE-PF,VT-MODEM-1xx,VT-MODEM-2xx,VT-MODEM-3xx,VT-MODEM-4xx,VT-MODEM-5xx,

RM-PS-024-01F,SP-TELCO-1,ET-16DI2-H,ET-16DO2-H,ET-16AI2-H,ET-8INS-U,ET-8CNT-U,ET-8DI2-8DO2-H,ET-8DI2-8AI2-H,ET-8AI2-4AO2-H,ET-4RTD-4DI2-U,ET-MIX24880-D,ET-GT-ST-3,ET-GT-ST-2,RM-PS-024-01F,SP-ETH-2,ST-CABLE-PF,RM-8DI2-F,RM-8DI2-U,RM-16DI2-H,RM-8DO2-F,RM-16DO2-H,RM-8AI2-F,

RM-16AI2-H,RM-8INS-U,RM-4AO2-F,RM-8AO2-F,RM-4DI2-4AI2-U,RM-4DI2-4DO2-,RM-RTU-8440-F,RM-232-485-4U,RM-232-SETUP,RM-PS-024-01F,

ST-PS-024-02N,RM-PS-024-01F,VT-MODEM-#,SP-ETH-2,SP-TELCO-1,ST-CABLE-PF,VT-CABLE-MDM,PAK1210-FG,PAK1614-F

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

G,PAK2016-FG,PAK2420-ST,
PAK3630-ST,PAK4836-ST,SXTOOLS-1,SXTOOLS-2,SXTOOLS-3,SXTOOLS-4,SXTOOLS-5,SXTOOLS-U#,SXLOAD-1,ST-1131-3
2,ST-1131-256,ST-1131-1K,
ST-1131-BIG,VT-M2-224-##P,VT-M2-420-##P,VT-M2-220-##P,VT-A2-220-##P,VT-A2-420-##P,VT-A2-222-##P,VT-A2-422-##P,VT
-A2-22E-##P,VT-A2-42E-##P,
VT-A3-220-##P,VT-A3-420-##P,VT-A3-222-##P,VT-A3-422-##P,VT-A3-22E-##P,VT-A3-42E-##P,ST-GT-ETH-##P,232-##P,ST-GT-
422-##P,ST-GT-ETH-02N,
ST-GT-232-02N,ST-GT-422-02N,ST-DI-005-08M,ST-AI-INS-08M,RM-8DI2-M,ET-16DI2-M,ST-DI-024-08M,ST-AI-20M-08M,RM-8DI
2-M,ET-16DO2-M,
ST-DI-048-08M,ST-AI-20M-16M,RM-16DI2-M,ET-16AI2-M,ST-DI-120-08M,ST-CL-20M-16M,RM-8DO2-M,ET-8INS-M,ST-DI-240-08
M,ST-AI-10V-08M,RM-16DO2-M,
ET-8CNT-M,ST-DI-024-16M,ST-AI-RTD-06M,RM-8AI2-M,ET-8DI2-8DO2-M,ST-DI-024-32M,ST-AI-RTC-06M,RM-16AI2-M,ET-8DI2-
8AI2-M,ST-DI-CNT-08M,
ST-AO-20M-04M,RM-8INS-M,ET-8AI2-4AO2-M,ST-DO-DC1-08M,ST-AO-20M-08M,RM-4AO2-M,ET-4RTD-4DI2-M,ST-DO-DC3-08
M,ST-AO-10V-08M,RM-8AO2-M,
ET-MIX24880-M,ST-DO-AC1-08M,ST-EX-001-20M,RM-4DI2-4AI2-M,VT-MIPM-131-M,ST-DO-AC2-08M,ST-MIX16880-M,RM-4DI2-
4DO2-M,
VT-MIPM-241-MST-DO-DC2-16M,ST-MIX12884-M,RM-RTU-8440-M,ST-DO-RLY-06M,RM-232-485-4M,RM-PS-024-01M;
System2000 VISUAL MOTION Open,flexible control anD drivesystem:CLC-D2.3,CLC-P1,CLC-P2,PPC-R01,PPC-R02;
System2000 MTC 200 ThE InnovativE For cEiN CNC-Technology:BTV20,BTV30,RECO-modulaRI/Osystem,MTC-R-CNCiN
AcompacTrackformat,
MTC-P-CNCOnthEPCbackplane,MTS-R,MTC-R,RECO,MTC-P,MTS-p,SMX-Space-savinGdistributeDI/Omodules,BTAanDBTM-fle
xiblEmachinEoperatoRpanels,
BTC-thEportablEhandhelDterminal,DIAXanDECODRIVE-digitalIntelligenTdrives,MTC200-P,MTC200-R;
电网保护SepaM80系列:SEP888,SEP383,SEP080,DSM303,CSH120,CSH200,CSH30,MES120,MES120G,MET148-2,MSA141,ACE
949,ACE959,ACE937,
ACE969TP,ACE969FO,MES120,MES120G,MET148-,MSA141,DSM303,ACE949-2,ACE959,ACE937,ACE969TP,ACE969FO,ACE9
09-2,ACE919CA,ACE919CC,
EGX200,EGX400,CSH120,CSH200,CSH30,ACE990,ACE917;
SunyTDCS9200集散控制系统:ST9111,ST9121,ST9131,ST9132,ST9134,ST9134,ST9161,ST9172,ST9173,ST9174,ST9181,ST918
2,ST9211,ST9212,ST9221,
ST9231,ST9241,ST9251,ST9261,ST9262,ST9271,ST9281,ST9291,ST9292,ST9293,ST9294,ST9311,ST9312,ST9313,ST9314,ST9
315,ST9321,ST9322,ST9331,
ST9341,ST9351,ST9361,ST9376,ST9381,ST9611,ST9621,ST9622,ST9631,ST9632,ST9601,ST9602,ST9661,ST9662;
维修ATLAS光照试验设备:CI3000,CI3000+,CI4000,CI5000;
AUTOFLAME燃烧管理系统:MK6MM,MK6EGA,MK6模拟I/O模块,MK6数字I/O模块,MK6DTI;
CTPLC:TIU050:CTIU050-001,CTIU050-002;**TIU10x:**CTIU100-01,CTIU100-02;**TIU11x:**CTIU110-01,CTIU110-02;**TIU20X:**CTIU200;
芯片级维修各种电源模块:
LAMBDA:EWS300,EWS600,EWS15-5,EWS15-6,EWS15-9,EWS15-12,EWS15-15,EWS15-18,EWS15-24,EWS15-28,EWS15-48,E
WS25-5,EWS25-6,EWS25-9,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

EWS25-12,EWS25-15,EWS25-18,EWS25-24,EWS25-28,EWS25-48,EWS50-5,EWS50-6,EWS50-9,EWS50-12,EWS50-15,EWS50-18,EWS50-24,EWS50-28,
EWS50-48,EWS100-5,EWS100-6,EWS100-9,EWS100-12,EWS100-15,EWS100-18,EWS100-24,EWS100-28,EWS100-48,EWS150-5,EWS150-6,EWS150-9,
EWS150-12,EWS150-15,EWS150-18,EWS150-24,EWS150-28,EWS150-48,EWS300-5,EWS300-6,EWS300-9,EWS300-12,EWS300-15,EWS300-18,EWS300-24,
EWS300-28,EWS300-48,EWS600-5,EWS600-6,EWS600-9,EWS600-12,EWS600-15,EWS600-18,EWS600-24,EWS600-28,EWS600-48,EWS1500-5,EWS1500-2,
EWS1500-33,EWS1500-12,EWS1500-15,EWS1500-10,EWS1500-24,EWS1500-28,EWS1500-48;

芯片级维修各种编码器:

芯片级维修**P+F**编码器:SCS10-11336-8192B,SCS10-22386-8192G,SCS14-350-8192B,AHS74N-0B2K2R0GN-0013,AVE14-123A0B,

芯片级维修各种UPS:

芯片级维修**东芝UPS4100PLUS**系列:U41B3F10KC6,U41B3F750C6,M41-IO-750,M41-IO-750,M41-IO-750,M41-IO-750,M41-IO-750,M41-IO-10K,M41-IO-10K,
M41-IO-10K,M41-IO-10K,M41-IO-10K,M41-IOMB-750,M41-IOMB-750,M41-IOMB-750,M41-IOMB-750,M41-IOMB-10K,M41-IOMB-10K,M41-IOMB-10K,
M41-IOMB-10K;

东芝UPSTOSNIC-7000系列:TOSNIC-7000-50,TOSNIC-7000-75,TOSNIC-7000-100,TOSNIC-7000-150,TOSNIC-7000-200,TOSNIC-7000-250,TOSNIC-7000-300,
TOSNIC-7000-400,TOSNIC-7000-500;台达-UPS:

芯片级维修各种流量计:

芯片级维修**科龙(KROHNE)**电磁流量计:Aquaflux,AQUAFLUXF分离式电磁流量计**科龙(KROHNE)**液位开关**BM34**:BM34/RR,BM34/RBM34/R-PVC,BM34/R-PP,BM34/R-PTFE,BM34/R-Titanium,BM34/R-Hastelloy-C4;科龙微小流量金属管浮子流量计:DK32,DK34,DK38,科龙(KROHNE)涡街流量计:VFM3100F-T,VFM3100W-T;

高准**LF**系列小流量流量计/控制器:LFM2M,LFM3M,LFM4M;

芯片级维修各种拧紧机:

芯片级维修**乔治雷诺(gorgeSRENAULT)**拧紧机**CVI II**:CVISII,CVIII,TWINCVIII,CVISIIUS,CVIIIUS,TWINCVIIIUS,MODCVI-1,MODCVI-2,CPUCVI,CVIII PROFIBUS,
TWINCVIII PROFIBUS,TWINCVIII1SERVO,ERP3L,ERP5L,ERP10,LERP20L,ERP20S,ERP30S,ERP40S,ERP3LT,ERP5LT,ERP10LT,ERP20LT,ERAL15-15,
ERAL15-25,ERAL15-35,ERAL15-45,ERAL15-55,ERAL15-70,ERAL2-30,ERAL2-40,ERAL2-60,ERAL2-80,ERA70J,ERA90J,ERA115J,ERA125J,ERA150J,ERA200J,
ERA125-6J,ERA250-6J,ERA300-6J,ERA400-6J,ERD5J,ERDL15-12,ERDL15-20,ERDL15-30,ERDL15-40,ERDL15-50,ERD50J,ERD70J,ERD120J,ERD150-6J,
ERD200-6J,ERD250-6J,EM35-10J,EM35-20J,EM38-10J,EM38-20J,EM51-10J,EM51-20J,EM60-10J,EM60-20J,EM60-30J,EM80-10J,EM80-20J,EM80-30J,
EM80-40J,EM80-50J,EM106-10J,EM106-20J,EML38-20J,EML51-20J,EML60-20J,EML60-30J,EML80-40J;
乔治雷诺(gorgeSRENAULT)拧紧机**CVI Assembly Systems**:MULTICVI,CVIScontroller,CVIS/CVIC,ERA20J,ERA30J,ERA40J,ERA60J,ERA70J,ERA90J,

公司地址:武汉市洪山区雄楚大街699号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

ERA115J,ERA125J,ERA150J,ER180J,ERA200J,ERA300-6J,ERA400-6J,ERD5J,ERD20J,ERD30J,ERD50J,ERD70J,ERD120J,ERP5J,ER20PJ,ER30PJ,EM35-10J,
EM35-20J,EM38-10J,EM38-20J,EM51-10J,EM51-20J,EM60-10J,EM60-20J,EM60-30J,EM80-10J,EM80-20J,EM80-30J,EM80-40J,EM106-10J,EM106-20J,
EML38-20J,EML51-20J,EML60-20J,EML60-30J,EML80-40J;
乔治雷诺 (**gorgeS RENAULT**) 拧紧机**TWIN5200**电机:UE14-50,UE14-28,UE34-50,UE34-28,UE34-13,UE38-27,UE38-15,UE38-11,UE58-27,UE58-20,UE58-16,
UE58-14,UE58-10,UE58-06,UE59-6,UE59-5,UE59-4,UE59-3,UE59-2,SE20,SE30,SE50,SE70,SE120,SE180,SE20D,SE30D,SE50D,SE20P,SE30PEP20J,EP30J,
EP50J,EP90J,EP120J,EP180J,EP20DJ,EP30DJ,EP50DJ,EP70DJ,EP20PJ,EP30PJ,HG12-70,HG14-70,HG14-40,HG34-70,HG38-40,HG38-20,HG58-40,HG58-30,
HG58-20,HG58-12,HG59-20,HG59-12,HG59-7,HG59-3,HG110-2;
芯片级维修各种空压机:
芯片级维修阿特拉斯空压机:**GA5-10**:
GA5-7.5,GA7-7.5,GA10-7.5,GA5-8,GA7-8,GA10-8,GA5-10,GA7-10,GA10-10,GA5-13,GA7-13,GA10-13;
GA11-22:GA11-7.5,GA15-7.5,GA18-7.5,GA22-7.5,GA11-8,GA15-8,GA18-8,GA22-8,GA11-10,GA15-10,GA18-10,GA22-10,GA11-13,GA15-13,GA18-13,GA22-13;
GA30-45C:GA30-7.5,GA37-7.5,GA45-7.5,GA30-8,GA37-8,GA45-8,GA30-10,GA37-10,GA45-10,GA30-13,GA37-13,GA45-13;
GA30og90VSD:GA30VSD-13,GA37VSD-13,GA50VSD-13,GA75VSD-13,GA90VSD-13,GA55AP-7.5,GA55AP-10,GA55AFF-7.5,GA55AFF-10,GA75AP-7.5,
GA75AP-10,GA75AP-13,GA75AFF-7.5,GA75AFF-10,GA75AFF-13,GA 18 VSD,GA 22 VSD;
GA55-75:GA55-7.5,GA75-7.5,GA55-8,GA75-8,GA55-10,GA75-10,GA55-13,GA75-13;
芯片级维修Atlas Copco空压机:
GA55-7.5P,DTL250,LF22-10/120,LF22,SF2,SF2FF,GX3-10FF/200,SF4/120,SF4P,SF4P,GX4-7.5FF/200,LE40-10/250,SF6FF,
GA7-10P,LE75Pack,GA7-7.5P,GX11-10,GA10,GA11-10FF,GA11-10SP,GA11-10Pack,GA11-10FF,GA111-7.5,GA15FFP13,XAS30,
GA11-7.5,GA11-7.5P,GA11FF,
GA18-10,GA15-8.5P,GA208P,XAS46D,ZT1-52,GA18,GA18-7.5,GA22-7.5P,XAS56Dd,GA308Pack,GA122-7.5,GA22FF-10,GA22-10P,GA22-12,GA18-7.5FF,
GA22-7.5,GA22-P-7.5,XAS66,XAS76,GA30VSD-P,GA408P,GA408P,GA37-10,GA30-7.5,GA45-13PW,GA37FF-10,GA37-10FF,ZT37-7.5P,XAS90,XAS96Dd,
GA45-13,GA345-10,ZT245-8,GA37-7.5P,GA608,GA608Pack,GA710P,GA37,GA45-10,GA345-7.5,GA708P,GA45-7.5,GA132-7.5,XAS125,GA55-10P,GA55-10,
GA55-7.5P,GA810,FD345,ZT275-8,GA75-10P,GA808Pack,XAS186,GA375W,GA75-7.5,GA90-10P,GA375-7.5,ZT290,GA75,ZA3BE,ZR3b,GA90-7.5,GA110,ZR3A,
ZR3-53,GA132-10,ZR3-53,GA110-7.5,GA1408A,GA1410Pack,GA1207.5,XRHS350,XAHS365,GR200Pack,GA132-10,XRHS385,GA200-10,XAS945,FD512,ZT4A,
ZR4-52,ZR5-B,ZR6A,GA90VSD,GX18-10FF,GA30-10FF,ZT255-8,GA710,GA808Pack,ZT45-7.5,GA10,GA11,GA100,GA11C,GA1107,GA1108,GA118,GA115,
GA1110,GA1207,GA1208,GA1210,GA122,GA1308,GA132,GA1407,GA1408,GA1410,GA160,GA207,GA208,GA200,GA230,GA237,GA250,GA307,GA308,GA310,

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

GA315,GA345,GA355,GA375,GA407,GA408,GA410,GA507,GA508,GA510,GA607,GA608,GA610,GA707,GA708,GA710,GA807,G
A808,GA810,GAH115,GAH118,
GAH122,GR1120,GR1520,GR620,GX11,GX15,GX2,GX22,GX3,GX4,GX5,GX7,HRHS210D,HRHS350D,LE5,LE6,LE7,LE8,LE11,XA
120,XA125,XA125D,XA160,
XA175D,XA210D,XA250,XA30,XA35,XA350,XA350D,XA40,XA40D,XA45,XA50,XA50D,XA55,XA60,XA65,XA70,XA75,XA80,XA85,
XA90,XAHH160,XAHH175,
XAHH125,XAHH125D,XAHH280D,XAHH350,XAM445,XAS120,XAS125,XAS146,XAS160,XAS175,XAS175D,XAS186,XAS210D,X
AS230,XAS25,XAS26,XAS280,
XAS35,XAS30,XAS32,XAS35D,XAS36,XAS40,XAS40D,XAS430,XAS430D,XAS45,XAS46,XAS495MD,XAS50,XAS50D,XAS55,XA
S60,XAS65,XAS66,XAS75,
XAS75D,XAS76,XAS80,XAS85D,XAS90,XAS96,XASS120,XASS125,XASS160,XASS175,XASS120,XASS30,XASS35,XASS40,XA
SS45,XASS50,XASS55,XASS60,
XASS65,XASS80,XASS85,XASS90,XASS75,XR210,XR210D,XR350,XRF350,XRH350,XRHS350D,XRS350,XRS210,XRVS450,XR
VS450D,XRVS455MD;

芯片级维修各种断路器:

芯片级维修默勒断路器open IZM circuit-breaker:

IZM Circuit-Breakers 3-pole:IZMB1-A630,IZMB1-A800,IZMB1-A1000,IZMB1-A1250,IZMB1-A1600,IZMB1-V630,
IZMB1-V800,IZMB1-V1000,IZMB1-V1250,IZMB1-V1600,IZMB1-U630,IZMB1-U800,IZMB1-U1000,IZMB1-U1250,IZMB1-U1600,IZM
B1-D630,IZMB1-D800,
IZMB1-D1000,IZMB1-D1250,IZMB1-D1600,IZMB2-A800,IZMB2-A1000,IZMB2-A1250,IZMB2-A1600,IZMB2-A2000,IZMB2-A2500,IZ
MB2-A3200,IZMB2-V800,
IZMB2-V1000,IZMB2-V1250,IZMB2-V1600,IZMB2-V2000,IZMB2-V2500,IZMB2-V3200,IZMB2-U800,IZMB2-U1000,IZMB2-U1250,IZ
MB2-U1600,IZMB2-U2000,
IZMB2-U2500,IZMB2-U3200,IZMB2-D800,IZMB2-D1000,IZMB2-D1250,IZMB2-D1600,IZMB2-D2000,IZMB2-D2500,IZMB2-D3200;
IZM Circuit-Breakers 4-pole:IZMB1-4-A630,IZMB1-4-A800,IZMB1-4-A1000,IZMB1-4-A1250,IZMB1-4-A1600,IZMB1-4-V630,IZMB
1-4-V800,IZMB1-4-V1000,
IZMB1-4-V1250,IZMB1-4-V1600,IZMB1-4-U630,IZMB1-4-U800,IZMB1-4-U1000,IZMB1-4-U1250,IZMB1-4-U1600,IZMB1-4-D630,IZ
MB1-4-D800,IZMB1-4-D1000,
IZMB1-4-D1250,IZMB1-4-D1600,IZMB2-4-A800,IZMB2-4-A1000,IZMB2-4-A1250,IZMB2-4-A1600,IZMB2-4-A2000,IZMB2-4-A2500,I
ZMB2-4-A3200,IZMB2-4-V800,
IZMB2-4-V1000,IZMB2-4-V1250,IZMB2-4-V1600,IZMB2-4-V2000,IZMB2-4-V2500,IZMB2-4-V3200,IZMB2-4-U800,IZMB2-4-U1000,I
ZMB2-4-U1250,IZMB2-4-U1600,
IZMB2-4-U2000,IZMB2-4-U2500,IZMB2-4-U3200,IZMB2-4-D800,IZMB2-4-D1000,IZMB2-4-D1250,IZMB2-4-D1600,IZMB2-4-D2000,
IZMB2-4-D2500,IZMB2-4-D3200,
INB1-630,INB1-800,INB1-1000,INB1-1250,INB1-1600,INN1-630,INN1-800,INN1-1000,INN1-1250,INN1-1600,INB2-800,INB2-1000,I
NB2-1250,INB2-1600,INB2-2000,
INB2-2500,INB2-3200,INN2-800,INN2-1000,INN2-1250,INN2-1600,INN2-2000,INN2-2500,INN2-3200,INH2-800,INH2-1000,INH2-12
50,INH2-1600,INH2-2000,
INH2-2500,INH2-3200,INH3-4000,INH3-5000,INH3-6300-AV;

UniOP Universal Operator Panel:BKDC-16,BKDC-16T,BKDL-16,BKDL-16T,BKDR-16,BKDR-16T,CP01F-02,CP01R-04,CP02F-0

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

2,CP02R-04,CP04F-04,
CP04F-04G,CP05R-04,CP10G-04,CP11G-04,CP12G-04,CP13G-04,ECT-16,ECT-VGA,EF-02,EF-04,EL-16,EL-16N,EL-25,EL-25T,
ELT-16,ELT-VGA,EL-VGA,ER-04,
ER-16,ER-16TA,ER-25,ER-25T,ERT-16,ERT-VGA,ER-VGA,ETT-VGA,MD00G-04,MD00R-02,MD00R-04,MD01R-02,MD02F-02,MD
02R-04,MD03R-02,MD03R-04,
MKDC-VGA,MKDC-VGA-T,MKDF-02,MKDF-04,MKDG-06,MKDG-07,MKDL-16,MKDL-16N,MKDL-25,MKDL-VGA,MKDR-04,MKDR-
05,MKDR-16,MKDR-16TA,
MKDR-25,MKDR-VGA,MKDR-VGA-T,MKDT-VGA,MKDT-VGA-T,TP01C-16,TP01R-16;
芯片级维修各种熔胶机:
诺信熔胶机 (NORDSON) :Series3000 Vista Control Units:3100V1EAV2D/AH,3400V1EAV2D/AH,3500V1EAV2D/AH,3700V1EA
V2D/AH,3830V1EAV2D/AH,
3860V1EAV2D/AH,3890V1EAV2D/AH,3930V1EAV2D/AH,3960V1EAV2D/AH,3100VEAV2D/AH,3400V2EAV2D/AH,3500V2EAV2D/
AH,3700V2EAV2D/AH,
3830V2EAV2D/AH,3860V2EAV2D/AH,3890V2EAV2D/AH,3930V2EAV2D/AH,3960V2EAV2D/AH,3100V3EAV2D/AH,3400V3EAV2D
/AH,3500V3EAV2D/AH,
3700V3EAV2D/AH,3830V3EAV2D/AH,3860V3EAV2D/AH,3890V3EAV2D/AH,3930V3EAV2D/AH,3960V3EAV2D/AH,3100V4EAV2D
/AH,3400V4EAV2D/AH,
3500V4EAV2D/AH,3700V4EAV2D/AH,3830V4EAV2D/AH,3860V4EAV2D/AH,3890V4EAV2D/AH,3930V4EAV2D/AH,3960V4EAV2D
/AH,3100V1FAV2D/AH,
3400V1FAV2D/AH,3500V1FAV2D/AH,3700V1FAV2D/AH,3830V1FAV2D/AH,3860V1FAV2D/AH,3890V1FAV2D/AH,3930V1FAV2D/
AH,3960V1FAV2D/AH,
3100VFAV2D/AH,3400V2FAV2D/AH,3500V2FAV2D/AH,3700V2FAV2D/AH,3830V2FAV2D/AH,3860V2FAV2D/AH,3890V2FAV2D/A
H,3930V2FAV2D/AH,
3960V2FAV2D/AH,3100V3FAV2D/AH,3400V3FAV2D/AH,3500V3FAV2D/AH,3700V3FAV2D/AH,3830V3FAV2D/AH,3860V3FAV2D/
AH,3890V3FAV2D/AH,
3930V3FAV2D/AH,3960V3FAV2D/AH,3100V4FAV2D/AH,3400V4FAV2D/AH,3500V4FAV2D/AH,3700V4FAV2D/AH,3830V4FAV2D/
AH,3860V4FAV2D/AH,
3890V4FAV2D/AH,3930V4FAV2D/AH,3960V4FAV2D/AH,3100V1GAV2D/AH,3400V1GAV2D/AH,3500V1GAV2D/AH,3700V1GAV2
D/AH,3830V1GAV2D/AH,
3860V1GAV2D/AH,3890V1GAV2D/AH,3930V1GAV2D/AH,3960V1GAV2D/AH,3100VGAV2D/AH,3400V2GAV2D/AH,3500V2GAV2
D/AH,3700V2GAV2D/AH,
3830V2GAV2D/AH,3860V2GAV2D/AH,3890V2GAV2D/AH,3930V2GAV2D/AH,3960V2GAV2D/AH,3100V3GAV2D/AH,3400V3GAV
2D/AH,3500V3GAV2D/AH,
3700V3GAV2D/AH,3830V3GAV2D/AH,3860V3GAV2D/AH,3890V3GAV2D/AH,3930V3GAV2D/AH,3960V3GAV2D/AH,3100V4GAV
2D/AH,3400V4GAV2D/AH,
3500V4GAV2D/AH,3700V4GAV2D/AH,3830V4GAV2D/AH,3860V4GAV2D/AH,3890V4GAV2D/AH,3930V4GAV2D/AH,3960V4GAV
2D/AH;

Series3000 Microset Control Units:3100-1EA32/ADE,3400-1EA32/ADE,3500-1EA32/ADE,3700-1EA32/ADE,3830-1EA32/ADE,3
860-1EA32/ADE,

公司地址:武汉市洪山区雄楚大街 699 号
业务联系电话:027-63005490 027-51778300 13487094272
网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理
传真:027-51778300
邮编:430074

武汉市中江科技有限公司维修内容列表

3890-1EA32/ADE,3930-1EA32/ADE,3960-1EA32/ADE,3100-2EA32/ADE,3400-2EA32/ADE,3500-2EA32/ADE,3700-2EA32/ADE,3830-2EA32/ADE,3860-2EA32/ADE,
3890-2EA32/ADE,3930-2EA32/ADE,3960-2EA32/ADE,3100-3EA32/ADE,3400-3EA32/ADE,3500-3EA32/ADE,3700-3EA32/ADE,3830-3EA32/ADE,3860-3EA32/ADE,
3890-3EA32/ADE,3930-3EA32/ADE,3960-3EA32/ADE,3100-1FA32/ADE,3400-1FA32/ADE,3500-1FA32/ADE,3700-1FA32/ADE,3830-1FA32/ADE,3860-1FA32/ADE,
3890-1FA32/ADE,3930-1FA32/ADE,3960-1FA32/ADE,3100-2FA32/ADE,3400-2FA32/ADE,3500-2FA32/ADE,3700-2FA32/ADE,3830-2FA32/ADE,3860-2FA32/ADE,
3890-2FA32/ADE,3930-2FA32/ADE,3960-2FA32/ADE,3100-3FA32/ADE,3400-3FA32/ADE,3500-3FA32/ADE,3700-3FA32/ADE,3830-3FA32/ADE,3860-3FA32/ADE,
3890-3FA32/ADE,3930-3FA32/ADE,3960-3FA32/ADE,3100-1GA32/ADE,3400-1GA32/ADE,3500-1GA32/ADE,3700-1GA32/ADE,3830-1GA32/ADE,
3860-1GA32/ADE,3890-1GA32/ADE,3930-1GA32/ADE,3960-1GA32/ADE,3100-2GA32/ADE,3400-2GA32/ADE,3500-2GA32/ADE,3700-2GA32/ADE,
3830-2GA32/ADE,3860-2GA32/ADE,3890-2GA32/ADE,3930-2GA32/ADE,3960-2GA32/ADE,3100-3GA32/ADE,3400-3GA32/ADE,3500-3GA32/ADE,
3700-3GA32/ADE,3830-3GA32/ADE,3860-3GA32/ADE,3890-3GA32/ADE,3930-3GA32/ADE,3960-3GA32/ADE;
H200 Guns:H201-StandardGun,H202-StandardGun,H204-LPStandardGun,H204-ReducedCavity(RC)Gun,H200-MiniBeadwithNozzlePlates,
H204-ZeroCavity(ZC)Gun;Uniscan,Multiscan,MultiscanControl; **H201 TopFeed MiniGun:**H201-T;
Series 3000 Guns:H101-RC08-T,H101-RC12-T,H101-RC16-T,H101-RC20-T,H102-RC12-T,H102-RC08-T,H102-RC16-T,H102-RC20-T,H102-RC12-T,
H102-RC16-T,H102-RC20-T,H104-RC08-T,H102-RC12-T,H102-RC16-T,H102-RC20-T,H104-RC08-T,H104-RC12-T,H104-RC16-T,
H104-RC20-T,H104-RC16-T,
H104-RC20-T,H104-RC08-T,H104-RC12-T,H104-RC16-T,H104-RC20-T,H104-RC12-T,H104-RC16-T,H104-RC20-T,H104-RC08-T
H104-RC12-T,H104-RC16-T,
H104-RC20-T,MODULE,H100RC,MODULE,H100RC,MODULE,H100RC;**H202 and H203 Guns:**H202-T,H202-T,H202-T,H202-T,H202-T,
H202-T,H202-T,H202-T,H202-T,
H202-T-F,H202-T-F,H202-T-W,H202-T-LP,H202-T-LP-W,H202-T-LP,H202-T-LP,H202-T-LP-W,H202-T-LP,H203-T,H203-T;**H204Guns:**H204-T,H204-T,H204T,
H204-T,H204-T,H204-T,H204-T-W,H204-T-F,H204-T-LP,H204-T-LP,H204-T-LP;
H206Guns:H206-T,H206-T,H208-T,H208-T,088"CTR,CAH208-T-LP,H208-T-LP,H208-T-LP; **H201 Automatic Guns:**H201-T,H201-T-W,H201-T-F,H201-T-F;
H200 Zero Cavity Guns:H201-ZC08-T,H201-ZC12-T,H201-ZC16-T,H201-ZC20-T,H201-ZC32-T,H201-ZC40-T,H201-ZC12-T-F,H201-ZC16-T-F,H201-ZC12-T-W,
H201-ZCS12-T,H201-ZCS12-T-W,H202-ZC12-T,H204-ZC12-T,H204-ZC12-T,H206-ZC12-T,H206-ZC12-T,H208-ZC08-T,H208-ZC12-T,H208-ZC08-T,H208-ZC12-T,
H208-ZC16-T,H208-ZC20-T,H208-ZC32-T,H208-ZC40-T;**CF200 Guns:**CF201-T,CF201-HAM,CF201-T-HAM-DF-SV,CF201-M-HAM-DF-SV;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whzjk.com> E-MAIL:whzjkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

H200 Reduced CavityGun:H201-RC08-T,H201-RC12-T,H201-RC16-T,H201-RC20-T,H201-RC12-T-F,H201-RC16-T-F,H201-RC20-T-F,H201-RC12-T-W,
H201-RC16-T-W,H201-RC12-T,H201-RC16-T,H201-RC20-T,H202-RC08-T,H202-RC12-T,H202-RC16-T,H202-RC12-T,H202-RC16-T-T,H202-RC16-T,H202-RC12-T,
H202-RC12-T,H202-RC08-T,H202-RC16-T,H204-RC12-T,H204-RC16-T,H204-RC12-T,H204-RC20-T,H204-RC20-T,088,H204-RC16-T,H204-RC20-T,H204-RC20-T,
H204-RC20-T,H206-RC08-T,H206-RC16-T,H206-RC20-T,H206-RC16-T,H206-RC08-T,H206-RC12-T,H206-RC16-T,H206-RC20-T,
H208-RC08-T,H208-RC12-T,088,
H208-RC16-T,H208-RC20-T;**AD-31andAD-41Hand guns:**AD31-T,AD31-T,AD31-T-L,AD31-T-PA,AD31-STR(1),AD31-STR-WP(1)A
D31-ST,AD-41,AD-41,AD-41;
H20 Guns:H20-T,H20-T-W,H20-T-LBS,H20-T,H20-T-F/D;**E700 Guns:**E700,E700-T-W,E700-T;**E350 Guns:**E351-T,E351-T,E351-T,
E354-T,E354-T-LP;
Gun Heaters:H20A,H20A,H201,H202Close,H202-LP,H202-E,H204Close,H204Expanded,H204-LP,AD24-2,AD24-2LP,AD24-4,AD24-4LP,
AD24-4Expanded,AD31-A,
AD31-D,AD31-E; **CF202Guns:**CF202-T,CF202-T-HAM-DF;**CF203Guns:**CF203-T-HAM,CF203-M-HAM-DF-SL,CF203-T-HAM-DF-SR;
JSW Model 280EII-SP280-Ton Plastic Injection Moulding Machine:S/N295724905,295724902,295724904,205724901,S/N296716102,
296716003,296;
JSW Model J220E-P220-Ton Plastic Injection Moulding Machines:S/N292010012,292010011,292010010,292010009;
JSW Model J150SAII150-Ton Plastic Injection Moulding Machines:S/N225710707,286710120,287710705,287710722,287710719,
285710614,2377107219,
286710117,286710118;**JSW Model J150E-P150-Ton Plastic Injection Moulding Machine:**S/N291710015;
基金会现场总线
块:FT5010_AI,FT5010_B,FT5010_CS,FT5010_DI,FT5010_DO,FT5010_ML,FT5010_PD,FT5010_PID,FT5010_R,FT5010_RB,FT5010_TX,
FT5010_AO;
芯片级维修各种电动执行机构: 乔登电动执行机构, (JORDAN); 西博斯电动执行机构, (SIPOS); 罗泰克电动执行机构, (ROTORK);
GEMU盖米定位器:GEMU417,GEMU418,GEMU423,GEMU723,GEMU9428,GEMU563,GEMU568,GEMU613,GEMU618,GEMU9618,GEMU601,GEMU602,
GEMU610,GEMU615,GEMU612,GEMU625,GEMU630,GEMU635,GEMU650,GEMU671,GEMU672,GEMU673,GEMU687,GEMU693,GEMU698,
GEMU9698,
GEMU695,GEMU800,GEMU850,GEMU920,GEMU921,GEMU922,GEMU925,GEMU930,GEMU931,GEMU932,GEMU933,GEMU934,GEMU1290,
GEMU1291,
GEMU940,GEMU941,GEMU947,GEMU1201,GEMU1214,GEMU1230,GEMU1232,GEMU1211,GEMU1231,GEMU1215,GEMU1234,GEMU1275,
GEMU E-MODULE1281,GEMU E-MODULE 1284,GEMU E-MODULE1286,GEMU E-MODULE 1289,GEMU1290SDA,GEMU1290LEVELLINE,
GEMU 1291LEVELLINE,GEMU1435EPOS,
GEMU1436CPOS,GEMU3021,GEMU3030,GEMU3120,GEMU4221,GEMU4222,GEMU9468,GEMU EPOS1435;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

SIPART

PS2:6DR5010-xNxxx-0AA0,6DR5020-xNxxx-0AA0,6DR5011-xNxxx-0AA0,6DR5010-xExxx-0AA0,6DR5020-xExxx-0AA0,6DR5011-xExxx-0AA0,
6DR5015-xExxx-0AA0,6DR5025-xExxx-0AA0,6DR5110-xNxxx-0AA0,6DR5120-xNxxx-0AA0,6DR5111-xNxxx-0AA0,6DR5210-xExxx-0AA0,6DR5220-xExxx-0AA0,
6DR5211-xExxx-0AA0,6DR5215-xExxx-0AA0,6DR5225-xExxx-0AA0,6DR4004-8G,6DR4004-6G,6DR4004-8A,6DR4004-6A,6DR4004-7A,6DR4004-8J,6DR4004-6J,
6DR4004-7J,6DR4004-8V,6DR4004-8L,6DR4004-8D,6DR4004-1C,6DR4004-1M,6DR4004-2M,6DR4004-1B,6DR4004-8S,7MF4997-1DA;

芯片级维修乔登电动执行机构(**JORDAN CONTROLS ACTUATORS**):

SM

Series:SM-1110-N,SM-1120-N,SM-1140-N,SM-1150-N,SM-1170-N,SM-1180-N,SM-1520-N,SM-1530-N,SM-1540-N,SM-1550-N,SM-1580-N,SM-1590-N,
SM-1630-N,SM-1650-N,SM-1680-N,SM-1550-D,SM-1590-D,SM-1630-D,SM-1650-D,SM-1520-D,SM-1530-D,SM-1110-D,SM-1120-D,SM-1170-D,SM-1150-D,
SM-1720-N,SM-1715-N,SM-1790-D,SM-1750-N,SM-1750-D,SM-1760-N,SM-1790-N,SM-1720-D,SM-1730-N,SM-1730-D,SM-1740-N,SM-5115-A,SM-5115-N,
SM-5120-D,SM-5120-N,SM-5190-D,SM-5140-N,SM-5160-N,SM-5190-N,SM-5160-A,SM-5160-D,SM-5220-N,SM-5220-D,SM-5260-A,SM-5260-N,SM-5210-N,
SM-5210-A,SM-5260-D,SM-5310-N,SM-5310-A,SM-5320-N,SM-5360-N,SM-5360-A,SM-5360-D,SM-5480-N,SM-5430-A,SM-5430-N,SM-5480-D,SM-5480-A,
LA-1110-N,LA-1110-D,LA-1140-N,LA-1170-N,LA-1170-D,LA-2320-N,LA-230D,LA-2390-N,LA-2390-D,LA-2410-N,LA-2410-D,LA-2420-N,LA-2420-D,LA-2440-N,
LA-2450-N,LA-2450-D,LA-2460-N,LA-2490-N,LA-2490-D,LA-2315-N,LA-2415-N,LA-2520-D,LA-2520-E,LA-2520-N,LA-2620-D,LA-2610-A,LA-2610-A,LA-2610-A,
LA-2610-A,LA-2510-N,LA-2610-N,LA-2620-N,LA-2980-N,LA-2720-N,LA-2710-A,LA-2710-A,LA-2710-N,LA-2910-N,LA-2710-A,LA-2710-A,LA-2710-A,LA-2710-A,
MV-1110-N,MV-1110-D,MV-1140-N,MV-1170-N,MV-1170-D,MV-1510-N,MV-1510-D,MV-1530-N,MV-1530-D,MV-1540-N,MV-1550-N,MV-1550-D,MV-1570-N,
MV-1570-D,PF-1010,PT-1010,PF-1210,LF-1210,PT-1330,PT-1510,LT-1010,JOM-N,JOM-A,JBM2-N,JOMB-N,JOMB-A,JOM1-N,JOM1-A,JOM2-N,JOM2-A,JOM2-A,
JOM3-N,JOM3-A,JOM3-A,JOM4-N,JOM4-A,JOM4-A,JOM5-N,JOM5-A,JOM5-A,JOM6-N,JOM6-A,JOM6-A,JOM7-N,JOM7-A,JOM7-A,JOM8-N,JOM8-A,JOM8-A,
JOM9-N,JOM9-A,JOM9-A,JOM10-N,JOM10-A,JOM10-A,JOM11-N,JOM11-A,JOM11-A,JOM12-N,JOM12-A,JOM12-A;

芯片级维修乔登电动执行机构伺服放大器:AD-7530,AD-8240,AD-7540,AD-8900,AD-7540,AD-7830,AD-9120,AD-8900,AD-8130;

芯片级维修福斯-利密托克电动执行机构:

Limitorque Accutronix MX 直行程阀门执行机构:MX-5, MX-10, MX-20, MX-40;

Limitorque EP5 Electropneumatic positioner:EP5XX,EP5FS,EP5IS,EP5EU,EP5US,EP5,EP5-EX,EP5-FS,EP5-IS,EP5XX-HPNU-23K01-PV9DA-4Z;Logix800Series,Logix1400DigitalPositioner,ValtekXL90Positioner,ValtekMaxFlo3ControlValves,MaxFlo3ControlValves;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

Limitorque Gate Valve:

Series353,SERIESBW353,SERIES358,SERIES32353,SERIES363,SERIESBW363,SERIES368,SERIES32363,SERIES373,SERIE
S13373,
SERIES11403,SERIESBW373,SERIES378,SERIES32373,SERIES12111,SERIES13111,SERIES11103,SERIES12161,SERIESSW
12111,SERIESSW13111,
SERIESSW11103,SERIESSW12161,SERIESTT12111,SERIESST12111,SERIESCT12111,SERIES2801,SERIES2801B,SERIES28
11,SERIESSW2801,
SERIESSW2801B,SERIESSW2811,SERIESTT2801,SERIESTT2811,SERIESST2801,SERIESCT2801,SERIESCT2901,SERIES59
851,SERIESSW59851,
SERIES32111,SERIESSW32111,SERIES12401,SERIES13401,SERIESSW12401,SERIESSW13401,SERIES2831,SERIESSW283
1,SERIESTT2831,
SERIESST2831,SERIESCT2831,SERIES59951,SERIESSW59951,SERIES82401,SERIESSW82401,SERIES12421,SERIESSW124
21,SERIES12921,
SERIESSW12921,SERIES12321,SERIESSW12321,SERIES12521,SERIESSW12521,SERIES15111,SERIES16111,SERIES1033,S
ERIES1043,SERIESSW15111,
SERIESSW16111,SERIESSW1043,SERIESSW1033,SERIES15373,SERIES11603,SERIES11683,SERIES15801,SERIESSW1580
1,SERIESST15801,
SERIES35111,SERIESSW35111,SERIES15401,SERIESSW15401,SERIES15831,SERIESSW15831,SERIES15321,SERIESSW15
321,SERIES66703,
SERIESSW66703,SERIES66713,SERIESSW66713,SERIESSW66773;

Limitorque Globe

Valve:SERIES473,SERIES473B,SERIES32473,SERIES483,SERIES483B,SERIES22483CL,SERIES32483493,SERIES493B,SERI
ES22493CL,
SERIES22493MT,SERIES10403,SERIES32493,SERIES12141,SERIES12141B,SERIES13141,SERIES22141,SERIES12443,SERI
ES22461,SERIES10103,
SERIES1971,SERIES12181,SERIESSW12141,SERIES12141B,SERIESSW13141,SERIESSW22141,SERIESSW12443,SERIESS
W22461,SERIESSW10103,
SERIESSW1971,SERIESSW12181,SERIESTT12141,SERIESST12141,SERIESCT12141,SERIES2821,SERIES810,SERIESSW28
21,SERIESSW810,SERIES801,
SERIES851,SERIESSW801,SERIESSW851,SERIES12501,SERIESSW12501,SERIES82501,SERIESSW82501,SERIESSW12351,
SERIES811,SERIESSW811,
SERIES12551,SERIES822,SERIESSW822,SERIES32141,SERIESSW32141,SERIES15141,SERIES15443,SERIES1003,SERIES1
023,SERIESSW15141,
SERIESSW15443,SERIES,SERIESSW1003,SERIESSW1023,SERIES15493,SERIES10603,SERIES10683,SERIES15821,SERIES
SW15821,SERIES15501,
SERIESSW15501,SERIES15351,SERIESSW15351,SERIES1510,SERIESSW1510,SERIES1511,SERIESSW1511,SERIES1522,S
ERIESSW1522,SERIES66723,
SERIESSW66723,SERIES66733,SERIESSW66733,SERIES66793,SERIESSW66793,SERIES2510,SERIESSW2510,SERIES2511,
SERIESSW2511,SERIES2522,
SERIESSW2522;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074

武汉市中江科技有限公司维修内容列表

Limitorque Check Valve:

SERIES73,SERIESS673,SERIES32573,SERIES583,SERIESS683,SERIES32583,SERIES593,SERIESS69332593,SERIES701,
SERIES701ZL,SERIES710,SERIES13701,SERIESB701,SERIESB710,SERIES4835,SERIESS701,SERIESSW701,SERIESSW710,
SERIESSW13701,
SERIESSWB701,SERIESSWB710,SERIESSW4835,SERIESSWS701,SERIESS74,SERIESSWS74,SERIES9091,SERIESB9091,S
ERIES54853,SERIESSW9091,
SERIESSWB9091,SERIESSW5483,SERIES718,SERIESSW718,SERIESS718,SERIESSWS718,SERIESB718,SERIESSWB718,SE
RIES5486382718,
SERIESSW82718,SERIES32701,SERIESSW32701,SERIES15701,SERIESB15701,SERIESSW15701,SERIESSWB15701,SERIES
15593,SERIES1610,
SERIESSW1610,SERIES1622,SERIESSW1622,SERIES2610,SERIESSW2610,SERIES2611,SERIESSW2611,SERIES2622,SERI
ESSW2622;

Limitorque Meter Globe Valve: SERIES 1331T,SERIES 1881T,SERIES 2891T,SERIES SW1871T,SERIES SW1331T,SERIES
SW2891T,SERIES 54831T,
SERIES SW54381T,SERIES 9871T,SERIES 9841TSW9871T,SERIES SW9841T,SERIES 98717T,SERIES 9841T,SERIES
SW9871T,SERIES SW9841T,
SERIES 9871T,SERIES 9841T,SERIES SW9871T,SERIES SW9841T,SERIES 9821T,SERIES SW9821T,SERIES 3991T,SERIES
SW3991T;

Limitorque Hydraulic Check Valve: SERIES 1551,SERIES 2191,SERIES SW1551,SERIES SW2191,SERIES B1551,SERIES
SWB1551,SERIES 4881,
SERIES SW4881;

芯片级维修伯纳德系列角行程电动执行机

构:SD250/K30,SD250/F30,SD600/K30,SD600/F30,SD1000/K30,SD1000/F30,SD1000/K48,SD1000/F48,SD1600/K28,
SD1600/F28,SD1600/K40,SD1600/F40,SD2500/F28,SD2500/K40,SD2500/F40,SD4000/F28,SD4000/F40,SD4000/K65,SD4000/F6
5,SD4000/K105,SD4000/F105,SD6000/F40,SD6000/F65,SD6000/K105,SD6000/K105,SD100,SD8000;

芯片级维修SIPOS5Flash电动执行机构PROFITRON专业型:2SA5010,GS503,GS633,2SA5021,GS633,2SA5021,GS803,2SA5031,G
S803,2SA5011,GS1003-VZ43,

2SA5021,GS1003-VZ43,2SA5021,GS1253-VZ43,2SA5031,GS1253-VZ43,2SA5031,GS1603-GZ1603(4:1),2SA5021,GS1603-GZ16
03(8:1),2SA5043,

GS2003-GZ2003(4:1),2SA5031,GS2003-GZ2003(8:1),2SA5021GS2003-GZ2003(16:1),2SA5053,GS2503-GZ2503(4:1),2SA5043,G
S2503-GZ2503(8:1),2SA5033,

GS2503-GZ2503(16:1);

Bernecker + Rainer Power Panel 100/200:

4PP120.0571-01,4PP120.0571-21,4PP120.1043-31,4PP120.1505-31,4PP210.0000-95,4PP220.0571-45,
4PP220.0571-65,4PP220.0571-85,4PP220.0571-A5,4PP220.1043-75,4PP220.1043-B5,4PP220.1505-75,4PP220.1505-B5,4PP251.
0571-65,4PP251.0571-A5;

公司地址:武汉市洪山区雄楚大街 699 号

业务联系电话:027-63005490 027-51778300 13487094272

网址:<http://www.whz.jk.com> E-MAIL:whz.jkj@163.com

联系人:汪经理

传真:027-51778300

邮编:430074